SUZUKI

PARTS CATALOGUE

DF4A/5A/6A

SUZUKI Way of Life!

OUTBOARD MOTOR

020 021

2020-10

P01

1ST EDITION

This part catalogue supersedes all the following part catalogue with immediate effect

Model of catalogue	Parts catalogue No.
DF4A/5A/6A_P01_020	9900B-45456

PREFACE

When it becomes necessary to replace parts on SUZUKI OUTBOARD MOTORS, always use SUZUKI GENUINE PARTS which have passed a strict inspection which guarantees quality and performance.

This parts catalogue covers the list of all service parts for SUZUKI DF4A/5A/6A production start from 2019 to 2020.

INSTRUCTIONS FOR QUOTING THE CATALOGUE

1. DIMENSIONS

Dimensions of the parts in this catalogue are indicated in unit millimeters.

2. ABBREVIATIONS

Abbreviations used in this catalogue are as follows:

AR	: As required	NT	: Number of teeth
ASSY	: Assembly	OPT	: Optional
E.NO.	: Engine number	OS	: Over size
F.NO.	: Frame number	STD	: Standard
D	: Diameter of material	T	: Thickness
ID	: Inside diameter	US	: Under size
OD	: Outside diameter	W	: Width
L	: Length	W/	: With
LH(PORT)	: Left hand side	S,L	: Transom type
RH(STBD)	: Right hand side	SUS	: Stainless steel

～123456 : Up to E.NO.00403F-123456

123456～ : From E.NO.00403F-123456

12 x 34 x 5.6…… Figures in the description column show the dimensions of parts.

ID OD T(or W,L)

→12345-56781 (Parts No.) : indicates that the parts number was changed to 12345-56781 and the new parts are interchangeable with the former ones but the former ones are not interchangeable with new ones.

←12345-56781 (Parts No.) : indicates that the former and new parts are interchangeable with each other and both are usable.

3. INNER PARTS OF ASSEMBLY

Part name with a dot (.) in front as shown in the description column indicates the component of the assembly also available individually.

4. MODIFICATION NOTICE

A parts bulletin will be sent to you on all occasions when changes in parts occur, including interchangeable modifications between new parts and old ones.

5. NOTE

5-1. There are some different parts from those of production models among spare parts for the administrative reasons and common use of them with other models.

5-2. In respect of rubber hoses and vinyl tubes, please be sure to use them by cutting off according to the length mentioned on parts catalogue or what is actually required on the vehicle.

5-3. Note that the drawings on the illustration page are for ready reference of spare parts number, not to be used as an assembly manual. When assembling, use "SUZUKI SERVICE MANUAL".

6. MODEL NAME AND ENGINE NUMBER

MODEL	DESTINATION	TYPE	TRANSOM	ENGINE No.
DF4A_020	P01	00403F	S,L	00403F-040001～
DF4A_021	P01	00403F	S,L	00403F-140001～
DF5A_020	P01	00503F	S,L	00503F-040001～
DF5A_021	P01	00503F	S,L	00503F-140001～
DF6A_020	P01	00603F	S,L	00603F-040001～
DF6A_021	P01	00603F	S,L	00603F-140001～

MILLIMETER → INCH CONVERSION CHART

	0	1	2	3	4	5	6	7	8	9
00	.000	.039	.079	.118	.157	.197	.236	.276	.315	.354
10	.394	.433	.472	.512	.551	.591	.630	.669	.709	.748
20	.787	.827	.866	.906	.945	.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.535
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.214	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.031	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898


How to read

	0	1	2	3	4
00	…	…	…	…	…
10	…	…	…	…	…
20	…	…	…	0.906	…
30	…	…	…	…	…

23 millimeters equal 0.906 inch


Contents are subject to change without notice or obligation.

FIG. 111A




DF9A_9A_6A_P01_021_111A
CYLINDER HEAD

FIG. 113A




DF9A_9A_6A_P01_021_113A
CYLINDER BLOCK

FIG. 116A




DF9A_9A_6A_P01_021_116A
CRANKSHAFT

FIG. 122A




DF9A_9A_6A_P01_021_122A
INTAKE MANIFOLD

FIG. 128A




DF9A_9A_6A_P01_021_128A
CARBURETOR

FIG. 128B




DF9A_9A_6A_P01_021_128B
CARBURETOR

FIG. 128C




DF9A_9A_6A_P01_021_128C
CARBURETOR

FIG. 146A




DF9A_9A_6A_P01_021_146A
FUEL PUMP

FIG.146B




DF8A_9A_9A_F01_021_146B
FUEL PUMP

FIG.160A




DF8A_9A_9A_F01_021_160A
WATER PUMP

FIG.167A




DF8A_9A_9A_F01_021_167A
RECOIL STARTER

FIG.175A




DF8A_9A_9A_F01_021_175A
OIL PUMP

FIG.208A




DF8A_9A_9A_F01_021_208A
CLUTCH LEVER

FIG.210A




DF8A_9A_9A_F01_021_210A
SHIFT ROD

FIG.230A




DF8A_9A_9A_F01_021_230A
DRIVE SHAFT

FIG.303A




DF8A_9A_9A_F01_021_303A
MAGNETO

FIG.303B




DF9A_5A_6A_P01_021_303B
MAGNETO

FIG.303C




DF9A_5A_6A_P01_021_303C
MAGNETO

FIG.335A




DF9A_5A_6A_P01_021_335A
CLAMP BRACKET

FIG.336A




DF9A_5A_6A_P01_021_336A
SWIVEL BRACKET

FIG.405A




DF9A_5A_6A_P01_021_405A
DRIVE SHAFT HOUSING

FIG.407A




DF9A_5A_6A_P01_021_407A
GEAR CASE

FIG.412A




DF9A_5A_6A_P01_021_412A
LOWER COVER

FIG.412C




DF9A_5A_6A_P01_021_412C
LOWER COVER

FIG. 420A




DF8A, 9A, 9A, P01_021_420A
ENGINE COVER

FIG. 420D




DF8A, 9A, 9A, P01_021_420D
ENGINE COVER

FIG. 420G




DF8A, 9A, 9A, P01_021_420G
ENGINE COVER

FIG. 420H




DF8A, 9A, 9A, P01_021_420H
ENGINE COVER

FIG. 420L




DF8A, 9A, 9A, P01_021_420L
ENGINE COVER

FIG. 420P




DF8A, 9A, 9A, P01_021_420P
ENGINE COVER

FIG. 432B




DF8A, 9A, 9A, P01_021_432B
FUEL TANK

FIG. 444A




DF8A, 9A, 9A, P01_021_444A
TILLER HANDLE

FIG.508A




DF9A_9A_6A_P01_021_508A
OPT:REMOTE CONTROL

FIG.514A




DF9A_9A_6A_P01_021_514A
OPT:REMOCON PARTS SET

FIG.550A



DF9A_9A_6A_P01_021_550A
OPT:ELECTRICAL

FIG.583A



DF9A_9A_6A_P01_021_583A
OPT:FUEL TANK

FIG.111A




FIG.111A (1-B-2) CYLINDER HEAD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11110-97L00	HEAD,CYLINDER	1	
2	11115-93E00-001	GUIDE,VALVE (OS:0.3)	2	OPT
3	11141-97L00	GASKET,CYLINDER HEAD	1	
4	09352-70113-600	HOSE (7X11X600)	1	
5	11117-91JL0	BOLT,CYLINDER HEAD	4	
6	09401-10412	CLIP	2	
7	04211-11169	PIN (L:16)	2	
8	11170-97L00	COVER,CYLINDER HEAD	1	
9	11189-97L00	GASKET,CYLINDER HEAD COVER	1	
10	01550-0620C	BOLT	4	
11	09482-00L04	PLUG,SPARK (CPR6EA-9)	1	
12	17670-91J02	THERMOSTAT,WATER (50C)	1	
13	55321-95J00	ANODE,PROTECTION	1	
14	09126-05011	SCREW (5X20)	1	
15	17680-97L00	COVER,THERMOSTAT	1	
16	33833-97L40	PROTECTOR (16X17X60)	1	
17	01550-0620C	BOLT	2	

FIG.113A




FIG.113A (1-B-3) CYLINDER BLOCK

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11200-97L00	BLOCK ASSY,CYLINDER	1	
2	11971-97L00	.LENS,OIL CHECK	1	
3	09283-21009	.SEAL,OIL (19.7X33X6)	1	
4	11300-97L11	CASE ASSY,CRANKSHAFT	1	
5	16152-97L00	.SPRING,OIL RELIEF VALVE	1	
6	16153-97L00	.RETAINER,RELIEF VALVE SPRING	1	
7	09168-16009	.GASKET (16X22X0.8)	1	
8	09283-10009	.SEAL,OIL (10X45X5)	1	
9	09283-25076	.SEAL,OIL (25X45X5)	1	
10	06111-15004	.BALL	1	
11	11351-97L00	GASKET,CRANKCASE	1	
12	11381-91J10	GAUGE,ENGINE OIL LEVEL	1	
13	09280-15007	O-RING (D:2.4,ID:15.8)	1	
14	01550-0630C	BOLT (6X30)	8	
15	04211-09149	PIN	2	
16	11173-97L00	PLATE,BREATHER	1	
17	11177-97L00	PIPE,BREATHER OIL DRAIN	1	
18	11179-97L00	GASKET,BREATHER PLATE	1	
19	11186-97L00	SEPARATOR,OIL BREATHER	1	
20	11431-97L00	PLATE,UNDER OIL SEAL	1	
21	09168-12017	GASKET (12X17X1)	1	
22	09248-12009	PLUG (12X18.65)	1	
23	09321-08022	CUSHION	2	
24	09387-52002	RING	1	
25	01550-0640C	BOLT	1	
26	11452-91J00	VALVE,REED	1	
27	02112-0612A	SCREW	1	
28	02142-06127	SCREW	5	

FIG.116A




FIG.116A (1-B-4) CRANKSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12111-89L10-0B0	PISTON (BLACK)	1	
2	12140-89L20	RING SET,PISTON	1	
3	12151-89L00	PIN,PISTON	1	
4	09381-16001	CIRCLIP (OD:18)	2	
5	12160-97L00	CONNROD ASSY	1	
6	12163-97L00	.BOLT,CONNROD	2	
7	12200-97L00	CRANKSHAFT ASSY	1	
8	08211-25361	WASHER	1	
9	12711-97L00	CAMSHAFT (NT:46)	1	
10	12951-91J01	CAM,DECOMP	1	
11	09106-02001	BOLT (2X9.8)	1	
12	08211-17251	WASHER (T:1.0)	1	
13	12894-91JL0	ROD,PUSH	2	
14	12840-97L00	ARM ASSY,VALVE ROCKER	2	
15	12842-97L00	.SCREW,TAPPET ADJUSTING	2	
16	12843-27A00	.NUT,TAPPET ADJUSTING	2	
17	12891-87C00	TAPPET	2	
18	12911-91J02	VALVE,INTAKE	1	
19	12915-91J02	VALVE,EXHAUST	1	
20	12921-91J00	SPRING,VALVE	2	
21	12931-78G00	RETAINER,VALVE SPRING	2	
22	12932-24400	COTTER,VALVE	4	
23	09261-04017	PIN (4X43)	1	
24	09289-05006	SEAL,OIL (5.5X11X8.2)	1	
25	12100-97L10-050	PISTON SET,OS (OS:0.50)	1	OPT
26	12140-89L20-050	.RING SET,PISTON (OS:0.50)	1	OPT

FIG.122A




FIG.122A (1-B-5) INTAKE MANIFOLD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-97L00	MANIFOLD,INTAKE	1	
2	13119-97L00	GASKET,INTAKE MANIFOLD	1	
3	01547-0625C	BOLT	2	
4	13810-97L00	SILENCER	1	
5	11174-97L00	HOSE,BREATHER	1	

FIG.128A




FIG.128A (1-B-6) CARBURETOR (DF4A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13200-97L01	CARBURETOR ASSY	1	
2	13236-97L00	.NOZZLE,MAIN	1	
3-1	09491-52L01	.JET,MAIN (52)	1	
3-2	09491-54L01	.JET,MAIN (54)	1	
4	13371-91J20	.VALVE,NEEDLE	1	
5	13250-97J20	.FLOAT	1	
6	13254-97J00	.PIN,FLOAT	1	
7	13268-97J30	.SPRING	1	
8	13251-97J00	.GASKET	1	
9	13245-97J00	.CHAMBER,FLOAT	1	
10	13249-97J00	.GASKET	1	
11	13247-97J00	.SCREW	1	
12	13268-97J10	.SPRING	1	
13	13616-97J00	.SCREW	1	
14	13267-97J00	.SCREW	4	
15-1	09492-32011	.JET,PILOT (32)	1	
15-2	09492-34004	.JET,PILOT (34)	1	
16	13267-97J10	.SCREW	1	
17	09493-26010	.JET,MAIN AIR (130)	1	
18	09493-85003	.JET,SLOW AIR (85)	1	
19	13249-97J10	.GASKET	1	
20	13248-97J00	.PLATE	1	
21	13268-97J20	.SPRING	1	
22	13534-97J10	.SCREW	1	
23	09401-09404	CLIP	2	
24	13125-91J10	GASKET,CARBURETOR	2	
25	13413-97L01	ROD,CHOKE	1	
26	13436-91J00	CONNECTOR,CHOKE ROD	1	
27	13631-97L00	KNOB,CHOKE	1	
28	09103-06521	BOLT (8X85)	2	
29	09343-50L01-060	HOSE,FUEL (5X10X60)	1	
30	13124-91JL0	INSULATOR,CARBURETOR	1	

FIG.128B




FIG.128B (1-B-7) CARBURETOR (DF5A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13200-97L11	CARBURETOR ASSY	1	
2	13236-97L10	.NOZZLE,MAIN	1	
3-1	09491-64003	.JET,MAIN (64)	1	
3-2	09491-66005	.JET,MAIN (66)	1	
4	13371-91J20	.VALVE,NEEDLE	1	
5	13250-97J20	.FLOAT	1	
6	13254-97J00	.PIN,FLOAT	1	
7	13268-97J30	.SPRING	1	
8	13251-97J00	.GASKET	1	
9	13245-97J00	.CHAMBER,FLOAT	1	
10	13249-97J00	.GASKET	1	
11	13247-97J00	.SCREW	1	
12	13268-97J10	.SPRING	1	
13	13616-97J00	.SCREW	1	
14	13267-97J00	.SCREW	4	
15-1	09492-35035	.JET,PILOT (35)	1	
15-2	09492-37005	.JET,PILOT (37)	1	
16	13267-97J10	.SCREW	1	
17	09493-30007	.JET,MAIN AIR (150)	1	
18	09493-75001	.JET,SLOW AIR (75)	1	
19	13249-97J10	.GASKET	1	
20	13248-97J00	.PLATE	1	
21	13268-97J20	.SPRING	1	
22	13534-97J10	.SCREW	1	
23	09401-09404	CLIP	2	
24	13125-91J10	GASKET,CARBURETOR	2	
25	13413-97L01	ROD,CHOKE	1	
26	13436-91J00	CONNECTOR,CHOKE ROD	1	
27	13631-97L00	KNOB,CHOKE	1	
28	09103-06521	BOLT (8X85)	2	
29	09343-50L01-060	HOSE,FUEL (5X10X60)	1	
30	13124-91JL0	INSULATOR,CARBURETOR	1	

FIG.128C




FIG.128C (1-B-8) CARBURETOR (DF6A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13200-97L21	CARBURETOR ASSY	1	
2	13236-97L20	.NOZZLE,MAIN	1	
3-1	09491-70018	.JET,MAIN (70)	1	
3-2	09491-72015	.JET,MAIN (72)	1	
4	13371-91J20	.VALVE,NEEDLE	1	
5	13250-97J20	.FLOAT	1	
6	13254-97J00	.PIN,FLOAT	1	
7	13268-97J30	.SPRING	1	
8	13251-97J00	.GASKET	1	
9	13245-97J00	.CHAMBER,FLOAT	1	
10	13249-97J00	.GASKET	1	
11	13247-97J00	.SCREW	1	
12	13268-97J10	.SPRING	1	
13	13616-97J00	.SCREW	1	
14	13267-97J00	.SCREW	4	
15-1	09492-39003	.JET,PILOT (39)	1	
15-2	09492-41004	.JET,PILOT (41)	1	
16	13267-97J10	.SCREW	1	
17	09493-22L01	.JET,AIR MAIN (110)	1	
18	09493-80015	.JET,SLOW AIR (80)	1	
19	13249-97J10	.GASKET	1	
20	13248-97J00	.PLATE	1	
21	13268-97J20	.SPRING	1	
22	13534-97J10	.SCREW	1	
23	09401-09404	CLIP	2	
24	13125-91J10	GASKET,CARBURETOR	2	
25	13413-97L01	ROD,CHOKE	1	
26	13436-91J00	CONNECTOR,CHOKE ROD	1	
27	13631-97L00	KNOB,CHOKE	1	
28	09103-06521	BOLT (8X85)	2	
29	09343-50L01-060	HOSE,FUEL (5X10X60)	1	
30	13124-91JL0	INSULATOR,CARBURETOR	1	

FIG.146A




FIG.146A (1-B-9) FUEL PUMP (DF4A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15100-91J03	PUMP ASSY,FUEL	1	
2	15170-91J02	.DIAPHRAGM SET	1	
3	15251-91J00	.SCREW	4	
4	15191-97L00	HOSE,FUEL	1	PUMP TO 3WAY
5	15850-97L01	VALVE,FUEL RTN CHECK	1	
6	33833-97L30	PROTECTOR,FUEL HOSE	1	
7	44330-13H00	FILTER,FUEL	1	
8	09280-27006	O-RING (D:2,ID:27.5)	1	
9	09343-50L01-040	HOSE,FUEL (5X10X40)	1	FILTER TO PUMP
10	09343-50L01-040	HOSE,FUEL (5X10X40)	1	3WAY TO VALVE
11	09343-50L01-080	HOSE,FUEL (5X10X80)	1	VALVE TO 3WAY
12	09343-50L01-120	HOSE,FUEL (5X10X120)	1	COCK TO 3WAY
13	09343-50L01-550	HOSE,FUEL (5X10X550)	1	3WAY TO FILTER
14	09367-06007	3 WAY	2	
15	09401-09404	CLIP	1	
16	09403-09001	CLAMP,FUEL HOSE	3	
17	01550-0630C	BOLT (6X30)	2	

FIG.146B




FIG.146B (1-B-10) FUEL PUMP (DF5A,DF6A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15100-91J03	PUMP ASSY,FUEL	1	
2	15170-91J02	.DIAPHRAGM SET	1	
3	15251-91J00	.SCREW	4	
4	15191-97L00	HOSE,FUEL	1	PUMP TO 3WAY
5	15192-97L00	HOSE,FUEL	1	CONN TO 3WAY
6	15850-97L01	VALVE,FUEL RTN CHECK	1	
7	33833-97L00	PROTECTOR,FUEL HOSE (12X13X40)	1	
8	33833-97L10	PROTECTOR,FUEL HOSE (12X13X75)	1	
9	33833-97L20	PROTECTOR,FUEL HOSE (12X13X240)	1	
10	44330-13H00	FILTER,FUEL	2	
11	09280-27006	O-RING (D:2,ID:27.5)	1	
12	09343-50L01-040	HOSE,FUEL (5X10X40)	1	FILTER TO PUMP
13	09343-50L01-040	HOSE,FUEL (5X10X40)	1	3WAY TO VALVE
14	09343-50L01-080	HOSE,FUEL (5X10X80)	1	VALVE TO 3WAY
15	09343-50L01-110	HOSE,FUEL (5X10X110)	1	JOINT,3WAY TO FILTER
16	09343-50L01-120	HOSE,FUEL (5X10X120)	1	COCK TO 3WAY
17	09343-50L01-380	HOSE,FUEL	1	3WAY TO JOINT,3WAY
18	09367-06002	JOINT,3 WAY	1	
19	09367-06007	3 WAY	2	
20	09401-09404	CLIP	17	
21	09401-11424	CLIP	1	
22	09403-09001	CLAMP,FUEL HOSE	3	
23	01550-0630C	BOLT (6X30)	2	
24	09343-50L01-040	HOSE,FUEL (5X10X40)	1	

FIG.160A




FIG.160A (1-B-11) WATER PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-91JL0	CASE,WATER PUMP	1	
2	17415-98501	GROMMET,WATER PUMP CASE	1	
3	17461-985M0	IMPELLER,WATER PUMP	1	
4	17471-98610	PANEL,PUMP CASE UNDER	1	
5	17472-91J00	GASKET,PUMP CASE PANEL (L:479)	1	
6-1	17561-97L00	TUBE,WATER	1	W/TRANSOM(S)
6-2	17561-97L10	TUBE,WATER	1	W/TRANSOM(L)
7	17563-97L00	GROMMET,WATER TUBE UPPER	1	
8	17564-98600	GUIDE,WATER TUBE	1	
9	09108-06146	BOLT,STUD	4	
10	09116-06225	BOLT (6X16)	1	
11	29141-93J00	NUT (M6)	4	
12	09160-06082	WASHER (6.5X13X1.0)	4	
13	17412-91JL0	PANEL,WATER PUMP CASE UPPER	1	
14	17413-91JL0	SLEEVE,WATER PUMP CASE	1	
15	09420-03002	KEY	1	
16	56130-91J20	HOUSING,DRIVE SFT BRG	1	
17	09282-10008	.SEAL,OIL (10X21X4.5)	2	
18	56132-91J00	GASKET,DRIVE SFT HSG	1	
19	09116-06229	BOLT (6X25)	1	
20	25215-98601	STOPPER,SHIFT ROD GUIDE	1	
21	17400-986L2	KIT,WATER PUMP REPAIR	1	

FIG.167A




FIG.167A (1-B-12) RECOIL STARTER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-97L00	STARTER ASSY,RECOIL	1	
2	18121-97L00	.REEL	1	
3	18130-97L00	.RATCHET SET	1	
4	18142-97L00	.SPRING,SPIRAL	1	
5	18178-98310	.CIRCLIP	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-91J00	.NSI SET	1	
8	99000-81157-50M	STARTER ROPE 4MMDIA,50M ROLE (L:50000)	1	OPT
9	18290-97L00	CABLE ASSY,NSI	1	
10	01550-0612C	BOLT	3	
11	69711-91J11	LABEL	1	
12	61472-97L00	LABEL,RECOIL STARTER	1	
13	61494-97L00	LABEL,OIL & CLEARANCE	1	

DF4A_5A_6A_P01_021_167A
RECOIL STARTER

FIG.175A




FIG.175A (1-B-13) OIL PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	16131-97L00	ROTOR,OIL PUMP INNER	1	
2	16132-97L00	ROTOR,OIL PUMP OUTER	1	
3	16161-97L00	COVER,OIL PUMP ROTOR	1	
4	16165-97L00	SEAL,OIL PUMP COVER	1	
5	16520-97L00	STRAINER,OIL	1	
6	16524-97L01	GROMMET,OIL STRAINER	1	
7	01550-0620A	BOLT	1	
8	01547-0620C	BOLT,OIL PUMP COVER	3	
9	16510-16H11	FILTER,ENG OIL	1	
10	16512-97L00	CAP,OIL FILTER	1	
11	09280-39002	O RING	1	
12	09440-10038	SPRING	1	
13	01550-0616C	BOLT (6X16)	2	

FIG.208A




FIG.208A (1-B-14) CLUTCH LEVER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21110-97L00	LEVER,CLUTCH	1	
2	21120-97L00	PLATE,CLUTCH NOTCH	1	
3	21216-91J00	SPACER,CLUTCH SHAFT	1	
4	23110-97L00	ROD,CLUTCH	1	
5	23210-91J00	ARM,CLUTCH ROD	1	
6	23212-91J00	PIN,CLUTCH NOTCH	1	
7	23213-91J00	SPRING,CLUTCH NOTCH	1	
8	23310-91J00	CONNECTOR,CLUTCH ROD NO.1	1	
9	23321-91J00	CONNECTOR,CLUTCH ROD NO.2	1	
10	09116-06227	BOLT (6X20)	2	
11	09100-06181	BOLT	1	
12	09160-06173	WASHER (6.2X19X3)	1	
13	09204-01002	PIN	1	
14	09280-16005	O-RING (D:2.4,ID:15.8)	2	

FIG.210A




FIG.210A (1-B-15) SHIFT ROD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	25111-97L00	ROD,SHIFT	1	W/TRANSOM(S)
1-2	25111-97L10	ROD,SHIFT	1	W/TRANSOM(L)
2	25211-98601	GUIDE,SHIFT ROD	1	
3	25222-91JL0	BOOT,SHIFT ROD	1	
4	25311-91J01	CAM,SHIFT	1	
5	09160-05501	WASHER (5.5X20X1.2)	1	
6	09205-02004	SPRING PIN (2.5X12)	2	
7	09280-05008	O-RING (D:2.9,ID:4.8)	1	
8	09280-15007	O-RING (D:2.4,ID:15.8)	1	

DF4A_5A_6A_P01_021_210A
SHIFTROD

FIG.230A




FIG.230A (1-B-16) DRIVE SHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57111-91J21	SHAFT,DRIVE	1	W/TRANSOM(S)
1-2	57111-91J31	SHAFT,DRIVE	1	W/TRANSOM(L)
2	09181-10156	SHIM (10X16X1.5)	1	
3	57130-91J00	BUSH,DRIVE SHAFT	1	W/TRANSOM(L)
4	09380-10003	CIRCLIP	2	
5	57311-91J00	PINION (NT:12)	1	
6-1	09160-10088	WASHER (T:1.7)	1	PINION ADJ
6-2	09160-10089	WASHER (T:1.8)	1	PINION ADJ
6-3	09160-10090	WASHER (T:1.9)	1	PINION ADJ
6-4	09160-10091	WASHER (T:2.0)	1	PINION ADJ
6-5	09160-10092	WASHER (T:2.1)	1	PINION ADJ
7	09166-12L01	WASHER,PINION THRUST	1	
8	57510-91J00	GEAR,FORWARD (NT:23)	1	
9	57520-97L00	GEAR,REVERSE (NT:23)	1	
10-1	59171-97L00	WASHER (12X16X0.6)	1	
10-2	59171-97L10	WASHER (12X16X0.8)	1	
10-3	59171-97L20	WASHER (12X16X1.0)	1	
11	09181-12111	SHIM (12X16X1)	1	PROP SFT FWD
12-1	09181-12022	SHIM (12X20X1.3)	1	REV GEAR
12-2	09181-12023	SHIM (12X20X1.4)	1	REV GEAR
12-3	09181-12024	SHIM (12X20X1.5)	1	REV GEAR
12-4	09181-12017	WASHER (12X20X1.6)	1	REV GEAR
12-5	09181-12018	WASHER (12X20X1.7)	1	REV GEAR
13-1	09181-20162	SHIM (20X28X0.8)	1	FWD GEAR
13-2	09181-20164	SHIM (20X28X0.9)	1	FWD GEAR
13-3	09181-20167	SHIM (20X28X1)	1	FWD GEAR
13-4	09181-20172	SHIM (20X28X1.1)	1	FWD GEAR
13-5	09181-20176	SHIM (20X28X1.2)	1	FWD GEAR
14	57611-97L00	SHAFT,PROPELLER	1	
15	57621-986L0	SHIFTER,CLUTCH DOG	1	
16	09202-04016	PIN	1	
17	09440-05039	SPRING	1	
18	09440-24007	SPRING	1	
19	57631-98601	ROD,PUSH	1	
20	57632-97L00	PIN,PUSH (6X6)	1	

DF4A_5A_6A_P01_021_230A
DRIVE SHAFT

FIG.303A




FIG.303A (1-C-2) MAGNETO (DF4A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32102-97L00	FLYWHEEL,MAGNETO	1	
2	33410-97L10	IGNITER ASSY,MAGNETO	1	
3	01547-0620C	BOLT,OIL PUMP COVER	2	
4	08316-1012A	NUT	1	
5	08341-31039	KEY	1	
6	33510-07H00	CAP,SPARK PLUG	1	
7	33541-16H00	SEAL,SPARK PLUG	1	
8	33542-07H00	SEAL,HIGH TENSION CORD	1	
9	37830-97L00	SWITCH ASSY,EMERGENCY & STOP	1	
10	37823-97J00	.PLATE,LOCK	1	
11	37826-97J01	.NUT,EMERGENCY SWITCH	1	
12-1	37835-91J00-YAY	LABEL,STOP (BLACK)	1	FOR YAY
12-2	37835-91J00-Y5S	LABEL,STOP (WHITE)	1	020 FOR Y5S
13	36991-94L00	CLAMP,HARNESS	1	
14	09408-00159	CLAMP	1	
15	08322-01067	WASHER	1	
16	09407-14407	CLAMP (L:145)	2	
17	17110-97L00	FAN,COOLING	1	
18	01550-0612C	BOLT	3	

FIG.303B




FIG.303B (1-C-3) MAGNETO (DF5A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32102-97L00	FLYWHEEL,MAGNETO	1	
2	33410-97L20	IGNITER ASSY,MAGNETO	1	
3	01547-0620C	BOLT,OIL PUMP COVER	2	
4	08316-1012A	NUT	1	
5	08341-31039	KEY	1	
6	33510-07H00	CAP,SPARK PLUG	1	
7	33541-16H00	SEAL,SPARK PLUG	1	
8	33542-07H00	SEAL,HIGH TENSION CORD	1	
9	37830-97L00	SWITCH ASSY,EMERGENCY & STOP	1	
10	37823-97J00	.PLATE,LOCK	1	
11	37826-97J01	.NUT,EMERGENCY SWITCH	1	
12-1	37835-91J00-YAY	LABEL,STOP (BLACK)	1	FOR YAY
12-2	37835-91J00-Y5S	LABEL,STOP (WHITE)	1	020 FOR Y5S
13	36991-94L00	CLAMP,HARNESS	1	
14	09408-00159	CLAMP	1	
15	08322-01067	WASHER	1	
16	09407-14407	CLAMP (L:145)	2	
17	17110-97L00	FAN,COOLING	1	
18	01550-0612C	BOLT	3	

FIG.303C




FIG.303C (1-C-4) MAGNETO (DF6A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32102-97L00	FLYWHEEL,MAGNETO	1	
2	33410-97L30	IGNITER ASSY,MAGNETO	1	
3	01547-0620C	BOLT,OIL PUMP COVER	2	
4	08316-1012A	NUT	1	
5	08341-31039	KEY	1	
6	33510-07H00	CAP,SPARK PLUG	1	
7	33541-16H00	SEAL,SPARK PLUG	1	
8	33542-07H00	SEAL,HIGH TENSION CORD	1	
9	37830-97L00	SWITCH ASSY,EMERGENCY & STOP	1	
10	37823-97J00	.PLATE,LOCK	1	
11	37826-97J01	.NUT,EMERGENCY SWITCH	1	
12-1	37835-91J00-YAY	LABEL,STOP (BLACK)	1	FOR YAY
12-2	37835-91J00-Y5S	LABEL,STOP (WHITE)	1	020 FOR Y5S
12-3	37835-91J00-QTN	LABEL,STOP (WHITE)	1	021 FOR QTN
13	36991-94L00	CLAMP,HARNESS	1	
14	09408-00159	CLAMP	1	
15	08322-01067	WASHER	1	
16	09407-14407	CLAMP (L:145)	2	
17	17110-97L00	FAN,COOLING	1	
18	01550-0612C	BOLT	3	

FIG.335A




FIG.335A (1-C-5) CLAMP BRACKET

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	41111-97L00-YAY	BRACKET,CLAMP STBD (BLACK)	1	STBD FOR YAY
1-2	41111-97L00-Y5S	BRACKET,CLAMP STBD (WHITE)	1	STBD:020 FOR Y5S
1-3	41111-97L00-QTN	BRACKET,CLAMP STBD (WHITE)	1	STBD:DF6A:021 FOR QTN
2-1	41121-97L00-YAY	BRACKET,CLAMP PORT (BLACK)	1	PORT FOR YAY
2-2	41121-97L00-Y5S	BRACKET,CLAMP PORT (WHITE)	1	PORT:020 FOR Y5S
2-3	41121-97L00-QTN	BRACKET,CLAMP PORT (WHITE)	1	PORT:DF6A:021 FOR QTN
3	41211-97L00	SCREW,CLAMP	2	
4	41212-91J00	HANDLE,CLAMP	2	
5	41213-94J01	PLATE,CLAMP	2	
6	09205-06021	PIN,SPRING (6X25)	2	
7	09100-06176	BOLT (6X120)	1	
8	09100-08314	BOLT (8X140)	1	
9	29141-93J00	NUT (M6)	1	
10	09159-08059	NUT (M8)	1	
11	09160-06082	WASHER (6.5X13X1.0)	1	
12	09160-08059	WASHER (8.5X18X1.6)	1	
13	09180-06371	SPACER (6.5X10.5X92)	1	
14	45420-97L00	PIN,TILT LOCK	1	
15	69911-91J50	MARK,CLAMP BRACKET	1	
16	45717-97L00	SPRING,SHALLOW DRIVE REGULATOR	1	
17	09125-05143	SCREW (5X20)	1	
18	09180-05067	SPACER	1	

FIG.336A




FIG.336A (1-C-6) SWIVEL BRACKET

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE,GREASE	4	
2-1	43111-97L00-YAY	BRACKET,SWIVEL (BLACK)	1	FOR YAY
2-2	43111-97L00-Y5S	BRACKET,SWIVEL (WHITE)	1	020 FOR Y5S
2-3	43111-97L00-QTN	BRACKET,SWIVEL (WHITE)	1	DF6A_021
3-1	43121-97L00-YAY	COVER,SWIVEL BRACKET (BLACK)	1	FOR YAY
3-2	43121-97L00-Y5S	COVER,SWIVEL BRACKET (WHITE)	1	020 FOR Y5S
3-3	43121-97L00-QTN	COVER,SWIVEL BRACKET (WHITE)	1	DF6A:021 FOR QTN
4	43211-97L00	BUSH,CLAMP BRACKET BOLT	2	
5	43711-97L00	BUSH,STEERING UPPER	2	
6-1	43751-97L00-YAY	BRACKET,STEERING (BLACK)	1	FOR YAY
6-2	43751-97L00-Y5S	BRACKET,STEERING (WHITE)	1	020 FOR Y5S
6-3	43751-97L00-QTN	BRACKET,STEERING (WHITE)	1	DF6A_021 FOR QTN
7-1	43752-97L00-YAY	COVER,STEERING BRACKET (BLACK)	1	FOR YAY
7-2	43752-97L00-Y5S	COVER,STEERING BRACKET (WHITE)	1	020 FOR Y5S
7-3	43752-97L00-QTN	COVER,STEERING BRACKET (WHITE)	1	DF6A:021 FOR QTN
8	09116-06234	BOLT (6X35)	6	
9	45211-97L00	SPRING,REVERSE LOCK ARM STBD	1	STBD
10	45212-97L00	SPRING,REVERSE LOCK ARM PORT	1	PORT
11	45230-97L00	ARM,REVERSE LOCK	1	
12	09116-06224	BOLT (6X12)	2	
13	43430-97L00	RUBBER,STEERING ADJUSTER	1	
14	43410-91J21	KNOB,STEERING ADJUSTER	1	
15	45247-99J00	PIN,REV LOCK ARM COTTER	1	
16	45710-97L00	ARM,SHALLOW WATER DRIVE	1	
17	45733-97L00	PLATE,SHALLOW DRIVE	1	
18	45751-97L00	BUSH,SHALLOW DRIVE WATER ARM	2	
19	09116-06226	BOLT (6X16)	2	
20	43417-97L00	SPACER,STEERING ADJUSTER	1	

DF4A_5A_6A_P01_021_336A
SWIVEL BRACKET

FIG.405A




FIG.405A (1-C-7) DRIVE SHAFT HOUSING

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	52110-97L01-YAY	HOUSING,DRIVE SHAFT (BLACK)	1	FOR YAY
1-2	52110-97L01-Y5S	HOUSING,DRIVE SHAFT (WHITE)	1	020 FOR Y5S
1-3	52110-97L01-QTN	HOUSING,DRIVE SHAFT (WHITE)	1	DF6A:021 FOR QTN
2	22511-99011	.NIPPLE,GREASE	1	
3	52113-97L00	GASKET,DRIVE SHAFT HOUSING	1	
4	52115-98600	COVER,CLUTCH AJUST HOLE	1	
5	09116-06233	BOLT (6X35)	7	
6	09168-10022	GASKET (10X17X1.5)	1	
7	09202-06023	PIN (6X10)	2	
8	09320-04010	BUSH	1	
9-1	52131-91J20-YAY	CASE,EXTENSION (BLACK)	1	FOR YAY
9-2	52131-91J20-Y5S	CASE,EXTENSION (WHITE)	1	020 FOR Y5S
9-3	52131-91J20-QTN	CASE,EXTENSION (WHITE)	1	DF6A:021 FOR QTN
10	09108-08309	BOLT,STUD	2	
11	09206-11006	PIN (11X8)	1	
12	54132-97L00	RUBBER,MOUNT UPPER	1	
13	54162-97L00	RUBBER,MOUNT LOWER	1	
14	52117-97L01	TUBE,WATER INSPECTION	1	
15	55181-95200	ATTACHMENT,FLUSH HOSE	1	OPT

DF4A_5A_6A_P01_021_405A
DRIVE SHAFTHOUSING

FIG.407A




FIG.407A (1-C-8) GEAR CASE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55110-97L00-YAY	CASE,GEAR (BLACK)	1	FOR YAY
1-2	55110-97L00-Y5S	CASE,GEAR (WHITE)	1	020 FOR Y5S
1-3	55110-97L00-QTN	CASE,GEAR (WHITE)	1	DF6A:021 FOR QTN
2	59311-91J00	.BUSH,PINION	1	
3	09262-20106	BEARING (20X42X12)	1	
4	55321-87J01	ANODE,PROTECTION	1	
5	09116-08156	BOLT,GEAR CASE (8X50)	2	
6	09103-06281	BOLT (6X14)	1	
7	59178-97J00	GASKET,DRAIN PLUG	2	
8	09206-11006	PIN (11X8)	1	
9	09248-08001	PLUG (8X7.5)	2	
10	09140-08023-XC0	NUT (M8)	2	
11	09160-08082	WASHER (8.5X16X1.2)	2	
12-1	56120-97L00-YAY	HOUSING,PROP SHAFT BRG (BLACK)	1	FOR YAY
12-2	56120-97L00-Y5S	HOUSING,PROP SHAFT BRG (WHITE)	1	020 FOR Y5S
12-3	56120-97L00-QTN	HOUSING,PROP SHAFT BRG (WHITE)	1	DF6A:021 FOR QTN
13	09167-23001	.WASHER	1	
14	09282-12L05	.SEAL,OIL (12X24X4.5)	2	
15	09262-12001	.BEARING (12X28X8)	1	
16	56122-98602	PROTECTOR,OIL SEAL	1	
17	56123-98600	WASHER,PROTECTOR	1	
18	09116-06225	BOLT (6X16)	2	
19	09280-49002	O-RING (D:2.6,ID:48.7)	1	
20-1	58110-91JL0-019	PROPELLER (3X7-1/2X6,BLACK)	1	
20-2	58110-91JM0-019	PROPELLER (3X7-1/2X6-1/2,BLACK)	1	
20-3	58110-91JN0-019	PROPELLER (3X7-1/2X7,BLACK)	1	
21	58120-91JL0	.BUSH,PROPELLER	1	
22	58130-91JL0	NUT,PROPELLER	1	
23	57635-97L00	STOPPER,PROPELLER BUSH	1	
24	09204-03003	PIN (D:3.6,L:25)	1	

DF4A_5A_6A_P01_021_407A
GEAR CASE

FIG.407A




FIG.407A (1-C-9) GEAR CASE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
25	55321-87J11	ANODE (MAGNESIUM)	1	OPT

DF4A_5A_6A_P01_021_407A
GEAR CASE

FIG.412A




FIG.412A (1-C-10) LOWER COVER (DF4A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61110-97L11-QGF	COVER,ENGINE LOWER (BLACK)	1	FOR YAY
1-2	61110-97L11-Y5S	COVER,ENGINE LOWER (WHITE)	1	020
				FOR Y5S
2	61112-97L00	RUBBER,ENGINE LOWER COVER	1	
3	61117-97L00	COVER,AIR INTAKE LOWER	1	
4	61133-97L00	DUCT,AIR VENT	1	
5	61135-97L01	CUSHION,AIR VENT DUCT LOWER	1	
6	61137-97L00	CUSHION,AIR VENT DUCT UPPER	1	
7	61189-97L00	GROMMET,OIL DRAIN	1	
8	09116-06227	BOLT (6X20)	2	
9	09116-06509	BOLT (6X20)	4	
10	09250-10030	CAP	1	
11	09250-12016	CAP (OD:20)	1	
12	03542-05169	SCREW	1	
13	61611-91J11	FASTENER,ENGINE COVER	2	
14	61626-97L00	NUT,FASTENER LEVER	2	
15	61640-91J10	LEVER,FASTENER	2	
16	09106-05035	BOLT (5X14)	2	
17-1	21131-94J00-YAY	MARK,CLUTCH SHIFT (BLACK)	1	FOR YAY
17-2	21131-94J00-Y5S	MARK,CLUTCH SHIFT (WHITE)	1	020
				FOR Y5S
18-1	61211-97L10-YAY	MARK,FUEL COCK (BLACK)	1	FOR YAY
18-2	61211-97L10-Y5S	MARK,FUEL COCK (WHITE)	1	020
				FOR Y5S
19	61619-97L00	CUSHION,ENG COVER FASTENER	1	

FIG.412C




FIG.412C (1-C-11) LOWER COVER (DF5A,DF6A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61110-97L11-QGF	COVER,ENGINE LOWER (BLACK)	1	FOR YAY
1-2	61110-97L11-Y5S	COVER,ENGINE LOWER (WHITE)	1	020
				FOR Y5S
1-3	61110-97L11-QTN	COVER,ENGINE LOWER (WHITE)	1	DF6A:021
				FOR QTN
2	61112-97L00	RUBBER,ENGINE LOWER COVER	1	
3	61117-97L00	COVER,AIR INTAKE LOWER	1	
4	61133-97L00	DUCT,AIR VENT	1	
5	61135-97L01	CUSHION,AIR VENT DUCT LOWER	1	
6	61137-97L00	CUSHION,AIR VENT DUCT UPPER	1	
7	61189-97L00	GROMMET,OIL DRAIN	1	
8	09116-06227	BOLT (6X20)	2	
9	09116-06509	BOLT (6X20)	4	
10	09250-10030	CAP	1	
11	03542-05169	SCREW	1	
12	61611-91J11	FASTENER,ENGINE COVER	2	
13	61626-97L00	NUT,FASTENER LEVER	2	
14	61640-91J10	LEVER,FASTENER	2	
15	09106-05035	BOLT (5X14)	2	
16	65720-986L0	PLUG,FUEL CONNECTOR	1	
17	65727-91JL0	CAP,FUEL CONNECTOR PLUG	1	
18	09103-06237	BOLT (6X12.5)	1	
19	09160-06175	WASHER (6.5X15X1)	1	
20-1	21131-94J00-YAY	MARK,CLUTCH SHIFT (BLACK)	1	FOR YAY
20-2	21131-94J00-Y5S	MARK,CLUTCH SHIFT (WHITE)	1	020
				FOR Y5S
20-3	21131-94J00-QTN	MARK,CLUTCH SHIFT (WHITE)	1	DF6A:021
				FOR QTN
21-1	61211-97L00-YAY	MARK,FUEL COCK (BLACK)	1	FOR YAY
21-2	61211-97L00-Y5S	MARK,FUEL COCK (WHITE)	1	020
				FOR Y5S
21-3	61211-97L00-QTN	MARK,FUEL COCK (WHITE)	1	DF6A:021
				FOR QTN
22	61619-97L00	CUSHION,ENG COVER FASTENER	1	

FIG.420A




FIG.420A (1-C-12) ENGINE COVER (DF4A:020)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61411-97L00-YAY	COVER,ENGINE UPPER (BLACK)	1	FOR YAY
1-2	61411-97L00-Y5S	COVER,ENGINE UPPER (WHITE)	1	FOR Y5S
2	61622-97L00	SEAL,RECOIL STARTER	1	
3-1	61435-97L00-YAY	MARK,EMBLEM REAR (BLACK)	1	FOR YAY
3-2	61435-97L00-Y5S	MARK,EMBLEM REAR (WHITE)	1	FOR Y5S
4-1	61443-97L01-Y5S	STRIPE,ENG COVER STBD (WHITE)	1	FOR Y5S
4-2	61443-97L01-YAY	STRIPE,ENG COVER STBD (BLACK)	1	FOR YAY
5-1	61453-97L01-Y5S	STRIPE,ENG COVER PORT (WHITE)	1	FOR Y5S
5-2	61453-97L01-YAY	STRIPE,ENG COVER PORT (BLACK)	1	FOR YAY
6	61458-97J70	LABEL,ENGINE COVER	1	
7	77811-54GB0-0PG	EMBLEM,REAR MARK (CHROME)	1	
8	59800-97L00	TOOL ASSY	1	
9	99011-97L61-055	MANUAL,OWNER'S	1	

FIG.420D




FIG.420D (1-C-13) ENGINE COVER (DF5A:020)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61411-97L00-YAY	COVER,ENGINE UPPER (BLACK)	1	FOR YAY
1-2	61411-97L00-Y5S	COVER,ENGINE UPPER (WHITE)	1	FOR Y5S
2	61622-97L00	SEAL,RECOIL STARTER	1	
3-1	61435-97L10-YAY	MARK,EMBLEM REAR (BLACK)	1	FOR YAY
3-2	61435-97L10-Y5S	MARK,EMBLEM REAR (WHITE)	1	FOR Y5S
4-1	61443-97L01-Y5S	STRIPE,ENG COVER STBD (WHITE)	1	FOR Y5S
4-2	61443-97L01-YAY	STRIPE,ENG COVER STBD (BLACK)	1	FOR YAY
5-1	61453-97L01-Y5S	STRIPE,ENG COVER PORT (WHITE)	1	FOR Y5S
5-2	61453-97L01-YAY	STRIPE,ENG COVER PORT (BLACK)	1	FOR YAY
6	61458-97J70	LABEL,ENGINE COVER	1	
7	77811-54GB0-0PG	EMBLEM,REAR MARK (CHROME)	1	
8	59800-97L00	TOOL ASSY	1	
9	99011-97L61-055	MANUAL,OWNER'S	1	

FIG.420G




FIG.420G (1-C-14) ENGINE COVER (DF6A:020)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61411-97L00-YAY	COVER,ENGINE UPPER (BLACK)	1	FOR YAY
1-2	61411-97L00-Y5S	COVER,ENGINE UPPER (WHITE)	1	FOR Y5S
2	61622-97L00	SEAL,RECOIL STARTER	1	
3-1	61435-97L20-YAY	MARK,EMBLEM REAR (BLACK)	1	FOR YAY
3-2	61435-97L20-Y5S	MARK,EMBLEM REAR (WHITE)	1	FOR Y5S
4-1	61443-97L01-Y5S	STRIPE,ENG COVER STBD (WHITE)	1	FOR Y5S
4-2	61443-97L01-YAY	STRIPE,ENG COVER STBD (BLACK)	1	FOR YAY
5-1	61453-97L01-Y5S	STRIPE,ENG COVER PORT (WHITE)	1	FOR Y5S
5-2	61453-97L01-YAY	STRIPE,ENG COVER PORT (BLACK)	1	FOR YAY
6	61458-97J70	LABEL,ENGINE COVER	1	
7	77811-54GB0-0PG	EMBLEM,REAR MARK (CHROME)	1	
8	59800-97L00	TOOL ASSY	1	
9	99011-97L61-055	MANUAL,OWNER'S	1	

DF4A_5A_6A_P01_021_420G
ENGINE COVER

FIG.420H




FIG.420H (1-C-15) ENGINE COVER (DF4A:021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61411-97L00-YAY	COVER,ENGINE UPPER (BLACK)	1	FOR YAY
2	61622-97L00	SEAL,RECOIL STARTER	1	
3	61435-97L30-YAY	MARK,EMBLEM REAR (BLACK)	1	FOR YAY
4	61443-97L10-YAY	STRIPE,ENGINE COVER STBD	1	FOR YAY
5	61453-97L10-YAY	STRIPE,ENGINE COVER PORT	1	FOR YAY
6	61458-97J70	LABEL,ENGINE COVER	1	
7	77811-54GB0-0PG	EMBLEM,REAR MARK (CHROME)	1	
8	59800-97L00	TOOL ASSY	1	
9	99011-97L61-055	MANUAL,OWNER'S	1	

DF4A_5A_6A_P01_021_420H
ENGINE COVER

FIG.420L




FIG.420L (1-C-16) ENGINE COVER (DF5A:021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61411-97L00-YAY	COVER,ENGINE UPPER (BLACK)	1	FOR YAY
2	61622-97L00	SEAL,RECOIL STARTER	1	
3	61435-97L40-YAY	MARK,EMBLEM REAR (BLACK)	1	
4	61443-97L10-YAY	STRIPE,ENGINE COVER STBD	1	FOR YAY
5	61453-97L10-YAY	STRIPE,ENGINE COVER PORT	1	FOR YAY
6	61458-97J70	LABEL,ENGINE COVER	1	
7	77811-54GB0-0PG	EMBLEM,REAR MARK (CHROME)	1	
8	59800-97L00	TOOL ASSY	1	
9	99011-97L61-055	MANUAL,OWNER'S	1	

DF4A_5A_6A_P01_021_420L
ENGINE COVER

FIG.420P




FIG.420P (1-D-2) ENGINE COVER (DF6A:021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61411-97L00-YAY	COVER,ENGINE UPPER (BLACK)	1	FOR YAY
1-2	61411-97L00-QTN	COVER,ENGINE UPPER (WHITE)	1	FOR QTN
2	61622-97L00	SEAL,RECOIL STARTER	1	
3-1	61435-97L50-YAY	MARK,EMBLEM REAR (BLACK)	1	FOR YAY
3-2	61435-97L50-QTN	MARK,EMBLEM REAR (WHITE)	1	FOR QTN
4-1	61443-97L10-YAY	STRIPE,ENGINE COVER STBD	1	FOR YAY
4-2	61443-97L10-QTN	STRIPE,ENGINE COVER STBD	1	FOR QTN
5-1	61453-97L10-YAY	STRIPE,ENGINE COVER PORT	1	FOR YAY
5-2	61453-97L10-QTN	STRIPE,ENGINE COVER PORT	1	FOR QTN
6	61458-97J70	LABEL,ENGINE COVER	1	
7	77811-54GB0-0PG	EMBLEM,REAR MARK (CHROME)	1	
8	59800-97L00	TOOL ASSY	1	
9	99011-97L61-055	MANUAL,OWNER'S	1	

FIG.432B




FIG.432B (1-D-3) FUEL TANK

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61416-97L01	GUARD,FUEL TANK	1	
2	65110-97L10	TANK,FUEL	1	
3	65112-97L00	COVER,FUEL TANK PLATE	1	
4	65113-97L00	PLATE,FUEL TANK	1	
5	65136-97L00	FILTER,FUEL TANK INLET	1	
6	65281-97L01	GROMMET,FUEL TANK	1	
7	65284-97L00	RUBBER,FUEL TANK GROMMET	1	
8	65510-97L01	CAP ASSY,FUEL TANK	1	
9	65561-91J01	.GASKET,TANK CAP (32X48X3)	1	
10	09116-06512	BOLT (6X35)	3	
11	09169-06092	WASHER	3	
12	09320-05019	CUSHION	2	
13	09320-08051	CUSHION	1	
14	09320-09507	CUSHION,FUEL TANK FLANGE	3	
15	09321-08022	CUSHION	1	
16	66100-97L00	COCK ASSY,FUEL	1	
17	66121-97L00	LEVER,FUEL COCK	1	
18	66122-97L00	SHAFT,FUEL COCK	1	
19	66142-97L01	PIPE,JOINT	1	
20	66160-97L00	CLAMP ASSY,JOINT PIPE	1	
21	09125-05050	SCREW (5X8)	1	

DF4A_5A_6A_P01_021_432B
FUELTANK

FIG.444A




FIG.444A (1-D-4) TILLER HANDLE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33833-97L50	PROTECTOR (16X17X90)	1	
2	09440-12027	SPRING	1	
3-1	63111-97L00-YAY	HANDLE,TILLER (BLACK)	1	FOR YAY
3-2	63111-97L00-Y5S	HANDLE,TILLER (WHITE)	1	020 FOR Y5S
3-3	63111-97L00-QTN	HANDLE,TILLER (WHITE)	1	DF6A:021 FOR QTN
4	63115-97L00	BUSH,TILLER HANDLE	2	
5	63116-97L00	MOUNT,TILLER HANDLE	2	
6	63125-97L00	STOPPER,TILLER HANDLE	1	
7	63210-94L01	GRIP,HANDLE	1	
8	63220-97L00	ROD,HANDLE	1	
9	63225-93200	BUSH,HANDLE ROD	1	
10	63228-97L00	HOLDER,HANDLE ROD	1	
11	63240-95L00	KNOB,THROTTLE ADJ	1	
12	63241-95L02	ADJUSTER,HANDLE GRIP	1	
13	63610-97L00	CABLE ASSY,THROTTLE	2	
14	09116-06225	BOLT (6X16)	2	
15	09125-05046	SCREW (5X12)	2	
16	09126-06015	SCREW (6X23)	1	
17	09163-06001	WASHER,LOCK (6.4X12X0.5)	1	
18	09385-04004	CLIP	1	
19	09250-35006	CAP,THROTTLE CABLE	1	
20	09403-05312	CLAMP	2	
21	63615-97L00	BRACKET,THROTTLE CABLE CLAMP	1	
22	19184-97L00	BRACKET,THROTTLE CABLE	1	
23	69714-97L00	MARK,HANDLE GRIP	1	
24	29141-93J00	NUT (M6)	1	

FIG.508A




FIG.508A (1-D-5) OPT:REMOTE CONTROL

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-91J30	REMOTE CONTROL ASSY	1	
2	36628-91J00	.GROMMET,WIRING HARNESS	1	
3	37830-95D10	.SWITCH ASSY,EMERGENCY & STOP	1	
4	37823-92E02	..PLATE ASSY,EMERGENCY SW LOCK	1	
5	67212-95600	.WASHER	1	
6	67220-95630	.PLATE ASSY	1	
7	67223-99E10	.KNOB,BRAKE ADJUST	1	
8	67229-95600	.ROLLER	1	
9	67232-95600	.BUSH	1	
10	67238-87D00	.GEAR,DRIVE	1	
11	67241-99E11	.LEVER,FREE THROTTLE	1	
12	67243-95600	.BUSH	1	
13	67244-95600	.WAVE WASHER	1	
14	67245-95600	.DRUM,FREE THROTTLE	1	
15	67251-96L00	.LEVER,HANDLE	1	
16	67252-95600	.BUSH	2	
17	67253-95600	.WASHER	1	
18	67255-96L00	.NEUTRAL LOCK ARM	1	
19	67256-95600	.HOLDER,NEUTRAL LOCK	1	
20	67257-96L00	.CAP ASSY,LEVER	1	
21	77811-54GB0-0PG	..EMBLEM,REAR MARK (CHROME)	1	
22	67258-99E00	.BRACKET	1	
23	67259-87D00	.SPRING,NEUTRAL ARM	1	
24	67261-96L00	.GRIP	1	
25	67296-96L10	.SCREW	2	
26	67264-95600	.WASHER	1	
27	67267-96L00	.COVER,WIRE SUB ASSY	1	
28	67273-95600	.SPACER	1	
29	67275-95600	.END,CABLE	2	
30	67292-94300	.E RING	3	
31	67294-95600	.SPACER	3	
32	67296-90J20	.SCREW	5	
33	67296-96L00	.SCREW	2	
34	67296-95630	.SCREW	3	
35	67296-95610	.SCREW	2	

FIG.508A




FIG.508A (1-D-6) OPT:REMOTE CONTROL

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
36	67297-95600	.WASHER	2	
37	09100-08232	.BOLT (8X30)	1	
38	67269-96L10	.SCREW (5X12)	2	
39	09140-06020	.NUT	3	
40	67288-94320	.WAHSER (6.5X24X2)	3	
41	67284-94L10	.MARK,HANDLE LEVER	1	
42	67224-96L00	.ARM,BRAKE ASSY	1	
43	67238-96L00	.GEAR,SHIFT ASSY	1	
44	67263-88L30	.CAP,GRIP SW HOLE	1	
45-1	67320-93J00	CABLE ASSY,REMOCON (2.4M)	2	
45-2	67320-93J10	CABLE ASSY,REMOCON (3.1M)	2	
45-3	67320-93J20	CABLE ASSY,REMOCON (3.7M)	2	
45-4	67320-93J30	CABLE ASSY,REMOCON (4.2M)	2	
45-5	67320-93J40	CABLE ASSY,REMOCON (4.8M)	2	

FIG.514A




FIG.514A (1-D-7) OPT:REMOCON PARTS SET

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67101-97L00	PARTS SET,R/CON	1	
2	29141-93J00	.NUT (M6)	1	
3	63610-97L10	.CABLE ASSY,THROTTLE R/CON	2	
4	67110-97L00	.ATTACHMENT,R/CON NO.2	1	
5	67112-97L00	.ATTACHMENT,R/CON NO.1	1	
6	67412-97L00	.LEVER,R/CON THROTTLE	1	
7	67415-97L00	.DRUM,R/CON THROTTLE LEVER	1	
8	67416-91J00	.BOLT,REMOCON THROTTLE LEVER	1	
9	67447-91J10	.BOLT,REMOCON THROTTLE CABLE	1	
10	67447-97L00	.PIN,R/CON CLUTCH CABLE	1	
11	67448-91J00	.STOPPER,REMOCON CABLE PIN	2	
12	09204-01002	.PIN	1	
13	67449-97L00	.BOLT,R/CON ATTACHMENT STUD	2	
14	67460-97L00	.BRACKET,R/CON THROT LEVER	1	
15	67466-95200	.CONNECTOR	1	THROT
16	67467-93E01	.CONNECTOR,REMOCON CABLE	1	CLUTCH
17	09116-06232	.BOLT (6X30)	1	
18	09116-06229	.BOLT (6X25)	1	
19	09159-06079	.NUT	1	
20	09159-08059	.NUT (M8)	2	
21	09160-06082	.WASHER (6.5X13X1.0)	1	
22	09160-06104	.WASHER (6.5X24X2)	1	
23	09160-08145	.WASHER (8X14X1.5)	2	
24	09164-08017	.WASHER	1	
25	09180-06097	.SPACER (6.1X9X12.3)	1	
26	09306-08002	.BUSH	2	
27	09320-11017	.CUSHION (11X20X13.5)	1	
28	09403-07340	.CLAMP	1	
29	36991-94L00	.CLAMP,HARNESS	1	
30	09407-14407	.CLAMP (L:145)	2	
31	36831-97L00	.LEAD,STOP SWITCH	1	
32	09407-11401	.CLAMP (L:95)	2	

FIG.550A




FIG.550A (1-D-8) OPT:ELECTRICAL

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32000-97L01	KIT,BATTERY CHARGING	1	
2	32801-97L00	.RECTIFIER SET	1	
3	32800-94J11	..RECTIFIER & REGULATOR ASSY	1	
4	36740-95253	..CASE ASSY,FUSE	1	
5	09481-20001	...FUSE (20A)	1	
6	37132-93700	..CONNECTOR,WIRE	1	
7	01550-06207	..BOLT (6X20)	2	
8	08310-00067	..NUT	2	
9	37801-98300	..LEAD,STOP SWITCH	1	
10	39600-97L01	.COIL SET,WITH RECEPTACLE	1	
11	32102-97L10	..FLYWHEEL,MAGNETO	1	
12	32120-97L00	..COIL,MAGNETO LIGHTING	1	
13	32916-92L00	..COVER,CONNECTOR	1	
14	39601-95D01	..RECEPTACLE	1	
15	36634-93910	...CAP	1	
16	39602-93900	..PLUG ASSY,LAMP CORD	1	
17	09320-06016	..CUSHION	1	
18	29404-93J20	..CLAMP (L:80)	1	
19	09407-14407	..CLAMP (L:145)	3	
20	01547-06257	..BOLT	4	
21	01550-06127	..BOLT	1	
22	32815-97L00	..BRACKET,RECTIFIER	1	
23	36991-94L00	..CLAMP,HARNESS	1	
24	01550-06167	..BOLT (6X16)	2	
25	36990-87D00	TERMINAL & SLEEVE SET	1	

FIG.583A




FIG.583A (1-D-9) OPT:FUEL TANK (DF5A,DF6A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	65000-89L10	TANK ASSY,FUEL SEP (12L)	1	
2	65520-99100	.CAP ASSY,FUEL TANK	1	
3	65561-95D00	.GASKET,TANK CAP	1	
4	65831-95D00	.FILTER,OUTLET	1	
5	65890-99100	.OUTLET ASSY	1	
6	65892-95D00	.O-RING,FUEL OUTLET	1	
7	65740-95D01	.PLUG,FUEL CONNECTOR	1	
8	65700-89L32	HOSE,FUEL	1	
9	65750-87J11	.SOCKET,FUEL HOSE	1	
10	65750-95501	.SOCKET,FUEL HOSE	1	
11	65770-89L00	.PUMP,SQUEEZE	1	
12	65781-98500	.CLIP,FUEL HOSE	4	

PART NO.	FIG.NO.-REF.NO.
10000	
11110-97L00	111A-1
11115-93E00-001	111A-2
11117-91JL0	111A-5
11141-97L00	111A-3
11170-97L00	111A-8
11173-97L00	113A-16
11174-97L00	122A-5
11177-97L00	113A-17
11179-97L00	113A-18
11186-97L00	113A-19
11189-97L00	111A-9
11200-97L00	113A-1
11300-97L11	113A-4
11351-97L00	113A-11
11381-91J10	113A-12
11431-97L00	113A-20
11452-91J00	113A-26
11971-97L00	113A-2
12100-97L10-050	116A-25
12111-89L10-0B0	116A-1
12140-89L20	116A-2
12140-89L20-050	116A-26
12151-89L00	116A-3
12160-97L00	116A-5
12163-97L00	116A-6
12200-97L00	116A-7
12711-97L00	116A-9
12840-97L00	116A-14
12842-97L00	116A-15
12843-27A00	116A-16
12891-87C00	116A-17
12894-91JL0	116A-13
12911-91J02	116A-18
12915-91J02	116A-19
12921-91J00	116A-20
12931-78G00	116A-21
12932-24400	116A-22
12951-91J01	116A-10
13111-97L00	122A-1
13119-97L00	122A-2
13124-91JL0	128A-30
	128B-30
	128C-30
13125-91J10	128A-24
	128B-24
	128C-24
13200-97L01	128A-1
13200-97L11	128B-1
13200-97L21	128C-1
13236-97L00	128A-2
13236-97L10	128B-2
13236-97L20	128C-2
13245-97J00	128A-9
	128B-9
	128C-9
13247-97J00	128A-11
	128B-11
	128C-11
13248-97J00	128A-20
	128B-20
	128C-20
13249-97J00	128A-10
	128B-10
	128C-10
13249-97J10	128A-19
	128B-19
	128C-19
13250-97J20	128A-5
	128B-5
	128C-5
13251-97J00	128A-8
	128B-8
	128C-8
13254-97J00	128A-6
	128B-6
	128C-6
13267-97J00	128A-14
	128B-14
	128C-14
13267-97J10	128A-16
	128B-16
	128C-16
13268-97J10	128A-12
	128B-12
	128C-12
13268-97J20	128A-21
	128B-21
	128C-21
13268-97J30	128A-7
	128B-7
	128C-7
13371-91J20	128A-4
	128B-4
	128C-4
13413-97L01	128A-25
13436-91J00	128A-26
	128B-26
	128C-26
13534-97J10	128A-22
	128B-22
	128C-22
13616-97J00	128A-13
	128B-13
	128C-13
13631-97L00	128A-27
	128B-27
	128C-27
13810-97L00	122A-4
15100-91J03	146A-1
	146B-1
15170-91J02	146A-2
	146B-2
15191-97L00	146A-4
	146B-4
15192-97L00	146B-5
15251-91J00	146A-3
	146B-3
15850-97L01	146A-5
	146B-6
16131-97L00	175A-1
16132-97L00	175A-2
16152-97L00	113A-5
16153-97L00	113A-6
16161-97L00	175A-3
16165-97L00	175A-4
16510-16H11	175A-9
16512-97L00	175A-10
16520-97L00	175A-5
16524-97L01	175A-6
17110-97L00	303A-17
	303B-17
	303C-17
17400-986L2	160A-21
17410-91JL0	160A-1
17412-91JL0	160A-13
17413-91JL0	160A-14
17415-98501	160A-2
17461-985M0	160A-3
17471-98610	160A-4
17472-91J00	160A-5
17561-97L00	160A-6-1
17561-97L10	160A-6-2
17563-97L00	160A-7
17564-98600	160A-8
17670-91J02	111A-12
17680-97L00	111A-15
18100-97L00	167A-1
18121-97L00	167A-2
18130-97L00	167A-3
18142-97L00	167A-4
18178-98310	167A-5
18210-95L00	167A-6
18280-91J00	167A-7
18290-97L00	167A-9
19184-97L00	444A-22
20000	
21110-97L00	208A-1
21120-97L00	208A-2
21131-94J00-QTN	412C-20-3
21131-94J00-Y5S	412A-17-2
	412C-20-2
21131-94J00-YAY	412A-17-1
	412C-20-1
21216-91J00	208A-3
22511-99011	336A-1
	405A-2
23110-97L00	208A-4
23210-91J00	208A-5
23212-91J00	208A-6
23213-91J00	208A-7
23310-91J00	208A-8
23321-91J00	208A-9
25111-97L00	210A-1-1
25111-97L10	210A-1-2
25211-98601	210A-2
25215-98601	160A-20
25222-91JL0	210A-3
25311-91J01	210A-4
29141-93J00	160A-11
	335A-9
	444A-24
	514A-2
29404-93J20	550A-18
30000	
32000-97L01	550A-1
32102-97L00	303A-1
	303B-1
	303C-1
32102-97L10	550A-11
32120-97L00	550A-12
32800-94J11	550A-3
32801-97L00	550A-2
32815-97L00	550A-22
32916-92L00	550A-13
33410-97L10	303A-2
33410-97L20	303B-2
33410-97L30	303C-2
33510-07H00	303A-6
	303B-6
	303C-6
33541-16H00	303A-7
	303B-7
	303C-7
33542-07H00	303A-8
	303B-8
	303C-8
33833-97L00	146B-7
33833-97L10	146B-8
33833-97L20	146B-9
33833-97L30	146A-6
33833-97L40	111A-16
33833-97L50	444A-1
36628-91J00	508A-2
36634-93910	550A-15
36740-95253	550A-4
36831-97L00	514A-31
36990-87D00	550A-25
36991-94L00	303A-13
	303B-13
	303C-13
	514A-29
	550A-23
37132-93700	550A-6
37801-98300	550A-9
37823-92E02	508A-4
37823-97J00	303A-10
	303B-10
	303C-10
37826-97J01	303A-11
	303B-11
	303C-11
37830-95D10	508A-3
37830-97L00	303A-9
	303B-9
	303C-9
37835-91J00-QTN	303C-12-3
37835-91J00-Y5S	303A-12-2
	303B-12-2
	303C-12-2
37835-91J00-YAY	303A-12-1
	303B-12-1
	303C-12-1
39600-97L01	550A-10
39601-95D01	550A-14
39602-93900	550A-16
40000	
41111-97L00-QTN	335A-1-3
41111-97L00-Y5S	335A-1-2
41111-97L00-YAY	335A-1-1
41121-97L00-QTN	335A-2-3
41121-97L00-Y5S	335A-2-2
41121-97L00-YAY	335A-2-1
41211-97L00	335A-3
41212-91J00	335A-4
41213-94J01	335A-5
43111-97L00-QTN	336A-2-3
43111-97L00-Y5S	336A-2-2
43111-97L00-YAY	336A-2-1
43121-97L00-QTN	336A-3-3
43121-97L00-Y5S	336A-3-2
43121-97L00-YAY	336A-3-1
43211-97L00	336A-4
43410-91J21	336A-14
43417-97L00	336A-20
43430-97L00	336A-13
43711-97L00	336A-5
43751-97L00-QTN	336A-6-3
43751-97L00-Y5S	336A-6-2
43751-97L00-YAY	336A-6-1
43752-97L00-QTN	336A-7-3
43752-97L00-Y5S	336A-7-2

PART NO.	FIG.NO.-REF.NO.
43752-97L00-YAY	336A-7-1
44330-13H00	146A-7
	146B-10
45211-97L00	336A-9
45212-97L00	336A-10
45230-97L00	336A-11
45247-99J00	336A-15
45420-97L00	335A-14
45710-97L00	336A-16
45717-97L00	335A-16
45733-97L00	336A-17
45751-97L00	336A-18
50000	
52110-97L01-QTN	405A-1-3
52110-97L01-Y5S	405A-1-2
52110-97L01-YAY	405A-1-1
52113-97L00	405A-3
52115-98600	405A-4
52117-97L01	405A-14
52131-91J20-QTN	405A-9-3
52131-91J20-Y5S	405A-9-2
52131-91J20-YAY	405A-9-1
54132-97L00	405A-12
54162-97L00	405A-13
55110-97L00-QTN	407A-1-3
55110-97L00-Y5S	407A-1-2
55110-97L00-YAY	407A-1-1
55181-95200	405A-15
55321-87J01	407A-4
55321-87J11	407A-25
55321-95J00	111A-13
56120-97L00-QTN	407A-12-3
56120-97L00-Y5S	407A-12-2
56120-97L00-YAY	407A-12-1
56122-98602	407A-16
56123-98600	407A-17
56130-91J20	160A-16
56132-91J00	160A-18
57111-91J21	230A-1-1
57111-91J31	230A-1-2
57130-91J00	230A-3
57311-91J00	230A-5
57510-91J00	230A-8
57520-97L00	230A-9
57611-97L00	230A-14
57621-986L0	230A-15
57631-98601	230A-19
57632-97L00	230A-20
57635-97L00	407A-23
58110-91JL0-019	407A-20-1
58110-91JM0-019	407A-20-2
58110-91JN0-019	407A-20-3
58120-91JL0	407A-21
58130-91JL0	407A-22
59171-97L00	230A-10-1
59171-97L10	230A-10-2
59171-97L20	230A-10-3
59178-97J00	407A-7
59311-91J00	407A-2
59800-97L00	420A-8
	420D-8
	420G-8
	420H-8
	420L-8
	420P-8
60000	
61110-97L11-QGF	412A-1-1
	412C-1-1
61110-97L11-QTN	412C-1-3
61110-97L11-Y5S	412A-1-2
	412C-1-2
61112-97L00	412A-2
	412C-2
61117-97L00	412A-3
	412C-3
61133-97L00	412A-4
	412C-4
61135-97L01	412A-5
	412C-5
61137-97L00	412A-6
	412C-6
61189-97L00	412A-7
	412C-7
61211-97L00-QTN	412C-21-3
61211-97L00-Y5S	412C-21-2
61211-97L00-YAY	412C-21-1
61211-97L10-Y5S	412A-18-2
61211-97L10-YAY	412A-18-1
61411-97L00-QTN	420P-1-2
61411-97L00-Y5S	420A-1-2
	420D-1-2
	420G-1-2
61411-97L00-YAY	420A-1-1
	420D-1-1
	420G-1-1
	420H-1
	420L-1
	420P-1-1
61416-97L01	432B-1
61435-97L00-Y5S	420A-3-2
61435-97L00-YAY	420A-3-1
61435-97L10-Y5S	420D-3-2
61435-97L10-YAY	420D-3-1
61435-97L20-Y5S	420G-3-2
61435-97L20-YAY	420G-3-1
61435-97L30-YAY	420H-3
61435-97L40-YAY	420L-3
61435-97L50-QTN	420P-3-2
61435-97L50-YAY	420P-3-1
61443-97L01-Y5S	420A-4-1
	420D-4-1
	420G-4-1
61443-97L01-YAY	420A-4-2
	420D-4-2
	420G-4-2
61443-97L10-QTN	420P-4-2
61443-97L10-YAY	420H-4
	420L-4
	420P-4-1
61453-97L01-Y5S	420A-5-1
	420D-5-1
	420G-5-1
61453-97L01-YAY	420A-5-2
	420D-5-2
	420G-5-2
61453-97L10-QTN	420P-5-2
61453-97L10-YAY	420H-5
	420L-5
	420P-5-1
61458-97J70	420A-6
	420D-6
	420G-6
	420H-6
	420L-6
	420P-6
61472-97L00	167A-12
61494-97L00	167A-13
61611-91J11	412A-13
	412C-12
61619-97L00	412A-19
	412C-22
61622-97L00	420A-2
	420D-2
	420G-2
	420H-2
	420L-2
	420P-2
61626-97L00	412A-14
	412C-13
61640-91J10	412A-15
	412C-14
63111-97L00-QTN	444A-3-3
63111-97L00-Y5S	444A-3-2
63111-97L00-YAY	444A-3-1
63115-97L00	444A-4
63116-97L00	444A-5
63125-97L00	444A-6
63210-94L01	444A-7
63220-97L00	444A-8
63225-93200	444A-9
63228-97L00	444A-10
63240-95L00	444A-11
63241-95L02	444A-12
63610-97L00	444A-13
63610-97L10	514A-3
63615-97L00	444A-21
65000-89L10	583A-1
65110-97L10	432B-2
65112-97L00	432B-3
65113-97L00	432B-4
65136-97L00	432B-5
65281-97L01	432B-6
65284-97L00	432B-7
65510-97L01	432B-8
65520-99100	583A-2
65561-91J01	432B-9
65561-95D00	583A-3
65700-89L32	583A-8
65720-986L0	412C-16
65727-91JL0	412C-17
65740-95D01	583A-7
65750-87J11	583A-9
65750-95501	583A-10
65770-89L00	583A-11
65781-98500	583A-12
65831-95D00	583A-4
65890-99100	583A-5
65892-95D00	583A-6
66100-97L00	432B-16
66121-97L00	432B-17
66122-97L00	432B-18
66142-97L01	432B-19
66160-97L00	432B-20
67101-97L00	514A-1
67110-97L00	514A-4
67112-97L00	514A-5
67200-91J30	508A-1
67212-95600	508A-5
67220-95630	508A-6
67223-99E10	508A-7
67224-96L00	508A-42
67229-95600	508A-8
67232-95600	508A-9
67238-87D00	508A-10
67238-96L00	508A-43
67241-99E11	508A-11
67243-95600	508A-12
67244-95600	508A-13
67245-95600	508A-14
67251-96L00	508A-15
67252-95600	508A-16
67253-95600	508A-17
67255-96L00	508A-18
67256-95600	508A-19
67257-96L00	508A-20
67258-99E00	508A-22
67259-87D00	508A-23
67261-96L00	508A-24
67263-88L30	508A-44
67264-95600	508A-26
67267-96L00	508A-27
67269-96L10	508A-38
67273-95600	508A-28
67275-95600	508A-29
67284-94L10	508A-41
67288-94320	508A-40
67292-94300	508A-30
67294-95600	508A-31
67296-90J20	508A-32
67296-95610	508A-35
67296-95630	508A-34
67296-96L00	508A-33
67296-96L10	508A-25
67297-95600	508A-36
67320-93J00	508A-45-1
67320-93J10	508A-45-2
67320-93J20	508A-45-3
67320-93J30	508A-45-4
67320-93J40	508A-45-5
67412-97L00	514A-6
67415-97L00	514A-7
67416-91J00	514A-8
67447-91J10	514A-9
67447-97L00	514A-10
67448-91J00	514A-11
67449-97L00	514A-13
67460-97L00	514A-14
67466-95200	514A-15
67467-93E01	514A-16
69711-91J11	167A-11
69714-97L00	444A-23
69911-91J50	335A-15
70000	
77811-54GB0-0PG	420A-7
	420D-7
	420G-7
	420H-7
	420L-7
	420P-7
	508A-21
90000	
99000-81157-50M	167A-8
99011-97L61-055	420A-9
	420D-9
	420G-9
	420H-9
	420L-9
	420P-9

PART NO.	FIG.NO.-REF.NO.
00000	
01547-0620C	175A-8
	303A-3
	303B-3
	303C-3
01547-06257	550A-20
01547-0625C	122A-3
01550-06127	550A-21
01550-0612C	167A-10
	303A-18
	303B-18
	303C-18
01550-06167	550A-24
01550-0616C	175A-13
01550-06207	550A-7
01550-0620A	175A-7
01550-0620C	111A-10
	111A-17
01550-0630C	113A-14
	146A-17
	146B-23
01550-0640C	113A-25
02112-0612A	113A-27
02142-06127	113A-28
03542-05169	412A-12
	412C-11
04211-09149	113A-15
04211-11169	111A-7
06111-15004	113A-10
08211-17251	116A-12
08211-25361	116A-8
08310-00067	550A-8
08316-1012A	303A-4
	303B-4
	303C-4
08322-01067	303A-15
	303B-15
	303C-15
08341-31039	303A-5
	303B-5
	303C-5
09100-06176	335A-7
09100-06181	208A-11
09100-08232	508A-37
09100-08314	335A-8
09103-06237	412C-18
09103-06281	407A-6
09103-06521	128A-28
	128B-28
	128C-28
09106-02001	116A-11
09106-05035	412A-16
	412C-15
09108-06146	160A-9
09108-08309	405A-10
09116-06224	336A-12
09116-06225	160A-10
	407A-18
	444A-14
09116-06226	336A-19
09116-06227	208A-10
	412A-8
	412C-8
09116-06229	160A-19
	514A-18
09116-06232	514A-17
09116-06233	405A-5
09116-06234	336A-8
09116-06509	412A-9
	412C-9
09116-06512	432B-10
09116-08156	407A-5
09125-05046	444A-15
09125-05050	432B-21
09125-05143	335A-17
09126-05011	111A-14
09126-06015	444A-16
09140-06020	508A-39
09140-08023-XC0	407A-10
09159-06079	514A-19
09159-08059	335A-10
	514A-20
09160-05501	210A-5
09160-06082	160A-12
	335A-11
	514A-21
09160-06104	514A-22
09160-06173	208A-12
09160-06175	412C-19
09160-08059	335A-12
09160-08082	407A-11
09160-08145	514A-23
09160-10088	230A-6-1
09160-10089	230A-6-2
09160-10090	230A-6-3
09160-10091	230A-6-4
09160-10092	230A-6-5
09163-06001	444A-17
09164-08017	514A-24
09166-12L01	230A-7
09167-23001	407A-13
09168-10022	405A-6
09168-12017	113A-21
09168-16009	113A-7
09169-06092	432B-11
09180-05067	335A-18
09180-06097	514A-25
09180-06371	335A-13
09181-10156	230A-2
09181-12017	230A-12-4
09181-12018	230A-12-5
09181-12022	230A-12-1
09181-12023	230A-12-2
09181-12024	230A-12-3
09181-12111	230A-11
09181-20162	230A-13-1
09181-20164	230A-13-2
09181-20167	230A-13-3
09181-20172	230A-13-4
09181-20176	230A-13-5
09202-04016	230A-16
09202-06023	405A-7
09204-01002	208A-13
	514A-12
09204-03003	407A-24
09205-02004	210A-6
09205-06021	335A-6
09206-11006	405A-11
	407A-8
09248-08001	407A-9
09248-12009	113A-22
09250-10030	412A-10
	412C-10
09250-12016	412A-11
09250-35006	444A-19
09261-04017	116A-23
09262-12001	407A-15
09262-20106	407A-3
09280-05008	210A-7
09280-15007	113A-13
	210A-8
09280-16005	208A-14
09280-27006	146A-8
	146B-11
09280-39002	175A-11
09280-49002	407A-19

PART NO.	FIG.NO.-REF.NO.
09282-10008	160A-17
09282-12L05	407A-14
09283-10009	113A-8
09283-21009	113A-3
09283-25076	113A-9
09289-05006	116A-24
09306-08002	514A-26
09320-04010	405A-8
09320-05019	432B-12
09320-06016	550A-17
09320-08051	432B-13
09320-09507	432B-14
09320-11017	514A-27
09321-08022	113A-23
	432B-15
09343-50L01-040	146A-9
	146A-10
	146B-12
	146B-13
	146B-24
09343-50L01-060	128A-29
	128B-29
	128C-29
09343-50L01-080	146A-11
	146B-14
09343-50L01-110	146B-15
09343-50L01-120	146A-12
	146B-16
09343-50L01-380	146B-17
09343-50L01-550	146A-13
09352-70113-600	111A-4
09367-06002	146B-18
09367-06007	146A-14
	146B-19
09380-10003	230A-4
09381-16001	116A-4
09385-04004	444A-18
09387-52002	113A-24
09401-09404	128A-23
	128B-23
	128C-23
	146A-15
	146B-20
09401-10412	111A-6
09401-11424	146B-21
09403-05312	444A-20
09403-07340	514A-28
09403-09001	146A-16
	146B-22
09407-11401	514A-32
09407-14407	303A-16
	303B-16
	303C-16
	514A-30
	550A-19
09408-00159	303A-14
	303B-14
	303C-14
09420-03002	160A-15
09440-05039	230A-17
09440-10038	175A-12
09440-12027	444A-2
09440-24007	230A-18
09481-20001	550A-5
09482-00L04	111A-11
09491-52L01	128A-3-1
09491-54L01	128A-3-2
09491-64003	128B-3-1
09491-66005	128B-3-2
09491-70018	128C-3-1
09491-72015	128C-3-2
09492-32011	128A-15-1
09492-34004	128A-15-2
09492-35035	128B-15-1
09492-37005	128B-15-2
09492-39003	128C-15-1
09492-41004	128C-15-2
09493-22L01	128C-17
09493-26010	128A-17
09493-30007	128B-17
09493-75001	128B-18
09493-80015	128C-18
09493-85003	128A-18

PART NO.	FIG.NO.-REF.NO.

SUZUKI **DF4A/5A/6A** PARTS CATALOGUE

SUZUKI MOTOR CORPORATION All rights reserved
No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Suzuki Motor Corporation.

SUZUKI MOTOR CORPORATION
Technical Readiness Group, Quality Administration Department
300 Takatsuka, Minami, Hamamatsu, Japan

Copyright © SUZUKI MOTOR CORPORATION 2020 All Rights Reserved

SUZUKI MOTOR CORPORATION

PRINTED IN JAPAN

9900B-45486-000