SUZUKI

PARTS CATALOGUE

DF300AP/250AP

SUZUKI Way of Life!

OUTBOARD MOTOR

020 021 022

E11/E40/E03/E01

2021-5

1ST EDITION

This part catalogue supersedes all the following part catalogue with immediate effect

Model of catalogue	Parts catalogue No.
DF300AP/250AP_021	9900B-45474

PREFACE

When it becomes necessary to replace parts on SUZUKI OUTBOARD MOTORS, always use SUZUKI GENUINE PARTS which have passed a strict inspection which guarantees quality and performance.

This parts catalogue covers the list of all service parts for SUZUKI DF300A/250A production start from 2019 to 2021.

INSTRUCTIONS FOR QUOTING THE CATALOGUE

1. DIMENSIONS

Dimensions of the parts in this catalogue are indicated in unit millimeters.

2. ABBREVIATIONS

Abbreviations used in this catalogue are as follows:

AR	: As required	NT	: Number of teeth
ASSY	: Assembly	OPT	: Optional
E.NO.	: Engine number	OS	: Over size
F.NO.	: Frame number	STD	: Standard
D	: Diameter of material	T	: Thickness
ID	: Inside diameter	US	: Under size
OD	: Outside diameter	W	: Width
L	: Length	W/	: With
LH(PORT)	: Left hand side	L,X,XX	: Transom type
RH(STBD)	: Right hand side	SUS	: Stainless steel
～123456	: Up to E.NO.30002P-123456	PTT	: Power trim and tilt
123456～	: From E.NO.30002P-123456		

12 x 34 x 5.6····· Figures in the description column show the dimensions of parts.
ID OD T(or W,L)

→12345-56781 (Parts No.) : indicates that the parts number was changed to 12345-56781 and the new parts are interchangeable with the former ones but the former ones are not interchangeable with new ones.

←12345-56781 (Parts No.) : indicates that the former and new parts are interchangeable with each other and both are usable.

3. INNER PARTS OF ASSEMBLY

Part name with a dot (.) in front as shown in the description column indicates the component of the assembly also available individually.

4. MODIFICATION NOTICE

A parts bulletin will be sent to you on all occasions when changes in parts occur, including interchangeable modifications between new parts and old ones.

5. NOTE

5-1. There are some different parts from those of production models among spare parts for the administrative reasons and common use of them with other models.

5-2. In respect of rubber hoses and vinyl tubes, please be sure to use them by cutting off according to the length mentioned on parts catalogue or what is actually required on the vehicle.

5-3. Note that the drawings on the illustration page are for ready reference of spare parts number, not to be used as an assembly manual. When assembling, use "SUZUKI SERVICE MANUAL".

6. MODEL NAME AND ENGINE NUMBER

MODEL	DESTINATION	TYPE	TRANSOM	COLOR	ENGINE No.
DF300AP_020	E01,E40	30002P	X,XX	YAY,Y5S	30002P-040001～
DF300AP_020	E03	30002P	L,X,XX	YAY,Y5S	30002P-040001～
DF300AP_021	E11	30002P	L,X,XX	YAY,QTN	30002P-140001～
DF300AP_021	E40	30002P	X,XX	YAY,QTN	30002P-140001～
DF300AP_022	E11	30002P	L,X,XX	YAY,QTN	30002P-240001～
DF300AP_022	E40	30002P	X,XX	YAY,QTN	30002P-240001～
DF250AP_020	E01,E40	25003P	X,XX	YAY,Y5S	25003P-040001～
DF250AP_020	E03	25003P	X,XX	YAY,Y5S	25003P-040001～
DF250AP_021	E11,E40	25003P	X,XX	YAY,QTN	25003P-140001～
DF250AP_022	E11,E40	25003P	X,XX	YAY,QTN	25003P-240001～

PREFACE

Quand il devient nécessarie de remplacer des pièces sur SUZUKI MOTEURS HORSBOARD toujours utiliser les PIECES D'ORIGINE SUZUKI qui ont été soumises à des contriles de qualité sévères leur garantissant qualité et performance impeccables.

Ce catalogue de pièces détachées couvre la liste de toutes les pièces de rechange pour SUZUKI DF300A/250A production start from 2019 to 2021.

INSTRUCTIONS POUR UTILISER LE CATALOGUE

1. DIMENSIONS

Les dimensions des pièces dans ce catalogue sont indiquées en unités de millimètres.

2. ABREVIATIONS

Les abréviations utilisées dans ce catalogue sont les suivantes:

AR	: Comme requis	NT	: Nombre de dents
ASSY	: Assemblage	OPT	: Sur option
E.NO.	: Numéro du moteur	OS	: Sur-dimensionné
F.NO.	: Numéro du chfssis	T	: Epaisseur
ID	: Diamètre intérieur	US	: Sous-dimensionné
OD	: Diamètre extérieur	W	: Largeur
L	: Longueur		
LH(PORT)	: Côté gauche		
RH(STBD)	: Côte droit		
～123456	: Jusqu'à E.NO.30002F-123456		
123456～	: Depuis E.NO.30002F-123456		

12 x 34 x 5.6····· Les chiffres dans la colonne
| | | remarques montrent les dimensions
ID OD T(or W,L) des pieces comme suit.

→12345-56781 (N^{O} de pieces) : indique que le numéro des pièces a été ehangé en 12345-56781 et que les nouvelles pièces sont interchange-ables avec les anciennes, mais que celles-cine sont pas interchangeables avec les nouvelles.

←12345-56781 (N^{O} de pieces) : indique que les anciennes et nouvelles pièces sont interchangeables les unes avec les autres et sont utilisables chacune.

3. PIECES INTERNES DE L'ASSEMBLAGE

Les numéros de pièces qui comportent un point (.) avant la désignation de pièce détachée indique la pièce interne se rapportant à l'assemblage.

4. AVIS DE MODIFICATION

Un bulletin de pièces détachées vous sera envoyé à tout moment opportun quand des changements de pièces ont lieu, y compris les modifications de pièces interchangeables entre les nouvelles et anciennes pièces.

5. A NOTER

5-1. Il existe certaines pièces différentes de celles de rechange pour les modèles de production vu des rainsons administratives et dont l'usage est commun avec celles d'autres modèles.

5-2. Concernant les durites en caoutchouc et les tuyaux en vinyle, ne pas manquer de les couper à la bonne longueur comme indiqué dans le catalogue des pièces détachées ou selon ce qui est utile pour le véhicule affecté.

5-3. Noter que les dessins à la page d'illustration servent à titre de référence pour les numéros de pièces détachées, et non pas comme référence pour l'assemblage. Pour cette dernière opération, se reporter au "MANUEL D'ENTRETIEN SUZUKI".

6. NOM DU MODELE / NUMERO DE SERIE DU MOTEUR

MODELE	DESTINATION	TYPE	HOUTEUR DE BARRE D'ARCASSE	COULEUR	N^{O} DELA MOTEUR
DF300AP_020	E01,E40	30002P	X,XX	YAY,Y5S	30002P-040001～
DF300AP_020	E03	30002P	L,X,XX	YAY,Y5S	30002P-040001～
DF300AP_021	E11	30002P	L,X,XX	YAY,QTN	30002P-140001～
DF300AP_021	E40	30002P	X,XX	YAY,QTN	30002P-140001～
DF300AP_022	E11	30002P	L,X,XX	YAY,QTN	30002P-240001～
DF300AP_022	E40	30002P	X,XX	YAY,QTN	30002P-240001～
DF250AP_020	E01,E40	25003P	X,XX	YAY,Y5S	25003P-040001～
DF250AP_020	E03	25003P	X,XX	YAY,Y5S	25003P-040001～
DF250AP_021	E11,E40	25003P	X,XX	YAY,QTN	25003P-140001～
DF250AP_022	E11,E40	25003P	X,XX	YAY,QTN	25003P-240001～

COLOR CHART
TABLEAU DES COULEURS

COLOR NO. NO DE COULEUR	COLOR DESCRIPTION DESCRIPTION DE COULEUR	COLOR NO. NO DE COULEUR	COLOR DESCRIPTION DESCRIPTION DE COULEUR
QTN	SLD. SUPER COOL WHITE		
YAY	PEARL NEBULAR BLACK		
Y5S	SLD.WHITE		
0PG	CHROME		

COLOR NO. NO DE COULEUR	COLOR DESCRIPTION DESCRIPTION DE COULEUR	COLOR NO. NO DE COULEUR	COLOR DESCRIPTION DESCRIPTION DE COULEUR

MILLIMETER → INCH CONVERSION CHART

	0	1	2	3	4	5	6	7	8	9
00	.000	.039	.079	.118	.157	.197	.236	.276	.315	.354
10	.394	.433	.472	.512	.551	.591	.630	.669	.709	.748
20	.787	.827	.866	.906	.945	.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.535
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.214	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.031	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898


How to read

	0	1	2	3	4
00	…	…	…	…	…
10	…	…	…	…	…
20	…	…	…	0.906	…
30	…	…	…	…	…

23 millimeters equal 0.906 inch


Contents are subject to change without notice or obligation.

FIG. 111A




DF300A_E1_L_032_111A
CYLINDER HEAD

FIG. 113A




DF300A_E1_L_032_113A
CYLINDER BLOCK

FIG. 116A




DF300A_E1_L_032_116A
CRANKSHAFT

FIG. 119A




DF300A_E1_L_032_119A
TIMING CHAIN

FIG. 121A




DF300A_E1_L_032_121A
CAMSHAFT

FIG. 121B




DF300A_E1_L_032_121B
CAMSHAFT

FIG. 121C




DF300A_E1_L_032_121C
CAMSHAFT

FIG. 121D




DF300A_E1_L_032_121D
CAMSHAFT

FIG. 122A




DF300A_E1_000_122A
INTAKE MANIFOLD

FIG. 136A




DF300A_E1_000_136A
RING GEAR COVER

FIG. 140A




DF300A_E1_000_140A
EXHAUST COVER

FIG. 144A




DF300A_E1_000_144A
FUEL INJECTOR

FIG. 144B




DF300A_E1_000_144B
FUEL INJECTOR

FIG. 147A




DF300A_E1_000_147A
FUEL PUMP/FUEL VAPOR SEPARATOR

FIG. 147B




DF300A_E1_000_147B
FUEL PUMP/FUEL VAPOR SEPARATOR

FIG. 147C




DF300A_E1_000_147C
FUEL PUMP/FUEL VAPOR SEPARATOR

FIG.147D




DF300A_E1_L_032_147D
FUEL PUMP/FUEL VAPOR SEPARATOR

FIG.160A




DF300A_E1_L_032_160A
WATER PUMP

FIG.160B




DF300A_E1_L_032_160B
WATER PUMP

FIG.162A




DF300A_E1_L_032_162A
THERMOSTAT

FIG.163A




DF300A_E1_L_032_163A
THROTTLE BODY

FIG.175A




DF300A_E1_L_032_175A
OIL PUMP

FIG.180A




DF300A_E1_L_032_180A
OIL PAN

FIG.204A




DF300A_E1_L_032_204A
CLUTCH/SHAFT

FIG.206A




DF300A_E1_020_206A
CLUTCH(RD)

FIG.206B




DF300A_E1_020_206B
CLUTCH(RD)

FIG.220A




DF300A_E1_020_220A
TRANSMISSION

FIG.220B




DF300A_E1_020_220B
TRANSMISSION

FIG.301A




DF300A_E1_020_301A
STARTING MOTOR

FIG.303A




DF300A_E1_020_303A
MAGNETO

FIG.310A




DF300A_E1_020_310A
RECTIFIER/IGNITION COIL

FIG.315A




DF300A_E1_020_315A
SENSOR

FIG.315B




DF300A_E11_020_315B
SENSOR

FIG.322A




DF300A_E11_020_322A
HARNESS

FIG.326A




DF300A_E11_020_326A
FITSWITCHENGINE CONTROL UNIT

FIG.326B




DF300A_E11_020_326B
FITSWITCHENGINE CONTROL UNIT

FIG.331A




DF300A_E11_020_331A
KEYLESSSTART

FIG.331B




DF300A_E11_020_331B
KEYLESSSTART

FIG.335A




DF300A_E11_020_335A
CLAMPBRACKET

FIG.335B




DF300A_E11_020_335B
CLAMPBRACKET

FIG.336A




DF300A_E1_G03_336A
SWIVEL BRACKET

FIG.336B




DF300A_E1_G03_336B
SWIVEL BRACKET

FIG.337A




DF300A_E1_G03_337A
TRIM CYLINDER

FIG.337B




DF300A_E1_G03_337B
TRIM CYLINDER

FIG.337C




DF300A_E1_G03_337C
TRIM CYLINDER

FIG.340A




DF300A_E1_G03_340A
FITMOTOR

FIG.340B




DF300A_E1_G03_340B
FITMOTOR

FIG.401A




DF300A_E1_G03_401A
ENGINE HOLDER

FIG.405A




DF300A_E1_L_032_405A
DRIVE SHAFT HOUSING

FIG.405B




DF300A_E1_L_032_405B
DRIVE SHAFT HOUSING

FIG.405C




DF300A_E1_L_032_405C
DRIVE SHAFT HOUSING

FIG.407A




DF300A_E1_L_032_407A
GEAR CASE

FIG.407B




DF300A_E1_L_032_407B
GEAR CASE

FIG.410A




DF300A_E1_L_032_410A
SIDE COVER

FIG.410B




DF300A_E1_L_032_410B
SIDE COVER

FIG.420A




DF300A_E1_L_032_420A
ENGINE COVER

FIG.420B




DF300A_E11_020_420B
ENGINE COVER

FIG.420C




DF300A_E11_020_420C
ENGINE COVER

FIG.420D




DF300A_E11_020_420D
ENGINE COVER

FIG.430A




DF300A_E11_020_430A
FUEL HOSE

FIG.475A




DF300A_E11_020_475A
SQUEEZE PUMP

FIG.520A




DF300A_E11_020_520A
OPT:FLUSH MOUNT REMOCON

FIG.520B




DF300A_E11_020_520B
OPT:FLUSH MOUNT REMOCON

FIG.522A




DF300A_E11_020_522A
OPT:HARNESS (1)

FIG.522B




DF300A_E1 I_022_522B
OPT:HARNESS(1)

FIG.523A




DF300A_E1 I_022_523A
OPT:HARNESS(2)

FIG.523B




DF300A_E1 I_022_523B
OPT:HARNESS(2)

FIG.530A




DF300A_E1 I_022_530A
OPT:SWITCH

FIG.530B




DF300A_E1 I_022_530B
OPT:SWITCH

FIG.535A




DF300A_E1 I_022_535A
OPT:KEY LESS START

FIG.535B




DF300A_E1 I_022_535B
OPT:KEY LESS START

FIG.540A




DF300A_E1 I_022_540A
OPT:REMOTE CONTROL ASSY,DUAL

FIG.540B




DF300A_E1_L_020_540B
OPT:REMOTE CONTROL ASSY,DUAL

FIG.543A




DF300A_E1_L_020_543A
OPT:REMOTE CONTROL ASSY,SINGLE

FIG.543B




DF300A_E1_L_020_543B
OPT:REMOTE CONTROL ASSY,SINGLE

FIG.585A




DF300A_E1_L_020_585A
OPT:GASKET SET

FIG.601A




DF300A_E1_L_020_601A
OPT:MULTI FUNCTION GAUGE (1)

FIG.601B




DF300A_E1_L_020_601B
OPT:MULTI FUNCTION GAUGE (1)

FIG.602A



DF300A_E1_L_020_602A
OPT:MULTI FUNCTION GAUGE (2)

FIG.602B



DF300A_E1_L_020_602B
OPT:MULTI FUNCTION GAUGE (2)

FIG.111A




FIG.111A (1-B-2) CYLINDER HEAD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	11101-98J04	HEAD ASSY,CYLINDER STBD	1	020,021 STBD
1-2	11101-98J10	HEAD ASSY,CYLINDER STBD	1	022 STBD
2-1	11128-90J00	.BOLT,CAMSHAFT HOUSING (6X39)	16	020,021
2-2	09103-06266	.BOLT (6X40)	16	022
3	09206-08001	.PIN (8X11)	14	
4	01550-06207	.BOLT (6X20)	4	
5-1	11103-98J04	HEAD ASSY,CYLINDER PORT	1	020,021 PORT
5-2	11103-98J10	HEAD ASSY,CYLINDER PORT	1	022 PORT
6-1	11128-90J00	.BOLT,CAMSHAFT HOUSING (6X39)	16	020,021
6-2	09103-06266	.BOLT (6X40)	16	022
7	09206-08001	.PIN (8X11)	14	
8	01550-06207	.BOLT (6X20)	2	
9	11116-93J01	PLUG	4	
10	11141-98J10	GASKET,CYLINDER HEAD STBD	1	STBD
11	11142-98J10	GASKET,CYLINDER HEAD PORT	1	PORT
12	11216-98L10	GASKET	4	
13	11261-93J00	COVER,PROTECTION ANODE	4	
14	09280-22019	O RING (D:1.9,ID:21.8)	4	
15	55321-87J01	ANODE,PROTECTION	4	
16	09103-06281	BOLT (6X14)	4	
17-1	01550-08207	BOLT	4	020,021
17-2	01550-0820C	BOLT (8X20)	4	022
18	01550-08607	BOLT	5	
19	01550-08607	BOLT	4	
20	09206-14004	PIN (14X11.4X23)	4	
21	11170-93J01	COVER,CYLINDER HEAD STBD	1	STBD
22	11180-98J01	COVER,CYLINDER HEAD PORT	1	PORT
23	11173-93J00	PLATE,BREATHER STBD	1	STBD
24	11183-93J00	PLATE,BREATHER PORT	1	PORT
25	11179-93J00	GASKET,CYL HEAD COVER STBD	1	STBD
26	11189-93J00	GASKET,CYL HEAD COVER PORT	1	PORT

FIG.111A




FIG.111A (1-B-3) CYLINDER HEAD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
27	09206-08001	PIN (8X11)	1	
28	02112-0612A	SCREW	14	
29-1	01547-06257	BOLT	16	020,021
29-2	01547-0625C	BOLT	16	022
30-1	01547-06507	BOLT (6X50)	6	020,021
30-2	01547-0650C	BOLT	6	022
31	11382-93J00	CAP,OIL FILLER	1	
32	09280-26006	O RING (D:3.1,ID:26.4)	1	
33	09482-00427	SPARK PLUG,NGK BKR6E (BKR6E)	6	NGK
34	11291-93J00	HOOK,ENGINE	2	
35-1	01550-08207	BOLT	4	020,021
35-2	01550-0820C	BOLT (8X20)	4	022
36	11115-93J10-001	GUIDE,VALVE OS (OS)	24	OPT
37	11291-98J00	HOOK,ENGINE	1	OPT

FIG.113A




FIG.113A (1-B-4) CYLINDER BLOCK

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11293-98J00	HOOK,ENGINE FRONT	1	
2-1	01550-08207	BOLT	2	020,021
2-2	01550-0820C	BOLT (8X20)	2	022
3	11301-98J40	BLOCK SET,CYLINDER	1	
4	11112-93J00	.PLUG,OIL VENTURI	2	
5	11117-93J10	.BOLT,CRANKCASE	12	
6	11117-98J10	.BOLT,CRANKCASE STUD	4	
7	11119-93J00	.BOLT,CYLINDER HEAD	16	
8	11216-98L00	.GASKET,M26 PLUG	3	
9	09248-26001	.PLUG (M26)	3	
10	09160-18031	.WASHER (18.5X28X2.6)	2	
11	09248-18006	.PLUG (18X8)	2	
12	09159-10116	.NUT (M10)	4	
13	09206-13019	.PIN (10.4X13X16)	5	
14	16700-93J00	.VALVE,PISTON JET	1	
15	09280-10009	..O-RING (D:1.3,ID:9.8)	1	
16	09280-10015	..O-RING (D:1.9,ID:9.8)	1	
17	07130-0616A	.BOLT	1	
18	07130-0510A	.BOLT	6	
19	11390-98J00	.JET,PISTON COOLING	6	
20	09280-06005	..O-RING (D:1.9,ID:5.7)	6	
21	09246-04009	.PLUG (1/8PT,H:8)	1	
22	11330-93J01	COVER,CRANKCASE WTR JKT	1	
23	11332-93J00	GASKET,CRANKCASE WTR JKT COVER	1	
24-1	01550-06207	BOLT (6X20)	12	020,021
24-2	01550-0620C	BOLT (6X20)	12	022
25	16430-93J00	COVER,OIL GALLERY	1	
26	16431-93J00	PLATE,OIL GALLERY	1	
27	16433-93J00	GASKET,OIL GALLERY	2	
28	01550-0835A	BOLT (8X35)	9	
29-1	01550-08457	BOLT (8X45)	8	020,021
29-2	01550-0845C	BOLT	8	022
30	16510-96J10	FILTER ASSY,OIL	1	

FIG.116A




FIG.116A (1-B-5) CRANKSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12111-98J00-0B0	PISTON	6	
2	12140-98J00	RING SET,PISTON	6	
3	12151-02F00	PIN,PISTON	6	
4	09381-22010	CIRCLIP	12	
5	12160-98J00	CONNROD ASSY	6	
6-1	12100-98810-0A0	BEARING SET,CONNROD (STD)	6	GREEN
6-2	12100-98810-025	BEARING SET,CONNROD US (US:0.25)	6	OPT
7	12220-98J00	CRANKSHAFT	1	
8-1	12340-98J00-0A0	BEARING SUB SET,CRANKSHAFT (STD)	4	BLACK
8-2	12340-98J00-0B0	BEARING SUB SET,CRANKSHAFT (STD)	4	NON
8-3	12340-98J00-0C0	BEARING SUB SET,CRANKSHAFT (STD)	4	YELLOW
8-4	12340-98J00-0D0	BEARING SUB SET,CRANKSHAFT (STD)	4	BLUE
8-5	12340-98J00-0E0	BEARING SUB SET,CRANKSHAFT (STD)	4	PINK
8-6	12300-98810-0AA	BEARING SET,CSHAFT US (US:0.25)	4	OPT,RED/BLACK
8-7	12300-98810-0BA	BEARING SET,CSHAFT US (US:0.25)	4	OPT,RED
8-8	12300-98810-0CA	BEARING SET,CSHAFT US (US:0.25)	4	OPT,RED/YELLOW
8-9	12300-98810-0DA	BEARING SET,CSHAFT US (US:0.25)	4	OPT,RED/BLUE
8-10	12300-98810-0EA	BEARING SET,CSHAFT US (US:0.25)	4	OPT,RED/PINK
9-1	12300-98821	BEARING SET,CRANK THRUST (STD)	1	
9-2	12300-98821-012	BEARING SET,CRANK THRUST (OS:0.12)	1	OPT
10	12242-98J00	GEAR,DRIVE (NT:32)	1	
11	09160-10104	WASHER (10.5X50X3.2)	1	
12	01550-1025A	BOLT	1	

FIG.116A




FIG.116A (1-B-6) CRANKSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
13	09283-91001	SEAL,OIL (91X109X10)	1	
14	12100-98J00-050	PISTON SET,OS (OS:0.50)	6	OPT
15	12140-98J00-050	.RING SET,PISTON OS (OS:0.50)	6	OPT

FIG.119A




FIG.119A (1-B-7) TIMING CHAIN

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12730-98J02	GEAR,DRIVEN (NT:40)	1	
2	09262-40021	BEARING (40X80X18)	1	LOWER
3	09262-40017	BEARING (40X80X18)	1	UPPER
4	09283-32044	OIL SEAL (32X47X6)	1	
5	12734-93J00	HOLDER,DRIVEN GEAR	1	
6	09280-70012	O-RING (D:5.7,ID:69.6)	1	
7	01550-0855A	BOLT	4	
8	12761-93J00	CHAIN,TIMING 1ST	1	
9	12762-93J00	CHAIN,TIMING 2ND	2	
10	12770-93J00	BASE,T/C GUIDE NO.1	1	
11	12778-93J00	GASKET,TIMING CHAIN GUIDE BASE	1	
12	04211-13149	PIN (13X14)	2	
13	01550-0830A	BOLT (8X30)	2	
14	12771-93J00	SHOE,TIMING CHAIN UPPER	1	
15	12775-93J00	SHOE,TIMING CHAIN LOWER	1	
16	12772-93J00	GUIDE,TIMING CHAIN NO.2	1	
17	01550-0830A	BOLT (8X30)	2	
18	12810-93J00	TENSIONER ASSY,TIMING CHAIN	1	
19	12813-73G00	.PAD,TIMING CHAIN TENSIONER	1	
20	12812-90J00	SPACER,TIMING CHAIN TENSIONER	1	
21	01550-0830A	BOLT (8X30)	1	
22	12831-93J01	ADJUSTER ASSY,TENSIONER NO.1	1	
23	12832-93J00	TENSIONER ASSY,STBD	1	STBD
24	12833-93J00	TENSIONER ASSY,PORT	1	PORT
25	01550-0620A	BOLT	2	
26	01550-0620A	BOLT	4	

DF300A_E11_022_119A
TIMING CHAIN

FIG.121A




FIG.121A (1-B-8) CAMSHAFT (DF300A:(020,021))

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12701-98J10	CAMSHAFT,INTK STBD	1	STBD
2	12705-98J10	CAMSHAFT,INTK PORT	1	PORT
3	12721-98J10	CAMSHAFT,EXH STBD	1	STBD
4	12729-98J20	CAMSHAFT,EXH PORT	1	PORT
5	12740-93J00	SPROCKET ASSY,CAM TIMING (NT:22/32)	2	
6	12748-93J00	SPROCKET,CAMSHAFT (NT:22)	2	
7	12753-93J00	BOLT,INTK CAMSHAFT	2	
8	12749-93J00	BOLT,CAMSHAFT	2	
9	09202-05032	PIN (5X12)	3	
10	09261-05006	PIN (5X18)	1	
11	16550-93J00	VALVE,OIL CONTROL	2	
12	16555-93J01	GASKET,OCV	2	
13	01550-06257	BOLT (6X25)	8	
14	12891-93J00	TAPPET	24	
15-1	12892-93J00-218	SHIM,TAPPET (T:2.175)	AR	
15-2	12892-93J00-220	SHIM,TAPPET (T:2.200)	AR	
15-3	12892-93J00-223	SHIM,TAPPET (T:2.225)	AR	
15-4	12892-93J00-225	SHIM,TAPPET (T:2.250)	AR	
15-5	12892-93J00-228	SHIM,TAPPET (T:2.275)	AR	
15-6	12892-93J00-230	SHIM,TAPPET (T:2.300)	AR	
15-7	12892-93J00-233	SHIM,TAPPET (T:2.325)	AR	
15-8	12892-93J00-235	SHIM,TAPPET (T:2.350)	AR	
15-9	12892-93J00-238	SHIM,TAPPET (T:2.375)	AR	
15-10	12892-93J00-240	SHIM,TAPPET (T:2.400)	AR	
15-11	12892-93J00-243	SHIM,TAPPET (T:2.425)	AR	
15-12	12892-93J00-245	SHIM,TAPPET (T:2.450)	AR	
15-13	12892-93J00-248	SHIM,TAPPET (T:2.475)	AR	
15-14	12892-93J00-250	SHIM,TAPPET (T:2.500)	AR	
15-15	12892-93J00-253	SHIM,TAPPET (T:2.525)	AR	
15-16	12892-93J00-255	SHIM,TAPPET (T:2.550)	AR	
15-17	12892-93J00-258	SHIM,TAPPET (T:2.575)	AR	
15-18	12892-93J00-260	SHIM,TAPPET (T:2.600)	AR	
15-19	12892-93J00-263	SHIM,TAPPET (T:2.625)	AR	
15-20	12892-93J00-265	SHIM,TAPPET (T:2.650)	AR	

FIG.121A




FIG.121A (1-B-9) CAMSHAFT (DF300A:(020,021))

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
15-21	12892-93J00-268	SHIM,TAPPET (T:2.675)	AR	
15-22	12892-93J00-270	SHIM,TAPPET (T:2.700)	AR	
15-23	12892-93J00-273	SHIM,TAPPET (T:2.725)	AR	
15-24	12892-93J00-275	SHIM,TAPPET (T:2.750)	AR	
15-25	12892-93J00-278	SHIM,TAPPET (T:2.775)	AR	
15-26	12892-93J00-280	SHIM,TAPPET (T:2.800)	AR	
15-27	12892-93J00-283	SHIM,TAPPET (T:2.825)	AR	
15-28	12892-93J00-285	SHIM,TAPPET (T:2.850)	AR	
15-29	12892-93J00-288	SHIM,TAPPET (T:2.875)	AR	
15-30	12892-93J00-290	SHIM,TAPPET (T:2.900)	AR	
15-31	12892-93J00-293	SHIM,TAPPET (T:2.925)	AR	
15-32	12892-93J00-295	SHIM,TAPPET (T:2.950)	AR	
15-33	12892-93J00-298	SHIM,TAPPET (T:2.975)	AR	
15-34	12892-93J00-300	SHIM,TAPPET (T:3.000)	AR	
16	12911-98J00	VALVE,INTK	12	
17	12915-93J60	VALVE,EXHAUST	12	
18	12921-93J11	SPRING,VALVE	24	
19	12931-78G00	RETAINER,VALVE SPRING	24	
20	12932-24400	COTTER,VALVE	48	
21	12933-69G10	SEAT,VALVE SPRING	24	
22	09289-05012	SEAL,OIL (5.5X11.5X9.3)	24	

FIG.121B




FIG.121B (1-B-10) CAMSHAFT (DF300A:022)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12701-98J10	CAMSHAFT,INTK STBD	1	STBD
2	12705-98J10	CAMSHAFT,INTK PORT	1	PORT
3	12721-98J10	CAMSHAFT,EXH STBD	1	STBD
4	12729-98J20	CAMSHAFT,EXH PORT	1	PORT
5	12740-93J00	SPROCKET ASSY,CAM TIMING (NT:22/32)	2	
6	12748-93J00	SPROCKET,CAMSHAFT (NT:22)	2	
7	12753-93J00	BOLT,INTK CAMSHAFT	2	
8	12749-93J00	BOLT,CAMSHAFT	2	
9	09202-05032	PIN (5X12)	3	
10	09261-05006	PIN (5X18)	1	
11	16550-93J00	VALVE,OIL CONTROL	2	
12	16555-93J01	GASKET,OCV	2	
13	01550-0625C	BOLT (6X25)	8	
14	12891-93J10	TAPPET	24	
15-1	12892-93J10-218	SHIM,TAPPET (T:2.175)	AR	
15-2	12892-93J10-220	SHIM,TAPPET (T:2.200)	AR	
15-3	12892-93J10-223	SHIM,TAPPET (T:2.225)	AR	
15-4	12892-93J10-225	SHIM,TAPPET (T:2.250)	AR	
15-5	12892-93J10-228	SHIM,TAPPET (T:2.275)	AR	
15-6	12892-93J10-230	SHIM,TAPPET (T:2.300)	AR	
15-7	12892-93J10-233	SHIM,TAPPET (T:2.325)	AR	
15-8	12892-93J10-235	SHIM,TAPPET (T:2.350)	AR	
15-9	12892-93J10-238	SHIM,TAPPET (T:2.375)	AR	
15-10	12892-93J10-240	SHIM,TAPPET (T:2.400)	AR	
15-11	12892-93J10-243	SHIM,TAPPET (T:2.425)	AR	
15-12	12892-93J10-245	SHIM,TAPPET (T:2.450)	AR	
15-13	12892-93J10-248	SHIM,TAPPET (T:2.475)	AR	
15-14	12892-93J10-250	SHIM,TAPPET (T:2.500)	AR	
15-15	12892-93J10-253	SHIM,TAPPET (T:2.525)	AR	
15-16	12892-93J10-255	SHIM,TAPPET (T:2.550)	AR	
15-17	12892-93J10-258	SHIM,TAPPET (T:2.575)	AR	
15-18	12892-93J10-260	SHIM,TAPPET (T:2.600)	AR	
15-19	12892-93J10-263	SHIM,TAPPET (T:2.625)	AR	
15-20	12892-93J10-265	SHIM,TAPPET (T:2.650)	AR	

FIG.121B




FIG.121B (1-B-11) CAMSHAFT (DF300A:022)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
15-21	12892-93J10-268	SHIM,TAPPET (T:2.675)	AR	
15-22	12892-93J10-270	SHIM,TAPPET (T:2.700)	AR	
15-23	12892-93J10-273	SHIM,TAPPET (T:2.725)	AR	
15-24	12892-93J10-275	SHIM,TAPPET (T:2.750)	AR	
15-25	12892-93J10-278	SHIM,TAPPET (T:2.775)	AR	
15-26	12892-93J10-280	SHIM,TAPPET (T:2.800)	AR	
15-27	12892-93J10-283	SHIM,TAPPET (T:2.825)	AR	
15-28	12892-93J10-285	SHIM,TAPPET (T:2.850)	AR	
15-29	12892-93J10-288	SHIM,TAPPET (T:2.875)	AR	
15-30	12892-93J10-290	SHIM,TAPPET (T:2.900)	AR	
15-31	12892-93J10-293	SHIM,TAPPET (T:2.925)	AR	
15-32	12892-93J10-295	SHIM,TAPPET (T:2.950)	AR	
15-33	12892-93J10-298	SHIM,TAPPET (T:2.975)	AR	
15-34	12892-93J10-300	SHIM,TAPPET (T:3.000)	AR	
16	12911-98J00	VALVE,INTK	12	
17	12915-93J60	VALVE,EXHAUST	12	
18	12921-93J11	SPRING,VALVE	24	
19	12931-78G00	RETAINER,VALVE SPRING	24	
20	12932-24400	COTTER,VALVE	48	
21	12933-69G10	SEAT,VALVE SPRING	24	
22	09289-05012	SEAL,OIL (5.5X11.5X9.3)	24	

FIG.121C




FIG.121C (1-B-12) CAMSHAFT (DF250A:(020,021))

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12701-98J20	CAMSHAFT,INTK STBD	1	STBD
2	12705-98J10	CAMSHAFT,INTK PORT	1	PORT
3	12721-98J10	CAMSHAFT,EXH STBD	1	STBD
4	12729-98J20	CAMSHAFT,EXH PORT	1	PORT
5	12740-93J00	SPROCKET ASSY,CAM TIMING (NT:22/32)	2	
6	12748-93J00	SPROCKET,CAMSHAFT (NT:22)	2	
7	12753-93J00	BOLT,INTK CAMSHAFT	2	
8	12749-93J00	BOLT,CAMSHAFT	2	
9	09202-05032	PIN (5X12)	3	
10	09261-05006	PIN (5X18)	1	
11	16550-93J00	VALVE,OIL CONTROL	2	
12	16555-93J01	GASKET,OCV	2	
13	01550-06257	BOLT (6X25)	8	
14	12891-93J00	TAPPET	24	
15-1	12892-93J00-218	SHIM,TAPPET (T:2.175)	AR	
15-2	12892-93J00-220	SHIM,TAPPET (T:2.200)	AR	
15-3	12892-93J00-223	SHIM,TAPPET (T:2.225)	AR	
15-4	12892-93J00-225	SHIM,TAPPET (T:2.250)	AR	
15-5	12892-93J00-228	SHIM,TAPPET (T:2.275)	AR	
15-6	12892-93J00-230	SHIM,TAPPET (T:2.300)	AR	
15-7	12892-93J00-233	SHIM,TAPPET (T:2.325)	AR	
15-8	12892-93J00-235	SHIM,TAPPET (T:2.350)	AR	
15-9	12892-93J00-238	SHIM,TAPPET (T:2.375)	AR	
15-10	12892-93J00-240	SHIM,TAPPET (T:2.400)	AR	
15-11	12892-93J00-243	SHIM,TAPPET (T:2.425)	AR	
15-12	12892-93J00-245	SHIM,TAPPET (T:2.450)	AR	
15-13	12892-93J00-248	SHIM,TAPPET (T:2.475)	AR	
15-14	12892-93J00-250	SHIM,TAPPET (T:2.500)	AR	
15-15	12892-93J00-253	SHIM,TAPPET (T:2.525)	AR	
15-16	12892-93J00-255	SHIM,TAPPET (T:2.550)	AR	
15-17	12892-93J00-258	SHIM,TAPPET (T:2.575)	AR	
15-18	12892-93J00-260	SHIM,TAPPET (T:2.600)	AR	
15-19	12892-93J00-263	SHIM,TAPPET (T:2.625)	AR	
15-20	12892-93J00-265	SHIM,TAPPET (T:2.650)	AR	

FIG.121C




FIG.121C (1-B-13) CAMSHAFT (DF250A:(020,021))

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
15-21	12892-93J00-268	SHIM,TAPPET (T:2.675)	AR	
15-22	12892-93J00-270	SHIM,TAPPET (T:2.700)	AR	
15-23	12892-93J00-273	SHIM,TAPPET (T:2.725)	AR	
15-24	12892-93J00-275	SHIM,TAPPET (T:2.750)	AR	
15-25	12892-93J00-278	SHIM,TAPPET (T:2.775)	AR	
15-26	12892-93J00-280	SHIM,TAPPET (T:2.800)	AR	
15-27	12892-93J00-283	SHIM,TAPPET (T:2.825)	AR	
15-28	12892-93J00-285	SHIM,TAPPET (T:2.850)	AR	
15-29	12892-93J00-288	SHIM,TAPPET (T:2.875)	AR	
15-30	12892-93J00-290	SHIM,TAPPET (T:2.900)	AR	
15-31	12892-93J00-293	SHIM,TAPPET (T:2.925)	AR	
15-32	12892-93J00-295	SHIM,TAPPET (T:2.950)	AR	
15-33	12892-93J00-298	SHIM,TAPPET (T:2.975)	AR	
15-34	12892-93J00-300	SHIM,TAPPET (T:3.000)	AR	
16	12911-98J00	VALVE,INTK	12	
17	12915-93J60	VALVE,EXHAUST	12	
18	12921-93J11	SPRING,VALVE	24	
19	12931-78G00	RETAINER,VALVE SPRING	24	
20	12932-24400	COTTER,VALVE	48	
21	12933-69G10	SEAT,VALVE SPRING	24	
22	09289-05012	SEAL,OIL (5.5X11.5X9.3)	24	

FIG.121D




FIG.121D (1-B-14) CAMSHAFT (DF250A:022)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12701-98J20	CAMSHAFT,INTK STBD	1	STBD
2	12705-98J10	CAMSHAFT,INTK PORT	1	PORT
3	12721-98J10	CAMSHAFT,EXH STBD	1	STBD
4	12729-98J20	CAMSHAFT,EXH PORT	1	PORT
5	12740-93J00	SPROCKET ASSY,CAM TIMING (NT:22/32)	2	
6	12748-93J00	SPROCKET,CAMSHAFT (NT:22)	2	
7	12753-93J00	BOLT,INTK CAMSHAFT	2	
8	12749-93J00	BOLT,CAMSHAFT	2	
9	09202-05032	PIN (5X12)	3	
10	09261-05006	PIN (5X18)	1	
11	16550-93J00	VALVE,OIL CONTROL	2	
12	16555-93J01	GASKET,OCV	2	
13	01550-0625C	BOLT (6X25)	8	
14	12891-93J10	TAPPET	24	
15-1	12892-93J10-218	SHIM,TAPPET (T:2.175)	AR	
15-2	12892-93J10-220	SHIM,TAPPET (T:2.200)	AR	
15-3	12892-93J10-223	SHIM,TAPPET (T:2.225)	AR	
15-4	12892-93J10-225	SHIM,TAPPET (T:2.250)	AR	
15-5	12892-93J10-228	SHIM,TAPPET (T:2.275)	AR	
15-6	12892-93J10-230	SHIM,TAPPET (T:2.300)	AR	
15-7	12892-93J10-233	SHIM,TAPPET (T:2.325)	AR	
15-8	12892-93J10-235	SHIM,TAPPET (T:2.350)	AR	
15-9	12892-93J10-238	SHIM,TAPPET (T:2.375)	AR	
15-10	12892-93J10-240	SHIM,TAPPET (T:2.400)	AR	
15-11	12892-93J10-243	SHIM,TAPPET (T:2.425)	AR	
15-12	12892-93J10-245	SHIM,TAPPET (T:2.450)	AR	
15-13	12892-93J10-248	SHIM,TAPPET (T:2.475)	AR	
15-14	12892-93J10-250	SHIM,TAPPET (T:2.500)	AR	
15-15	12892-93J10-253	SHIM,TAPPET (T:2.525)	AR	
15-16	12892-93J10-255	SHIM,TAPPET (T:2.550)	AR	
15-17	12892-93J10-258	SHIM,TAPPET (T:2.575)	AR	
15-18	12892-93J10-260	SHIM,TAPPET (T:2.600)	AR	
15-19	12892-93J10-263	SHIM,TAPPET (T:2.625)	AR	
15-20	12892-93J10-265	SHIM,TAPPET (T:2.650)	AR	

FIG.121D




FIG.121D (1-B-15) CAMSHAFT (DF250A:022)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
15-21	12892-93J10-268	SHIM,TAPPET (T:2.675)	AR	
15-22	12892-93J10-270	SHIM,TAPPET (T:2.700)	AR	
15-23	12892-93J10-273	SHIM,TAPPET (T:2.725)	AR	
15-24	12892-93J10-275	SHIM,TAPPET (T:2.750)	AR	
15-25	12892-93J10-278	SHIM,TAPPET (T:2.775)	AR	
15-26	12892-93J10-280	SHIM,TAPPET (T:2.800)	AR	
15-27	12892-93J10-283	SHIM,TAPPET (T:2.825)	AR	
15-28	12892-93J10-285	SHIM,TAPPET (T:2.850)	AR	
15-29	12892-93J10-288	SHIM,TAPPET (T:2.875)	AR	
15-30	12892-93J10-290	SHIM,TAPPET (T:2.900)	AR	
15-31	12892-93J10-293	SHIM,TAPPET (T:2.925)	AR	
15-32	12892-93J10-295	SHIM,TAPPET (T:2.950)	AR	
15-33	12892-93J10-298	SHIM,TAPPET (T:2.975)	AR	
15-34	12892-93J10-300	SHIM,TAPPET (T:3.000)	AR	
16	12911-98J00	VALVE,INTK	12	
17	12915-93J60	VALVE,EXHAUST	12	
18	12921-93J11	SPRING,VALVE	24	
19	12931-78G00	RETAINER,VALVE SPRING	24	
20	12932-24400	COTTER,VALVE	48	
21	12933-69G10	SEAT,VALVE SPRING	24	
22	09289-05012	SEAL,OIL (5.5X11.5X9.3)	24	

FIG.122A




FIG.122A (1-B-16) INTAKE MANIFOLD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13110-98J10	MANIFOLD,INTAKE	1	
2	13119-98J00	GASKET,INTAKE MANIFOLD	2	
3	09108-08282	BOLT,STUD	4	
4	09103-08437	BOLT (8X65)	4	
5	09159-08136	NUT (M8)	4	
6	09160-08161	WASHER (8.2X23X3.2)	8	

FIG.136A




FIG.136A (1-C-2) RING GEAR COVER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11510-98J03	COVER,RING GEAR	1	
2	11174-98J01	.HOSE,BREATHER	1	
3	11176-98J00	.UNION,BREATHER	1	
4	11514-98J00	.PLATE,RING GEAR COVER	1	
5	13710-98J00	.ARRESTER,FLAME	1	
6	13811-98J00	.SILENCER,UPPER COVER	1	
7	09401-18410	.CLIP	2	
8	01550-06127	.BOLT	4	
9	01550-06207	.BOLT (6X20)	5	
10	11517-98J00	.SCREW	3	
11	11515-93J00	BRACE,RING GEAR COVER	1	
12	13841-98J10	GUARD,AIR DUCT STBD	1	STBD
13	13851-98J10	GUARD,AIR DUCT PORT	1	PORT
14-1	01550-06207	BOLT (6X20)	4	020,021
14-2	01550-0620C	BOLT (6X20)	4	022
15-1	01550-06207	BOLT (6X20)	2	020,021
15-2	01550-0620C	BOLT (6X20)	2	022
16-1	01550-06407	BOLT (6X40)	1	020,021
16-2	01550-0640C	BOLT	1	022
17-1	01550-08357	BOLT	2	020,021
17-2	01550-0835C	BOLT	2	022
18	69711-93E11	LABEL,S.I.G.P (S.I.G.P.)	1	
19	61494-93J01	LABEL,OIL & CLEARANCE	1	

DF300A_E11_022_136A
RING GEAR COVER

FIG.140A




FIG.140A (1-C-3) EXHAUST COVER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	14141-93J01	COVER,EXHAUST STBD	1	STBD
2	14140-98J01	COVER,EXHAUST PORT	1	PORT
3	14151-93J00	GASKET,EXH COVER STBD	1	STBD
4	14152-93J00	GASKET,EXH COVER PORT	1	PORT
5	11261-93J00	COVER,PROTECTION ANODE	2	
6	55321-87J01	ANODE,PROTECTION	2	
7	09103-06281	BOLT (6X14)	2	
8	09280-22019	O RING (D:1.9,ID:21.8)	2	
9-1	01550-08207	BOLT	2	020,021
9-2	01550-0820C	BOLT (8X20)	2	022
10	01550-06257	BOLT (6X25)	23	

FIG.144A




FIG.144A (1-C-4) FUEL INJECTOR (E01,E03,E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15681-93J02	HOSE,FUEL	1	
2	15710-96J00	INJECTOR ASSY,FUEL	6	
3	15717-16G00	.O RING	6	
4	15735-58B00	INSULATOR,DELIVERY PIPE	4	
5	15751-93J00	PIPE,DELIVERY	2	
6	15756-93J02	HOSE,FUEL	1	
7	15762-93J00	GASKET,DELIVERY PIPE	5	
8	15830-77EA0	JOINT,FUEL MAIN	1	
9	15831-93J00	UNION,DELIVERY PIPE	2	
10	18498-93J01	PROTECTOR,FUEL HOSE (L:340)	1	
11	09247-14041	PLUG (14X14)	1	
12	09320-08062	CUSHION (8.7X16.3X5.5)	6	
13	09360-14009	UNION (14X27)	1	
14	09401-11425	CLIP	4	
15	09403-16307	CLAMP	1	
16	09408-00105	CLAMP (ID:17.5,ID:11.5)	1	
17	09408-00155	CLAMP	1	
18-1	01550-08407	BOLT	4	(E01,E03):020,E11:021
18-2	01550-0840C	BOLT	4	E11:022
19	15680-93J40	HOSE,FUEL INLET	1	
20	09401-14409	CLIP	1	
21	09408-00135	CLIP	2	
22	15684-98J00	GUIDE,FUEL HOSE	1	
23-1	01550-06127	BOLT	2	(E01,E03):020,E11:021
23-2	01550-0612C	BOLT (6X12)	2	E11:022
24	09251-09009	PLUG (OD:13.6)	1	

DF300A_E11_022_144A
FUELINJECTOR

FIG.144B




FIG.144B (1-C-5) FUEL INJECTOR (E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15681-93J02	HOSE,FUEL	1	
2	15710-96J00	INJECTOR ASSY,FUEL	6	
3	15717-16G00	.O RING	6	
4	15735-58B00	INSULATOR,DELIVERY PIPE	4	
5	15751-93J00	PIPE,DELIVERY	2	
6	15756-93J02	HOSE,FUEL	1	
7	15762-93J10	GASKET,DELIVERY PIPE	5	
8	15832-93J00	UNION,DELIVERY PIPE	1	
9	15831-93J00	UNION,DELIVERY PIPE	2	
10	18498-93J01	PROTECTOR,FUEL HOSE (L:340)	1	
11	09247-14042	PLUG (14X14)	1	
12	09320-08062	CUSHION (8.7X16.3X5.5)	6	
13	09360-14014	UNION	1	
14	09401-11425	CLIP	4	
15	09403-16307	CLAMP	1	
16	09408-00105	CLAMP (ID:17.5,ID:11.5)	1	
17	09408-00155	CLAMP	1	
18-1	01550-08407	BOLT	4	020,021
18-2	01550-0840C	BOLT	4	022
19	15680-93J40	HOSE,FUEL INLET	1	
20	09401-14409	CLIP	1	
21	09408-00135	CLIP	2	
22	15684-98J00	GUIDE,FUEL HOSE	1	
23-1	01550-06127	BOLT	2	020,021
23-2	01550-0612C	BOLT (6X12)	2	022
24	09251-09009	PLUG (OD:13.6)	1	

DF300A_E11_022_144B
FUELINJECTOR

FIG.147A




FIG.147A (1-C-6) FUEL PUMP/FUEL VAPOR SEPARATOR ((020,021):(E01,E03,E11))

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15100-98J00	PUMP ASSY,FUEL	1	
2	15410-93J11	FILTER,FUEL	1	
3	15411-93J10	.CAP,FUEL FILTER	1	
4	15415-93J10	.SEAL,FUEL FILTER NO.1	1	
5	15412-93J10	.FILTER ASSY,FUEL	1	
6	15413-93J10	.CASE ASSY,FUEL FILTER	1	
7	15644-93J00	COVER,FUEL FILTER	1	
8	15633-93J20	HOSE,FUEL	1	
9	09343-75002-600	HOSE (7.5X13.5X600)	1	L:600->65
10	15440-93J00	FILTER,FUEL	1	
11	09320-08501	CUSHION (8X18X10)	2	
12	15773-90J10	UNION,FUEL HOSE	1	
13	15830-93J00	UNION,THREE WAY FUEL HOSE	1	
14	09169-06093	WASHER	3	
15	15770-93J00	COOLER,FUEL	1	
16	09168-12013	GASKET (11.8X22X1.2)	3	
17	09360-12008	UNION (12X27)	1	
18	09363-08004	UNION	1	
19	15600-98J21	SEPARATOR ASSY,FUEL VAPOR	1	
20	13370-93J00	.VALVE ASSY,NEEDLE	1	
21	15626-93J00	.GASKET,SEPARATOR	1	
22	15650-93J00	.FLOAT ASSY	1	
23	15200-98J00	.PUMP ASSY,FUEL	1	
24	15647-93J00	.BUSH,FUEL PUMP	1	
25	15641-90J00	.SPACER	1	
26	15642-90J00	.FILTER	1	
27	15654-99E00	.PIN	1	
28	02142-0408B	.SCREW	1	
29	13602-05108	.SCREW	1	
30	15760-93J01	.REGULATOR,FUEL PRESSURE	1	
31	15628-99E00	.SCREW (L:15)	6	
32	15627-93J00	.SCREW	1	
33	09320-12094	CUSHION	3	
34	15675-93J00	BOLT,COOLER BRACKET	3	
35	09343-75002-600	HOSE (7.5X13.5X600)	1	L:600->50

DF300A_E11_022_147A
FUELPUMP/FUELVAPOR SEPARATOR

FIG.147A




FIG.147A (1-C-7) FUEL PUMP/FUEL VAPOR SEPARATOR ((020,021):(E01,E03,E11))

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
36	09401-11414	CLIP (ID:11.5)	15	
37	15636-93J30	HOSE,FUEL	1	
38	15685-93J00	CLIP,FUEL HOSE NO.1	3	
39	15672-93J10	BRACKET,FUEL COOLER	1	
40	01500-06167	BOLT	4	
41	15635-93J30	HOSE,FUEL	1	
42	15632-93J30	HOSE,FUEL	1	
43	15673-98J00	BRACKET,FUEL FILTER	1	
44	01550-06257	BOLT (6X25)	2	
45	15643-93J00	FILTER,FUEL	1	
46	09343-75002-600	HOSE (7.5X13.5X600)	1	L:600->65
47	15634-93J20	HOSE,FUEL	1	
48	09116-06525	BOLT (6X35)	3	
49	15674-93J00	BRACKET,CHECK VALVE	1	
50	15645-93J00	VALVE,CHECK	1	
51	15637-93J30	HOSE,FUEL	1	
52	15629-99E10	SCREW,DRAIN	2	
53	15683-87J00	HOSE (L:120)	1	
54	02112-0406B	SCREW	3	
55	09343-70503-600	HOSE (7X12X600)	1	L:600->240
56	09401-11423	CLIP	2	
57	18498-87J51	PROTECTOR,EVAP HOSE (L:160)	1	
58	09169-06062	WASHER (6.3X17X1.6)	2	
59	09116-06202	BOLT (6X25)	2	
60	15671-93J00	BRACKET,VAPOR SEPARATOR	1	
61	01550-06357	BOLT (6X35)	2	
62	09169-08042	WASHER (8.5X22X2)	6	
63	01550-08407	BOLT	3	
64	18417-93J00	BRACKET,PURGE VALVE	1	
65	01550-06127	BOLT	2	
66	09320-08520	CUSHION	1	
67	09403-14304	CLAMP	1	
68	13671-02F00	CLIP	1	
69	15114-93J00	BRACKET COMP,FUEL PUMP NO.1	1	
70	15115-93J02	BRACKET,FUEL PUMP NO.2	1	

DF300A_E11_022_147A
FUELPUMP/FUELVAPOR SEPARATOR

FIG.147A




FIG.147A (1-C-8) FUEL PUMP/FUEL VAPOR SEPARATOR ((020,021):(E01,E03,E11))

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
71	15695-98L00	UNION,EVAPORATION	1	
72	09352-50003-00A	HOSE,EVAPORATION (5X8.2X1000)	1	
73	09401-08412	CLIP	1	
74	09408-00056	CLIP (D1:12,D2:8)	1	
75	09408-00050	CLIP (ID:12X2)	1	
76	18498-93J20	PROTECTOR,EVAP HOSE (L:900)	1	
77	15118-93J00	BOLT	1	

DF300A_E11_022_147A
FUELPUMP/FUELVAPOR SEPARATOR

FIG.147B




FIG.147B (1-C-9) FUEL PUMP/FUEL VAPOR SEPARATOR ((020,021):E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15100-98J00	PUMP ASSY,FUEL	1	
2	15410-93J11	FILTER,FUEL	1	
3	15411-93J10	.CAP,FUEL FILTER	1	
4	15415-93J10	.SEAL,FUEL FILTER NO.1	1	
5	15412-93J10	.FILTER ASSY,FUEL	1	
6	15413-93J10	.CASE ASSY,FUEL FILTER	1	
7	15644-93J00	COVER,FUEL FILTER	1	
8	15633-93J20	HOSE,FUEL	1	
9	09343-75002-600	HOSE (7.5X13.5X600)	1	L:600->65
10	15440-93J10	FILTER,FUEL	1	
11	09320-08501	CUSHION (8X18X10)	2	
12	15773-90J10	UNION,FUEL HOSE	1	
13	15830-93J00	UNION,THREE WAY FUEL HOSE	1	
14	09169-06093	WASHER	3	
15	15770-93J00	COOLER,FUEL	1	
16	15762-90J00	GASKET,UNION (11.8X22X1.2)	3	
17	09360-12013	UNION (12X27)	1	
18	15830-90J00	JOINT,FUEL MAIN	1	
19	15600-98J31	SEPARATOR ASSY,FUEL VAPOR	1	
20	13370-93J10	.VALVE ASSY,NEEDLE	1	
21	15626-93J10	.GASKET,SEPARATOR	1	
22	15650-93J00	.FLOAT ASSY	1	
23	15200-98J10	.PUMP ASSY,FUEL	1	
24	15647-93J10	.BUSH,FUEL PUMP	1	
25	15641-90J10	.SPACER,FUEL PUMP	1	
26	15642-90J00	.FILTER	1	
27	15654-99E00	.PIN	1	
28	13614-93J00	.SCREW	1	
29	15631-99E10	.SCREW,REGULATOR	1	
30	15760-93J01	.REGULATOR,FUEL PRESSURE	1	
31	15628-99E00	.SCREW (L:15)	6	
32	15627-93J00	.SCREW	1	
33	09320-12094	CUSHION	3	
34	15675-93J00	BOLT,COOLER BRACKET	3	
35	09343-75002-600	HOSE (7.5X13.5X600)	1	L:600->50

DF300A_E11_022_147B
FUELPUMP/FUELVAPOR SEPARATOR

FIG.147B




FIG.147B (1-C-10) FUEL PUMP/FUEL VAPOR SEPARATOR ((020,021):E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
36	09401-11414	CLIP (ID:11.5)	15	
37	15636-93J30	HOSE,FUEL	1	
38	15685-93J00	CLIP,FUEL HOSE NO.1	3	
39	15672-93J10	BRACKET,FUEL COOLER	1	
40	01500-06167	BOLT	4	
41	15635-93J30	HOSE,FUEL	1	
42	15632-93J30	HOSE,FUEL	1	
43	15673-98J00	BRACKET,FUEL FILTER	1	
44	01550-06257	BOLT (6X25)	2	
45	15643-93J00	FILTER,FUEL	1	
46	09343-75002-600	HOSE (7.5X13.5X600)	1	L:600->65
47	15634-93J20	HOSE,FUEL	1	
48	09116-06525	BOLT (6X35)	3	
49	15674-93J00	BRACKET,CHECK VALVE	1	
50	15645-93J10	VALVE,CHECK	1	
51	15637-93J30	HOSE,FUEL	1	
52	15629-99E10	SCREW,DRAIN	2	
53	15683-87J00	HOSE (L:120)	1	
54	02112-0406B	SCREW	3	
55	09343-70503-600	HOSE (7X12X600)	1	L:600->240
56	09401-11423	CLIP	2	
57	18498-87J51	PROTECTOR,EVAP HOSE (L:160)	1	
58	09169-06062	WASHER (6.3X17X1.6)	2	
59	09116-06202	BOLT (6X25)	2	
60	15671-93J00	BRACKET,VAPOR SEPARATOR	1	
61	01550-06357	BOLT (6X35)	2	
62	09169-08042	WASHER (8.5X22X2)	6	
63	01550-08407	BOLT	3	
64	18417-93J00	BRACKET,PURGE VALVE	1	
65	01550-06127	BOLT	2	
66	09320-08520	CUSHION	1	
67	09403-14304	CLAMP	1	
68	13671-02F00	CLIP	1	
69	15114-93J00	BRACKET COMP,FUEL PUMP NO.1	1	
70	15115-93J02	BRACKET,FUEL PUMP NO.2	1	

DF300A_E11_022_147B
FUELPUMP/FUELVAPOR SEPARATOR

FIG.147B




FIG.147B (1-C-11) FUEL PUMP/FUEL VAPOR SEPARATOR ((020,021):E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
71	15695-98L00	UNION,EVAPORATION	1	
72	09352-50003-00A	HOSE,EVAPORATION (5X8.2X1000)	1	
73	09401-08412	CLIP	1	
74	09408-00056	CLIP (D1:12,D2:8)	1	
75	09408-00050	CLIP (ID:12X2)	1	
76	18498-93J20	PROTECTOR,EVAP HOSE (L:900)	1	
77	15118-93J00	BOLT	1	

DF300A_E11_022_147B
FUELPUMP/FUELVAPOR SEPARATOR

FIG.147C




FIG.147C (1-C-12) FUEL PUMP/FUEL VAPOR SEPARATOR (022:(E01,E03,E11))

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15100-98J00	PUMP ASSY,FUEL	1	
2	15410-93J11	FILTER,FUEL	1	
3	15411-93J10	.CAP,FUEL FILTER	1	
4	15415-93J10	.SEAL,FUEL FILTER NO.1	1	
5	15412-93J10	.FILTER ASSY,FUEL	1	
6	15413-93J10	.CASE ASSY,FUEL FILTER	1	
7	15644-93J00	COVER,FUEL FILTER	1	
8	15633-93J20	HOSE,FUEL	1	
9	09343-75002-600	HOSE (7.5X13.5X600)	1	L:600->65
10	15440-93J00	FILTER,FUEL	1	
11	09320-08501	CUSHION (8X18X10)	2	
12	15773-90J10	UNION,FUEL HOSE	1	
13	15830-93J00	UNION,THREE WAY FUEL HOSE	1	
14	09169-06093	WASHER	3	
15	15770-93J00	COOLER,FUEL	1	
16	09168-12013	GASKET (11.8X22X1.2)	3	
17	09360-12008	UNION (12X27)	1	
18	09363-08004	UNION	1	
19	15600-98J40	SEPARATOR ASSY,FUEL VAPOR	1	
20	13370-93J00	.VALVE ASSY,NEEDLE	1	
21	15626-93J00	.GASKET,SEPARATOR	1	
22	15650-93J00	.FLOAT ASSY	1	
23	15200-98J00	.PUMP ASSY,FUEL	1	
24	15647-93J00	.BUSH,FUEL PUMP	1	
25	15641-90J00	.SPACER	1	
26	15642-90J00	.FILTER	1	
27	15654-99E00	.PIN	1	
28	02142-0408B	.SCREW	1	
29	13602-05108	.SCREW	1	
30	15760-93J01	.REGULATOR,FUEL PRESSURE	1	
31	15628-99E00	.SCREW (L:15)	6	
32	15627-93J00	.SCREW	1	
33	09320-12094	CUSHION	3	
34	15675-93J00	BOLT,COOLER BRACKET	3	
35	09343-75002-600	HOSE (7.5X13.5X600)	1	L:600->50

DF300A_E11_022_147C
FUELPUMP/FUELVAPOR SEPARATOR

FIG.147C




FIG.147C (1-C-13) FUEL PUMP/FUEL VAPOR SEPARATOR (022:(E01,E03,E11))

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
36	09401-11414	CLIP (ID:11.5)	15	
37	15636-93J30	HOSE,FUEL	1	
38	15685-93J00	CLIP,FUEL HOSE NO.1	3	
39	15672-93J10	BRACKET,FUEL COOLER	1	
40	01500-06167	BOLT	4	
41	15635-93J30	HOSE,FUEL	1	
42	15632-93J30	HOSE,FUEL	1	
43	15673-98J00	BRACKET,FUEL FILTER	1	
44	01550-06257	BOLT (6X25)	2	
45	15643-93J00	FILTER,FUEL	1	
46	09343-75002-600	HOSE (7.5X13.5X600)	1	L:600->65
47	15634-93J20	HOSE,FUEL	1	
48	09116-06525	BOLT (6X35)	3	
49	15674-93J00	BRACKET,CHECK VALVE	1	
50	15645-93J00	VALVE,CHECK	1	
51	15637-93J30	HOSE,FUEL	1	
52	15629-99E10	SCREW,DRAIN	2	
53	15683-87J00	HOSE (L:120)	1	
54	02112-0406B	SCREW	3	
55	09343-70503-600	HOSE (7X12X600)	1	L:600->130
56	09401-11423	CLIP	2	
57	18498-90J61	PROTECTOR (15.4X18.4X70)	1	
58	09169-06062	WASHER (6.3X17X1.6)	2	
59	09116-06202	BOLT (6X25)	2	
60	15671-93J00	BRACKET,VAPOR SEPARATOR	1	
61	01550-06357	BOLT (6X35)	2	
62	09169-08042	WASHER (8.5X22X2)	6	
63	01550-0840C	BOLT	3	
64	18417-93J00	BRACKET,PURGE VALVE	1	
65	01550-0612C	BOLT (6X12)	2	
66	18117-52G10	VALVE,WASTE GATE CONT	1	
67	09352-50003-080	HOSE	1	
68	13671-02F00	CLIP	1	
69	15114-93J00	BRACKET COMP,FUEL PUMP NO.1	1	
70	15115-93J02	BRACKET,FUEL PUMP NO.2	1	

DF300A_E11_022_147C
FUELPUMP/FUELVAPOR SEPARATOR

FIG.147C




FIG.147C (1-C-14) FUEL PUMP/FUEL VAPOR SEPARATOR (022:(E01,E03,E11))

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
71	15695-98L00	UNION,EVAPORATION	1	
72	09352-50003-810	HOSE	1	
73	09401-08412	CLIP	4	
74	09408-00056	CLIP (D1:12,D2:8)	1	
75	18498-87JC1	PROTECTOR,HOSE (L:450)	1	
76	18498-87J01	PROTECTOR,HOSE	1	
77	15118-93J00	BOLT	1	
78	08316-10067	NUT	1	
79	09408-00105	CLAMP (ID:17.5,ID:11.5)	1	

DF300A_E11_022_147C
FUELPUMP/FUELVAPOR SEPARATOR

FIG.147D




FIG.147D (1-C-15) FUEL PUMP/FUEL VAPOR SEPARATOR (022:E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15100-98J00	PUMP ASSY,FUEL	1	
2	15410-93J11	FILTER,FUEL	1	
3	15411-93J10	.CAP,FUEL FILTER	1	
4	15415-93J10	.SEAL,FUEL FILTER NO.1	1	
5	15412-93J10	.FILTER ASSY,FUEL	1	
6	15413-93J10	.CASE ASSY,FUEL FILTER	1	
7	15644-93J00	COVER,FUEL FILTER	1	
8	15633-93J20	HOSE,FUEL	1	
9	09343-75002-600	HOSE (7.5X13.5X600)	1	L:600->65
10	15440-93J10	FILTER,FUEL	1	
11	09320-08501	CUSHION (8X18X10)	2	
12	15773-90J10	UNION,FUEL HOSE	1	
13	15830-93J00	UNION,THREE WAY FUEL HOSE	1	
14	09169-06093	WASHER	3	
15	15770-93J00	COOLER,FUEL	1	
16	15762-90J00	GASKET,UNION (11.8X22X1.2)	3	
17	09360-12013	UNION (12X27)	1	
18	15830-90J00	JOINT,FUEL MAIN	1	
19	15600-98J50	SEPARATOR ASSY,FUEL VAPOR	1	
20	13370-93J10	.VALVE ASSY,NEEDLE	1	
21	15626-93J10	.GASKET,SEPARATOR	1	
22	15650-93J00	.FLOAT ASSY	1	
23	15200-98J10	.PUMP ASSY,FUEL	1	
24	15647-93J10	.BUSH,FUEL PUMP	1	
25	15641-90J10	.SPACER,FUEL PUMP	1	
26	15642-90J00	.FILTER	1	
27	15654-99E00	.PIN	1	
28	13614-93J00	.SCREW	1	
29	15631-99E10	.SCREW,REGULATOR	1	
30	15760-93J01	.REGULATOR,FUEL PRESSURE	1	
31	15628-99E00	.SCREW (L:15)	6	
32	15627-93J00	.SCREW	1	
33	09320-12094	CUSHION	3	
34	15675-93J00	BOLT,COOLER BRACKET	3	
35	09343-75002-600	HOSE (7.5X13.5X600)	1	L:600->50

DF300A_E11_022_147D
FUELPUMP/FUELVAPOR SEPARATOR

FIG.147D




FIG.147D (1-C-16) FUEL PUMP/FUEL VAPOR SEPARATOR (022:E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
36	09401-11414	CLIP (ID:11.5)	15	
37	15636-93J30	HOSE,FUEL	1	
38	15685-93J00	CLIP,FUEL HOSE NO.1	3	
39	15672-93J10	BRACKET,FUEL COOLER	1	
40	01500-06167	BOLT	4	
41	15635-93J30	HOSE,FUEL	1	
42	15632-93J30	HOSE,FUEL	1	
43	15673-98J00	BRACKET,FUEL FILTER	1	
44	01550-06257	BOLT (6X25)	2	
45	15643-93J00	FILTER,FUEL	1	
46	09343-75002-600	HOSE (7.5X13.5X600)	1	L:600->65
47	15634-93J20	HOSE,FUEL	1	
48	09116-06525	BOLT (6X35)	3	
49	15674-93J00	BRACKET,CHECK VALVE	1	
50	15645-93J10	VALVE,CHECK	1	
51	15637-93J30	HOSE,FUEL	1	
52	15629-99E10	SCREW,DRAIN	2	
53	15683-87J00	HOSE (L:120)	1	
54	02112-0406B	SCREW	3	
55	09343-70503-600	HOSE (7X12X600)	1	L:600->130
56	09401-11423	CLIP	2	
57	18498-90J61	PROTECTOR (15.4X18.4X70)	1	
58	09169-06062	WASHER (6.3X17X1.6)	2	
59	09116-06202	BOLT (6X25)	2	
60	15671-93J00	BRACKET,VAPOR SEPARATOR	1	
61	01550-06357	BOLT (6X35)	2	
62	09169-08042	WASHER (8.5X22X2)	6	
63	01550-0840C	BOLT	3	
64	18417-93J00	BRACKET,PURGE VALVE	1	
65	01550-0612C	BOLT (6X12)	2	
66	18117-52G10	VALVE,WASTE GATE CONT	1	
67	09352-50003-080	HOSE	1	
68	13671-02F00	CLIP	1	
69	15114-93J00	BRACKET COMP,FUEL PUMP NO.1	1	
70	15115-93J02	BRACKET,FUEL PUMP NO.2	1	

DF300A_E11_022_147D
FUELPUMP/FUELVAPOR SEPARATOR

FIG.147D




FIG.147D (1-D-2) FUEL PUMP/FUEL VAPOR SEPARATOR (022:E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
71	15695-98L00	UNION,EVAPORATION	1	
72	09352-50003-810	HOSE	1	
73	09401-08412	CLIP	4	
74	09408-00056	CLIP (D1:12,D2:8)	1	
75	18498-87JC1	PROTECTOR,HOSE (L:450)	1	
76	18498-87J01	PROTECTOR,HOSE	1	
77	15118-93J00	BOLT	1	
78	08316-10067	NUT	1	
79	09408-00105	CLAMP (ID:17.5,ID:11.5)	1	

DF300A_E11_022_147D
FUELPUMP/FUELVAPOR SEPARATOR

FIG.160A





FIG.160A (1-D-3) WATER PUMP (E01,E03,E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-93J01	CASE,WATER PUMP	1	
2	17413-93J02	SLEEVE,WATER PUMP CASE	1	
3	17416-93J01	SEAL,WATER PUMP CASE	1	
4	17461-93J00	IMPELLER,WATER PUMP	1	
5	17471-98J01	PANEL,PUMP CASE UNDER	1	
6	17472-98J00	GASKET,PUMP CASE PANEL	1	
7	17473-98J00	PANEL,WATER PUMP NO.2	1	
8-1	17561-93J03	TUBE,WATER	1	E01:X-TRANSOM
8-2	17561-93J13	TUBE,WATER	1	E01:XX-TRANSOM
8-3	17561-93J21	TUBE,WATER	1	E03:L-TRANSOM
8-4	17561-93J03	TUBE,WATER	1	E03:X-TRANSOM
8-5	17561-93J13	TUBE,WATER	1	E03:XX-TRANSOM
8-6	17561-93J21	TUBE,WATER	1	E11:L-TRANSOM
8-7	17561-93J03	TUBE,WATER	1	E11:X-TRANSOM
8-8	17561-93J13	TUBE,WATER	1	E11:XX-TRANSOM
9	17562-93J01	BUSH,WATER TUBE UPPER	1	
10	17563-93J01	BUSH,WATER TUBE LOWER	1	
11	17564-93J01	BUSH,WATER PUMP CASE	1	
12	17612-93J00	SPACER,WATER TUBE	1	
13	17631-93L10	FILTER,WATER PORT SIDE	1	
14	17632-93L10	FILTER,WATER STBD SIDE	1	
15	29116-93J00	BOLT (6X20)	2	
16	09116-08131	BOLT (8X45)	4	
17	09132-04034	SCREW (4X18)	1	
18	09202-06031	PIN (6X12)	2	
19	09420-05009	KEY	1	
20	09168-20002	GASKET (20.5X30X1.5)	1	WATER TUBE UPPER
21	17633-93L00	COVER,WATER FILTER	1	
22	17400-98J03	KIT,WATER PUMP REPAIR	1	OPT
23	17416-93J01	.SEAL,WATER PUMP CASE	1	OPT

DF300A_E11_022_160A
WATER PUMP

FIG.160A




DF300A_E11_022_160A
WATER PUMP

FIG.160A (1-D-4) WATER PUMP (E01,E03,E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
24	17461-93J00	.IMPELLER,WATER PUMP	1	OPT
25	17471-98J01	.PANEL,PUMP CASE UNDER	1	OPT
26	17472-98J00	.GASKET,PUMP CASE PANEL	1	OPT
27	17473-98J00	.PANEL,WATER PUMP NO.2	1	OPT
28	09420-05009	.KEY	1	OPT
29	17413-93J02	.SLEEVE,WATER PUMP CASE	1	OPT

FIG.160B



DF300A_E11_022_160B
WATER PUMP

FIG.160B (1-D-5) WATER PUMP (E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-93J01	CASE,WATER PUMP	1	
2	17413-93J12	SLEEVE,WATER PUMP CASE	1	
3	17416-93J01	SEAL,WATER PUMP CASE	1	
4	17461-93J00	IMPELLER,WATER PUMP	1	
5	17471-98J11	PANEL,PUMP CASE UNDER	1	
6	17472-98J00	GASKET,PUMP CASE PANEL	1	
7	17473-98J00	PANEL,WATER PUMP NO.2	1	
8-1	17561-93J03	TUBE,WATER	1	X-TRANSOM
8-2	17561-93J13	TUBE,WATER	1	XX-TRANSOM
9	17562-93J01	BUSH,WATER TUBE UPPER	1	
10	17563-93J01	BUSH,WATER TUBE LOWER	1	
11	17564-93J01	BUSH,WATER PUMP CASE	1	
12	17612-93J00	SPACER,WATER TUBE	1	
13	17631-93L00	FILTER,WATER PORT SIDE	1	PORT
14	17632-93L00	FILTER,WATER STBD SIDE	1	STBD
15	29116-93J00	BOLT (6X20)	2	
16	09116-08131	BOLT (8X45)	4	
17	09132-04034	SCREW (4X18)	1	
18	09202-06031	PIN (6X12)	2	
19	09420-05009	KEY	1	
20	09168-20002	GASKET (20.5X30X1.5)	1	WATER TUBE UPPER

FIG.162A




FIG.162A (1-D-6) THERMOSTAT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11196-93J00	HOSE,WATER RETURN STBD	1	STBD
2	11197-93J00	HOSE,WATER RETURN PORT	1	PORT
3	11270-93J00	PLATE,CYL BLOCK WTR JKT	1	
4	11272-93J00	GASKET,CYLINDER BLOCK PLATE	1	
5	17581-93J00	PIPE,WATER OUTLET	2	
6	17582-93J00	GASKET,WTR OUTLET PIPE	2	
7	17611-90J00	COVER,WTR PRESS VALVE	1	
8	17660-99E01	VALVE,WATER PRESSURE	1	
9-1	17670-90J21	THERMOSTAT,WATER (50C)	2	
9-2	17670-90J11	THERMOSTAT,WATER (71C)	1	OPT
10	17681-93J00	COVER,THERMOSTAT	2	
11	17711-90J00	3WAY,WATER HOSE	1	
12	17712-93J01	HOSE,WATER	1	
13	09116-06121	BOLT (6X25)	2	
14	09280-26006	O RING (D:3.1,ID:26.4)	1	
15	09320-12093	CUSHION	1	
16	09352-50006-600	HOSE (5X9X600)	1	L:600->60
17	09352-50006-600	HOSE (5X9X600)	1	L:600->120
18	09352-50006-600	HOSE (5X9X600)	1	L:600->190
19	09352-50006-600	HOSE (5X9X600)	1	L:600->300
20	09352-50006-600	HOSE (5X9X600)	1	L:600->330
21	09352-50006-600	HOSE (5X9X600)	1	
22	09352-50006-600	HOSE (5X9X600)	1	
23	09352-50006-00B	HOSE (5X9X2000)	1	L:2000->850
24	09352-50006-00B	HOSE (5X9X2000)	1	L:2000->1010
25-1	01550-08127	BOLT	1	020,021
25-2	01550-0812C	BOLT	1	022
26	09367-06002	JOINT,3 WAY	1	
27	09401-08413	CLIP	18	
28	09401-14409	CLIP	2	
29	09401-25406	CLIP	4	
30	09403-25304	CLAMP	1	
31	09408-00008	CLIP (ID:20)	1	
32	09408-00056	CLIP (D1:12,D2:8)	1	
33-1	01550-06207	BOLT (6X20)	6	020,021

FIG.162A




FIG.162A (1-D-7) THERMOSTAT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
33-2	01550-0620C	BOLT (6X20)	6	022
34-1	01550-06207	BOLT (6X20)	4	020,021
34-2	01550-0620C	BOLT (6X20)	4	022
35-1	01550-06257	BOLT (6X25)	10	020,021
35-2	01550-0625C	BOLT (6X25)	10	022
36	17713-98J01	HOLDER,WATER HOSE	1	
37	09401-15414	CLIP	2	
38	17915-98J02	HOSE,WATER FLUSH	1	
39	09408-00024	CLIP (ID:23)	1	
40	09408-00021	CLIP (ID:16)	1	
41	36617-93J10	BRACKET,HARNESS	1	
42-1	01550-06127	BOLT	1	020,021
42-2	01550-0612C	BOLT (6X12)	1	022

FIG.163A




FIG.163A (1-D-8) THROTTLE BODY

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11193-98J01	HOSE,PCV	1	
2	11198-98L00	SEAL,PCV VALVE	1	
3-1	13100-98J11	COLLECTOR ASSY	1	020,021
3-2	13100-98J20	COLLECTOR ASSY	1	022
4	13137-98J00	.SPACER,COLLECTOR	4	
5	13140-98J10	.COVER,COLLECTOR	1	
6	13147-98J00	.GASKET,COLLECTOR COVER	1	
7	13180-98J01	.FUNNEL,AIR COLLECTOR	2	
8	18590-68H00	.SENSOR,PRESSURE	1	
9	09280-10009	.O-RING (D:1.3,ID:9.8)	8	
10	01550-08167	.BOLT	4	
11	01550-08357	.BOLT	11	
12-1	02162-05207	.SCREW	2	020,021
12-2	09103-05028	.BOLT,PRESSURE SENSOR (5X20)	2	022
13	04211-11129	.PIN (11X12)	8	
14	13134-98J00	BRACKET,COLLECTOR	1	
15	13139-98J01	GASKET,COLLECTOR	1	
16	13310-98J01	BODY ASSY,THROTTLE	1	
17	13343-98J10	GASKET,THROTTLE BODY	1	
18	13315-98J01	DAMPER,THROTTLE BODY	1	
19	13421-98L00	GASKET,THROTTLE BODY	1	
20	13813-98J01	GROMMET,THROTTLE BODY	1	
21	09401-13423	CLIP	2	
22	18118-93J00	VALVE,PCV	1	
23	09103-08370	BOLT (8X250)	6	
24	09320-08517	GROMMET	4	
25	09403-13310	CLAMP	1	
26	09408-00155	CLAMP	1	
27	01421-08357	BOLT,STUD	2	
28-1	01550-08167	BOLT	5	020,021
28-2	01550-0816C	BOLT	5	022
29-1	01550-08357	BOLT	2	020,021
29-2	01550-0835C	BOLT	2	022
30-1	01550-08607	BOLT	2	020,021
30-2	01550-0860C	BOLT	2	022

FIG.163A




FIG.163A (1-D-9) THROTTLE BODY

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
31	04211-11129	PIN (11X12)	2	
32	09159-08136	NUT (M8)	4	
33-1	08316-10087	NUT	2	020,021
33-2	08316-1008C	NUT	2	022
34	09160-08161	WASHER (8.2X23X3.2)	2	

DF300A_E11_022_163A
THROTTLE BODY

FIG.175A




FIG.175A (1-D-10) OIL PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12632-93J11	SPROCKET,OIL PUMP DRIVE (NT:32)	1	
2	16113-93J10	SPROCKET,OIL PUMP DRIVEN (NT:18)	1	
3	16400-93J20	PUMP ASSY,OIL	1	
4	16520-93J00	STRAINER,OIL PUMP	1	
5	16760-93J00	CHAIN,OIL PUMP DRIVE	1	
6	16781-93J00	TENSIONER,OIL PUMP CHAIN	1	
7	16782-93J00	SPRING,OIL PUMP TENSIONER	1	
8	16783-93J01	BOLT,OIL PUMP TENSIONER	1	
9	09181-12158	SHIM (12X20X0.5)	1	
10	09280-22020	O RING (D:2.4,ID:21.8)	2	
11	01550-0616A	BOLT (6X16)	3	
12	01550-0845A	BOLT	1	
13	01550-0865A	BOLT	3	
14	01550-0885A	BOLT	1	
15	08110-60020	BEARING	1	

DF300A_E11_022_175A
OIL PUMP

FIG.180A




FIG.180A (1-D-11) OIL PAN

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11261-93J10	COVER,PROTECTION ANODE	1	
2-1	55321-87J01	ANODE,PROTECTION	1	
2-2	55321-87J11	ANODE (MAGNESIUM)	1	OPT
3	29103-93J30	BOLT (8X25)	1	
4	09103-06281	BOLT (6X14)	1	
5	09280-22019	O RING (D:1.9,ID:21.8)	1	
6	11489-93J00	GASKET,OIL PAN	1	
7-1	11501-93J03-YAY	PAN,OIL (BLACK)	1	020 BODY COLOR:YAY
7-2	11501-93J03-Y5S	PAN,OIL (WHITE)	1	020 BODY COLOR:Y5S
7-3	11501-93J03-QTN	PAN,OIL (WHITE)	1	021,022 BODY COLOR:QTN
7-4	11501-93J03-YAY	PAN,OIL (BLACK)	1	021,022 BODY COLOR:YAY
8	11591-93J11	UNION,OIL PAN	1	
9-1	11541-93J00-YAY	PIPE,EXHAUST (BLACK)	1	020 BODY COLOR:YAY
9-2	11541-93J00-Y5S	PIPE,EXHAUST (WHITE)	1	020 BODY COLOR:Y5S
9-3	11541-93J00-QTN	PIPE,EXHAUST (WHITE)	1	021,022 BODY COLOR:QTN
9-4	11541-93J00-YAY	PIPE,EXHAUST (BLACK)	1	021,022 BODY COLOR:YAY
10	14154-93J02	SEAL,EXHAUST TUBE	1	
11	14211-98J00	TUBE,EXHAUST	1	
12	14212-93J00	GASKET,EXHAUST TUBE	1	
13	29116-93J00	BOLT (6X20)	4	
14	11435-93J01	PIPE,EXHAUST RELEASE	1	
15	09168-12012	GASKET (12.5X20X2.5)	1	
16	09248-12009	PLUG (12X18.65)	1	
17	09202-08006	PIN (8X12)	2	
18	09202-08006	PIN (8X12)	2	
19	01550-1050A	BOLT	4	
20	09116-08128	BOLT,8X40 (8X40)	10	

DF300A_E11_022_180A
OIL PAN

FIG.180A




FIG.180A (1-D-12) OIL PAN

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
21	09116-10175	BOLT (10X50)	2	
22	09116-10146	BOLT (10X195)	2	
23	09116-10184	BOLT (10X200)	2	
24	29103-93J00	BOLT (6X12)	1	
25	29404-93J11	CLAMP (L:65)	1	
26	16910-93J00	GAUGE,OIL LEVEL	1	
27	16930-93J00	GUIDE,OIL LEVEL GAUGE	1	
28	09280-09008	O-RING (D:2.1,ID:8.8)	1	
29-1	01550-06127	BOLT	1	020,021
29-2	01550-0612C	BOLT (6X12)	1	022

FIG.204A




FIG.204A (1-D-13) CLUTCH SHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21110-98J02	LEVER,CLUTCH	1	
2	21131-93J00	BUSH,CLUTCH LEVER	1	
3	21151-93J00	HOLDER,CLUTCH LEVER	1	
4	09160-10148	WASHER (10X20X3)	1	
5	21210-98J01	SHAFT,CLUTCH	1	
6	21230-98J01	ARM,CLUTCH SHAFT	1	
7-1	23111-93J10	ROD,CLUTCH	1	L-TRANSOM
7-2	23111-93J00	ROD,CLUTCH	1	X-TRANSOM,XX-TRANSOM
8	23115-98J00	LINK,CLUTCH LEVER	1	
9	25223-96J00	SEAL,CLUTCH ROD	1	
10	09160-06094	WASHER (6.5X15X1.0)	2	
11	09204-01006	PIN	2	
12	09205-10006	PIN,SPRING (10.2X10)	1	
13	09248-12011	PLUG (12X9)	1	
14	09260-10005	BALL	1	
15	09262-17019	BEARING (17X35X8)	1	
16	09289-18001	OIL SEAL (18X30X8)	1	
17	09306-06005	BUSH	2	
18	09306-10001	BUSH	3	
19	09383-08004	E RING	1	
20	09440-07051	SPRING	1	
21-1	01550-06207	BOLT (6X20)	1	020,021
21-2	01550-0620C	BOLT (6X20)	1	022
22	02142-05107	SCREW	2	
23	08331-41359	CIRCLIP	1	
24	21241-98J10	LINK,CLUTCH LEVER NO.2	1	
25	67467-89J01	CONNECTOR	1	
26	67471-99E00	NUT,REMOCON CABLE	1	
27	09160-06055	WASHER (7X12X1.0)	2	
28	09385-06012	CLIP	2	
29	19115-98J10	HOLDER,CLUTCH LEVER	1	
30-1	01550-08557	BOLT	2	020,021
30-2	01550-0855C	BOLT	2	022
31	67467-89J10	CONNECTOR,REMOCON CABLE NO.2	1	
32	67471-99E10	NUT,REMOCON CABLE NO.2	1	

FIG.206A




FIG.206A (1-D-14) CLUTCH ROD (020,021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	25112-93L00	ROD,SHIFT DRIVE	1	L-TRANSOM,X-TRANSOM
1-2	25112-93L10	ROD,SHIFT DRIVE	1	XX-TRANSOM
2	25130-93L00	YOKE,SHIFTER	1	
3	25232-90J00	MAGNET,GEAR CASE	1	
4	09205-03004	SPRING PIN (3X20)	1	
5-1	25141-93L10-YAY	HOUSING,SHIFT ROD GUIDE (BLACK)	1	020 BODY COLOR:YAY
5-2	25141-93L10-Y5S	HOUSING,SHIFT ROD GUIDE (WHITE)	1	020 BODY COLOR:Y5S
5-3	25141-93L10-QTN	HOUSING,SHIFT ROD GUIDE (WHITE)	1	021 BODY COLOR:QTN
5-4	25141-93L10-YAY	HOUSING,SHIFT ROD GUIDE (BLACK)	1	021 BODY COLOR:YAY
6	25222-90J01	COVER,SFT GUIDE HSG OIL SEAL	1	
7	09283-10011	OIL SEAL (10X22X8)	1	
8	25321-93L00	SLIDER,SHIFT HORIZONTAL	1	
9	29116-93J00	BOLT (6X20)	3	
10	09160-10082	WASHER (10.5X19X2.0)	1	
11	25113-93L00	GEAR,SHIFT ROD (NT:13)	2	
12	25215-93L00	HOUSING,MAGNET	1	
13	09383-07003	E RING (7X14X1.2)	3	
14	55122-93L00	SEALING,SHIFT ROD GUIDE HSG	1	
15	56141-93L00	HOUSING,SHIFT SLIDER	1	
16	17637-93L00	FILTER,WATER PORT FRONT SIDE	1	PORT
17	17638-93L00	FILTER,WATER STBD FRONT SIDE	1	STBD
18	55321-87J01	ANODE,PROTECTION	1	
19	01550-06357	BOLT (6X35)	2	
20	09103-06281	BOLT (6X14)	1	
21	09206-09012	PIN (7.4X9X10)	2	
22	09132-04034	SCREW (4X18)	1	
23	25231-93L00	HOLDER,MAGNET	2	
24	25232-94300	MAGNET,GEAR CASE	2	

DF300A_E11_022_206A
CLUTCHROD

FIG.206B




FIG.206B (1-D-15) CLUTCH ROD (022)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	25112-93L00	ROD,SHIFT DRIVE	1	L-TRANSOM,X-TRANSOM
1-2	25112-93L10	ROD,SHIFT DRIVE	1	XX-TRANSOM
2	25130-93L00	YOKE,SHIFTER	1	
3	25232-90J00	MAGNET,GEAR CASE	1	
4	09205-03004	SPRING PIN (3X20)	1	
5-1	25141-93L11-QTN	HOUSING,SHIFT ROD GUIDE (WHITE)	1	BODY COLOR:QTN
5-2	25141-93L11-YAY	HOUSING,SHIFT ROD GUIDE (BLACK)	1	BODY COLOR:YAY
6	25222-90J01	COVER,SFT GUIDE HSG OIL SEAL	1	
7	09283-10011	OIL SEAL (10X22X8)	1	
8	25321-93L00	SLIDER,SHIFT HORIZONTAL	1	
9	29116-93J00	BOLT (6X20)	3	
10	09160-10082	WASHER (10.5X19X2.0)	1	
11	25113-93L20	GEAR,SHIFT ROD	2	
12	25215-93L00	HOUSING,MAGNET	1	
13	09383-07003	E RING (7X14X1.2)	3	
14	55122-93L00	SEALING,SHIFT ROD GUIDE HSG	1	
15	56141-93L00	HOUSING,SHIFT SLIDER	1	
16	17637-93L00	FILTER,WATER PORT FRONT SIDE	1	PORT
17	17638-93L00	FILTER,WATER STBD FRONT SIDE	1	STBD
18	55321-87J01	ANODE,PROTECTION	1	
19	01550-06357	BOLT (6X35)	2	
20	09103-06281	BOLT (6X14)	1	
21	09206-09012	PIN (7.4X9X10)	2	
22	09132-04034	SCREW (4X18)	1	
23	25231-93L00	HOLDER,MAGNET	2	
24	25232-94300	MAGNET,GEAR CASE	2	

DF300A_E11_022_206B
CLUTCHROD

FIG.220A




FIG.220A (1-D-16) TRANSMISSION (020,021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57110-93L02	SHAFT,DRIVE	1	L-TRANSOM
1-2	57110-93L12	SHAFT,DRIVE	1	X-TRANSOM
1-3	57110-93L22	SHAFT,DRIVE	1	XX-TRANSOM
2	57133-93L00	COLLAR,DRIVE SHAFT	1	
3	57134-93J00	SPACER,DRIVE SFT BRG	1	
4	09159-28003	NUT (M28)	1	
5	09269-32002	BEARING (32X66X49)	1	
6	57300-93L20	SET,GEAR	1	
7-1	09181-60004	SHIM (60X66X0.45)	1	
7-2	09181-60005	SHIM (60X66X0.5)	1	
7-3	09181-60006	SHIM (60X66X0.55)	1	
7-4	09181-60007	SHIM (60X66X0.6)	1	
7-5	09181-60008	SHIM (60X66X0.65)	1	
7-6	09181-60009	SHIM (60X66X0.7)	1	
7-7	09181-60010	SHIM (60X66X0.75)	1	
7-8	09181-60011	SHIM (60X66X0.8)	1	
7-9	09181-60012	SHIM (60X66X0.85)	1	
7-10	09181-60013	SHIM (60X66X0.9)	1	
8	09140-16026	NUT	1	
9	08221-16256	SHIM	1	
10	09180-32006	SPACER (32.4X40X3)	1	REAR GEAR
11-1	09181-32035	SHIM (32X37X0.5)	1	REAR GEAR
11-2	09181-32036	SHIM (32X37X0.55)	1	REAR GEAR
11-3	09181-32037	SHIM (32X37X0.6)	1	REAR GEAR
11-4	09181-32038	SHIM (32X37X0.65)	1	REAR GEAR
11-5	09181-32039	SHIM (32X37X0.7)	1	REAR GEAR
11-6	09181-32040	SHIM (32X37X0.75)	1	REAR GEAR
11-7	09181-32041	SHIM (32X37X0.8)	1	REAR GEAR
11-8	09181-32042	SHIM (32X37X0.85)	1	REAR GEAR
11-9	09181-32043	SHIM (32X37X0.9)	1	REAR GEAR
11-10	09181-32044	SHIM (32X37X0.95)	1	REAR GEAR
12	09160-60012	WASHER (60X72X3)	1	FRONT GEAR
13	09263-80002	BEARING (80X105X4)	1	FRONT GEAR
14-1	09181-93101	SHIM,REAR GEAR (T:0.50)	2	
14-2	09181-93102	SHIM,REAR GEAR (T:0.55)	2	

FIG.220A




FIG.220A (1-E-2) TRANSMISSION (020,021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14-3	09181-93103	SHIM,REAR GEAR (T:0.60)	2	
14-4	09181-93104	SHIM,REAR GEAR (T:0.65)	2	
14-5	09181-93105	SHIM,REAR GEAR (T:0.70)	2	
14-6	09181-93106	SHIM,REAR GEAR (T:0.75)	2	
14-7	09181-93107	SHIM,REAR GEAR (T:0.80)	2	
14-8	09181-93108	SHIM,REAR GEAR (T:0.85)	2	
14-9	09181-93109	SHIM,REAR GEAR (T:0.90)	2	
14-10	09181-93110	SHIM,REAR GEAR (T:0.95)	2	
14-11	09181-93111	SHIM,REAR GEAR (T:1.00)	2	
14-12	09181-93112	SHIM,REAR GEAR (T:1.05)	2	
14-13	09181-93113	SHIM,REAR GEAR (T:1.10)	2	
15-1	59171-93L00	SHIM,FRONT GEAR (T:3.50)	1	FRONT GEAR
15-2	59171-93L10	SHIM,FRONT GEAR (T:3.55)	1	FRONT GEAR
15-3	59171-93L20	SHIM,FRONT GEAR (T:3.60)	1	FRONT GEAR
15-4	59171-93L30	SHIM,FRONT GEAR (T:3.65)	1	FRONT GEAR
15-5	59171-93L40	SHIM,FRONT GEAR (T:3.70)	1	FRONT GEAR
15-6	59171-93L50	SHIM,FRONT GEAR (T:3.75)	1	FRONT GEAR
15-7	59171-93L60	SHIM,FRONT GEAR (T:3.80)	1	FRONT GEAR
15-8	59171-93L70	SHIM,FRONT GEAR (T:3.85)	1	FRONT GEAR
15-9	59171-93L80	SHIM,FRONT GEAR (T:3.90)	1	FRONT GEAR
15-10	59171-93L90	SHIM,FRONT GEAR (T:3.95)	1	FRONT GEAR
15-11	59171-93LA0	SHIM,FRONT GEAR (T:4.00)	1	FRONT GEAR
15-12	59171-93LB0	SHIM,FRONT GEAR (T:4.05)	1	FRONT GEAR
15-13	59171-93LC0	SHIM,FRONT GEAR (T:4.10)	1	FRONT GEAR
16	09265-30033	BEARING (30X72X28.75)	1	
17	57610-93L10	SHAFT,PROPELLER	1	
18	57621-93L00	SHIFTER,CLUTCH DOG	1	
19	09202-08013	PIN (8X55)	1	
20	57631-93L01	PIN,CONNECTOR	1	
21	09440-58001	SPRING	1	
22	57617-93L00	SPRING,DETENT	1	
23	06111-07004	BALL	2	DETENT NO.1
24	06111-11004	BALL	2	DETENT NO.2
25	56120-93L20	HOUSING,PROP SHAFT BRG	1	
26	09263-30063	.BEARING (30X40X25)	1	

FIG.220A




FIG.220A (1-E-3) TRANSMISSION (020,021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
27	09265-32003	.BEARING (32X58X17)	1	
28	09280-00047	.O-RING (D:3,ID:109)	1	
29	09282-30006	.SEAL,OIL (30X45X6)	2	
30	09381-40003	.CIRCLIP	1	
31	56147-93L00	SPACER,PROP SFT BRG HSG	1	
32	56130-93J02	HOUSING,DRIVE SHAFT BRG	1	
33	09280-66004	.O-RING (D:3.1,ID:65.4)	1	
34	09282-24004	.OIL SEAL (24X40X7)	2	
35	09381-40003	.CIRCLIP	1	
36	57622-93L00	SPACER,FORWARD THRUST	1	FRONT
37	09164-50002	WASHER,WAVE	1	
38	09381-72003	CIRCLIP	1	FRONT
39	09140-48001	NUT (M48,T:6.0)	1	REAR GEAR
40	56122-93L00	STOPPER,PROP SHAFT BRG HOUSING	1	
41	56126-93L10	WASHER,PROP SFT BRG HSG NO.1	1	
42	56127-93L00	WASHER,PROP SFT BRG HSG NO.2	1	
43	56128-93L00	SEAL,PROP SFT BRG HOUSING	1	
44	56129-93L00	BUSH,STOPPER	1	
45	09280-00050	O RING (D:1.8,ID:117.6)	1	
46	57527-93L00	SPACER,BEARING INNER	1	
47	57541-93L00	SPACER,BEARING OUTER	1	
48	09265-50004	BEARING (50X80X20)	1	REAR GEAR R
49	09265-55001	BEARING (55X100X22.75)	1	REAR GEAR F

FIG.220B




FIG.220B (1-E-4) TRANSMISSION (022)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57110-93L02	SHAFT,DRIVE	1	L-TRANSOM
1-2	57110-93L12	SHAFT,DRIVE	1	X-TRANSOM
1-3	57110-93L22	SHAFT,DRIVE	1	XX-TRANSOM
2	57133-93L00	COLLAR,DRIVE SHAFT	1	
3	57134-93J00	SPACER,DRIVE SFT BRG	1	
4	09159-28003	NUT (M28)	1	
5	09269-32002	BEARING (32X66X49)	1	
6	57300-93L20	SET,GEAR	1	
7-1	09181-60004	SHIM (60X66X0.45)	1	
7-2	09181-60005	SHIM (60X66X0.5)	1	
7-3	09181-60006	SHIM (60X66X0.55)	1	
7-4	09181-60007	SHIM (60X66X0.6)	1	
7-5	09181-60008	SHIM (60X66X0.65)	1	
7-6	09181-60009	SHIM (60X66X0.7)	1	
7-7	09181-60010	SHIM (60X66X0.75)	1	
7-8	09181-60011	SHIM (60X66X0.8)	1	
7-9	09181-60012	SHIM (60X66X0.85)	1	
7-10	09181-60013	SHIM (60X66X0.9)	1	
8	09140-16026	NUT	1	
9	08221-16256	SHIM	1	
10	09180-32006	SPACER (32.4X40X3)	1	REAR GEAR
11-1	09181-32035	SHIM (32X37X0.5)	1	REAR GEAR
11-2	09181-32036	SHIM (32X37X0.55)	1	REAR GEAR
11-3	09181-32037	SHIM (32X37X0.6)	1	REAR GEAR
11-4	09181-32038	SHIM (32X37X0.65)	1	REAR GEAR
11-5	09181-32039	SHIM (32X37X0.7)	1	REAR GEAR
11-6	09181-32040	SHIM (32X37X0.75)	1	REAR GEAR
11-7	09181-32041	SHIM (32X37X0.8)	1	REAR GEAR
11-8	09181-32042	SHIM (32X37X0.85)	1	REAR GEAR
11-9	09181-32043	SHIM (32X37X0.9)	1	REAR GEAR
11-10	09181-32044	SHIM (32X37X0.95)	1	REAR GEAR
12	09160-60012	WASHER (60X72X3)	1	FRONT GEAR
13	09263-80002	BEARING (80X105X4)	1	FRONT GEAR
14-1	09181-93101	SHIM,REAR GEAR (T:0.50)	2	
14-2	09181-93102	SHIM,REAR GEAR (T:0.55)	2	

FIG.220B




FIG.220B (1-E-5) TRANSMISSION (022)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14-3	09181-93103	SHIM,REAR GEAR (T:0.60)	2	
14-4	09181-93104	SHIM,REAR GEAR (T:0.65)	2	
14-5	09181-93105	SHIM,REAR GEAR (T:0.70)	2	
14-6	09181-93106	SHIM,REAR GEAR (T:0.75)	2	
14-7	09181-93107	SHIM,REAR GEAR (T:0.80)	2	
14-8	09181-93108	SHIM,REAR GEAR (T:0.85)	2	
14-9	09181-93109	SHIM,REAR GEAR (T:0.90)	2	
14-10	09181-93110	SHIM,REAR GEAR (T:0.95)	2	
14-11	09181-93111	SHIM,REAR GEAR (T:1.00)	2	
14-12	09181-93112	SHIM,REAR GEAR (T:1.05)	2	
14-13	09181-93113	SHIM,REAR GEAR (T:1.10)	2	
15-1	59171-93L00	SHIM,FRONT GEAR (T:3.50)	1	FRONT GEAR
15-2	59171-93L10	SHIM,FRONT GEAR (T:3.55)	1	FRONT GEAR
15-3	59171-93L20	SHIM,FRONT GEAR (T:3.60)	1	FRONT GEAR
15-4	59171-93L30	SHIM,FRONT GEAR (T:3.65)	1	FRONT GEAR
15-5	59171-93L40	SHIM,FRONT GEAR (T:3.70)	1	FRONT GEAR
15-6	59171-93L50	SHIM,FRONT GEAR (T:3.75)	1	FRONT GEAR
15-7	59171-93L60	SHIM,FRONT GEAR (T:3.80)	1	FRONT GEAR
15-8	59171-93L70	SHIM,FRONT GEAR (T:3.85)	1	FRONT GEAR
15-9	59171-93L80	SHIM,FRONT GEAR (T:3.90)	1	FRONT GEAR
15-10	59171-93L90	SHIM,FRONT GEAR (T:3.95)	1	FRONT GEAR
15-11	59171-93LA0	SHIM,FRONT GEAR (T:4.00)	1	FRONT GEAR
15-12	59171-93LB0	SHIM,FRONT GEAR (T:4.05)	1	FRONT GEAR
15-13	59171-93LC0	SHIM,FRONT GEAR (T:4.10)	1	FRONT GEAR
16	09265-30033	BEARING (30X72X28.75)	1	
17	57610-93L10	SHAFT,PROPELLER	1	
18	57621-93L00	SHIFTER,CLUTCH DOG	1	
19	09202-08013	PIN (8X55)	1	
20	57631-93L01	PIN,CONNECTOR	1	
21	09440-58001	SPRING	1	
22	57617-93L00	SPRING,DETENT	1	
23	06111-07004	BALL	2	DETENT NO.1
24	06111-11004	BALL	2	DETENT NO.2
25	56120-93L30	HOUSING,PROP SHAFT BRG	1	
26	09263-30063	.BEARING (30X40X25)	1	

FIG.220B




FIG.220B (1-E-6) TRANSMISSION (022)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
27	09265-32003	.BEARING (32X58X17)	1	
28	09280-00047	.O-RING (D:3,ID:109)	1	
29	09280-80001	.O RING (D:2.4,ID:79.8)	1	
30	09282-30006	.SEAL,OIL (30X45X6)	2	
31	09381-40003	.CIRCLIP	1	
32	56147-93L00	SPACER,PROP SFT BRG HSG	1	
33	56130-93J02	HOUSING,DRIVE SHAFT BRG	1	
34	09280-66004	.O-RING (D:3.1,ID:65.4)	1	
35	09282-24004	.OIL SEAL (24X40X7)	2	
36	09381-40003	.CIRCLIP	1	
37	57622-93L00	SPACER,FORWARD THRUST	1	FRONT
38	09164-50002	WASHER,WAVE	1	
39	09381-72003	CIRCLIP	1	FRONT
40	09140-48001	NUT (M48,T:6.0)	1	REAR GEAR
41	56122-93L00	STOPPER,PROP SHAFT BRG HOUSING	1	
42	56126-93L10	WASHER,PROP SFT BRG HSG NO.1	1	
43	56127-93L00	WASHER,PROP SFT BRG HSG NO.2	1	
44	56128-93L00	SEAL,PROP SFT BRG HOUSING	1	
45	56129-93L00	BUSH,STOPPER	1	
46	09280-00050	O RING (D:1.8,ID:117.6)	1	
47	57527-93L00	SPACER,BEARING INNER	1	
48	57541-93L00	SPACER,BEARING OUTER	1	
49	09265-50004	BEARING (50X80X20)	1	REAR GEAR R
50	09265-55001	BEARING (55X100X22.75)	1	REAR GEAR F

FIG.301A




FIG.301A (1-E-7) STARTING MOTOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31100-98L10	MOTOR ASSY,STARTING	1	
2	31150-98L00	.CASE,GEAR	1	
3	31170-92J00	.HOUSING,REAR	1	
4	31173-98L00	.HOLDER ASSY,BRUSH	1	
5	31191-63J00	.LEVER SET	1	
6	31220-98L10	.SWITCH ASSY	1	
7	31311-63J00	.ARMATURE	1	
8	31192-92J00	.SCREW SET	1	
9	31261-75F10	.BOLT	2	
10	31340-98L00	.CLUTCH SET,STARTING MOTOR	1	
11	31313-86030	..STOPPER SET	1	
12	31320-98L00	..PINION	1	
13	31341-98L00	..SHAFT,PINION	1	
14	31343-63J00	..INTERNAL GEAR ASSY	1	
15	31344-63J00	..GEAR ASSY	3	
16	31912-98J00	BAND,STARTER MOTOR	1	
17	31918-92J01	DAMPER,LOWER	1	
18	01550-08207	BOLT	2	
19-1	01550-08307	BOLT	2	020,021
19-2	01550-0835C	BOLT	2	022
20	36645-93J00	LEAD WIRE,STARTER MOTOR	1	

FIG.303A




FIG.303A (1-E-8) MAGNETO

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	32102-98J20	FLYWHEEL,MAGNETO	1	FROM 25003P040001
				UPTO 25003P041265
				FROM 30002P040001
				UPTO 30002P044338
1-2	32102-98J11	FLYWHEEL,MAGNETO	1	FROM 25003P041266
				FROM 30002P044339
2	09103-12125	BOLT (12X26)	8	
3	09202-06031	PIN (6X12)	1	
4-1	32120-93J10	COIL,BATTERY CHARGING	1	FROM 25003P040001
				UPTO 25003P041265
				FROM 30002P040001
				UPTO 30002P044338
4-2	32120-93J01	COIL,BATTERY CHARGING	1	FROM 25003P041266
				FROM 30002P044339
5	32131-93J00	HOLDER,STATOR CONNECTOR	1	
6-1	01550-06167	BOLT (6X16)	2	020,021
6-2	01550-0616C	BOLT (6X16)	2	022
7	32160-88L01	COIL,IGN TIMING	1	
8	09106-05030	BOLT (5X10)	2	
9	33220-98J00	SENSOR ASSY,CMP	3	
10	33221-42F00	.O-RING	3	
11-1	01550-06167	BOLT (6X16)	3	020,021
11-2	01550-0616C	BOLT (6X16)	3	022
12	09103-06231	BOLT (6X35)	4	
13	09403-13414	CLAMP	2	
14-1	01550-06127	BOLT	2	020,021
14-2	01550-0612C	BOLT (6X12)	2	022

FIG.310A




FIG.310A (1-E-9) RECTIFIER/IGNITION COIL

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-98J01	RECTIFIER & REGULATOR ASSY	1	
2	32805-93J00	O-RING,RECT & REGULATOR	2	
3	32890-98J01	HOLDER,ELECTRIC PARTS	1	
4	09160-06134	WASHER (6.5X24X1.6)	1	
5	09169-06062	WASHER (6.3X17X1.6)	3	
6	09320-09016	CUSHION (9X18X9.5)	3	
7	09116-06202	BOLT (6X25)	3	
8	09320-12095	CUSHION	1	
9-1	01550-06127	BOLT	1	020,021
9-2	01550-0612C	BOLT (6X12)	1	022
10-1	01550-06257	BOLT (6X25)	4	020,021
10-2	01550-0625C	BOLT (6X25)	4	022
11	33410-93J00	COIL ASSY,IGNITION	6	
12-1	01550-06207	BOLT (6X20)	6	020,021
12-2	01550-0620C	BOLT (6X20)	6	022
13	09408-00021	CLIP (ID:16)	1	

FIG.315A




FIG.315A (1-E-10) SENSOR (X-TRANSOM,XX-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13650-52G00	SENSOR,INLET AIR TEMP	1	
2	13655-87J01	GROMMET,INLET AIR TEMP SNSR	1	
3	29103-93J00	BOLT (6X12)	1	
4	34830-87J20	SENSOR,TEMP	2	EXHAUST TEMP
5	34830-87J20	SENSOR,TEMP	1	CYLINDER TEMP
6	34840-98J03	SENSOR ASSY,TRIM & TILT	1	
7	37820-98J00	SENSOR ASSY,OIL PRESSURE	1	
8	09125-06063	SCREW (6X10)	1	
9	09403-19412	CLAMP	1	
10	29404-93J11	CLAMP (L:65)	1	
11	09407-14407	CLAMP (L:145)	2	
12	34841-88L01	LEVER,TRIM SENSOR	1	
13	34845-88L02	BRACKET,TRIM SENSOR	1	
14	09140-05005	.NUT (M5)	1	
15	09125-05048	SCREW (5X16)	1	
16	09160-05029	WASHER (5.5X12X0.8)	1	
17	09103-06093	BOLT (6X20)	2	
18	18213-98J30	SENSOR,OXYGEN	1	
19	09403-07340	CLAMP	1	
20	11218-98J02	HOLDER,TEMP SENSOR	1	
21	11219-98J00	HOLDER,OIL SENSOR	1	
22	34830-98J00	SENSOR ASSY,OIL TEMP	1	

FIG.315B




FIG.315B (1-E-11) SENSOR (L-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13650-52G00	SENSOR,INLET AIR TEMP	1	
2	13655-87J01	GROMMET,INLET AIR TEMP SNSR	1	
3	29103-93J00	BOLT (6X12)	1	
4	34830-87J20	SENSOR,TEMP	2	EXHAUST TEMP
5	34830-87J20	SENSOR,TEMP	1	CYLINDER TEMP
6	34840-98J11	SENSOR ASSY,TRIM	1	
7	37820-98J00	SENSOR ASSY,OIL PRESSURE	1	
8	29103-93J00	BOLT (6X12)	1	
9	09403-19412	CLAMP	1	
10	29404-93J21	CLAMP (L:80)	1	
11	09407-14407	CLAMP (L:145)	2	
12	34841-96J00	LEVER,TRIM SENSOR	1	
13	34845-96J00	BRACKET,TRIM SENSOR	1	
14	09125-05048	SCREW (5X16)	1	
15	09160-05029	WASHER (5.5X12X0.8)	1	
16	09103-06093	BOLT (6X20)	2	
17	18213-98J30	SENSOR,OXYGEN	1	
18	09403-07340	CLAMP	1	
19	11218-98J02	HOLDER,TEMP SENSOR	1	
20	11219-98J00	HOLDER,OIL SENSOR	1	
21	34830-98J00	SENSOR ASSY,OIL TEMP	1	
22	34813-93J00	PROTECTOR,LEAD WIRE	1	
23	36611-96J01	WIRE,TRIM SENSOR	1	
24	43117-96J00	CAM,TRIM SENDER	1	
25	09116-05010	BOLT (5X12)	2	
26	43118-96J00	PLATE,TRIM SENDER CAM	1	

FIG.322A




FIG.322A (1-E-12) HARNESS

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-98J01	CABLE ASSY,STARTER MOTOR (L:4000)	1	
2	08316-10087	NUT	1	
3-1	36610-98J81	HARNESS ASSY,WIRING	1	020 ->36610-98J82+09407-14407 FROM 25003P040001 UPTO 25003P041020 FROM 30002P040001 UPTO 30002P042865
3-2	36610-98J82	HARNESS ASSY,WIRING	1	020,021 FROM 25003P041021 FROM 30002P042866
3-3	36610-98JA0	HARNESS ASSY,WIRING	1	022
4	09481-10504	.FUSE (10A)	2	
5	36612-98J10	.CONNECTOR,SELECT TERMINAL	1	
6	36721-98L10	.O RING,UPR COVER	1	
7	36737-98L00	.PULLER,FUSE	1	
8	36738-98L00	.COVER,FUSE CASE UPPER	1	
9	09320-08510	.CUSHION (8.5X20X8)	2	
10	38860-76F01	.RELAY ASSY	1	FOR ENG CONTROL UNIT
11	38860-76F01	.RELAY ASSY	1	FOR STARTER MOTOR
12	09481-15504	.FUSE (15A)	4	
13	09481-30504	.FUSE (30A)	3	
14	09481-40403	.FUSE (40A)	1	
15	09481-60403	.FUSE (60A)	2	
16	36612-96J01	.CAP,TERMINAL	1	020,021
17	08310-00067	NUT	1	
18	08321-01067	WASHER,LOCK	1	
19	36617-93J00	BRACKET,HARNESS	4	
20	36617-93J10	BRACKET,HARNESS	8	
21	36617-98J00	BRACKET,HARNESS	1	
22	01550-0612C	BOLT (6X12)	13	
23	09403-20308	CLAMP	1	
24-1	09407-14407	CLAMP (L:145)	4	FROM 25003P040001 UPTO 25003P041020

FIG.322A




FIG.322A (1-E-13) HARNESS

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
				FROM 30002P040001
				UPTO 30002P042865
24-2	09407-14407	CLAMP (L:145)	5	FROM 25003P041021
				FROM 30002P042866
25-1	09408-00008	CLIP (ID:20)	3	FROM 25003P040001
				UPTO 25003P041020
				FROM 30002P040001
				UPTO 30002P042865
25-2	09408-00008	CLIP (ID:20)	2	FROM 25003P041021
				FROM 30002P042866
26	09408-00184	CLAMP	3	
27	09408-00012	CLIP (ID:11.5)	1	
28	09408-00024	CLIP (ID:23)	2	
29	01550-06127	BOLT	1	

FIG.326A




FIG.326A (1-E-14) PTT SWITCH/ENGINE CONTROL UNIT (DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13580-98J03	SENSOR ASSY,SHIFT POSITION	1	
2	13575-40F00	.O RING	1	
3	37729-96L00	LEVER,SHIFT SENSOR	1	
4	09160-05029	WASHER (5.5X12X0.8)	1	
5	07130-05167	BOLT	1	
6	08321-0105A	WASHER,LOCK	1	
7	37721-93J00	SWITCH ASSY,NEUTRAL	1	
8	09137-04004	SCREW (4X16)	2	
9	09407-10404	CLAMP (L:100)	2	
10	37725-93J11	COVER,SWITCH ASSY	1	
11	37850-92J00	SWITCH ASSY,PTT	1	
12	37856-92J00	.TAPE,PTT SWITCH	1	
13	37857-92J01	BUSH,PTT SWITCH	1	
14	09403-11328	CLAMP	1	
15-1	01550-06127	BOLT	1	020,021
15-2	01550-0612C	BOLT (6X12)	1	022
16	37722-93J13	SWITCH ASSY,TILT LIMIT	1	
17-1	09407-14407	CLAMP (L:145)	1	L-TRANSOM
17-2	09403-09330	CLAMP	1	X-TRANSOM,XX-TRANSOM
18	29125-93J00	SCREW (6X12)	1	X-TRANSOM,XX-TRANSOM
19	38410-93J12	RELAY ASSY,PTT	1	
20	38415-93J00	HOLDER,PTT RELAY	1	
21	01550-06127	BOLT	1	
22	09407-30401	CLAMP (L:300)	1	
23-1	33930-98JE0	UNIT,ENGINE CONTROL	1	L-TRANSOM:(020,021)
23-2	33930-98JH0	UNIT,ENGINE CONTROL	1	L-TRANSOM:022
23-3	33930-98JC0	UNIT,ENGINE CONTROL	1	(X-TRANSOM,XX-TRANSOM):(020,021)
23-4	33930-98JF0	UNIT,ENGINE CONTROL	1	(X-TRANSOM,XX-TRANSOM):022
24	33925-98J00	CUSHION,ENGINE CONTROL UNIT	1	
25	38890-98J12	ACTUATOR ASSY,SHIFT	1	
26	38892-98J01	DAMPER,SHIFT ACTUATOR	1	
27	38895-98J00	BRACKET,SHIFT ACTUATOR	1	
28-1	01550-06167	BOLT (6X16)	2	020,021
28-2	01550-0616C	BOLT (6X16)	2	022
29	01550-06357	BOLT (6X35)	3	

DF300A_E11_022_326A
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326A




FIG.326A (1-E-15) PTT SWITCH/ENGINE CONTROL UNIT (DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
30	38860-76F01	RELAY ASSY	2	
31	38915-90J00	HOLDER,RELAY	2	

DF300A_E11_022_326A
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326B




FIG.326B (1-E-16) PTT SWITCH/ENGINE CONTROL UNIT (DF250A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13580-98J03	SENSOR ASSY,SHIFT POSITION	1	
2	13575-40F00	.O RING	1	
3	37729-96L00	LEVER,SHIFT SENSOR	1	
4	09160-05029	WASHER (5.5X12X0.8)	1	
5	07130-05167	BOLT	1	
6	08321-0105A	WASHER,LOCK	1	
7	37721-93J00	SWITCH ASSY,NEUTRAL	1	
8	09137-04004	SCREW (4X16)	2	
9	09407-10404	CLAMP (L:100)	2	
10	37725-93J11	COVER,SWITCH ASSY	1	
11	37850-92J00	SWITCH ASSY,PTT	1	
12	37856-92J00	.TAPE,PTT SWITCH	1	
13	37857-92J01	BUSH,PTT SWITCH	1	
14	09403-11328	CLAMP	1	
15-1	01550-06127	BOLT	1	020,021
15-2	01550-0612C	BOLT (6X12)	1	022
16	37722-93J13	SWITCH ASSY,TILT LIMIT	1	
17	09403-09330	CLAMP	1	
18	29125-93J00	SCREW (6X12)	1	
19	38410-93J12	RELAY ASSY,PTT	1	
20	38415-93J00	HOLDER,PTT RELAY	1	
21	01550-06127	BOLT	1	
22	09407-30401	CLAMP (L:300)	1	
23-1	33930-98JD0	UNIT,ENGINE CONTROL	1	020,021
23-2	33930-98JG0	UNIT,ENGINE CONTROL	1	022
24	33925-98J00	CUSHION,ENGINE CONTROL UNIT	1	
25	38890-98J12	ACTUATOR ASSY,SHIFT	1	
26	38892-98J01	DAMPER,SHIFT ACTUATOR	1	
27	38895-98J00	BRACKET,SHIFT ACTUATOR	1	
28-1	01550-06167	BOLT (6X16)	2	020,021
28-2	01550-0616C	BOLT (6X16)	2	022
29	01550-06357	BOLT (6X35)	3	
30	38860-76F01	RELAY ASSY	2	
31	38915-90J00	HOLDER,RELAY	2	

DF300A_E11_022_326B
PTT SWITCH/ENGINE CONTROL UNIT

FIG.331A





FIG.331A (1-F-2) KEY LESS START (020:(E01,E03),021:E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32851-93J00	CUSHION,LEAD WIRE	1	
2	32980-38F00	CUSHION,CDI UNIT	1	
3	36623-96L02	HARNESS ASSY,KLS CONTROLLER	1	
4	36615-96300	.TERMINAL	1	
5	36662-96L01	HARNESS ASSY,KLS CAN (L:6500+110)	1	
6	37117-96L00	DECAL,KLS	2	
7-1	37171-96L02	CONTROLLER ASSY,KLS (433MHZ)	1	
7-2	37171-96L12	CONTROLLER ASSY,KLS (315MHZ)	1	020:E03,021:E11
8-1	37172-96L01	REMOCON ASSY,KLS (433MHZ)	2	
8-2	37172-96L10	REMOCON ASSY,KLS (315MHZ)	2	020:E03,021:E11
9	37173-96L10	HOLDER,KLS PARTS	1	
10	38500-93J90	BUZZER,WARNING	1	
11	38860-96L01	RELAY ASSY,KLS	1	
12	09407-14407	CLAMP (L:145)	1	

FIG.331B






FIG.331B (1-F-3) KEY LESS START (022:E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32851-93J00	CUSHION,LEAD WIRE	1	
2	32980-38F00	CUSHION,CDI UNIT	1	
3	36623-98LA0	HARNESS ASSY,KLS CONT	1	
4	37117-96L00	DECAL,KLS	2	
5-1	37171-98L00	CONTROLLER ASSY,KLS 433 (433MHZ)	1	
5-2	37171-98L10	CONTROLLER ASSY,KLS 315 (315MHZ)	1	
6-1	37172-96L02	REMOCON ASSY,KLS 433	2	433MHZ
6-2	37172-96L11	REMOCON ASSY,KLS 315	2	315MHZ
7	37173-96L10	HOLDER,KLS PARTS	1	
8	38860-96L01	RELAY ASSY,KLS	1	
9	09407-14407	CLAMP (L:145)	1	

FIG.335A




FIG.335A (1-F-4) CLAMP BRACKET (X-TRANSOM,XX-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	41111-93J16-YAY	BRACKET,CLAMP STBD (BLACK)	1	020 STBD BODY COLOR:YAY
1-2	41111-93J16-Y5S	BRACKET,CLAMP STBD (WHITE)	1	020 STBD BODY COLOR:Y5S
1-3	41111-93J16-QTN	BRACKET,CLAMP STBD (WHITE)	1	021,022 STBD BODY COLOR:QTN
1-4	41111-93J16-YAY	BRACKET,CLAMP STBD (BLACK)	1	021,022 STBD BODY COLOR:YAY
2-1	41121-93J08-YAY	BRACKET,CLAMP PORT (BLACK)	1	020 PORT BODY COLOR:YAY
2-2	41121-93J08-Y5S	BRACKET,CLAMP PORT (WHITE)	1	020 PORT BODY COLOR:Y5S
2-3	41121-93J08-QTN	BRACKET,CLAMP PORT (WHITE)	1	021,022 PORT BODY COLOR:QTN
2-4	41121-93J08-YAY	BRACKET,CLAMP PORT (BLACK)	1	021,022 PORT BODY COLOR:YAY
3	41117-93J02	PLATE,CLAMP BRACKET LWR STBD	1	STBD
4	41122-93J02	PLATE,CLAMP BRACKET LWR PORT	1	PORT
5	09125-06063	SCREW (6X10)	4	
6	41130-93J12	SHAFT,CLAMP BRACKET	1	
7	41135-93J11	WASHER,CLAMP BRACKET SHAFT	1	
8	09159-22006	NUT (M22)	1	
9-1	09100-12086	BOLT (12.7X150)	6	
9-2	09100-12085	BOLT (12.7X115)	1	OPT
9-3	09100-12092	BOLT (12.7X75)	1	OPT
10	09159-12062	NUT (12.7X19)	6	
11	09160-13022	WASHER (13.2X45X3)	4	

FIG.335A




FIG.335A (1-F-5) CLAMP BRACKET (X-TRANSOM,XX-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
12	09160-13021	WASHER (13.2X26X3)	6	
13	41155-93J02	PLATE,TRANSOM	2	
14	55320-94900	ANODE SET,CLAMP BRACKET	1	
15	09116-06121	.BOLT (6X25)	2	
16	45421-87D03	PIN,TILT LOCK	1	
17	09159-14020	NUT	2	
18	48140-93J01	CAM ASSY,TILT LIMIT SWITCH	1	
19	48144-93J00	HOLDER,TILT LIMIT SWITCH	1	
20	09103-06278	BOLT (6X25)	2	
21	55321-94910	ANODE (MAGNESIUM)	1	OPT
22	48145-93J00	COVER,TILT LIMIT SWITCH	1	
23	36894-87D00	LEAD (L:165)	1	CLAMP TO SWIVEL
24	09125-06063	SCREW (6X10)	2	

FIG.335B




FIG.335B (1-F-6) CLAMP BRACKET (L-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	41111-96J40-YAY	BRACKET,CLAMP STBD (BLACK)	1	020 STBD BODY COLOR:YAY
1-2	41111-96J40-Y5S	BRACKET,CLAMP STBD (WHITE)	1	020 STBD BODY COLOR:Y5S
1-3	41111-96J40-QTN	BRACKET,CLAMP STBD (WHITE)	1	021,022 STBD BODY COLOR:QTN
1-4	41111-96J40-YAY	BRACKET,CLAMP STBD (BLACK)	1	021,022 STBD BODY COLOR:YAY
2-1	41121-96J30-YAY	BRACKET,CLAMP PORT (BLACK)	1	020 PORT BODY COLOR:YAY
2-2	41121-96J30-Y5S	BRACKET,CLAMP PORT (WHITE)	1	020 PORT BODY COLOR:Y5S
2-3	41121-96J30-QTN	BRACKET,CLAMP PORT (WHITE)	1	021,022 PORT BODY COLOR:QTN
2-4	41121-96J30-YAY	BRACKET,CLAMP PORT (BLACK)	1	021,022 PORT BODY COLOR:YAY
3	41130-92J03	SHAFT,CLAMP BRACKET	1	
4	41135-92J00	WASHER,CLAMP BRACKET SHAFT	1	
5	09159-22006	NUT (M22)	1	
6-1	09100-12086	BOLT (12.7X150)	6	
6-2	09100-12085	BOLT (12.7X115)	1	OPT
6-3	09100-12092	BOLT (12.7X75)	1	OPT
7	09159-12062	NUT (12.7X19)	6	
8	09160-13021	WASHER (13.2X26X3)	6	
9	09160-13022	WASHER (13.2X45X3)	4	
10	41155-93J02	PLATE,TRANSOM	2	
11	55320-94900	ANODE SET,CLAMP BRACKET	1	

FIG.335B




FIG.335B (1-F-7) CLAMP BRACKET (L-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
12	09116-06121	.BOLT (6X25)	2	
13	48140-93J01	CAM ASSY,TILT LIMIT SWITCH	1	
14	48144-93J00	HOLDER,TILT LIMIT SWITCH	1	
15	09103-06278	BOLT (6X25)	2	
16	48145-93J00	COVER,TILT LIMIT SWITCH	1	
17	55321-94910	ANODE (MAGNESIUM)	1	OPT
18	41117-93L00	PLATE,CLAMP BRACKET LWR STBD	1	STBD
19	41122-93L00	PLATE,CLAMP BRACKET LWR PORT	1	PORT
20	03542-0516C	SCREW,CLAMP BRACKET LWR PLATE	4	
21	09160-05053	WASHER,LOWER PLATE SCREW	4	

DF300A_E11_022_335B
CLAMP BRACKET

FIG.336A




FIG.336A (1-F-8) SWIVEL BRACKET (X-TRANSOM,XX-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE,GREASE	4	
2	36894-87D00	LEAD (L:165)	1	SWIVEL TO MOUNT BRKT
3-1	43111-93J24-YAY	BRACKET,SWIVEL (BLACK)	1	020 BODY COLOR:YAY
3-2	43111-93J24-Y5S	BRACKET,SWIVEL (WHITE)	1	020 BODY COLOR:Y5S
3-3	43111-93J24-QTN	BRACKET,SWIVEL (WHITE)	1	021,022 BODY COLOR:QTN
3-4	43111-93J24-YAY	BRACKET,SWIVEL (BLACK)	1	021,022 BODY COLOR:YAY
4	43114-93J00	WASHER,SWIVEL TO CLAMP BRKT	2	
5	43211-93J11	BUSH,CLAMP SHAFT SWIVEL	2	
6	43711-97E11	BUSH,STEERING	2	
7-1	43750-93J03-YAY	BRACKET,STEERING (BLACK)	1	020 BODY COLOR:YAY
7-2	43750-93J03-Y5S	BRACKET,STEERING (WHITE)	1	020 BODY COLOR:Y5S
7-3	43750-93J03-QTN	BRACKET,STEERING (WHITE)	1	021,022 BODY COLOR:QTN
7-4	43750-93J03-YAY	BRACKET,STEERING (BLACK)	1	021,022 BODY COLOR:YAY
8	09125-06063	SCREW (6X10)	1	
9	09160-39001	WASHER (39.5X64X1.0)	2	
10	09181-39001	SHIM (39.5X64X0.30)	AR	
11	09282-39001	OIL SEAL (39X51X5)	1	
12	09380-38003	CIRCLIP	1	
13	41220-93J11	LEVER,TILT LOCK	1	
14	41234-93J11	LEVER,TILT LOCK PORT	1	PORT
15	41224-95E01	BUSH,TILT STOPPER ROD	2	
16	41230-96J00	LINK,TILT LOCK LEVER	1	
17	41233-95E10	BRACKET,TILT LOCK SPRING	1	
18	09125-06063	SCREW (6X10)	1	
19	09140-10032	NUT (M10)	1	
20	09160-06082	WASHER (6.5X13X1.0)	1	
21	09204-01006	PIN	1	

DF300A_E11_022_336A
SWIVEL BRACKET

FIG.336A




FIG.336A (1-F-9) SWIVEL BRACKET (X-TRANSOM,XX-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
22	09440-19028	SPRING	1	
23	09443-10043	SPRING	1	

DF300A_E11_022_336A
SWIVEL BRACKET

FIG.336B




FIG.336B (1-F-10) SWIVEL BRACKET (L-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE,GREASE	4	
2	36894-87D00	LEAD (L:165)	1	SWIVEL TO CLAMP
3-1	43111-96J20-YAY	BRACKET,SWIVEL (BLACK)	1	020 BODY COLOR:YAY
3-2	43111-96J20-Y5S	BRACKET,SWIVEL (WHITE)	1	020 BODY COLOR:Y5S
3-3	43111-96J20-QTN	BRACKET,SWIVEL (WHITE)	1	021,022 BODY COLOR:QTN
3-4	43111-96J20-YAY	BRACKET,SWIVEL (BLACK)	1	021,022 BODY COLOR:YAY
4	43211-93J11	BUSH,CLAMP SHAFT SWIVEL	2	
5	43711-97E11	BUSH,STEERING	2	
6-1	43750-96J03-YAY	BRACKET,STEERING (BLACK)	1	020 BODY COLOR:YAY
6-2	43750-96J03-Y5S	BRACKET,STEERING (WHITE)	1	020 BODY COLOR:Y5S
6-3	43750-96J03-QTN	BRACKET,STEERING (WHITE)	1	021,022 BODY COLOR:QTN
6-4	43750-96J03-YAY	BRACKET,STEERING (BLACK)	1	021,022 BODY COLOR:YAY
7	09125-06063	SCREW (6X10)	2	
8	09160-39001	WASHER (39.5X64X1.0)	2	
9	09181-39001	SHIM (39.5X64X0.30)	AR	
10	09380-38003	CIRCLIP	1	
11	09169-28003	WASHER (26.2X52.0X1.0)	2	
12	09282-39001	OIL SEAL (39X51X5)	1	
13	36895-87D10	LEAD (L:310)	1	SWIVEL TO HSG
14	09125-06063	SCREW (6X10)	1	
15	41220-96J10	LEVER,TILT LOCK	1	
16	41234-96J10	LEVER,TILT LOCK PORT	1	PORT
17	41224-95E01	BUSH,TILT STOPPER ROD	2	
18	41230-96J00	LINK,TILT LOCK LEVER	1	
19	41233-95E10	BRACKET,TILT LOCK SPRING	1	
20	09125-06063	SCREW (6X10)	1	
21	09140-10032	NUT (M10)	1	

DF300A_E11_022_336B
SWIVEL BRACKET

FIG.336B




FIG.336B (1-F-11) SWIVEL BRACKET (L-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
22	09160-06082	WASHER (6.5X13X1.0)	1	
23	09204-01006	PIN	1	
24	09440-19028	SPRING	1	
25	09443-10043	SPRING	1	
26	09125-06063	SCREW (6X10)	1	

FIG.337A




FIG.337A (1-F-12) TRIM CYLINDER (X-TRANSOM,XX-TRANSOM)(SEE NOTE 1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-98J10	TRIM ASSY,POWER WITH TILT	1	
2	31281-92J10	.BOLT,THROUGH	4	
3	38100-93J04	.MOTOR ASSY,PTT	1	
4	48500-98J12	.MANIFOLD ASSY	1	
5	48864-98L00	..MANUAL VALVE	1	
6	48320-93J00	..VALVE SET,UP BLOW	1	
7	48582-95E01	..FILTER	1	
8	48605-93J00	..O-RING SET	2	
9	48615-87D00	...RING,BACK UP	4	
10	48610-93J01	..PISTON / RAM	2	
11	48630-98L01	..ROD GUIDE	2	
12	48633-93J00	...O-RING	4	
13	48691-93J00	..CHECK VALVE	1	
14	48400-98J03	.CYLINDER	1	
15	48405-93J00	..O-RING SET	1	
16	48650-93J00	..PISTON,FREE	1	
17	48627-93J00	..O-RING SET	1	
18	48427-87D00	...O-RING,PISTON	1	
19	48572-87J10	.PLUG	1	
20	48585-95E00	.O RING	2	
21	48862-87J20	.BOLT,RESERVOIR	2	
22	48583-95E00	.JOINT,DRIVE	1	
23	48121-93J20	.SHAFT	1	
24	48125-93J10	.O-RING SET	1	
25	48451-93J00	..BACK UP RING	4	
26	48452-93J00	..O-RING	4	
27	48452-93J10	..O-RING	2	

DF300A_E11_022_337A
TRIM CYLNDER

FIG.337A




FIG.337A (1-F-15) TRIM CYLINDER (X-TRANSOM,XX-TRANSOM)(SEE NOTE 1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	48126-93J00	.WASHER,TILT CYL TO MANIFOLD	2	
29	48573-93J00	.COVER	1	
30	48128-93J11	.BOLT	1	
31	48571-93J00	.RESERVOIR TANK	1	
32	48311-96J10	PAD,TRIM CYLINDER RAM	2	
33	48321-93J00	SHAFT,TILT CYL UPPER	1	
34	09140-10031	NUT (M10)	2	
35	09162-10005	WASHER,LOCK (10.2X18.4X2.5)	2	
36	09306-24001	BUSH	2	
37	09380-21002	CIRCLIP	2	
38	09116-10175	BOLT (10X50)	8	
39	36894-87D00	LEAD (L:165)	1	
40	36895-87D01	LEAD (L:230)	1	
41	36895-87D01	LEAD (L:230)	1	
42	09125-06063	SCREW (6X10)	1	
43	09125-06063	SCREW (6X10)	1	
44	09125-06063	SCREW (6X10)	1	

NOTE 1:
FROM 25003P-040001 UPTO 25003P-041020
FROM 30002P-040001 UPTO 30002P-042865

DF300A_E11_022_337A
TRIM CYLNDER

FIG.337B




FIG.337B (1-G-3) TRIM CYLINDER (X-TRANSOM,XX-TRANSOM)(SEE NOTE 1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-98J11	TRIM ASSY,POWER WITH TILT	1	
2	31281-92J10	.BOLT,THROUGH	4	
3	38100-93J04	.MOTOR ASSY,PTT	1	
4	48500-98J12	.MANIFOLD ASSY	1	
5	48864-98L00	..MANUAL VALVE	1	
6	48320-93J00	..VALVE SET,UP BLOW	1	
7	48582-95E01	..FILTER	1	
8	48605-93J00	..O-RING SET	2	
9	48615-87D00	...RING,BACK UP	4	
10	48610-93J01	..PISTON / RAM	2	
11	48630-98L01	..ROD GUIDE	2	
12	48633-93J00	...O-RING	4	
13	48691-93J00	..CHECK VALVE	1	
14	48400-98J03	.CYLINDER	1	
15	48405-93J00	..O-RING SET	1	
16	48650-93J00	..PISTON,FREE	1	
17	48627-93J00	..O-RING SET	1	
18	48427-87D00	...O-RING,PISTON	1	
19	48572-87J10	.PLUG	1	
20	48585-95E00	.O RING	1	
21	48585-98L00	.O-RING	1	
22	48862-87J20	.BOLT,RESERVOIR	2	
23	48583-95E00	.JOINT,DRIVE	1	
24	48121-93J20	.SHAFT	1	
25	48125-93J10	.O-RING SET	1	
26	48451-93J00	..BACK UP RING	4	
27	48452-93J00	..O-RING	4	
28	48452-93J10	..O-RING	2	
29	48126-93J00	.WASHER,TILT CYL TO MANIFOLD	2	
30	48573-93J00	.COVER	1	
31	48128-93J11	.BOLT	1	
32	48571-93J00	.RESERVOIR TANK	1	
33	48311-96J10	PAD,TRIM CYLINDER RAM	2	
34	48321-93J00	SHAFT,TILT CYL UPPER	1	
35	09140-10031	NUT (M10)	2	

DF300A_E11_022_337B
TRIM CYLNDER

FIG.337B




FIG.337B (1-G-5) TRIM CYLINDER (X-TRANSOM,XX-TRANSOM)(SEE NOTE 1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
36	09162-10005	WASHER,LOCK (10.2X18.4X2.5)	2	
37	09306-24001	BUSH	2	
38	09380-21002	CIRCLIP	2	
39	09116-10175	BOLT (10X50)	8	
40	36894-87D00	LEAD (L:165)	1	
41	36895-87D01	LEAD (L:230)	1	
42	36895-87D01	LEAD (L:230)	1	
43	09125-06063	SCREW (6X10)	1	
44	09125-06063	SCREW (6X10)	1	
45	09125-06063	SCREW (6X10)	1	

NOTE 1:
FROM 25003P-041021
FROM 30002P-042866

DF300A_E11_022_337B
TRIM CYLNDER

FIG.337C




FIG.337C (1-G-6) TRIM CYLINDER (L-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-93L03	TRIM ASSY,POWER WITH TILT	1	
2	29404-93J01	.CLAMP (L:45)	1	
3	31281-92J10	.BOLT,THROUGH	4	
4	38100-93L01	.MOTOR ASSY,PTT	1	
5	48502-96J05	.PUMP ASSY,PTT	1	
6	48582-95E01	..FILTER	1	
7	48864-96J10	..VALVE SET,MANUAL	1	
8	48503-93L01	.MANIFOLD SUB ASSY	1	
9	48401-93L00	..PISTON ASSY	1	
10	48601-93L00	..PISTON/RAM ASSY	2	
11	48627-95E00	..O-RING SET	3	
12	48630-96J04	..HEAD,TRIM CYLINDER	2	
13	48633-94900	..O-RING SET,HEAD (2PCS)	2	
14	48641-93L01	..MANIFOLD,PTT	1	
15	48650-94900	..PISTON,FREE	1	
16	48405-93J00	...O-RING SET	1	
17	48615-97E00	...RING SET,PISTON	1	
18	48570-95E01	.RESERVOIR ASSY	1	
19	48572-95E00	..CAP	1	
20	48583-95E00	.JOINT,DRIVE	1	
21	48585-95E00	.O RING	1	
22	48588-94900	.O-RING SET (6PCS)	1	
23	48861-92J01	.BOLT,RESERVOIR	3	
24	48862-92J20	.BOLT,PUMP NO.1	1	
25	48862-92J30	.BOLT,PUMP NO.2	2	
26	48121-93L00	SHAFT,TILT CYLINDER LWR	1	
27	09160-10161	WASHER	2	
28	48311-96J20	PAD,TRIM CYLINDER RAM	2	
29	48321-87D03	SHAFT,TILT CYL UPPER	1	
30	48326-95E00	BUSH,TILT CYL LOWER	2	
31	09116-10183	BOLT (10X35)	2	
32	09140-10031	NUT (M10)	2	
33	09162-10005	WASHER,LOCK (10.2X18.4X2.5)	2	
34	09306-17001	BUSH	2	
35	09380-17009	CIRCLIP	2	

FIG.337C





FIG.337C (1-G-7) TRIM CYLINDER (L-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
36	36894-87D00	LEAD (L:165)	1	PTT TO ANODE
37	09125-06063	SCREW (6X10)	1	
38	09125-05050	SCREW (5X8)	1	
39	36895-87D10	LEAD (L:310)	1	PTT TO ANODE L

FIG.340A




DF300A_E11_022_340A
PTT MOTOR

FIG.340A (1-G-8) PTT MOTOR (X-TRANSOM,XX-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-93J04	MOTOR ASSY,PTT	1	
2	31111-94900	.SCREW	3	
3	31173-94920	.HOLDER ASSY,BRUSH	1	
4	31123-94910	..O RING	1	
5	31133-90J10	..BRUSH ASSY	1	
6	31133-94910	...BRUSH	1	
7	31135-94900	..SPRING	2	
8	31136-90J20	..BREAKER ASSY	1	
9	33799-97E00	..SEAL,OIL	1	
10	31311-93J00	.ARMATURE	1	

FIG.340B



DF300A_E11_022_340B
PTT MOTOR

FIG.340B (1-G-9) PTT MOTOR (L-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-93L01	MOTOR ASSY,PTT	1	
2	31111-94900	.SCREW	3	
3	31173-94920	.HOLDER ASSY,BRUSH	1	
4	31123-94910	..O RING	1	
5	31133-90J10	..BRUSH ASSY	1	
6	31133-94910	...BRUSH	1	
7	31135-94900	..SPRING	2	
8	31136-90J20	..BREAKER ASSY	1	
9	33799-97E00	..SEAL,OIL	1	
10	31311-94900	.ARMATURE	1	

FIG.401A




FIG.401A (1-G-10) ENGINE HOLDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	51111-93J31-YAY	HOLDER,ENGINE (BLACK)	1	020 BODY COLOR:YAY
1-2	51111-93J31-Y5S	HOLDER,ENGINE (WHITE)	1	020 BODY COLOR:Y5S
1-3	51111-93J31-YAY	HOLDER,ENGINE (BLACK)	1	021 BODY COLOR:YAY
1-4	51111-93J31-Y5S	HOLDER,ENGINE (WHITE)	1	021 BODY COLOR:QTN
1-5	51111-93J40-YAY	HOLDER,ENGINE (BLACK)	1	022 BODY COLOR:YAY
1-6	51111-93J40-Y5S	HOLDER,ENGINE (WHITE)	1	022 BODY COLOR:QTN
2	16519-93J00	SEAL,ENGINE HOLDER OIL	1	
3	17913-93J00	PLUG,WATER	1	
4	17914-93J01	GASKET,WATER PLUG	1	
5	51116-93J01	SEAL,WATER RETURN	1	
6	51211-93J00	GASKET,ENGINE HOLDER	1	
7	61155-93J20	PIPE,WATER INDICATOR	1	
8	09206-08001	PIN (8X11)	2	
9	01550-08307	BOLT	6	
10	22511-99011	NIPPLE,GREASE	1	
11	51120-98L00	COVER,MOUNT OIL SEAL	1	
12	51124-93J01	.SEAL,OIL	2	
13	51125-93J00	.SCRAPER	1	
14	51123-93J01	GASKET,MOUNT OIL SEAL COVER	1	
15	09103-08109	BOLT (8X120)	2	
16	09206-08001	PIN (8X11)	2	
17	01550-0830A	BOLT (8X30)	6	
18-1	51140-93J11-YAY	COVER,ENGINE HOLDER (BLACK)	1	020:L-TRANSOM BODY COLOR:YAY
18-2	51140-98J00-YAY	COVER,ENGINE HOLDER (BLACK)	1	020:(X-TRANSOM,XX-TRANSOM) BODY COLOR:YAY
18-3	51140-93J11-Y5S	COVER,ENGINE HOLDER (WHITE)	1	020:L-TRANSOM BODY COLOR:Y5S
18-4	51140-98J00-Y5S	COVER,ENGINE HOLDER (WHITE)	1	020:(X-TRANSOM,XX-TRANSOM)

DF300A_E11_022_401A
ENGINE HOLDER

FIG.401A




FIG.401A (1-G-11) ENGINE HOLDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
				BODY COLOR:Y5S
18-5	51140-93J11-QTN	COVER,ENGINE HOLDER (WHITE)	1	(021,022):L-TRANSOM
				BODY COLOR:QTN
18-6	51140-98J00-QTN	COVER,ENGINE HOLDER (WHITE)	1	(021,022):(X-TRANSOM,XX-TRANSOM)
				BODY COLOR:QTN
18-7	51140-93J11-YAY	COVER,ENGINE HOLDER (BLACK)	1	(021,022):L-TRANSOM
				BODY COLOR:YAY
18-8	51140-98J00-YAY	COVER,ENGINE HOLDER (BLACK)	1	(021,022):(X-TRANSOM,XX-TRANSOM)
				BODY COLOR:YAY
19	51142-93J00	GASKET,ENGINE HOLDER COVER	1	
20	09116-08122	BOLT (8X30)	8	
21	51151-93J00	COVER,ENGINE HOLDER UPPER	1	
22	51152-93J00	SEAL,ENGINE HOLDER UPPER COVER	1	
23	01550-08307	BOLT	3	
24	01550-08607	BOLT	2	
25	54123-93J03	PLATE,UPPER MOUNT	1	
26	54130-93J01	MOUNT,UPPER	2	
27	54112-93J00	BOLT,MOUNT (14X220)	2	
28	29159-93J00	NUT (M14)	2	
29	09160-15051	WASHER (15X24X3)	2	
30	54137-93J02	COVER,UPPER MOUNT	1	
31	09116-10135	BOLT (10X95)	2	
32	09116-10175	BOLT (10X50)	1	
33-1	54121-98J01	STOPPER,UPR THRUST	2	X-TRANSOM,XX-TRANSOM
33-2	54121-93J20	STOPPER,UPPER THRUST	2	L-TRANSOM
34	54140-98J01	MOUNT,UPPER THRUST REV	1	
35	09116-10137	BOLT (10X70)	6	
36	09116-10175	BOLT (10X50)	4	
37	09116-10146	BOLT (10X195)	2	
38	09116-10134	BOLT (10X115)	1	
39	09116-08126	BOLT (8X65)	4	
40	09169-08038	WASHER (8.3X15X3)	2	
41	54144-93J01	SEAL,UPPER MOUNT	1	

FIG.405A




FIG.405A (1-G-12) DRIVE SHAFT HOUSING (X-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	52111-98J00-YAY	HOUSING,DRIVE SHAFT (BLACK)	1	020 BODY COLOR:YAY
1-2	52111-98J00-Y5S	HOUSING,DRIVE SHAFT (WHITE)	1	020 BODY COLOR:Y5S
1-3	52111-98J00-QTN	HOUSING,DRIVE SHAFT (WHITE)	1	021,022 BODY COLOR:QTN
1-4	52111-98J00-YAY	HOUSING,DRIVE SHAFT (BLACK)	1	021,022 BODY COLOR:YAY
2	09116-10176	BOLT (10X44)	8	
3	09202-08006	PIN (8X12)	2	
4	57130-87D10	BUSH,DRIVE SHAFT	1	
5	09387-38002	RING	1	
6	09125-06063	SCREW (6X10)	1	
7	36894-87D00	LEAD (L:165)	1	MT BRKT TO HSG
8	09125-06063	SCREW (6X10)	1	
9	54150-98J01	MOUNT,LOWER THRUST	1	
10	54160-98J00	MOUNT,LOWER	2	
11	54112-93J00	BOLT,MOUNT (14X220)	2	
12	09160-16050	WASHER (16X32X3)	2	
13	29159-93J00	NUT (M14)	2	
14	09160-16050	WASHER (16X32X3)	2	
15-1	54211-93J00-YAY	BRACKET,LWR MOUNT (BLACK)	1	020 BODY COLOR:YAY
15-2	54211-93J00-Y5S	BRACKET,LOWER MOUNT (WHITE)	1	020 BODY COLOR:Y5S
15-3	54211-93J00-QTN	BRACKET,LWR MOUNT (WHITE)	1	021,022 BODY COLOR:QTN
15-4	54211-93J00-YAY	BRACKET,LWR MOUNT (BLACK)	1	021,022 BODY COLOR:YAY
16-1	54221-93J00-YAY	COVER,LWR MOUNT (BLACK)	2	020 BODY COLOR:YAY
16-2	54221-93J00-Y5S	COVER,LOWER MOUNT (WHITE)	2	020 BODY COLOR:Y5S
16-3	54221-93J00-QTN	COVER,LWR MOUNT (WHITE)	2	021 BODY COLOR:QTN

FIG.405A




FIG.405A (1-G-13) DRIVE SHAFT HOUSING (X-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
16-4	54221-93J00-YAY	COVER,LWR MOUNT (BLACK)	2	021 BODY COLOR:YAY
16-5	54221-93J00	COVER,LOWER MOUNT	2	022
17	09116-10175	BOLT (10X50)	4	
18	54165-98J01	STOPPER,LWR THRUST REVERSE	4	
19	09160-14066	WASHER (14X50X4)	2	
20	55321-93J01	ANODE,PROTECTION	1	
21	09116-06236	BOLT (6X16)	1	

FIG.405B




FIG.405B (1-G-14) DRIVE SHAFT HOUSING (XX-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	52111-98J00-YAY	HOUSING,DRIVE SHAFT (BLACK)	1	020 BODY COLOR:YAY
1-2	52111-98J00-Y5S	HOUSING,DRIVE SHAFT (WHITE)	1	020 BODY COLOR:Y5S
1-3	52111-98J00-QTN	HOUSING,DRIVE SHAFT (WHITE)	1	021,022 BODY COLOR:QTN
1-4	52111-98J00-YAY	HOUSING,DRIVE SHAFT (BLACK)	1	021,022 BODY COLOR:YAY
2	09116-10176	BOLT (10X44)	8	
3	09202-08006	PIN (8X12)	2	
4	57130-87D10	BUSH,DRIVE SHAFT	1	
5	09387-38002	RING	1	
6	09125-06063	SCREW (6X10)	1	
7-1	52131-93J00-YAY	CASE,EXTENSION (BLACK)	1	020 BODY COLOR:YAY
7-2	52131-93J00-Y5S	CASE,EXTENSION (WHITE)	1	020 BODY COLOR:Y5S
7-3	52131-93J00-QTN	CASE,EXTENSION (WHITE)	1	021,022 BODY COLOR:QTN
7-4	52131-93J00-YAY	CASE,EXTENSION (BLACK)	1	021,022 BODY COLOR:YAY
8	09108-10115	BOLT,STUD (10X167)	6	
9	09108-12013	BOLT,STUD	1	
10	09202-08006	PIN (8X12)	2	
11	36894-87D00	LEAD (L:165)	1	MT BRKT TO HSG
12	09125-06063	SCREW (6X10)	1	
13	54150-98J01	MOUNT,LOWER THRUST	1	
14	54160-98J00	MOUNT,LOWER	2	
15	54112-93J00	BOLT,MOUNT (14X220)	2	
16	09160-16050	WASHER (16X32X3)	2	
17	29159-93J00	NUT (M14)	2	
18	09160-16050	WASHER (16X32X3)	2	
19-1	54211-93J00-YAY	BRACKET,LWR MOUNT (BLACK)	1	020 BODY COLOR:YAY
19-2	54211-93J00-Y5S	BRACKET,LOWER MOUNT (WHITE)	1	020

FIG.405B




FIG.405B (1-G-15) DRIVE SHAFT HOUSING (XX-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
				BODY COLOR:Y5S
19-3	54211-93J00-QTN	BRACKET,LWR MOUNT (WHITE)	1	021,022
				BODY COLOR:QTN
19-4	54211-93J00-YAY	BRACKET,LWR MOUNT (BLACK)	1	021,022
				BODY COLOR:YAY
20-1	54221-93J00-YAY	COVER,LWR MOUNT (BLACK)	2	020
				BODY COLOR:YAY
20-2	54221-93J00-Y5S	COVER,LOWER MOUNT (WHITE)	2	020
				BODY COLOR:Y5S
20-3	54221-93J00-QTN	COVER,LWR MOUNT (WHITE)	2	021
				BODY COLOR:QTN
20-4	54221-93J00-YAY	COVER,LWR MOUNT (BLACK)	2	021
				BODY COLOR:YAY
20-5	54221-93J00	COVER,LOWER MOUNT	2	022
21	09116-10175	BOLT (10X50)	4	
22	54165-98J01	STOPPER,LWR THRUST REVERSE	4	
23	09160-14066	WASHER (14X50X4)	2	
24	55321-93J01	ANODE,PROTECTION	2	
25	09116-06236	BOLT (6X16)	2	

FIG.405C




FIG.405C (1-G-16) DRIVE SHAFT HOUSING (L-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	52111-98J20-YAY	HOUSING,DRIVE SHAFT (BLACK)	1	020 BODY COLOR:YAY
1-2	52111-98J20-Y5S	HOUSING,DRIVE SHAFT (WHITE)	1	020 BODY COLOR:Y5S
1-3	52111-98J20-QTN	HOUSING,DRIVE SHAFT (WHITE)	1	021,022 BODY COLOR:QTN
1-4	52111-98J20-YAY	HOUSING,DRIVE SHAFT (BLACK)	1	021,022 BODY COLOR:YAY
2	09116-10176	BOLT (10X44)	6	
3	09202-08006	PIN (8X12)	2	
4	09140-10031	NUT (M10)	2	
5	09108-10150	BOLT,STUD	2	
6	09160-10141	WASHER (10.5X19X2)	2	
7	09125-06063	SCREW (6X10)	1	
8	54150-98J01	MOUNT,LOWER THRUST	1	
9	54160-98J00	MOUNT,LOWER	2	
10	54112-93J00	BOLT,MOUNT (14X220)	2	
11	09160-16050	WASHER (16X32X3)	2	
12	29159-93J00	NUT (M14)	2	
13	09160-16050	WASHER (16X32X3)	2	
14-1	54211-93J00-YAY	BRACKET,LWR MOUNT (BLACK)	1	020 BODY COLOR:YAY
14-2	54211-93J00-Y5S	BRACKET,LOWER MOUNT (WHITE)	1	020 BODY COLOR:Y5S
14-3	54211-93J00-QTN	BRACKET,LWR MOUNT (WHITE)	1	021,022 BODY COLOR:QTN
14-4	54211-93J00-YAY	BRACKET,LWR MOUNT (BLACK)	1	021,022 BODY COLOR:YAY
15-1	54221-93J00-YAY	COVER,LWR MOUNT (BLACK)	2	020 BODY COLOR:YAY
15-2	54221-93J00-Y5S	COVER,LOWER MOUNT (WHITE)	2	020 BODY COLOR:Y5S
15-3	54221-93J00-QTN	COVER,LWR MOUNT (WHITE)	2	021 BODY COLOR:QTN
15-4	54221-93J00-YAY	COVER,LWR MOUNT (BLACK)	2	021

FIG.405C




FIG.405C (1-H-2) DRIVE SHAFT HOUSING (L-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
				BODY COLOR:YAY
15-5	54221-93J00	COVER,LOWER MOUNT	2	022
16	09116-10175	BOLT (10X50)	4	
17	54165-98J01	STOPPER,LWR THRUST REVERSE	4	
18	09160-14066	WASHER (14X50X4)	2	
19	36894-87D00	LEAD (L:165)	1	MT BRKT TO HSG
20	09125-06063	SCREW (6X10)	1	

FIG.407A




FIG.407A (1-H-3) GEAR CASE (E01,E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55110-93L20-YAY	CASE,GEAR (BLACK)	1	(E01,E40):020 BODY COLOR:YAY
1-2	55110-93L20-Y5S	CASE,GEAR (WHITE)	1	(E01,E40):020 BODY COLOR:Y5S
1-3	55110-93L20-QTN	CASE,GEAR (WHITE)	1	E40:(021,022) BODY COLOR:QTN
1-4	55110-93L20-YAY	CASE,GEAR (BLACK)	1	E40:(021,022) BODY COLOR:YAY
2	09263-35048	.BEARING (35X56X37)	1	
3	09263-80001	.BEARING (80X100X30)	1	
4	09100-12052	BOLT (12X70)	1	(E01,E40):X-TRANSOM
5	09116-10150	BOLT (10X55)	6	(E01,E40):X-TRANSOM
6	09160-10141	WASHER (10.5X19X2)	6	(E01,E40):XX-TRANSOM
7	09160-12066	WASHER (12.5X22X2.5)	1	(E01,E40):X-TRANSOM
8	09140-10031	NUT (M10)	6	(E01,E40):XX-TRANSOM
9	09159-12014	NUT (12X17)	1	(E01,E40):XX-TRANSOM
10	09202-08006	PIN (8X12)	2	E01,E40
11-1	55125-93L00-YAY	TAB,TRIM (BLACK)	1	(E01,E40):020 BODY COLOR:YAY
11-2	55125-93L00-Y5S	TAB,TRIM (WHITE)	1	(E01,E40):020 BODY COLOR:Y5S
11-3	55125-93L00-QTN	TAB,TRIM (WHITE)	1	E40:(021,022) BODY COLOR:QTN
11-4	55125-93L00-YAY	TAB,TRIM (BLACK)	1	E40:(021,022) BODY COLOR:YAY
12	09116-08137	BOLT (8X22)	1	
13	55128-93J10	PLUG,DRAIN	1	
14	09168-10034	GASKET (9.5X16.5X2)	2	
15	55321-93J01	ANODE,PROTECTION	2	
16	09116-06236	BOLT (6X16)	2	
17	55332-98J01	RUBBER,EXHAUST SEAL	1	
18	55333-98J00	PLATE,EXHAUST SEAL	1	
19	09202-06031	PIN (6X12)	2	
20-1	58700-93L01	PROPELLER (3X16X17)	1	W/REGULAR ROTATION

FIG.407A




FIG.407A (1-H-4) GEAR CASE (E01,E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20-2	58700-93L11	PROPELLER (3X16X18.5)	1	W/REGULAR ROTATION
20-3	58700-93L21	PROPELLER (3X16X20)	1	W/REGULAR ROTATION
20-4	58700-93L31	PROPELLER (3X16X21.5)	1	W/REGULAR ROTATION
20-5	58700-93L41	PROPELLER (3X16X23)	1	W/REGULAR ROTATION
20-6	58700-93L51	PROPELLER (3X16X24.5)	1	W/REGULAR ROTATION
20-7	58700-93L81	PROPELLER (3X16X15)	1	W/REGULAR ROTATION
20-8	58700-93L61	PROPELLER (3X16X26)	1	OPT,W/REGULAR ROTATION
20-9	58700-93L71	PROPELLER (3X16X27.5)	1	OPT,W/REGULAR ROTATION
20-10	58700-93J00	PROPELLER (4X15.25X18)	1	OPT,W/REGULAR ROTATION
20-11	58700-93J10	PROPELLER (4X15.25X20)	1	OPT,W/REGULAR ROTATION
20-12	58700-93J20	PROPELLER (4X15.25X22)	1	OPT,W/REGULAR ROTATION
20-13	58700-93J30	PROPELLER (4X15.25X24)	1	OPT,W/REGULAR ROTATION
20-14	58700-93J40	PROPELLER (4X15.25X26)	1	OPT,W/REGULAR ROTATION
20-15	58800-93L00	PROPELLER (3X16X17)	1	W/COUNTER ROTATION
20-16	58800-93L10	PROPELLER (3X16X18.5)	1	W/COUNTER ROTATION
20-17	58800-93L20	PROPELLER (3X16X20)	1	W/COUNTER ROTATION
20-18	58800-93L30	PROPELLER (3X16X21.5)	1	W/COUNTER ROTATION
20-19	58800-93L40	PROPELLER (3X16X23)	1	W/COUNTER ROTATION

FIG.407A




FIG.407A (1-H-5) GEAR CASE (E01,E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20-20	58800-93L50	PROPELLER (3X16X24.5)	1	OPT,W/COUNTER ROTATION
20-21	58800-93L60	PROPELLER (3X16X26)	1	OPT,W/COUNTER ROTATION
20-22	58800-93J10	PROPELLER (4X15.25X20)	1	OPT,W/COUNTER ROTATION
20-23	58800-93J20	PROPELLER (4X15.25X22)	1	OPT,W/COUNTER ROTATION
20-24	58800-93J30	PROPELLER (4X15.25X24)	1	OPT,W/COUNTER ROTATION
20-25	58800-93J40	PROPELLER (4X15.25X26)	1	OPT,W/COUNTER ROTATION
21	58120-93L00	.BUSH COMP,PROPELLER	1	
22-1	58700-96J00	PROPELLER (3X15.5X17)	1	OPT,W/REGULAR ROTATION
22-2	58700-96J10	PROPELLER (3X15.25X19)	1	OPT,W/REGULAR ROTATION
22-3	58700-96J20	PROPELLER (3X15X21)	1	OPT,W/REGULAR ROTATION
22-4	58700-96J30	PROPELLER (3X14.75X23)	1	OPT,W/REGULAR ROTATION
22-5	58700-96J40	PROPELLER (3X14.5X25)	1	OPT,W/REGULAR ROTATION
22-6	58700-96J50	PROPELLER (3X14.5X27)	1	OPT,W/REGULAR ROTATION
22-7	58800-96J00	PROPELLER (3X15.5X17)	1	OPT,W/COUNTER ROTATION
22-8	58800-96J10	PROPELLER (3X15.25X19)	1	OPT,W/COUNTER ROTATION
22-9	58800-96J20	PROPELLER (3X15X21)	1	OPT,W/COUNTER ROTATION
22-10	58800-96J30	PROPELLER (3X14.75X23)	1	OPT,W/COUNTER ROTATION
22-11	58800-96J40	PROPELLER (3X14.5X25)	1	OPT,W/COUNTER ROTATION

FIG.407A




FIG.407A (1-H-6) GEAR CASE (E01,E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
22-12	58800-96J50	PROPELLER (3X14.5X27)	1	OPT,W/COUNTER ROTATION
23	58120-93L00	.BUSH COMP,PROPELLER	1	OPT
24	57632-93L11	STOPPER,PROPELLER BUSH	1	
25	57633-93L00	SPACER,PROPELLER NUT	1	
26	09141-18005	NUT (M18)	1	
27	09160-18028	WASHER (18.5X31X1.0)	1	
28	09204-03003	PIN (D:3.6,L:25)	1	
29	55128-93L00	PLUG,DRAIN	1	
30	09160-12066	WASHER (12.5X22X2.5)	1	XX-TRANSOM
31	57630-93L00	KIT,PROPELLER NUT	1	OPT
32	25700-93L02	KIT,GEAR CASE SEALING	1	
				OPT,NOT ILLUSTRATED

FIG.407B




FIG.407B (1-H-7) GEAR CASE (E03,E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55110-93L20-YAY	CASE,GEAR (BLACK)	1	E03:020 BODY COLOR:YAY
1-2	55110-93L20-Y5S	CASE,GEAR (WHITE)	1	E03:020 BODY COLOR:Y5S
1-3	55110-93L20-QTN	CASE,GEAR (WHITE)	1	E11:(021,022) BODY COLOR:QTN
1-4	55110-93L20-YAY	CASE,GEAR (BLACK)	1	E11:(021,022) BODY COLOR:YAY
2	09263-35048	.BEARING (35X56X37)	1	
3	09263-80001	.BEARING (80X100X30)	1	
4-1	09100-12052	BOLT (12X70)	1	L-TRANSOM
4-2	09100-12052	BOLT (12X70)	1	X-TRANSOM
5-1	09116-10150	BOLT (10X55)	6	L-TRANSOM
5-2	09116-10150	BOLT (10X55)	6	X-TRANSOM
6	09160-10141	WASHER (10.5X19X2)	6	XX-TRANSOM
7	09160-12066	WASHER (12.5X22X2.5)	1	L-TRANSOM,X-TRANSOM
8	09140-10031	NUT (M10)	6	XX-TRANSOM
9	09159-12014	NUT (12X17)	1	XX-TRANSOM
10	09202-08006	PIN (8X12)	2	
11-1	55125-93L00-YAY	TAB,TRIM (BLACK)	1	E03:020 BODY COLOR:YAY
11-2	55125-93L00-Y5S	TAB,TRIM (WHITE)	1	E03:020 BODY COLOR:Y5S
11-3	55125-93L00-QTN	TAB,TRIM (WHITE)	1	E11:(021,022) BODY COLOR:QTN
11-4	55125-93L00-YAY	TAB,TRIM (BLACK)	1	E11:(021,022) BODY COLOR:YAY
12	09116-08137	BOLT (8X22)	1	
13	55128-93J10	PLUG,DRAIN	1	
14	09168-10034	GASKET (9.5X16.5X2)	2	
15	55321-93J01	ANODE,PROTECTION	2	
16	09116-06236	BOLT (6X16)	2	
17	55332-98J01	RUBBER,EXHAUST SEAL	1	
18	55333-98J00	PLATE,EXHAUST SEAL	1	
19	09202-06031	PIN (6X12)	2	

FIG.407B




FIG.407B (1-H-8) GEAR CASE (E03,E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20-1	58700-93L01	PROPELLER (3X16X17)	1	W/REGULAR ROTATION
20-2	58700-93L11	PROPELLER (3X16X18.5)	1	W/REGULAR ROTATION
20-3	58700-93L21	PROPELLER (3X16X20)	1	W/REGULAR ROTATION
20-4	58700-93L31	PROPELLER (3X16X21.5)	1	W/REGULAR ROTATION
20-5	58700-93L41	PROPELLER (3X16X23)	1	W/REGULAR ROTATION
20-6	58700-93L51	PROPELLER (3X16X24.5)	1	W/REGULAR ROTATION
20-7	58700-93L61	PROPELLER (3X16X26)	1	W/REGULAR ROTATION
20-8	58700-93L71	PROPELLER (3X16X27.5)	1	OPT,W/REGULAR ROTATION
20-9	58700-93L81	PROPELLER (3X16X15)	1	OPT,W/REGULAR ROTATION
20-10	58700-93J00	PROPELLER (4X15.25X18)	1	OPT,W/REGULAR ROTATION
20-11	58700-93J10	PROPELLER (4X15.25X20)	1	OPT,W/REGULAR ROTATION
20-12	58700-93J20	PROPELLER (4X15.25X22)	1	OPT,W/REGULAR ROTATION
20-13	58700-93J30	PROPELLER (4X15.25X24)	1	OPT,W/REGULAR ROTATION
20-14	58700-93J40	PROPELLER (4X15.25X26)	1	OPT,W/REGULAR ROTATION
20-15	58800-93L00	PROPELLER (3X16X17)	1	W/COUNTER ROTATION
20-16	58800-93L10	PROPELLER (3X16X18.5)	1	W/COUNTER ROTATION
20-17	58800-93L20	PROPELLER (3X16X20)	1	W/COUNTER ROTATION
20-18	58800-93L30	PROPELLER (3X16X21.5)	1	W/COUNTER ROTATION

FIG.407B




FIG.407B (1-H-9) GEAR CASE (E03,E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20-19	58800-93L40	PROPELLER (3X16X23)	1	W/COUNTER ROTATION
20-20	58800-93L50	PROPELLER (3X16X24.5)	1	OPT,W/COUNTER ROTATION
20-21	58800-93L60	PROPELLER (3X16X26)	1	OPT,W/COUNTER ROTATION
20-22	58800-93J10	PROPELLER (4X15.25X20)	1	OPT,W/COUNTER ROTATION
20-23	58800-93J20	PROPELLER (4X15.25X22)	1	OPT,W/COUNTER ROTATION
20-24	58800-93J30	PROPELLER (4X15.25X24)	1	OPT,W/COUNTER ROTATION
20-25	58800-93J40	PROPELLER (4X15.25X26)	1	OPT,W/COUNTER ROTATION
21	58120-93L00	.BUSH COMP,PROPELLER	1	
22-1	58700-96J00	PROPELLER (3X15.5X17)	1	OPT,W/REGULAR ROTATION
22-2	58700-96J10	PROPELLER (3X15.25X19)	1	OPT,W/REGULAR ROTATION
22-3	58700-96J20	PROPELLER (3X15X21)	1	OPT,W/REGULAR ROTATION
22-4	58700-96J30	PROPELLER (3X14.75X23)	1	OPT,W/REGULAR ROTATION
22-5	58700-96J40	PROPELLER (3X14.5X25)	1	OPT,W/REGULAR ROTATION
22-6	58700-96J50	PROPELLER (3X14.5X27)	1	OPT,W/REGULAR ROTATION
22-7	58800-96J00	PROPELLER (3X15.5X17)	1	OPT,W/COUNTER ROTATION
22-8	58800-96J10	PROPELLER (3X15.25X19)	1	OPT,W/COUNTER ROTATION
22-9	58800-96J20	PROPELLER (3X15X21)	1	OPT,W/COUNTER ROTATION
22-10	58800-96J30	PROPELLER (3X14.75X23)	1	OPT,W/COUNTER ROTATION

FIG.407B




FIG.407B (1-H-10) GEAR CASE (E03,E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
22-11	58800-96J40	PROPELLER (3X14.5X25)	1	OPT,W/COUNTER ROTATION
22-12	58800-96J50	PROPELLER (3X14.5X27)	1	OPT,W/COUNTER ROTATION
23	58120-93L00	.BUSH COMP,PROPELLER	1	OPT
24	57632-93L11	STOPPER,PROPELLER BUSH	1	
25	57633-93L00	SPACER,PROPELLER NUT	1	
26	09141-18005	NUT (M18)	1	
27	09160-18028	WASHER (18.5X31X1.0)	1	
28	09204-03003	PIN (D:3.6,L:25)	1	
29	55128-93L00	PLUG,DRAIN	1	
30	09160-12066	WASHER (12.5X22X2.5)	1	XX-TRANSOM
31	57630-93L00	KIT,PROPELLER NUT	1	OPT
32	25700-93L02	KIT,GEAR CASE SEALING	1	E03,E11
				OPT,NOT ILLUSTRATED

FIG.410A




FIG.410A (1-H-11) SIDE COVER (X-TRANSOM,XX-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61131-93J01-YAY	COVER,OIL PAN STBD (BLACK)	1	020 STBD BODY COLOR:YAY
1-2	61131-93J01-Y5S	COVER,OIL PAN STBD (WHITE)	1	020 STBD BODY COLOR:Y5S
1-3	61131-93J01-QTN	COVER,OIL PAN STBD (WHITE)	1	021,022 STBD BODY COLOR:QTN
1-4	61131-93J01-YAY	COVER,OIL PAN STBD (BLACK)	1	021,022 STBD BODY COLOR:YAY
2-1	61141-93J01-YAY	COVER,OIL PAN PORT (BLACK)	1	020 PORT BODY COLOR:YAY
2-2	61141-93J01-Y5S	COVER,OIL PAN PORT (WHITE)	1	020 PORT BODY COLOR:Y5S
2-3	61141-93J01-QTN	COVER,OIL PAN PORT (WHITE)	1	021,022 PORT BODY COLOR:QTN
2-4	61141-93J01-YAY	COVER,OIL PAN PORT (BLACK)	1	021,022 PORT BODY COLOR:YAY
3	61137-93J01	CUSHION,OIL PAN COVER UPPER	2	
4	09139-06135	SCREW (6X17)	5	
5	09139-06136	SCREW (6X65)	3	
6-1	61811-98J20-YAY	COVER,SIDE STBD (BLACK)	1	020 STBD BODY COLOR:YAY
6-2	61811-98J20-Y5S	COVER,SIDE STBD (WHITE)	1	020 STBD BODY COLOR:Y5S
6-3	61811-98J20-QTN	COVER,SIDE STBD (WHITE)	1	021,022 STBD

FIG.410A




FIG.410A (1-H-12) SIDE COVER (X-TRANSOM,XX-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
				BODY COLOR:QTN
6-4	61811-98J20-YAY	COVER,SIDE STBD (BLACK)	1	021,022
				STBD
				BODY COLOR:YAY
7-1	61821-98J10-YAY	COVER,SIDE PORT (BLACK)	1	020
				PORT
				BODY COLOR:YAY
7-2	61821-98J10-Y5S	COVER,SIDE PORT (WHITE)	1	020
				PORT
				BODY COLOR:Y5S
7-3	61821-98J10-QTN	COVER,SIDE PORT (WHITE)	1	021,022
				PORT
				BODY COLOR:QTN
7-4	61821-98J10-YAY	COVER,SIDE PORT (BLACK)	1	021,022
				PORT
				BODY COLOR:YAY
8	61134-93J21	SEAL,SIDE COVER	1	
9	09409-05302-5PK	CLIP (BLACK)	2	
10	61817-93J01	PLUG,SIDE COVER	2	
11	09136-06148	SCREW (6X35)	10	
12	61827-93J02	HOLDER,SIDE COVER	1	
13	09321-10049	CUSHION	2	
14	01550-08167	BOLT	2	
15	61832-98J00	SEAL,FRONT PANEL	1	STBD
16	61812-98J00	SEAL,SIDE COVER	1	
17	61814-98J00	PROTECTOR,SIDE COVER	1	
18-1	61831-98J02-YAY	PANEL,FRONT (BLACK)	1	020
				BODY COLOR:YAY
18-2	61831-98J02-Y5S	PANEL,FR (WHITE)	1	020
				BODY COLOR:Y5S
18-3	61831-98J02-QTN	PANEL,FRONT (WHITE)	1	021,022
				BODY COLOR:QTN
18-4	61831-98J02-YAY	PANEL,FRONT (BLACK)	1	021,022
				BODY COLOR:YAY
19	09116-08174	BOLT (8X38)	2	

FIG.410A




FIG.410A (1-H-13) SIDE COVER (X-TRANSOM,XX-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	09169-08050	WASHER (ID:8.5)	2	
21	09320-11023	CUSHION	2	
22	09321-10049	CUSHION	3	
23	17913-93J00	PLUG,WATER	1	
24	17914-93J01	GASKET,WATER PLUG	1	
25	61112-98J00	RUBBER,SIDE COVER	1	
26	61630-98J00	SHAFT,COVER HOOK	1	
27	63632-98J20	SHAFT,ENGINE COVER HOOK	1	PORT
28	63632-98J30	SHAFT,ENGINE COVER HOOK	1	STBD
29	09306-17002	BUSH	3	
30	09160-17052	WASHER (17X30X3)	3	
31	61636-98J00	BUSH	3	
32-1	61633-98J10-YAY	LEVER,HOOK REAR STBD (BLACK)	1	020 STBD BODY COLOR:YAY
32-2	61633-98J10-Y5S	LEVER,HOOK REAR STBD (WHITE)	1	020 STBD BODY COLOR:Y5S
32-3	61633-98J10-QTN	LEVER,HOOK REAR STBD (WHITE)	1	021,022 STBD BODY COLOR:QTN
32-4	61633-98J10-YAY	LEVER,HOOK REAR STBD (BLACK)	1	021,022 STBD BODY COLOR:YAY
33-1	61634-98J10-YAY	LEVER,HOOK REAR PORT (BLACK)	1	020 PORT BODY COLOR:YAY
33-2	61634-98J10-Y5S	LEVER,HOOK REAR PORT (WHITE)	1	020 PORT BODY COLOR:Y5S
33-3	61634-98J10-QTN	LEVER,HOOK REAR PORT (WHITE)	1	021,022 PORT BODY COLOR:QTN
33-4	61634-98J10-YAY	LEVER,HOOK REAR PORT (BLACK)	1	021,022 PORT

FIG.410A




FIG.410A (1-H-14) SIDE COVER (X-TRANSOM,XX-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
				BODY COLOR:YAY
34-1	61645-98J00-YAY	LEVER,HOOK FRONT (BLACK)	1	020
				BODY COLOR:YAY
34-2	61645-98J00-Y5S	LEVER,HOOK FRONT (WHITE)	1	020
				BODY COLOR:Y5S
34-3	61645-98J00-QTN	LEVER,HOOK FRONT (WHITE)	1	021,022
				BODY COLOR:QTN
34-4	61645-98J00-YAY	LEVER,HOOK FRONT (BLACK)	1	021,022
				BODY COLOR:YAY
35	29103-93J20	BOLT (8X45)	2	
36	29103-93J30	BOLT (8X25)	1	
37	09160-08152	WASHER (8.5X28X1.5)	2	
38	09160-08082	WASHER (8.5X16X1.2)	1	
39	61635-98J00	SPACER	2	
40	61643-98J00	BUSH	2	
41	61658-98J00	SPRING,HOOK SHAFT	3	
42	09329-14003	CUSHION (14X20X9)	1	
43-1	61124-98J20	GROMMET,R/CON CABLE	1	020,021
43-2	61124-98J30	GROMMET,R/CON CABLE	1	022
44-1	09407-25402	CLAMP (L:250)	1	020,021
44-2	09407-20405	CLAMP (L:202)	1	022
45	61458-90J01	LABEL,ENGINE COVER	1	
46	67361-90J10	ADAPTER,HOSE	1	
47-1	09208-06009	PIN (RIGGING)	2	020,021
47-2	09208-06011	PIN	2	022
48	09383-04002	E RING	2	020,021

FIG.410B




FIG.410B (1-H-15) SIDE COVER (L-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61131-93J20-YAY	COVER,OIL PAN STBD (BLACK)	1	020 STBD BODY COLOR:YAY
1-2	61131-93J20-Y5S	COVER,OIL PAN STBD (WHITE)	1	020 STBD BODY COLOR:Y5S
1-3	61131-93J20-QTN	COVER,OIL PAN STBD (WHITE)	1	021,022 STBD BODY COLOR:QTN
1-4	61131-93J20-YAY	COVER,OIL PAN STBD (BLACK)	1	021,022 STBD BODY COLOR:YAY
2-1	61141-93J20-YAY	COVER,OIL PAN PORT (BLACK)	1	020 PORT BODY COLOR:YAY
2-2	61141-93J20-Y5S	COVER,OIL PAN PORT (WHITE)	1	020 PORT BODY COLOR:Y5S
2-3	61141-93J20-QTN	COVER,OIL PAN PORT (WHITE)	1	021,022 PORT BODY COLOR:QTN
2-4	61141-93J20-YAY	COVER,OIL PAN PORT (BLACK)	1	021,022 PORT BODY COLOR:YAY
3	61137-93J01	CUSHION,OIL PAN COVER UPPER	2	
4	09136-06161	SCREW (6X17)	8	
5	09136-06148	SCREW (6X35)	3	
6-1	61811-98J20-YAY	COVER,SIDE STBD (BLACK)	1	020 STBD BODY COLOR:YAY
6-2	61811-98J20-Y5S	COVER,SIDE STBD (WHITE)	1	020 STBD BODY COLOR:Y5S
6-3	61811-98J20-QTN	COVER,SIDE STBD (WHITE)	1	021,022 STBD

FIG.410B




FIG.410B (1-H-16) SIDE COVER (L-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
				BODY COLOR:QTN
6-4	61811-98J20-YAY	COVER,SIDE STBD (BLACK)	1	021,022
				STBD
				BODY COLOR:YAY
7-1	61821-98J10-YAY	COVER,SIDE PORT (BLACK)	1	020
				PORT
				BODY COLOR:YAY
7-2	61821-98J10-Y5S	COVER,SIDE PORT (WHITE)	1	020
				PORT
				BODY COLOR:Y5S
7-3	61821-98J10-QTN	COVER,SIDE PORT (WHITE)	1	021,022
				PORT
				BODY COLOR:QTN
7-4	61821-98J10-YAY	COVER,SIDE PORT (BLACK)	1	021,022
				PORT
				BODY COLOR:YAY
8	61134-93J21	SEAL,SIDE COVER	1	
9	09409-05302-5PK	CLIP (BLACK)	2	
10	61817-93J01	PLUG,SIDE COVER	2	
11	09136-06148	SCREW (6X35)	10	
12	61827-93J02	HOLDER,SIDE COVER	1	
13	09321-10049	CUSHION	2	
14	01550-08167	BOLT	2	
15	61832-98J00	SEAL,FRONT PANEL	1	STBD
16	61812-98J00	SEAL,SIDE COVER	1	
17	61814-98J00	PROTECTOR,SIDE COVER	1	
18-1	61831-98J02-YAY	PANEL,FRONT (BLACK)	1	020
				BODY COLOR:YAY
18-2	61831-98J02-Y5S	PANEL,FR (WHITE)	1	020
				BODY COLOR:Y5S
18-3	61831-98J02-QTN	PANEL,FRONT (WHITE)	1	021,022
				BODY COLOR:QTN
18-4	61831-98J02-YAY	PANEL,FRONT (BLACK)	1	021,022
				BODY COLOR:YAY
19	09116-08174	BOLT (8X38)	2	

FIG.410B




FIG.410B (1-I-2) SIDE COVER (L-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	09169-08050	WASHER (ID:8.5)	2	
21	09320-11023	CUSHION	2	
22	09321-10049	CUSHION	3	
23	17913-93J00	PLUG,WATER	1	
24	17914-93J01	GASKET,WATER PLUG	1	
25	61112-98J00	RUBBER,SIDE COVER	1	
26	61630-98J00	SHAFT,COVER HOOK	1	
27	63632-98J20	SHAFT,ENGINE COVER HOOK	1	PORT
28	63632-98J30	SHAFT,ENGINE COVER HOOK	1	STBD
29	09306-17002	BUSH	3	
30	09160-17052	WASHER (17X30X3)	3	
31	61636-98J00	BUSH	3	
32-1	61633-98J10-YAY	LEVER,HOOK REAR STBD (BLACK)	1	020 STBD BODY COLOR:YAY
32-2	61633-98J10-Y5S	LEVER,HOOK REAR STBD (WHITE)	1	020 STBD BODY COLOR:Y5S
32-3	61633-98J10-QTN	LEVER,HOOK REAR STBD (WHITE)	1	021,022 STBD BODY COLOR:QTN
32-4	61633-98J10-YAY	LEVER,HOOK REAR STBD (BLACK)	1	021,022 STBD BODY COLOR:YAY
33-1	61634-98J10-YAY	LEVER,HOOK REAR PORT (BLACK)	1	020 PORT BODY COLOR:YAY
33-2	61634-98J10-Y5S	LEVER,HOOK REAR PORT (WHITE)	1	020 PORT BODY COLOR:Y5S
33-3	61634-98J10-QTN	LEVER,HOOK REAR PORT (WHITE)	1	021,022 PORT BODY COLOR:QTN
33-4	61634-98J10-YAY	LEVER,HOOK REAR PORT (BLACK)	1	021,022 PORT

FIG.410B




FIG.410B (1-I-3) SIDE COVER (L-TRANSOM)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
				BODY COLOR:YAY
34-1	61645-98J00-YAY	LEVER,HOOK FRONT (BLACK)	1	020
				BODY COLOR:YAY
34-2	61645-98J00-Y5S	LEVER,HOOK FRONT (WHITE)	1	020
				BODY COLOR:Y5S
34-3	61645-98J00-QTN	LEVER,HOOK FRONT (WHITE)	1	021,022
				BODY COLOR:QTN
34-4	61645-98J00-YAY	LEVER,HOOK FRONT (BLACK)	1	021,022
				BODY COLOR:YAY
35	29103-93J20	BOLT (8X45)	2	
36	29103-93J30	BOLT (8X25)	1	
37	09160-08152	WASHER (8.5X28X1.5)	2	
38	09160-08082	WASHER (8.5X16X1.2)	1	
39	61635-98J00	SPACER	2	
40	61643-98J00	BUSH	2	
41	61658-98J00	SPRING,HOOK SHAFT	3	
42	09329-14003	CUSHION (14X20X9)	1	
43-1	61124-98J20	GROMMET,R/CON CABLE	1	020,021
43-2	61124-98J30	GROMMET,R/CON CABLE	1	022
44-1	09407-25402	CLAMP (L:250)	1	020,021
44-2	09407-20405	CLAMP (L:202)	1	022
45	61458-90J01	LABEL,ENGINE COVER	1	
46	67361-90J10	ADAPTER,HOSE	1	
47-1	09208-06009	PIN (RIGGING)	2	020,021
47-2	09208-06011	PIN	2	022
48	09383-04002	E RING	2	020,021

FIG.420A




FIG.420A (1-I-4) ENGINE COVER (020:DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61420-98802-YAY	COVER SET,ENGINE (BLACK)	1	BODY COLOR:YAY
1-2	61420-98812-Y5S	COVER SET,ENGINE (WHITE)	1	BODY COLOR:Y5S
2-1	61431-98J10-YAY	.COVER,ENGINE TOP (BLACK)	1	BODY COLOR:YAY
2-2	61431-98J10-Y5S	.COVER,ENGINE TOP (WHITE)	1	BODY COLOR:Y5S
3	61432-98J01	.LOUVER,AIR INTAKE	1	
4	61433-98J01	.GRIP,ENGINE UPPER COVER STBD	1	STBD
5	61434-98J02	.GRIP,ENGINE UPPER COVER PORT	1	PORT
6	61439-98J01	.SEAL,GRIP STBD	1	STBD
7	61439-98J11	.SEAL,GRIP PORT	1	PORT
8	61439-98J21	.SEAL,AIR VENT NO.2	1	
9	61476-98J00	.SEAL,AIR VENT NO.1	1	
10	01550-06167	.BOLT (6X16)	2	
11	01550-06207	.BOLT (6X20)	3	
12	01550-06167	.BOLT (6X16)	3	
13	03542-06169	.SCREW (6X19)	5	
14	01550-06167	.BOLT (6X16)	4	
15	03542-06169	.SCREW (6X19)	4	
16	61610-98J00	.FASTENER,FRONT	1	
17	61610-98J30	.FASTENER,PORT	1	PORT
18	61610-98J40	.FASTENER,STBD	1	STBD
19	77811-54GC0-0PG	.EMBLEM,MARK S (CHROME)	1	
20	61614-98J00	.PROTECTOR,FASTENER	1	
21	61621-98J02	.BRACKET,FASTENER FRONT	1	
22	61624-98J11	.BRACKET,FASTENER PORT	1	PORT
23	61625-98J11	.BRACKET,FASTENER STBD	1	STBD
24	61619-98J00	.CUSHION,ENG COVER FASTENER	3	
25	01547-06167	.BOLT (6X16)	6	
26	01550-06127	.BOLT	1	
27	01550-06127	.BOLT	2	
28	61425-98J00	.CUSHION,ENGINE COVER	1	
29-1	61443-96J70	.STRIPE,ENGINE COVER STBD	1	BODY COLOR:YAY
29-2	61443-96J80	.STRIPE,ENGINE COVER STBD	1	BODY COLOR:Y5S
30-1	61453-96J70	.STRIPE,ENGINE COVER PORT	1	BODY COLOR:YAY
30-2	61453-96J80	.STRIPE,ENGINE COVER PORT	1	BODY COLOR:Y5S
31	61441-98L00	.MARK,SUZUKI	2	

FIG.420A




FIG.420A (1-I-5) ENGINE COVER (020:DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
32-1	61422-98J50	MARK,EMBLEM FRONT	1	BODY COLOR:YAY
32-2	61422-98J30	MARK,EMBLEM FRONT	1	BODY COLOR:Y5S
33-1	61435-98J50	MARK,EMBLEM REAR	1	BODY COLOR:YAY
33-2	61435-98J30	MARK,EMBLEM REAR	1	BODY COLOR:Y5S
34	09800-81835	TOOL SET	1	
35-1	99011-98J91-054	MANUAL,OWNER'S	1	E01,E03
35-2	99011-98J91-059	MANUAL,OWNER'S	1	E01,E40
35-3	99011-98J91-03B	MANUAL,OWNER'S	1	E03

FIG.420B




FIG.420B (1-I-6) ENGINE COVER (020:DF250A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61420-98802-YAY	COVER SET,ENGINE (BLACK)	1	BODY COLOR:YAY
1-2	61420-98812-Y5S	COVER SET,ENGINE (WHITE)	1	BODY COLOR:Y5S
2-1	61431-98J10-YAY	.COVER,ENGINE TOP (BLACK)	1	BODY COLOR:YAY
2-2	61431-98J10-Y5S	.COVER,ENGINE TOP (WHITE)	1	BODY COLOR:Y5S
3	61432-98J01	.LOUVER,AIR INTAKE	1	
4	61433-98J01	.GRIP,ENGINE UPPER COVER STBD	1	STBD
5	61434-98J02	.GRIP,ENGINE UPPER COVER PORT	1	PORT
6	61439-98J01	.SEAL,GRIP STBD	1	STBD
7	61439-98J11	.SEAL,GRIP PORT	1	PORT
8	61439-98J21	.SEAL,AIR VENT NO.2	1	
9	61476-98J00	.SEAL,AIR VENT NO.1	1	
10	01550-06167	.BOLT (6X16)	2	
11	01550-06207	.BOLT (6X20)	3	
12	01550-06167	.BOLT (6X16)	3	
13	03542-06169	.SCREW (6X19)	5	
14	01550-06167	.BOLT (6X16)	4	
15	03542-06169	.SCREW (6X19)	4	
16	61610-98J00	.FASTENER,FRONT	1	
17	61610-98J30	.FASTENER,PORT	1	PORT
18	61610-98J40	.FASTENER,STBD	1	STBD
19	77811-54GC0-0PG	.EMBLEM,MARK S (CHROME)	1	
20	61614-98J00	.PROTECTOR,FASTENER	1	
21	61621-98J02	.BRACKET,FASTENER FRONT	1	
22	61624-98J11	.BRACKET,FASTENER PORT	1	PORT
23	61625-98J11	.BRACKET,FASTENER STBD	1	STBD
24	61619-98J00	.CUSHION,ENG COVER FASTENER	3	
25	01547-06167	.BOLT (6X16)	6	
26	01550-06127	.BOLT	1	
27	01550-06127	.BOLT	2	
28	61425-98J00	.CUSHION,ENGINE COVER	1	
29-1	61443-96J70	.STRIPE,ENGINE COVER STBD	1	BODY COLOR:YAY
29-2	61443-96J80	.STRIPE,ENGINE COVER STBD	1	BODY COLOR:Y5S
30-1	61453-96J70	.STRIPE,ENGINE COVER PORT	1	BODY COLOR:YAY
30-2	61453-96J80	.STRIPE,ENGINE COVER PORT	1	BODY COLOR:Y5S
31	61441-98L00	.MARK,SUZUKI	2	

FIG.420B




FIG.420B (1-I-7) ENGINE COVER (020:DF250A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
32-1	61422-98J40	MARK,EMBLEM FRONT	1	BODY COLOR:YAY
32-2	61422-93JE0	MARK,EMBLEM FRONT	1	BODY COLOR:Y5S
33-1	61435-98J60	MARK,EMBLEM REAR	1	BODY COLOR:YAY
33-2	61435-93JD0	MARK,EMBLEM REAR	1	BODY COLOR:Y5S
34	09800-81835	TOOL SET	1	
35-1	99011-98J91-054	MANUAL,OWNER'S	1	E01,E03
35-2	99011-98J91-059	MANUAL,OWNER'S	1	E01,E40
35-3	99011-98J91-03B	MANUAL,OWNER'S	1	E03

FIG.420C




FIG.420C (1-I-8) ENGINE COVER ((021,022):DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61420-98840-YAY	COVER SET,ENGINE (BLACK)	1	BODY COLOR:YAY
1-2	61420-98850-QTN	COVER SET,ENGINE (WHITE)	1	BODY COLOR:QTN
2-1	61431-98J10-YAY	.COVER,ENGINE TOP (BLACK)	1	BODY COLOR:YAY
2-2	61431-98J10-QTN	.COVER,ENGINE TOP (WHITE)	1	BODY COLOR:QTN
3	61432-98J01	.LOUVER,AIR INTAKE	1	
4	61433-98J01	.GRIP,ENGINE UPPER COVER STBD	1	STBD
5	61434-98J02	.GRIP,ENGINE UPPER COVER PORT	1	PORT
6	61439-98J01	.SEAL,GRIP STBD	1	STBD
7	61439-98J11	.SEAL,GRIP PORT	1	PORT
8	61439-98J21	.SEAL,AIR VENT NO.2	1	
9	61476-98J00	.SEAL,AIR VENT NO.1	1	
10	01550-06167	.BOLT (6X16)	2	
11	01550-06207	.BOLT (6X20)	3	
12	01550-06167	.BOLT (6X16)	3	
13	03542-06169	.SCREW (6X19)	5	
14	01550-06167	.BOLT (6X16)	4	
15	03542-06169	.SCREW (6X19)	4	
16	61610-98J00	.FASTENER,FRONT	1	
17	61610-98J30	.FASTENER,PORT	1	PORT
18	61610-98J40	.FASTENER,STBD	1	STBD
19	77811-54GC0-0PG	.EMBLEM,MARK S (CHROME)	1	
20	61614-98J00	.PROTECTOR,FASTENER	1	
21	61621-98J02	.BRACKET,FASTENER FRONT	1	
22	61624-98J11	.BRACKET,FASTENER PORT	1	PORT

FIG.420C




FIG.420C (1-I-9) ENGINE COVER ((021,022):DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
23	61625-98J11	.BRACKET,FASTENER STBD	1	STBD
24	61619-98J00	.CUSHION,ENG COVER FASTENER	3	
25	01547-06167	.BOLT (6X16)	6	
26	01550-06127	.BOLT	1	
27	01550-06127	.BOLT	2	
28	61425-98J00	.CUSHION,ENGINE COVER	1	
29-1	61443-96L30	.STRIPE,ENGINE COVER STBD	1	BODY COLOR:YAY
29-2	61443-96L40	.STRIPE,ENGINE COVER STBD	1	BODY COLOR:QTN
30-1	61453-96L30	.STRIPE,ENGINE COVER PORT	1	BODY COLOR:YAY
30-2	61453-96L40	.STRIPE,ENGINE COVER PORT	1	BODY COLOR:QTN
31	61441-98L00	.MARK,SUZUKI	2	
32-1	61435-98J70	MARK,EMBLEM REAR	1	BODY COLOR:YAY
32-2	61435-98J80	MARK,EMBLEM REAR	1	BODY COLOR:QTN
33	09800-81835	TOOL SET	1	
34-1	99011-98JA0-03B	MANUAL,OWNER'S	1	021:E11
34-2	99011-98JB0-03B	MANUAL,OWNER'S	1	022:E11
34-3	99011-98JA0-054	MANUAL,OWNER'S	1	021:E11
34-4	99011-98JB0-054	MANUAL,OWNER'S	1	022:E11
34-5	99011-98JA0-059	MANUAL,OWNER'S	1	021:(E11,E40)
34-6	99011-98JB0-059	MANUAL,OWNER'S	1	022:(E11,E40)

FIG.420D




FIG.420D (1-I-10) ENGINE COVER ((021,022):DF250A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61420-98840-YAY	COVER SET,ENGINE (BLACK)	1	BODY COLOR:YAY
1-2	61420-98850-QTN	COVER SET,ENGINE (WHITE)	1	BODY COLOR:QTN
2-1	61431-98J10-YAY	.COVER,ENGINE TOP (BLACK)	1	BODY COLOR:YAY
2-2	61431-98J10-QTN	.COVER,ENGINE TOP (WHITE)	1	BODY COLOR:QTN
3	61432-98J01	.LOUVER,AIR INTAKE	1	
4	61433-98J01	.GRIP,ENGINE UPPER COVER STBD	1	STBD
5	61434-98J02	.GRIP,ENGINE UPPER COVER PORT	1	PORT
6	61439-98J01	.SEAL,GRIP STBD	1	STBD
7	61439-98J11	.SEAL,GRIP PORT	1	PORT
8	61439-98J21	.SEAL,AIR VENT NO.2	1	
9	61476-98J00	.SEAL,AIR VENT NO.1	1	
10	01550-06167	.BOLT (6X16)	2	
11	01550-06207	.BOLT (6X20)	3	
12	01550-06167	.BOLT (6X16)	3	
13	03542-06169	.SCREW (6X19)	5	
14	01550-06167	.BOLT (6X16)	4	
15	03542-06169	.SCREW (6X19)	4	
16	61610-98J00	.FASTENER,FRONT	1	
17	61610-98J30	.FASTENER,PORT	1	PORT
18	61610-98J40	.FASTENER,STBD	1	STBD
19	77811-54GC0-0PG	.EMBLEM,MARK S (CHROME)	1	
20	61614-98J00	.PROTECTOR,FASTENER	1	
21	61621-98J02	.BRACKET,FASTENER FRONT	1	
22	61624-98J11	.BRACKET,FASTENER PORT	1	PORT

FIG.420D




FIG.420D (1-I-11) ENGINE COVER ((021,022):DF250A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
23	61625-98J11	.BRACKET,FASTENER STBD	1	STBD
24	61619-98J00	.CUSHION,ENG COVER FASTENER	3	
25	01547-06167	.BOLT (6X16)	6	
26	01550-06127	.BOLT	1	
27	01550-06127	.BOLT	2	
28	61425-98J00	.CUSHION,ENGINE COVER	1	
29-1	61443-96L30	.STRIPE,ENGINE COVER STBD	1	BODY COLOR:YAY
29-2	61443-96L40	.STRIPE,ENGINE COVER STBD	1	BODY COLOR:QTN
30-1	61453-96L30	.STRIPE,ENGINE COVER PORT	1	BODY COLOR:YAY
30-2	61453-96L40	.STRIPE,ENGINE COVER PORT	1	BODY COLOR:QTN
31	61441-98L00	.MARK,SUZUKI	2	
32-1	61435-93JP0	MARK,EMBLEM REAR	1	BODY COLOR:YAY
32-2	61435-93JQ0	MARK,EMBLEM REAR	1	BODY COLOR:QTN
33	09800-81835	TOOL SET	1	
34-1	99011-98JA0-03B	MANUAL,OWNER'S	1	021:E11
34-2	99011-98JB0-03B	MANUAL,OWNER'S	1	022:E11
34-3	99011-98JA0-054	MANUAL,OWNER'S	1	021:E11
34-4	99011-98JB0-054	MANUAL,OWNER'S	1	022:E11
34-5	99011-98JA0-059	MANUAL,OWNER'S	1	021:(E11,E40)
34-6	99011-98JB0-059	MANUAL,OWNER'S	1	022:(E11,E40)

FIG.430A




FIG.430A (1-I-12) FUEL HOSE (E01,E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	65700-93J12	HOSE,FUEL	1	->65700-93J14+09401-14409
				FROM 25003P040001
				UPTO 25003P040544
				FROM 30002P040001
				UPTO 30002P041393
1-2	65700-93J14	HOSE,FUEL	1	FROM 25003P040545
				FROM 30002P041394
2	65770-93J13	.PUMP,SQUEEZE	1	
3-1	09401-13423	CLIP	2	FROM 25003P040001
				UPTO 25003P040544
				FROM 30002P040001
				UPTO 30002P041393
3-2	09401-14409	CLIP	2	FROM 25003P040545
				FROM 30002P041394

FIG.475A




FIG.475A (1-I-13) SQUEEZE PUMP (E03,E11,E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	65770-93J13	PUMP,SQUEEZE	1	E03,E40
1-2	65770-93J04	PUMP,SQUEEZE	1	E11

FIG.520A




FIG.520A (1-I-14) OPT:FLUSH MOUNT REMOCON (020,021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-98J24	REMOTE CONTROL ASSY,FLASH MT	1	
2	67271-98J20	.COVER,BOTTOM BASE	1	
3	67264-98J00	.COVER,TOP BASE	1	
4	67263-98J20	.COVER,LEVER	1	
5	67261-98J20	.GRIP,A	1	
6	67261-98J30	.GRIP,B	1	
7	67265-98J00	.BUTTON,NEUTRAL LOCK	1	
8	67255-98J00	.LINK,NEUTRAL LOCK NO.1	1	
9	67258-98J00	.PLATE,JOINT	1	
10	67256-98J00	.BLOCK,NEUTRAL LOCK	1	
11	67259-98J00	.SPRING	3	
12	67251-98J20	.LEVER,HANDLE	1	
13	67294-98J00	.SPACER	1	
14	67254-98J00	.LINK,NEUTRAL LOCK NO.2	1	
15	67233-98J00	.SLIDER,NEUTRAL BUTTON	1	
16	67296-98JA0	.SCREW (4X10)	3	
17	67234-98J00	.PLATE,LEVER	1	
18	67211-98J20	.HOUSING	1	
19	67269-98J20	.CLAMP,LEAD	1	
20	67296-98JB0	.SCREW (4X30)	1	
21	67227-98J20	.SCREW (4X35)	1	
22	67227-98J30	.SCREW (4X20)	1	
23	67288-98J50	.WASHER,PLANE	8	
24	67296-98JC0	.SCREW (6X40)	4	
25	67287-98J00	.NUT	4	
26	67226-98J10	.BOLT (6X50)	4	
27	67288-98J60	.WASHER,INNTERNAL TOOTH (M4)	3	
28	67296-98JD0	.SCREW (5X40)	1	
29	67238-98J00	.PIN	2	
30	67288-98J70	.WASHER,PLANE	5	
31	67246-98J00	.SHAFT,DRIVE	1	
32	67222-98J00	.PANEL ASSY,BACK	1	
33	67236-98J00	.ROLLER,DETENT	1	
34	67235-98J00	.GUIDE,DETENT ROOLER	1	
35	67237-98J00	.SPRING,DETENT	1	

FIG.520A




FIG.520A (1-I-15) OPT:FLUSH MOUNT REMOCON (020,021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
36	67223-98J00	.PAD,BRAKE	1	
37	67296-98JE0	.SCREW (5X35)	1	
38	67252-98J00	.BUSH,DRIVE SHAFT	1	
39	67288-98J20	.WASHER	1	
40	67292-98J00	.C RING	1	
41	15980-98J00	.POTENTIOMETER	1	
42	67227-98J10	.LEVER,POTENTIOMETER NO.2	1	
43	67296-94300	.SCREW (4X10)	2	
44	67288-98J00	.WASHER,POTENTIOMETER	5	
45	67296-98J10	.SCREW (5X35)	1	
46	67288-98J10	.WASHER,SPRING	8	
47	67228-98J50	.WASHER,WAVE	2	
48	67296-98J60	.SCREW (8X30)	1	
49	09160-06104	.WASHER (6.5X24X2)	4	
50	67296-98J50	.SCREW (5X18)	2	
51	67272-98J00	.GROMMET,COVER	2	
52	37850-98J03	.SWITCH ASSY,PTT	1	
53	67269-98J10	.BAND	1	
54	67257-98J00	.MARK,LEVER	1	
55	36890-98J00	.HARNESS,CONDENSER ADAPTER	1	

FIG.520B




FIG.520B (1-I-16) OPT:FLUSH MOUNT REMOCON (022)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-98L20	R/CON ASSY,FLASH MOUNT	1	
2	67272-98L20	.GROMMET,R/CON COVER	1	
3	67264-98L00	.COVER,TOP BASE	1	
4	67284-98L20	..MARK,HANDLE LEVER	1	
5	67263-98J20	.COVER,LEVER	1	
6	67261-98J20	.GRIP,A	1	
7	67261-98J30	.GRIP,B	1	
8	67265-98J00	.BUTTON,NEUTRAL LOCK	1	
9	67255-98J00	.LINK,NEUTRAL LOCK NO.1	1	
10	67258-98J00	.PLATE,JOINT	1	
11	67256-98L00	.BLOCK,NEUTRAL LOCK	1	
12	67259-98J00	.SPRING	3	
13	67251-98J20	.LEVER,HANDLE	1	
14	67294-98J00	.SPACER	1	
15	67254-98J00	.LINK,NEUTRAL LOCK NO.2	1	
16	67296-98JA0	.SCREW (4X10)	3	
17	67234-98J00	.PLATE,LEVER	1	
18	67211-98J20	.HOUSING	1	
19	67296-98JB0	.SCREW (4X30)	1	
20	67227-98J20	.SCREW (4X35)	1	
21	67288-98J50	.WASHER,PLANE	4	
22	67287-98J00	.NUT	4	
23	67226-98J10	.BOLT (6X50)	4	
24	67288-98J60	.WASHER,INNTERNAL TOOTH (M4)	3	
25	67238-98J00	.PIN	2	
26	67288-98J00	.WASHER,POTENTIOMETER	4	
27	67296-98J60	.SCREW (8X30)	1	
28	67288-94310	.WASHER (6.5X24X2)	4	
29	37850-98J03	.SWITCH ASSY,PTT	1	
30	67257-98J00	.MARK,LEVER	1	
31	37820-98L00	.SWITCH ASSY,EMERGENCY	1	
32	37823-98L00	..PLATE,EMERGENCY SW LOCK	1	
33	37130-98L20	.SWITCH ASSY,BOAT CONTROL	1	
34	67227-98L00	.SCREW	1	

DF300A_E11_022_520B
OPT:FLUSH MOUNT REMOCON

FIG.522A




FIG.522A (1-J-2) OPT:HARNESS (1) (020,021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36620-98J52	WIRE ASSY,REMOTE CONTROL	1	
2	33830-98J11	SET,BATTERY ISOLATOR LEAD	1	
3	09407-10404	.CLAMP (L:100)	2	
4	09481-40401	.FUSE (40A)	1	
5	33911-88BL0	CAP,RUBBER	1	
6	33925-93J00	CUSHION,ENGINE CONTROL UNIT	AR	
7	33926-98J00	RESISTOR,TERMINAL	AR	
8	36623-98J21	HARNESS ASSY,BCM NO.1 FOR SNGL	1	
9	36615-96300	.TERMINAL	4	
10-1	36770-98J13	CONTROLLER ASSY,BOAT ELECTRIC	1	
10-2	36770-98J22	CONTROLLER ASSY,BOAT ELECTRIC	2	
11	36775-98J00	HOLDER,BCM,L	AR	
12	36776-98J00	HOLDER,BCM,R	AR	
13	36622-98J00	HARNESS ASSY,DUAL STATION,MAIN	AR	
14	09481-10501	.FUSE (10A)	AR	
15	36624-98J02	HARNESS ASSY,BCM NO.2 FOR SNGL	1	
16	36615-96300	.TERMINAL	2	
17	36621-98J00	HARNESS ASSY,DUAL ENGINE	AR	
18	36623-98J30	HARNESS ASSY,BCM NO.1 FOR MULT	1	
19	36615-96300	.TERMINAL	5	
20	36624-98J11	HARNESS ASSY,BCM NO.2 FOR MULT	1	
21	36615-96300	.TERMINAL	2	
22	36621-98J10	HARNESS ASSY,TRIPLE ENGINE	1	
23	09403-13402	CLAMP (ID:13)	AR	
24-1	36612-98J01	CONNECTOR,COUNTER SELECT	1	020,021:E40 GREEN
24-2	36612-98J20	CONNECTOR,COUNTER SELECT	AR	WHITE
25	36990-87D00	TERMINAL & SLEEVE SET	1	
26	36667-96L20	WIRE,GAUGE EXT	1	

FIG.522B




FIG.522B (1-J-3) OPT:HARNESS (1) (022)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36620-98L00	WIRE ASSY,REMOTE CONTROL (L:6500)	1	
2	33830-98J11	SET,BATTERY ISOLATOR LEAD	1	
3	09407-10404	.CLAMP (L:100)	2	
4	09481-40401	.FUSE (40A)	1	
5	33925-98L00	CUSHION,ENGINE CONTROL UNIT	AR	
6	33926-98L00	RESISTOR,TERMINAL	AR	
7	36623-98L00	HARNESS ASSY,BCM NO.1 SNGL	1	
8	36770-98L00	CONTROLLER ASSY,BOAT ELECTRIC	AR	
9	36775-98L00	HOLDER,BCM	AR	
10	36776-98L00	HOLDER,BCM	AR	
11	36622-98L00	HARNESS ASSY,DUAL STATION MAIN	1	
12	36624-98L00	HARNESS ASSY,BCM NO.2 SNGL	1	
13	36621-98L00	HARNESS ASSY,DUAL ENGINE	AR	
14	36623-98L10	HARNESS ASSY,BCM NO.1 FOR MULT	1	E11
15	36624-98L10	HARNESS ASSY,BCM NO.2 MULTI	1	
16	36624-98L20	HARNESS ASSY,BCM NO.2 QDRPL	1	
17	36612-98J20	CONNECTOR,COUNTER SELECT	AR	
18	36667-96L60	WIRE,GAUGE EXT	1	
19	36990-87D00	TERMINAL & SLEEVE SET	1	
20	09403-13402	CLAMP (ID:13)	AR	
21	38860-96L10	RELAY ASSY	1	E11
22	37140-98L00	UNIT,SIGNAL CONVERTER	1	

DF300A_E11_022_522B
OPT:HARNESS (1)

FIG.523A





FIG.523A (1-J-4) OPT:HARNESS (2) (020,021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36625-98J10	WIRE ASSY,BATTERY (L:2250)	AR	
2	09481-30501	.FUSE (30A)	AR	
3	36623-98J40	HARNESS ASSY,BCM FOR QUADRUPLE	1	
4	36615-96300	.TERMINAL	8	
5	36627-98J00	.HARNESS,R/CON EXTENSION	1	
6	17917-87L00	CONNECTOR,FLUSH WATER	1	

DF300A_E11_022_523A
OPT:HARNESS (2)

FIG.523B



DF300A_E11_022_523B
OPT:HARNESS (2)

FIG.523B (1-J-5) OPT:HARNESS (2) (022)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	36625-98J10	WIRE ASSY,BATTERY (L:2250)	1	
1-2	36625-98J20	WIRE ASSY,BATTERY (L:6100)	1	
2	09481-30501	.FUSE (30A)	1	
3	36623-98L40	HARNESS ASSY,BCM NO.1 QDRPL	1	
4	36627-98L00	HARNESS,R/CON EXT	1	
5	36627-98L10	HARNESS ASSY,EM SWITCH EXT	1	
6	17917-87L00	CONNECTOR,FLUSH WATER	1	

FIG.530A




FIG.530A (1-J-6) OPT:SWITCH (020,021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-98J07	PANEL ASSY,MAIN SWITCH	1	
2	37110-98J02	.SWITCH ASSY,MAIN	1	
3-1	37141-99EA0	..KEY (941)	1	
3-2	37141-99EB0	..KEY (942)	1	
3-3	37141-99E00	..KEY (931)	1	
3-4	37141-99E10	..KEY (932)	1	
3-5	37141-99E20	..KEY (933)	1	
3-6	37141-99E30	..KEY (934)	1	
3-7	37141-99E40	..KEY (935)	1	
3-8	37141-99E50	..KEY (936)	1	
3-9	37141-99E60	..KEY (937)	1	
3-10	37141-99E70	..KEY (938)	1	
3-11	37141-99E80	..KEY (939)	1	
3-12	37141-99E90	..KEY (940)	1	
4	37143-99E01	..CAP,KEY	1	
5	37139-98J10	.PANEL,MAIN SW	1	
6	37820-93J11	.SWITCH ASSY,EMERGENCY	1	
7	37823-92E02	..PLATE ASSY,EMERGENCY SW LOCK	1	
8	37826-92J10	..NUT	1	
9	03122-05169	.SCREW	4	
10	37114-98J00	.SHEET,MAIN SW PANEL	1	
11	37100-98J11	PANEL ASSY,SINGLE	1	
12	37112-98J00	.NUT	1	
13	38500-93J90	BUZZER,WARNING	AR	
14	09407-08401	CLAMP (L:80)	AR	
15	37803-93J06	PANEL ASSY,EMERGENCY SW	1	
16	37825-99E10	.PANEL,EMERGENCY STOP SW	1	
17	37820-93J11	.SWITCH ASSY,EMERGENCY	1	
18	37823-92E02	..PLATE ASSY,EMERGENCY SW LOCK	1	
19	37826-92J10	..NUT	1	
20	03122-05169	.SCREW	4	
21	37100-98J21	PANEL ASSY,DUAL	AR	
22	37112-98J10	.NUT	AR	
23	37100-98J31	PANEL ASSY,TRIPLE	1	
24	37112-98J10	.NUT	1	

DF300A_E11_022_530A
OPT:SWITCH

FIG.530A




FIG.530A (1-J-7) OPT:SWITCH (020,021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
25	37860-87L00	PANEL ASSY,TROLLING CONTROL SW	1	
26	37862-87L00	.PANEL	1	
27	09131-05004	.SCREW (5X16)	4	

DF300A_E11_022_530A
OPT:SWITCH

FIG.530B




FIG.530B (1-J-8) OPT:SWITCH (022)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-98L00	PANEL ASSY,MAIN SWITCH	1	
2	37110-98L00	.SWITCH ASSY,MAIN	1	
3-1	37141-98L00	..KEY (931)	1	
3-2	37141-98L10	..KEY (932)	1	
3-3	37141-98L20	..KEY (933)	1	
3-4	37141-98L30	..KEY (934)	1	
3-5	37141-98L40	..KEY (935)	1	
3-6	37141-98L50	..KEY (936)	1	
3-7	37141-98L60	..KEY (937)	1	
3-8	37141-98L70	..KEY (938)	1	
3-9	37141-98L80	..KEY (939)	1	
3-10	37141-98L90	..KEY (940)	1	
3-11	37141-98LA0	..KEY (941)	1	
3-12	37141-98LB0	..KEY (942)	1	
4-1	37141-99E00	..KEY (931)	1	
4-2	37141-99E10	..KEY (932)	1	
4-3	37141-99E20	..KEY (933)	1	
4-4	37141-99E30	..KEY (934)	1	
4-5	37141-99E40	..KEY (935)	1	
4-6	37141-99E50	..KEY (936)	1	
4-7	37141-99E60	..KEY (937)	1	
4-8	37141-99E70	..KEY (938)	1	
4-9	37141-99E80	..KEY (939)	1	
4-10	37141-99E90	..KEY (940)	1	
4-11	37141-99EA0	..KEY (941)	1	
4-12	37141-99EB0	..KEY (942)	1	
5	37138-98L00	.COVER,MAIN SW PANEL	1	
6	38500-93J90	.BUZZER,WARNING	1	
7	03142-05169	.SCREW	4	
8	37803-98L00	PANEL ASSY,EMERGENCY SW	1	
9	37820-98L00	.SWITCH ASSY,EMERGENCY	1	
10	37823-98L00	..PLATE,EMERGENCY SW LOCK	1	
11	37832-98L00	.COVER,EMERGENCY SW PANEL	1	
12	03142-05169	.SCREW	4	
13	37100-98L10	PANEL ASSY,MAIN SWITCH	1	

DF300A_E11_022_530B
OPT:SWITCH

FIG.530B




FIG.530B (1-J-9) OPT:SWITCH (022)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	37110-98L00	.SWITCH ASSY,MAIN	1	
15-1	37141-98L00	..KEY (931)	1	
15-2	37141-98L10	..KEY (932)	1	
15-3	37141-98L20	..KEY (933)	1	
15-4	37141-98L30	..KEY (934)	1	
15-5	37141-98L40	..KEY (935)	1	
15-6	37141-98L50	..KEY (936)	1	
15-7	37141-98L60	..KEY (937)	1	
15-8	37141-98L70	..KEY (938)	1	
15-9	37141-98L80	..KEY (939)	1	
15-10	37141-98L90	..KEY (940)	1	
15-11	37141-98LA0	..KEY (941)	1	
15-12	37141-98LB0	..KEY (942)	1	
16-1	37141-99E00	..KEY (931)	1	
16-2	37141-99E10	..KEY (932)	1	
16-3	37141-99E20	..KEY (933)	1	
16-4	37141-99E30	..KEY (934)	1	
16-5	37141-99E40	..KEY (935)	1	
16-6	37141-99E50	..KEY (936)	1	
16-7	37141-99E60	..KEY (937)	1	
16-8	37141-99E70	..KEY (938)	1	
16-9	37141-99E80	..KEY (939)	1	
16-10	37141-99E90	..KEY (940)	1	
16-11	37141-99EA0	..KEY (941)	1	
16-12	37141-99EB0	..KEY (942)	1	
17	37138-98L10	.COVER,MAIN SW PANEL VERT	1	
18	37820-98L00	.SWITCH ASSY,EMERGENCY	1	
19	37823-98L00	..PLATE,EMERGENCY SW LOCK	1	
20	38500-93J90	.BUZZER,WARNING	1	
21	03142-05169	.SCREW	4	
22	37100-98L20	PANEL ASSY,MAIN SWITCH HORIZ	1	
23	37110-98L00	.SWITCH ASSY,MAIN	1	
24-1	37141-98L00	..KEY (931)	1	
24-2	37141-98L10	..KEY (932)	1	
24-3	37141-98L20	..KEY (933)	1	

DF300A_E11_022_530B
OPT:SWITCH

FIG.530B




FIG.530B (1-J-10) OPT:SWITCH (022)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
24-4	37141-98L30	..KEY (934)	1	
24-5	37141-98L40	..KEY (935)	1	
24-6	37141-98L50	..KEY (936)	1	
24-7	37141-98L60	..KEY (937)	1	
24-8	37141-98L70	..KEY (938)	1	
24-9	37141-98L80	..KEY (939)	1	
24-10	37141-98L90	..KEY (940)	1	
24-11	37141-98LA0	..KEY (941)	1	
24-12	37141-98LB0	..KEY (942)	1	
25-1	37141-99E00	..KEY (931)	1	
25-2	37141-99E10	..KEY (932)	1	
25-3	37141-99E20	..KEY (933)	1	
25-4	37141-99E30	..KEY (934)	1	
25-5	37141-99E40	..KEY (935)	1	
25-6	37141-99E50	..KEY (936)	1	
25-7	37141-99E60	..KEY (937)	1	
25-8	37141-99E70	..KEY (938)	1	
25-9	37141-99E80	..KEY (939)	1	
25-10	37141-99E90	..KEY (940)	1	
25-11	37141-99EA0	..KEY (941)	1	
25-12	37141-99EB0	..KEY (942)	1	
26	37138-98L20	.COVER,MAIN SW PANEL HORIZ	1	
27	37820-98L00	.SWITCH ASSY,EMERGENCY	1	
28	37823-98L00	..PLATE,EMERGENCY SW LOCK	1	
29	38500-93J90	.BUZZER,WARNING	1	
30	03142-05169	.SCREW	4	
31	37100-98L30	PANEL ASSY,MAIN SWITCH MULTI	1	E11
32	37110-98L00	.SWITCH ASSY,MAIN	2	E11
33-1	37141-98L00	..KEY (931)	2	E11
33-2	37141-98L10	..KEY (932)	2	E11
33-3	37141-98L20	..KEY (933)	2	E11
33-4	37141-98L30	..KEY (934)	2	E11
33-5	37141-98L40	..KEY (935)	2	E11
33-6	37141-98L50	..KEY (936)	2	E11
33-7	37141-98L60	..KEY (937)	2	E11

DF300A_E11_022_530B
OPT:SWITCH

FIG.530B




FIG.530B (1-J-11) OPT:SWITCH (022)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
33-8	37141-98L70	..KEY (938)	2	E11
33-9	37141-98L80	..KEY (939)	2	E11
33-10	37141-98L90	..KEY (940)	2	E11
33-11	37141-98LA0	..KEY (941)	2	E11
33-12	37141-98LB0	..KEY (942)	2	E11
34-1	37141-99E00	..KEY (931)	2	E11
34-2	37141-99E10	..KEY (932)	2	E11
34-3	37141-99E20	..KEY (933)	2	E11
34-4	37141-99E30	..KEY (934)	2	E11
34-5	37141-99E40	..KEY (935)	2	E11
34-6	37141-99E50	..KEY (936)	2	E11
34-7	37141-99E60	..KEY (937)	2	E11
34-8	37141-99E70	..KEY (938)	2	E11
34-9	37141-99E80	..KEY (939)	2	E11
34-10	37141-99E90	..KEY (940)	2	E11
34-11	37141-99EA0	..KEY (941)	2	E11
34-12	37141-99EB0	..KEY (942)	2	E11
35	37138-98L30	.COVER,MAIN SW PANEL MULTIPLE	1	E11
36	37820-98L00	.SWITCH ASSY,EMERGENCY	1	E11
37	37823-98L00	..PLATE,EMERGENCY SW LOCK	1	E11
38	38500-93J90	.BUZZER,WARNING	2	E11
39	03142-05169	.SCREW	4	E11
40	37860-98L00	PANEL ASSY,TROLLING CONTROL SW	1	
41	37865-98L00	.COVER,TROLLING CONTROL SW	1	
42	03142-05169	.SCREW	4	
43	37120-98L00	PANEL ASSY,DUAL	1	
44	37112-98J10	.NUT	1	
45	37120-98L10	PANEL ASSY,TRIPLE	1	
46	37112-98J10	.NUT	1	
47	37120-98L20	PANEL ASSY,QDRPL PORT	1	
48	37112-98J10	.NUT	1	
49	37120-98L30	PANEL ASSY,QDRPL STBD	1	
50	37112-98J10	.NUT	1	
51	37120-98L40	PANEL ASSY,QUINTUPLE	1	
52	37112-98J10	.NUT	1	

DF300A_E11_022_530B
OPT:SWITCH

FIG.530B




FIG.530B (1-J-12) OPT:SWITCH (022)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
53	37120-98L50	PANEL ASSY,SEXTUPLE PORT	1	
54	37112-98J10	.NUT	1	
55	37120-98L60	PANEL ASSY,SEXTUPLE STBD	1	
56	37112-98J10	.NUT	1	
57	38500-93J90	BUZZER,WARNING	1	
58	09407-08401	CLAMP (L:80)	1	

DF300A_E11_022_530B
OPT:SWITCH

FIG.535A




FIG.535A (1-J-13) OPT:KEY LESS START ((020,021):(E01,E03,E11))

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-96L02	PANEL ASSY,MAIN SWITCH	1	020:(E01,E03),021:E11
2	37110-96L00	.SWITCH ASSY,MAIN	1	020:(E01,E03),021:E11
3-1	37141-99E00	..KEY (931)	1	020:(E01,E03),021:E11
3-2	37141-99E10	..KEY (932)	1	020:(E01,E03),021:E11
3-3	37141-99E20	..KEY (933)	1	020:(E01,E03),021:E11
3-4	37141-99E30	..KEY (934)	1	020:(E01,E03),021:E11
3-5	37141-99E40	..KEY (935)	1	020:(E01,E03),021:E11
3-6	37141-99E50	..KEY (936)	1	020:(E01,E03),021:E11
4	37143-96L00	..KNOB,MAIN SWITCH	1	020:(E01,E03),021:E11
5	37114-98J00	.SHEET,MAIN SW PANEL	1	020:(E01,E03),021:E11
6	37139-96L30	.PANEL,MAIN SWITCH	1	020:(E01,E03),021:E11
7	37820-93J11	.SWITCH ASSY,EMERGENCY	1	020:(E01,E03),021:E11
8	37823-92E02	..PLATE ASSY,EMERGENCY SW LOCK	1	020:(E01,E03),021:E11
9	37826-92J10	..NUT	1	020:(E01,E03),021:E11
10	03122-05169	.SCREW	4	020:(E01,E03),021:E11
11	37105-96L04	HARNESS SET,KLS CONTROLLER	1	020:(E01,E03),021:E11
12	32980-38F00	.CUSHION,CDI UNIT	1	020:(E01,E03),021:E11
13	36623-96L02	.HARNESS ASSY,KLS CONTROLLER	1	020:(E01,E03),021:E11
14	36615-96300	..TERMINAL	1	020:(E01,E03),021:E11
15	36662-96L01	.HARNESS ASSY,KLS CAN (L:6500+110)	1	020:(E01,E03),021:E11 L:6500+110
16	37173-96L10	.HOLDER,KLS PARTS	1	020:(E01,E03),021:E11
17	38500-93J90	.BUZZER,WARNING	1	020:(E01,E03),021:E11
18	38860-96L01	.RELAY ASSY,KLS	1	020:(E01,E03),021:E11
19	32851-93J00	.CUSHION,LEAD WIRE	1	020:(E01,E03),021:E11
20	09407-14407	.CLAMP (L:145)	1	020:(E01,E03),021:E11
21-1	37170-96L15	CONTROLLER SET,KLS (315MHZ)	1	020:(E01,E03),021:E11
21-2	37170-96L05	CONTROLLER SET,KLS (433MHZ)	1	020:E03,021:E11
22	37117-96L00	.DECAL,KLS	2	020:(E01,E03),021:E11
23-1	37171-96L02	.CONTROLLER ASSY,KLS (433MHZ)	1	020:(E01,E03),021:E11 433MHZ
23-2	37171-96L12	.CONTROLLER ASSY,KLS (315MHZ)	1	020:E03,021:E11 315MHZ
24-1	37172-96L01	.REMOCON ASSY,KLS (433MHZ)	2	020:(E01,E03),021:E11 433MHZ

FIG.535A




FIG.535A (1-J-14) OPT:KEY LESS START ((020,021):(E01,E03,E11))

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
24-2	37172-96L10	.REMOCON ASSY,KLS (315MHZ)	2	020:E03,021:E11 315MHZ
25	36663-96L00	WIRE,KLS CAN EXT	1	020:(E01,E03),021:E11
26	36664-96L00	HARNESS ASSY,KLS CAN (L:810+11 0)	AR	020:(E01,E03),021:E11 L:810+110
27	37173-96L00	HOLDER,KLS PARTS	1	020:(E01,E03),021:E11

DF300A_E11_022_535A
OPT:KEY LESS START

FIG.535B




FIG.535B (1-J-15) OPT:KEY LESS START (022)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37290-98L00	PANEL ASSY,ENG START SW	1	
2	37292-98L00	.COVER,ENG START PANEL	1	
3	03142-05169	.SCREW	4	
4	37290-98L10	PANEL ASSY,ENG START SW VERT	1	
5	37292-98L10	.COVER,ENG START PANEL VERT	1	
6	37820-98L00	.SWITCH ASSY,EMERGENCY	1	
7	37823-98L00	..PLATE,EMERGENCY SW LOCK	1	
8	03142-05169	.SCREW	4	
9	37290-98L20	PANEL ASSY,ENG START SW HORIZ	1	
10	37292-98L20	.COVER,ENG START PANEL HORIZ	1	
11	37820-98L00	.SWITCH ASSY,EMERGENCY	1	
12	37823-98L00	..PLATE,EMERGENCY SW LOCK	1	
13	03142-05169	.SCREW	4	
14-1	37105-98L00	KIT,KLS	1	E11 433MHZ
14-2	37105-98L10	KIT,KLS	1	E11 315MHZ
15	32851-93J00	.CUSHION,LEAD WIRE	1	E11
16	32980-38F00	.CUSHION,CDI UNIT	1	E11
17	36623-98LA0	.HARNESS ASSY,KLS CONT	1	E11
18	37117-96L00	.DECAL,KLS	2	E11
19-1	37171-98L00	.CONTROLLER ASSY,KLS 433 (433MHZ)	1	E11 433MHZ
19-2	37171-98L10	.CONTROLLER ASSY,KLS 315 (315MHZ)	1	E11 315MHZ
20-1	37172-96L02	.REMOCON ASSY,KLS 433	2	E11 433MHZ
20-2	37172-96L11	.REMOCON ASSY,KLS 315	2	E11 315MHZ
21	37173-96L10	.HOLDER,KLS PARTS	1	E11
22	38860-96L01	.RELAY ASSY,KLS	1	E11
23	09407-14407	.CLAMP (L:145)	1	E11
24	36627-98L20	HARNESS,CAN EXT	1	

DF300A_E11_022_535B
OPT:KEY LESS START

FIG.540A




FIG.540A (1-J-16) OPT:REMOTE CONTROL ASSY DUAL (020,021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-98J16	REMOTE CONTROL ASSY,MULTIPLE	1	
2	67211-98J20	.HOUSING	1	
3	67251-98J00	.LEVER,HANDLE	2	
4	67246-98J10	.SHAFT,DRIVE REMOCON	1	
5	67261-98J00	.GRIP,NO.1	1	
6	67261-98J10	.GRIP,NO.2	1	
7	67263-98J00	.COVER,LEVER	2	
8	67212-98J30	.COVER,REMOCON UPPER	1	
9	67271-98J40	.COVER,REMOCON BOTTOM	1	
10	67222-98J10	.PANEL ASSY,BACK	1	
11	67236-98J10	.ROLLER,DETENT	2	
12	67235-98J10	.GUIDE,DETENT ROLLER	2	
13	67237-98J40	.SPRING,DETENT	2	
14	67233-98J10	.HOLDER,DETENT SPRING	2	
15	67287-92E00	.NUT (M5)	2	
16	67239-98J00	.SCREW,DETENT ADJUSTMENT (5X14)	2	
17	67223-98J00	.PAD,BRAKE	2	
18	67296-98J50	.SCREW (5X18)	8	
19	67296-98JA0	.SCREW (4X10)	2	
20	67272-98J10	.GROMMET,REMOCON COVER	2	
21	67252-98J10	.BUSH,DRIVE SHAFT	2	
22	67288-98J20	.WASHER	2	
23	67292-98J00	.C RING	2	
24	15980-98J00	.POTENTIOMETER	2	
25	67227-98J10	.LEVER,POTENTIOMETER NO.2	1	
26	37850-98J03	.SWITCH ASSY,PTT	1	
27	67269-98J01	.CLAMP,LEAD	1	
28	67273-98J20	.PACKING	1	
29	67296-98J60	.SCREW (8X30)	2	
30	67296-98J30	.SCREW (5X70)	4	
31	67296-98JG0	.SCREW (5X14)	2	
32	67296-98J00	.SCREW (5X12)	1	
33	67296-94300	.SCREW (4X10)	4	
34	67288-98J40	.WASHER,BOTTOM COVER	14	

DF300A_E11_022_540A
OPT:REMOTE CONTROL ASSY DUAL

FIG.540A




FIG.540A (1-K-2) OPT:REMOTE CONTROL ASSY DUAL (020,021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67288-98J00	.WASHER,POTENTIOMETER	4	
36	67288-92E20	.WASHER	2	
37	67226-98J00	.BOLT (5X50)	4	
38	09160-05024	.WASHER (5.5X16X1.5)	4	
39	67287-92E00	.NUT (M5)	4	
40	67296-98J90	.SCREW (8X30)	2	
41	67227-98J00	.LEVER,POTENTIOMETER NO.1	1	
42	67284-98J10	.MARK	1	
43	67257-98J00	.MARK,LEVER	2	
44	67269-98J30	.BAND	1	
45	67288-98J10	.WASHER,SPRING	16	
46	67288-98J30	.WASHER,LEVER COVER	2	
47	67228-98J50	.WASHER,WAVE	2	
48	67211-98J30	.HOUSING,REMOCON	1	
49	67222-98J20	.PANEL ASSY,BACK	1	
50	67246-98J20	.SHAFT,DRIVE REMOCON	1	
51	67273-98J10	.PACKING,FRONT	1	
52	67273-98J30	.PACKING,REAR	1	
53	67277-98J00	.GROMMET,REMOCON BOTTOM COVER	1	
54	67296-98JF0	.BOLT,UPPER COVER (5X14)	1	
55	67297-98J00	.NUT,UPPER COVER BOLT	1	
56	67237-98J50	.SPRING,DETENT	2	
57	36890-98J00	.HARNESS,CONDENSER ADAPTER	1	
58-1	36620-98J31	WIRE ASSY,REMOTE CONTROL (L:6500)	1	
58-2	36620-98J42	WIRE ASSY,REMOTE CONTROL (L:9500)	1	

DF300A_E11_022_540A
OPT:REMOTE CONTROL ASSY DUAL

FIG.540B




FIG.540B (1-K-3) OPT:REMOTE CONTROL ASSY DUAL (022)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-98L10	R/CON ASSY,MULTIPLE TOP MOUNT	1	
2	37130-98L10	.SWITCH ASSY,BOAT CONTROL	1	
3	37850-98L00	.SWITCH ASSY,PTT	1	
4	67212-98L10	.COVER,R/CON UPPER	1	
5	67284-98L00	..MARK,HANDLE LEVER	1	
6	67284-98L10	..MARK,HANDLE LEVER	1	
7	68111-88L00	..EMBLEM,MARK	1	
8	67226-98J00	.BOLT (5X50)	4	
9	67261-98L00	.GRIP,R/CON NO.1	2	
10	67261-98L10	.GRIP,R/CON NO.2	1	
11	67261-98L20	.GRIP,R/CON NO.3	1	
12	67269-98L00	.CLAMP,LEAD	1	
13	67271-98L10	.COVER,R/CON BOTTOM	1	
14	67272-98L10	.GROMMET,R/CON COVER	2	
15	67273-98L10	.PACKING,R/CON	1	
16	67277-98L10	.GROMMET,R/CON GRIP	2	
17	67277-98L20	.GROMMET,R/CON BOTTOM COVER	1	
18	67287-92E00	.NUT (M5)	6	
19	67288-98J40	.WASHER,BOTTOM COVER	12	
20	67296-98J50	.SCREW (5X18)	6	
21	67296-98L00	.SCREW	3	
22	67296-98L10	.BOLT,UPPER COVER	1	
23	67297-98J00	.NUT,UPPER COVER BOLT	1	
24	67288-92E50	.WASHER	4	
25	67296-88D00	.SCREW	4	
26-1	36620-98L00	WIRE ASSY,REMOTE CONTROL (L:6500)	1	
26-2	36620-98L10	WIRE ASSY,REMOTE CONTROL (L:9500)	1	
26-3	36620-98L20	WIRE ASSY,REMOTE CONTROL EXT (L:2000)	1	
27	38500-93J90	BUZZER,WARNING	1	
28	09407-08401	CLAMP (L:80)	1	

DF300A_E11_022_540B
OPT:REMOTE CONTROL ASSY DUAL

FIG.543A




FIG.543A (1-K-4) OPT:REMOTE CONTROL ASSY SINGLE (020,021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-98J06	REMOTE CONTROL ASSY,SINGLE	1	
2	67211-98J20	.HOUSING	1	
3	67251-98J00	.LEVER,HANDLE	1	
4	67246-98J10	.SHAFT,DRIVE REMOCON	1	
5	67261-98J00	.GRIP,NO.1	1	
6	67263-98J00	.COVER,LEVER	1	
7	67212-98J20	.COVER,REMOCON UPPER	1	
8	67271-98J30	.COVER,REMOCON BOTTOM	1	
9	67222-98J10	.PANEL ASSY,BACK	1	
10	67236-98J10	.ROLLER,DETENT	1	
11	67235-98J10	.GUIDE,DETENT ROLLER	1	
12	67237-98J30	.SPRING,DETENT	1	
13	67233-98J10	.HOLDER,DETENT SPRING	1	
14	67287-92E00	.NUT (M5)	1	
15	67239-98J00	.SCREW,DETENT ADJUSTMENT (5X14)	1	
16	67223-98J00	.PAD,BRAKE	1	
17	67296-98J50	.SCREW (5X18)	6	
18	67296-98JA0	.SCREW (4X10)	1	
19	67272-98J10	.GROMMET,REMOCON COVER	1	
20	67252-98J10	.BUSH,DRIVE SHAFT	1	
21	67288-98J20	.WASHER	1	
22	67292-98J00	.C RING	1	
23	15980-98J00	.POTENTIOMETER	1	
24	67227-98J10	.LEVER,POTENTIOMETER NO.2	1	
25	37850-98J03	.SWITCH ASSY,PTT	1	
26	67269-98J01	.CLAMP,LEAD	1	
27	67273-98J00	.PACKING	1	
28	67296-98J60	.SCREW (8X30)	1	
29	67274-98J00	.FLANGE,BASE	1	
30	67288-92E20	.WASHER	1	
31	67296-98J90	.SCREW (8X30)	1	
32	67296-98JG0	.SCREW (5X14)	1	
33	67296-94300	.SCREW (4X10)	2	
34	67288-98J00	.WASHER,POTENTIOMETER	2	

DF300A_E11_022_543A
OPT:REMOTE CONTROL ASSY SINGLE

FIG.543A




FIG.543A (1-K-5) OPT:REMOTE CONTROL ASSY SINGLE (020,021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67296-98J20	.SCREW (5X50)	2	
36	67226-98J00	.BOLT (5X50)	4	
37	09160-05024	.WASHER (5.5X16X1.5)	4	
38	67287-92E00	.NUT (M5)	4	
39	67296-98J00	.SCREW (5X12)	1	
40	67288-98J40	.WASHER,BOTTOM COVER	12	
41	67296-98J10	.SCREW (5X35)	1	
42	67284-98J10	.MARK	1	
43	67257-98J00	.MARK,LEVER	1	
44	67269-98J30	.BAND	1	
45	67288-98J10	.WASHER,SPRING	8	
46	67288-98J30	.WASHER,LEVER COVER	1	
47	67228-98J50	.WASHER,WAVE	1	
48	67273-98J10	.PACKING,FRONT	1	
49	67273-98J30	.PACKING,REAR	1	
50	67277-98J00	.GROMMET,REMOCON BOTTOM COVER	1	
51	67296-98JF0	.BOLT,UPPER COVER (5X14)	1	
52	67297-98J00	.NUT,UPPER COVER BOLT	1	
53	36890-98J00	.HARNESS,CONDENSER ADAPTER	1	
54-1	36620-98J31	WIRE ASSY,REMOTE CONTROL (L:6500)	1	
54-2	36620-98J42	WIRE ASSY,REMOTE CONTROL (L:9500)	1	

DF300A_E11_022_543A
OPT:REMOTE CONTROL ASSY SINGLE

FIG.543B




FIG.543B (1-K-6) OPT:REMOTE CONTROL ASSY SINGLE (022)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-98L00	R/CON ASSY,SINGLE TOP MOUNT	1	
2	37130-98L00	.SWITCH ASSY,BOAT CONTROL	1	
3	37850-98L00	.SWITCH ASSY,PTT	1	
4	67212-98L00	.COVER,R/CON UPPER	1	
5	67284-98L00	..MARK,HANDLE LEVER	1	
6	68111-88L00	..EMBLEM,MARK	1	
7	67226-98J00	.BOLT (5X50)	4	
8	67261-98L00	.GRIP,R/CON NO.1	1	
9	67261-98L10	.GRIP,R/CON NO.2	1	
10	67269-98L00	.CLAMP,LEAD	1	
11	67271-98L00	.COVER,R/CON BOTTOM	1	
12	67272-98L00	.GROMMET,R/CON COVER	1	
13	67273-98L00	.PACKING,R/CON	1	
14	67277-98L00	.GROMMET,R/CON BOTTOM COVER	1	
15	67277-98L10	.GROMMET,R/CON GRIP	1	
16	67287-92E00	.NUT (M5)	5	
17	67288-98J40	.WASHER,BOTTOM COVER	9	
18	67296-98J50	.SCREW (5X18)	3	
19	67296-98L00	.SCREW	2	
20	67296-98L10	.BOLT,UPPER COVER	1	
21	67297-98J00	.NUT,UPPER COVER BOLT	1	
22	67296-88D00	.SCREW	4	
23-1	36620-98L00	WIRE ASSY,REMOTE CONTROL (L:6500)	1	
23-2	36620-98L10	WIRE ASSY,REMOTE CONTROL (L:9500)	1	
23-3	36620-98L20	WIRE ASSY,REMOTE CONTROL EXT (L:2000)	1	

DF300A_E11_022_543B
OPT:REMOTE CONTROL ASSY SINGLE

FIG.585A




FIG.585A (1-K-7) OPT:GASKET SET (E01,E03,E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11410-98831	GASKET SET	1	
2	11141-98J10	.GASKET,CYLINDER HEAD STBD	1	STBD
3	11142-98J10	.GASKET,CYLINDER HEAD PORT	1	PORT
4	11179-93J00	.GASKET,CYL HEAD COVER STBD	1	STBD
5	11189-93J00	.GASKET,CYL HEAD COVER PORT	1	PORT
6	11332-93J00	.GASKET,CRANKCASE WTR JKT COVE R	1	CRANKCASE WTR JKT COVER
7	13119-98J00	.GASKET,INTAKE MANIFOLD	2	
8	14151-93J00	.GASKET,EXH COVER STBD	1	STBD
9	14152-93J00	.GASKET,EXH COVER PORT	1	PORT
10	17472-98J00	.GASKET,PUMP CASE PANEL	1	
11	11272-93J00	.GASKET,CYLINDER BLOCK PLATE	1	
12	11489-93J00	.GASKET,OIL PAN	1	
13	14212-93J00	.GASKET,EXHAUST TUBE	1	
14	51123-93J01	.GASKET,MOUNT OIL SEAL COVER	1	
15	51142-93J00	.GASKET,ENGINE HOLDER COVER	1	
16	51211-93J00	.GASKET,ENGINE HOLDER	1	

FIG.601A




FIG.601A (1-K-8) OPT:MULTI FUNCTION GAUGE (1) (020,021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34000-96L66	KIT,SINGLE GAUGE ELECTRIC	1	
2	34011-96L16	.GAUGE SET,MULTI	1	
3	34112-96L00	..NUT,GAUGE	1	
4	34193-96L00	..BEZEL,GAUGE	1	
5	34211-96L00	..COVER,GAUGE	1	
6	34825-96L00	..PACKING,GAUGE	1	
7	36661-96L20	.ADAPTER,GAUGE	1	
8	36615-96300	..TERMINAL	5	
9	34000-96L76	KIT,DUAL GAUGE ELECTRIC	1	
10	34011-96L16	.GAUGE SET,MULTI	2	
11	34112-96L00	..NUT,GAUGE	2	
12	34193-96L00	..BEZEL,GAUGE	2	
13	34211-96L00	..COVER,GAUGE	2	
14	34825-96L00	..PACKING,GAUGE	2	
15	36661-96L20	.ADAPTER,GAUGE	1	
16	36615-96300	..TERMINAL	5	
17	36662-88L10	.WIRE,2 EXTENSION	2	
18	36663-88L00	.HARNESS ASSY,NETWORK POWER	1	
19	36664-88L00	.CONNECTOR,BRANCH	2	
20	36665-88L00	.UNIT,RESISTOR FEMALE	1	
21	36665-88L10	.UNIT,RESISTOR MALE	1	
22	36667-96L00	.WIRE,GAUGE ADAPTER (L:100+100)	1	
23	36667-96L11	WIRE,DUAL GAUGE ADAPTER (L:100+150)	1	
24	36667-96L30	WIRE,GAUGE ADAPTER	1	

FIG.601B




FIG.601B (1-K-9) OPT:MULTI FUNCTION GAUGE (1) (022)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34011-96L40	GAUGE SET,MULTI	1	
2	34112-96L00	.NUT,GAUGE	1	
3	34193-96L00	.BEZEL,GAUGE	1	
4	34211-96L00	.COVER,GAUGE	1	
5	34825-96L00	.PACKING,GAUGE	1	
6	34011-96L50	GAUGE SET,MULTI	1	
7	34112-96L00	.NUT,GAUGE	1	
8	34193-96L00	.BEZEL,GAUGE	1	
9	34211-96L00	.COVER,GAUGE	1	
10	34825-96L00	.PACKING,GAUGE	1	
11	36662-88L10	WIRE,2 EXTENSION	1	
12	36663-88L00	HARNESS ASSY,NETWORK POWER	1	
13	36664-88L00	CONNECTOR,BRANCH	1	
14	36665-88L00	UNIT,RESISTOR FEMALE	1	
15	36665-88L10	UNIT,RESISTOR MALE	1	
16	36667-96L40	WIRE,DUAL GAUGE ADAPTER	1	
17	36667-96L50	WIRE,DUAL GAUGE ADAPTER	1	

FIG.602A




FIG.602A (1-K-10) OPT:MULTI FUNCTION GAUGE (2) (020,021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34002-96L16	KIT,DUAL STATION	1	
2	34011-96L16	.GAUGE SET,MULTI	1	
3	34112-96L00	..NUT,GAUGE	1	
4	34193-96L00	..BEZEL,GAUGE	1	
5	34211-96L00	..COVER,GAUGE	1	
6	34825-96L00	..PACKING,GAUGE	1	
7	36662-88L10	.WIRE,2 EXTENSION	1	
8	36664-88L00	.CONNECTOR,BRANCH	1	
9	36665-96L00	.ADAPTER,DUAL STATION	1	
10	36666-96L00	.ADAPTER,GAUGE POWER	1	
11	36682-92E00	.WIRE,TRIM METER EXT (L:6500)	1	
12	34011-96L16	GAUGE SET,MULTI	1	
13	34112-96L00	.NUT,GAUGE	1	
14	34193-96L00	.BEZEL,GAUGE	1	
15	34211-96L00	.COVER,GAUGE	1	
16	34825-96L00	.PACKING,GAUGE	1	
17	36001-88L00	SET,WIRE	1	
18	36662-88L10	.WIRE,2 EXTENSION	1	
19	36663-88L00	.HARNESS ASSY,NETWORK POWER	1	
20	36664-88L00	.CONNECTOR,BRANCH	1	
21	36665-88L00	.UNIT,RESISTOR FEMALE	1	
22	36665-88L10	.UNIT,RESISTOR MALE	1	
23	34190-88L00	SENSOR ASSY,PAD WHEEL	1	
24	36662-88L20	WIRE,6 EXTENSION	1	
25	36662-88L30	WIRE,15 EXTENSION	1	
26	39950-88L02	MODULE ASSY,GPS RECEIVER	1	
27	36662-88L00	WIRE,25 EXTENSION	1	
28	36663-88L00	HARNESS ASSY,NETWORK POWER	1	
29	36665-88L00	UNIT,RESISTOR FEMALE	1	
30	36665-88L10	UNIT,RESISTOR MALE	1	
31	36662-88L10	WIRE,2 EXTENSION	1	
32	36664-88L00	CONNECTOR,BRANCH	1	

DF300A_E11_022_602A
OPT:MULTI FUNCTION GAUGE (2)

FIG.602B




FIG.602B (1-K-11) OPT:MULTI FUNCTION GAUGE (2) (022)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34011-96L40	GAUGE SET,MULTI	1	
2	34112-96L00	.NUT,GAUGE	1	
3	34193-96L00	.BEZEL,GAUGE	1	
4	34211-96L00	.COVER,GAUGE	1	
5	34825-96L00	.PACKING,GAUGE	1	
6	34011-96L50	GAUGE SET,MULTI	1	
7	34112-96L00	.NUT,GAUGE	1	
8	34193-96L00	.BEZEL,GAUGE	1	
9	34211-96L00	.COVER,GAUGE	1	
10	34825-96L00	.PACKING,GAUGE	1	
11	36001-88L00	SET,WIRE	1	
12	36662-88L10	.WIRE,2 EXTENSION	1	
13	36663-88L00	.HARNESS ASSY,NETWORK POWER	1	
14	36664-88L00	.CONNECTOR,BRANCH	1	
15	36665-88L00	.UNIT,RESISTOR FEMALE	1	
16	36665-88L10	.UNIT,RESISTOR MALE	1	
17	34190-88L00	SENSOR ASSY,PAD WHEEL	1	
18	36662-88L20	WIRE,6 EXTENSION	1	
19	36662-88L30	WIRE,15 EXTENSION	1	
20	39950-88L02	MODULE ASSY,GPS RECEIVER	1	
21	36662-88L00	WIRE,25 EXTENSION	1	
22	36663-88L00	HARNESS ASSY,NETWORK POWER	1	
23	36665-88L00	UNIT,RESISTOR FEMALE	1	
24	36665-88L10	UNIT,RESISTOR MALE	1	
25	36662-88L10	WIRE,2 EXTENSION	1	
26	36664-88L00	CONNECTOR,BRANCH	1	

DF300A_E11_022_602B
OPT:MULTI FUNCTION GAUGE (2)

PART NO.	FIG.NO.-REF.NO.
10000	
11101-98J04	111A-1-1
11101-98J10	111A-1-2
11103-98J04	111A-5-1
11103-98J10	111A-5-2
11112-93J00	113A-4
11115-93J10-001	111A-36
11116-93J01	111A-9
11117-93J10	113A-5
11117-98J10	113A-6
11119-93J00	113A-7
11128-90J00	111A-2-1
	111A-6-1
11141-98J10	111A-10
	585A-2
11142-98J10	111A-11
	585A-3
11170-93J01	111A-21
11173-93J00	111A-23
11174-98J01	136A-2
11176-98J00	136A-3
11179-93J00	111A-25
	585A-4
11180-98J01	111A-22
11183-93J00	111A-24
11189-93J00	111A-26
	585A-5
11193-98J01	163A-1
11196-93J00	162A-1
11197-93J00	162A-2
11198-98L00	163A-2
11216-98L00	113A-8
11216-98L10	111A-12
11218-98J02	315A-20
	315B-19
11219-98J00	315A-21
	315B-20
11261-93J00	111A-13
	140A-5
11261-93J10	180A-1
11270-93J00	162A-3
11272-93J00	162A-4
	585A-11
11291-93J00	111A-34
11291-98J00	111A-37
11293-98J00	113A-1
11301-98J40	113A-3
11330-93J01	113A-22
11332-93J00	113A-23
	585A-6
11382-93J00	111A-31
11390-98J00	113A-19
11410-98831	585A-1
11435-93J01	180A-14
11489-93J00	180A-6
	585A-12
11501-93J03-QTN	180A-7-3
11501-93J03-Y5S	180A-7-2
11501-93J03-YAY	180A-7-1
	180A-7-4
11510-98J03	136A-1
11514-98J00	136A-4
11515-93J00	136A-11
11517-98J00	136A-10
11541-93J00-QTN	180A-9-3
11541-93J00-Y5S	180A-9-2
11541-93J00-YAY	180A-9-1
	180A-9-4
11591-93J11	180A-8
12100-98810-025	116A-6-2
12100-98810-0A0	116A-6-1
12100-98J00-050	116A-14
12111-98J00-0B0	116A-1
12140-98J00	116A-2
12140-98J00-050	116A-15
12151-02F00	116A-3
12160-98J00	116A-5
12220-98J00	116A-7
12242-98J00	116A-10
12300-98810-0AA	116A-8-6
12300-98810-0BA	116A-8-7
12300-98810-0CA	116A-8-8
12300-98810-0DA	116A-8-9
12300-98810-0EA	116A-8-10
12300-98821	116A-9-1
12300-98821-012	116A-9-2
12340-98J00-0A0	116A-8-1
12340-98J00-0B0	116A-8-2
12340-98J00-0C0	116A-8-3
12340-98J00-0D0	116A-8-4
12340-98J00-0E0	116A-8-5
12632-93J11	175A-1
12701-98J10	121A-1
	121B-1
12701-98J20	121C-1
	121D-1
12705-98J10	121A-2
	121B-2
	121C-2
	121D-2
12721-98J10	121A-3
	121B-3
	121C-3
	121D-3
12729-98J20	121A-4
	121B-4
	121C-4
	121D-4
12730-98J02	119A-1
12734-93J00	119A-5
12740-93J00	121A-5
	121B-5
	121C-5
	121D-5
12748-93J00	121A-6
	121B-6
	121C-6
	121D-6
12749-93J00	121A-8
	121B-8
	121C-8
	121D-8
12753-93J00	121A-7
	121B-7
	121C-7
	121D-7
12761-93J00	119A-8
12762-93J00	119A-9
12770-93J00	119A-10
12771-93J00	119A-14
12772-93J00	119A-16
12775-93J00	119A-15
12778-93J00	119A-11
12810-93J00	119A-18
12812-90J00	119A-20
12813-73G00	119A-19
12831-93J01	119A-22
12832-93J00	119A-23
12833-93J00	119A-24
12891-93J00	121A-14
	121C-14
12891-93J10	121B-14
	121D-14
12892-93J00-218	121A-15-1
	121C-15-1
12892-93J00-220	121A-15-2

PART NO.	FIG.NO.-REF.NO.
	121C-15-2
12892-93J00-223	121A-15-3
	121C-15-3
12892-93J00-225	121A-15-4
	121C-15-4
12892-93J00-228	121A-15-5
	121C-15-5
12892-93J00-230	121A-15-6
	121C-15-6
12892-93J00-233	121A-15-7
	121C-15-7
12892-93J00-235	121A-15-8
	121C-15-8
12892-93J00-238	121A-15-9
	121C-15-9
12892-93J00-240	121A-15-10
	121C-15-10
12892-93J00-243	121A-15-11
	121C-15-11
12892-93J00-245	121A-15-12
	121C-15-12
12892-93J00-248	121A-15-13
	121C-15-13
12892-93J00-250	121A-15-14
	121C-15-14
12892-93J00-253	121A-15-15
	121C-15-15
12892-93J00-255	121A-15-16
	121C-15-16
12892-93J00-258	121A-15-17
	121C-15-17
12892-93J00-260	121A-15-18
	121C-15-18
12892-93J00-263	121A-15-19
	121C-15-19
12892-93J00-265	121A-15-20
	121C-15-20
12892-93J00-268	121A-15-21
	121C-15-21
12892-93J00-270	121A-15-22
	121C-15-22
12892-93J00-273	121A-15-23
	121C-15-23
12892-93J00-275	121A-15-24
	121C-15-24
12892-93J00-278	121A-15-25
	121C-15-25
12892-93J00-280	121A-15-26
	121C-15-26
12892-93J00-283	121A-15-27
12892-93J00-285	121A-15-28
	121C-15-28
12892-93J00-288	121A-15-29
	121C-15-29
12892-93J00-290	121A-15-30
	121C-15-30
12892-93J00-293	121A-15-31
	121C-15-31
12892-93J00-295	121A-15-32
	121C-15-32
12892-93J00-298	121A-15-33
	121C-15-33
12892-93J00-300	121A-15-34
	121C-15-34
12892-93J10-218	121B-15-1
	121D-15-1
12892-93J10-220	121B-15-2
	121D-15-2
12892-93J10-223	121B-15-3
	121D-15-3
12892-93J10-225	121B-15-4
	121D-15-4
12892-93J10-228	121B-15-5
	121D-15-5
12892-93J10-230	121B-15-6
	121D-15-6
12892-93J10-233	121B-15-7
	121D-15-7
12892-93J10-235	121B-15-8
	121D-15-8
12892-93J10-238	121B-15-9
	121D-15-9
12892-93J10-240	121B-15-10
	121D-15-10
12892-93J10-243	121B-15-11
	121D-15-11
12892-93J10-245	121B-15-12
	121D-15-12
12892-93J10-248	121B-15-13
	121D-15-13
12892-93J10-250	121B-15-14
	121D-15-14
12892-93J10-253	121B-15-15
	121D-15-15
12892-93J10-255	121B-15-16
	121D-15-16
12892-93J10-258	121B-15-17
	121D-15-17
12892-93J10-260	121B-15-18
12892-93J10-263	121B-15-19
	121D-15-19
12892-93J10-265	121B-15-20
	121D-15-20
12892-93J10-268	121B-15-21
	121D-15-21
12892-93J10-270	121B-15-22
	121D-15-22
12892-93J10-273	121B-15-23
	121D-15-23
12892-93J10-275	121B-15-24
	121D-15-24
12892-93J10-278	121B-15-25
	121D-15-25
12892-93J10-280	121B-15-26
	121D-15-26
12892-93J10-283	121B-15-27
	121D-15-27
12892-93J10-285	121B-15-28
	121D-15-28
12892-93J10-288	121B-15-29
	121D-15-29
12892-93J10-290	121B-15-30
	121D-15-30
12892-93J10-293	121B-15-31
	121D-15-31
12892-93J10-295	121B-15-32
	121D-15-32
12892-93J10-298	121B-15-33
	121D-15-33
12892-93J10-300	121B-15-34
	121D-15-34
12911-98J00	121A-16
	121B-16
	121C-16
	121D-16
12915-93J60	121A-17
	121B-17
	121C-17
	121D-17
12921-93J11	121A-18
	121B-18
	121C-18
	121D-18
12931-78G00	121A-19
	121B-19
	121C-19
	121D-19
12932-24400	121A-20

PART NO.	FIG.NO.-REF.NO.
	121B-20
	121C-20
	121D-20
12933-69G10	121A-21
	121B-21
	121C-21
	121D-21
13100-98J11	163A-3-1
13100-98J20	163A-3-2
13110-98J10	122A-1
13119-98J00	122A-2
	585A-7
13134-98J00	163A-14
13137-98J00	163A-4
13139-98J01	163A-15
13140-98J10	163A-5
13147-98J00	163A-6
13180-98J01	163A-7
13310-98J01	163A-16
13315-98J01	163A-18
13343-98J10	163A-17
13370-93J00	147A-20
	147C-20
13370-93J10	147B-20
	147D-20
13421-98L00	163A-19
13575-40F00	326A-2
	326B-2
13580-98J03	326A-1
	326B-1
13602-05108	147A-29
	147C-29
13614-93J00	147B-28
	147D-28
13650-52G00	315A-1
	315B-1
13655-87J01	315A-2
	315B-2
13671-02F00	147A-68
	147B-68
	147C-68
	147D-68
13710-98J00	136A-5
13811-98J00	136A-6
13813-98J01	163A-20
13841-98J10	136A-12
13851-98J10	136A-13
14140-98J01	140A-2
14141-93J01	140A-1
14151-93J00	140A-3
	585A-8
14152-93J00	140A-4
	585A-9
14154-93J02	180A-10
14211-98J00	180A-11
14212-93J00	180A-12
	585A-13
15100-98J00	147A-1
	147B-1
	147C-1
	147D-1
15114-93J00	147A-69
	147B-69
	147C-69
	147D-69
15115-93J02	147A-70
	147B-70
	147C-70
	147D-70
15118-93J00	147A-77
	147B-77
	147C-77
	147D-77
15200-98J00	147A-23
	147C-23
15200-98J10	147B-23
	147D-23
15410-93J11	147A-2
	147B-2
	147C-2
	147D-2
15411-93J10	147A-3
	147B-3
	147C-3
	147D-3
15412-93J10	147A-5
	147B-5
	147C-5
	147D-5
15413-93J10	147A-6
	147B-6
	147C-6
	147D-6
15415-93J10	147A-4
	147B-4
	147C-4
	147D-4
15440-93J00	147A-10
	147C-10
15440-93J10	147B-10
15600-98J21	147A-19
15600-98J31	147B-19
15600-98J40	147C-19
15600-98J50	147D-19
15626-93J00	147A-21
	147C-21
15626-93J10	147B-21
	147D-21
15627-93J00	147A-32
	147B-32
	147C-32
	147D-32
15628-99E00	147A-31
	147B-31
	147C-31
	147D-31
15629-99E10	147A-52
	147B-52
	147C-52
	147D-52
15631-99E10	147B-29
	147D-29
15632-93J30	147A-42
	147B-42
	147C-42
	147D-42
15633-93J20	147A-8
	147B-8
	147C-8
	147D-8
15634-93J20	147A-47
	147B-47
	147C-47
	147D-47
15635-93J30	147A-41
	147B-41
	147C-41
	147D-41
15636-93J30	147A-37
	147B-37
	147C-37
	147D-37
15637-93J30	147A-51
	147B-51
	147C-51
	147D-51
15641-90J00	147A-25
	147C-25
15641-90J10	147B-25
	147D-10
15642-90J00	147A-26
	147B-26
	147C-26
	147D-26
15643-93J00	147A-45
	147B-45
	147C-45
	147D-45
15644-93J00	147A-7
	147B-7
	147C-7
	147D-7
15645-93J00	147A-50
	147C-50
15645-93J10	147B-50
	147D-50
15647-93J00	147A-24
	147C-24
15647-93J10	147B-24
	147D-24
15650-93J00	147A-22
	147B-22
	147C-22
	147D-22
15654-99E00	147A-27
	147B-27
	147C-27
	147D-27
15671-93J00	147A-60
	147B-60
	147C-60
	147D-60
15672-93J10	147A-39
	147B-39
	147C-39
	147D-39
15673-98J00	147A-43
	147B-43
	147C-43
	147D-43
15674-93J00	147A-49
	147B-49
	147C-49
	147D-49
15675-93J00	147A-34
	147B-34
	147C-34
	147D-34
15680-93J40	144A-19
	144B-19
15681-93J02	144A-1
	144B-1
15683-87J00	147A-53
	147B-53
	147C-53
	147D-53
15684-98J00	144A-22
	144B-22
15685-93J00	147A-38
	147B-38
	147C-38
	147D-38
15695-98L00	147A-71
	147B-71
	147C-71
	147D-71
15710-96J00	144A-2
	144B-2
15717-16G00	144A-3
	144B-3
15735-58B00	144A-4
	144B-4
15751-93J00	144A-5
	144B-5
15756-93J02	144A-6
	144B-6
15760-93J01	147A-30
	147B-30
	147C-30
	147D-30
15762-90J00	147B-16
	147D-16
15762-93J00	144A-7
15762-93J10	144B-7
15770-93J00	147A-15
	147B-15
	147C-15
	147D-15
15773-90J10	147A-12
	147B-12
	147C-12
	147D-12
15830-77EA0	144A-8
15830-90J00	147B-18
	147D-18
15830-93J00	147A-13
	147B-13
	147C-13
	147D-13
15831-93J00	144A-9
	144B-9
15832-93J00	144B-8
15980-98J00	520A-41
	540A-24
	543A-23
16113-93J10	175A-2
16400-93J20	175A-3
16430-93J00	113A-25
16431-93J00	113A-26
16433-93J00	113A-27
16510-96J10	113A-30
16519-93J00	401A-2
16520-93J00	175A-4
16550-93J00	121A-11
	121B-11
	121C-11
	121D-11
16555-93J01	121A-12
	121B-12
	121C-12
	121D-12
16700-93J00	113A-14
16760-93J00	175A-5
16781-93J00	175A-6
16782-93J00	175A-7
16783-93J01	175A-8
16910-93J00	180A-26
16930-93J00	180A-27
17400-98J03	160A-22
17410-93J01	160A-1
	160B-1
17413-93J02	160A-2
	160A-29
17413-93J12	160B-2
17416-93J01	160A-3
	160A-23
	160B-3
17461-93J00	160A-4
	160A-24
	160B-4
17471-98J01	160A-5
	160A-25
17471-98J11	160B-5
17472-98J00	160A-6
	160A-26
	160B-6
	585A-10
17473-98J00	160A-7
	160A-27

PART NO.	FIG.NO.-REF.NO.
	160B-7
17561-93J03	160A-8-1
	160A-8-4
	160A-8-7
	160B-8-1
17561-93J13	160A-8-2
	160A-8-5
	160A-8-8
	160B-8-2
17561-93J21	160A-8-3
	160A-8-6
17562-93J01	160A-9
	160B-9
17563-93J01	160A-10
	160B-10
17564-93J01	160A-11
	160B-11
17581-93J00	162A-5
17582-93J00	162A-6
17611-90J00	162A-7
17612-93J00	160A-12
	160B-12
17631-93L00	160B-13
17631-93L10	160A-13
17632-93L00	160B-14
17632-93L10	160A-14
17633-93L00	160A-21
17637-93L00	206A-16
	206B-16
17638-93L00	206A-17
	206B-17
17660-99E01	162A-8
17670-90J11	162A-9-2
17670-90J21	162A-9-1
17681-93J00	162A-10
17711-90J00	162A-11
17712-93J01	162A-12
17713-98J01	162A-36
17913-93J00	401A-3
	410A-23
	410B-23
17914-93J01	401A-4
	410A-24
	410B-24
17915-98J02	162A-38
17917-87L00	523A-6
	523B-6
18117-52G10	147C-66
	147D-66
18118-93J00	163A-22
18213-98J30	315A-18
	315B-17
18417-93J00	147A-64
	147B-64
	147C-64
	147D-64
18498-87J01	147C-76
	147D-76
18498-87J51	147A-57
	147B-57
18498-87JC1	147C-75
	147D-75
18498-90J61	147C-57
	147D-57
18498-93J01	144A-10
	144B-10
18498-93J20	147A-76
	147B-76
18590-68H00	163A-8
19115-98J10	204A-29
20000	
21110-98J02	204A-1
21131-93J00	204A-2
21151-93J00	204A-3
21210-98J01	204A-5
21230-98J01	204A-6
21241-98J10	204A-24
22511-99011	336A-1
	336B-1
	401A-10
23111-93J00	204A-7-2
23111-93J10	204A-7-1
23115-98J00	204A-8
25112-93L00	206A-1-1
	206B-1-1
25112-93L10	206A-1-2
	206B-1-2
25113-93L00	206A-11
25113-93L20	206B-11
25130-93L00	206A-2
	206B-2
25141-93L10-QTN	206A-5-3
25141-93L10-Y5S	206A-5-2
25141-93L10-YAY	206A-5-1
	206A-5-4
25141-93L11-QTN	206B-5-1
25141-93L11-YAY	206B-5-2
25215-93L00	206A-12
	206B-12
25222-90J01	206A-6
	206B-6
25223-96J00	204A-9
25231-93L00	206A-23
	206B-23
25232-90J00	206A-3
	206B-3
25232-94300	206A-24
	206B-24
25321-93L00	206A-8
	206B-8
25700-93L02	407A-32
	407B-32
29103-93J00	180A-24
	315A-3
	315B-3
	315B-8
29103-93J20	410A-35
	410B-35
29103-93J30	180A-3
	410A-36
	410B-36
29116-93J00	160A-15
	160B-15
	180A-13
	206A-9
	206B-9
29125-93J00	326A-18
	326B-18
29159-93J00	401A-28
	405A-13
	405B-17
	405C-12
29404-93J01	337C-2
29404-93J11	180A-25
	315A-10
29404-93J21	315B-10
30000	
31100-98L10	301A-1
31111-94900	340A-2
	340B-2
31123-94910	340A-4
	340B-4

PART NO.	FIG.NO.-REF.NO.
31133-90J10	340A-5
	340B-5
31133-94910	340A-6
	340B-6
31135-94900	340A-7
	340B-7
31136-90J20	340A-8
	340B-8
31150-98L00	301A-2
31170-92J00	301A-3
31173-94920	340A-3
	340B-3
31173-98L00	301A-4
31191-63J00	301A-5
31192-92J00	301A-8
31220-98L10	301A-6
31261-75F10	301A-9
31281-92J10	337A-2
	337B-2
	337C-3
31311-63J00	301A-7
31311-93J00	340A-10
31311-94900	340B-10
31313-86030	301A-11
31320-98L00	301A-12
31340-98L00	301A-10
31341-98L00	301A-13
31343-63J00	301A-14
31344-63J00	301A-15
31912-98J00	301A-16
31918-92J01	301A-17
32102-98J11	303A-1-2
32102-98J20	303A-1-1
32120-93J01	303A-4-2
32120-93J10	303A-4-1
32131-93J00	303A-5
32160-88L01	303A-7
32800-98J01	310A-1
32805-93J00	310A-2
32851-93J00	331A-1
	331B-1
	535A-19
	535B-15
32890-98J01	310A-3
32980-38F00	331A-2
	331B-2
	535A-12
	535B-16
33220-98J00	303A-9
33221-42F00	303A-10
33410-93J00	310A-11
33799-97E00	340A-9
	340B-9
33810-98J01	322A-1
33830-98J11	522A-2
	522B-2
33911-88BL0	522A-5
33925-93J00	522A-6
33925-98J00	326A-24
	326B-24
33925-98L00	522B-5
33926-98J00	522A-7
33926-98L00	522B-6
33930-98JC0	326A-23-3
33930-98JD0	326B-23-1
33930-98JE0	326A-23-1
33930-98JF0	326A-23-4
33930-98JG0	326B-23-2
33930-98JH0	326A-23-2
34000-96L66	601A-1
34000-96L76	601A-9
34002-96L16	602A-1
34011-96L16	601A-2
	601A-10
	602A-2
	602A-12
34011-96L40	601B-1
	602B-1
34011-96L50	601B-6
	602B-6
34112-96L00	601A-3
	601A-11
	601B-2
	601B-7
	602A-3
	602A-13
	602B-2
	602B-7
34190-88L00	602A-23
34193-96L00	601A-4
	601A-12
	601B-3
	601B-8
	602A-4
	602A-14
	602B-3
	602B-8
34211-96L00	601A-5
	601A-13
34810-98J00	601B-4
	601B-9
	602A-5
	602A-15
	602B-4
	602B-9
34813-93J00	315B-22
34825-96L00	601A-6
	601A-14
	601B-5
	601B-10
	602A-6
	602A-16
	602B-5
	602B-10
34830-87J20	315A-4
	315A-5
	315B-4
	315B-5
34830-98J00	315A-22
	315B-21
34840-98J03	315A-6
34840-98J11	315B-6
34841-88L01	315A-12
34841-96J00	315B-12
34845-88L02	315A-13
34845-96J00	315B-13
36001-88L00	602A-17
	602B-11
36610-98J81	322A-3-1
36610-98J82	322A-3-2
36610-98JA0	322A-3-3
36611-96J01	315B-23
36612-96J01	322A-16
36612-98J01	522A-24-1
36612-98J10	322A-5
36612-98J20	522A-24-2
	522B-17
36615-96300	331A-4
	522A-9
	522A-16
	522A-19
	522A-21
	523A-4
	535A-14
	601A-8
	601A-16
	322A-19
36617-93J00	162A-41
36617-93J10	322A-20

PART NO.	FIG.NO.-REF.NO.
36617-98J00	322A-21
36620-98J31	540A-58-1
	543A-54-1
36620-98J42	540A-58-2
	543A-54-2
36620-98J52	522A-1
36620-98L00	522B-1
	540B-26-1
	543B-23-1
36620-98L10	540B-26-2
	543B-23-2
36620-98L20	540B-26-3
	543B-23-3
36621-98J00	522A-17
36621-98J10	522A-22
36621-98L00	522B-13
36622-98J00	522A-13
36622-98L00	522B-11
36623-96L02	331A-3
	535A-13
36623-98J21	522A-8
36623-98J30	522A-18
36623-98J40	523A-3
36623-98L00	522B-7
36623-98L10	522B-14
36623-98L40	523B-3
36623-98LA0	331B-3
	535B-17
36624-98J02	522A-15
36624-98J11	522A-20
36624-98L00	522B-12
36624-98L10	522B-15
36624-98L20	522B-16
36625-98J10	523A-1
	523B-1-1
36625-98J20	523B-1-2
36627-98J00	523A-5
36627-98L00	523B-4
36627-98L10	523B-5
36627-98L20	535B-24
36645-93J00	301A-20
36661-96L20	601A-7
	601A-15
36662-88L00	602A-27
	602B-21
36662-88L10	601A-17
	601B-11
	602A-7
	602A-18
	602A-31
	602B-12
	602B-25
36662-88L20	602A-24
	602B-18
36662-88L30	602A-25
	602B-19
36662-96L01	331A-5
	535A-15
36663-88L00	601A-18
	601B-12
	602A-19
	602A-28
	602B-13
	602B-22
36663-96L00	535A-25
36664-88L00	601A-19
	601B-13
	602A-8
	602A-20
	602A-32
	602B-14
	602B-26
36664-96L00	535A-26
36665-88L00	601A-20
	601B-14
	602A-21
	602A-29
	602B-15
	602B-23
36665-88L10	601A-21
	601B-15
	602A-22
	602A-30
	602B-16
	602B-24
36665-96L00	602A-9
36666-96L00	602A-10
36667-96L00	601A-22
36667-96L11	601A-23
36667-96L20	522A-26
36667-96L30	601A-24
36667-96L40	601B-16
36667-96L50	601B-17
36667-96L60	522B-18
36682-92E00	602A-11
36721-98L10	322A-6
36737-98L00	322A-7
36738-98L00	322A-8
36770-98J13	522A-10-1
36770-98J22	522A-10-2
36770-98L00	522B-8
36775-98J00	522A-11
36775-98L00	522B-9
36776-98J00	522A-12
36776-98L00	522B-10
36890-98J00	520A-55
	540A-57
	543A-53
36894-87D00	335A-23
	336A-2
	336B-2
	337A-39
	337B-40
	337C-36
	405A-7
	405B-11
	405C-19
36895-87D01	337A-40
	337A-41
	337B-41
	337B-42
36895-87D10	336B-13
	337C-39
36990-87D00	522A-25
	522B-19
37100-96L02	535A-1
37100-98J07	530A-1
37100-98J11	530A-11
37100-98J21	530A-21
37100-98J31	530A-23
37100-98L00	530B-1
37100-98L10	530B-13
37100-98L20	530B-22
37100-98L30	530B-31
37105-96L04	535A-11
37105-98L00	535B-14-1
37105-98L10	535B-14-2
37110-96L00	535A-2
37110-98J02	530A-2
37110-98L00	530B-2
	530B-14
	530B-23
	530B-32
37112-98J00	530A-12
37112-98J10	530A-22
	530A-24
	530B-44
	530B-46
	530B-48
	530B-50
	530B-52
	530B-54
	530B-56
37114-98J00	530A-10
	535A-5
37117-96L00	331A-6
	331B-4
	535A-22
	535B-18
37120-98L00	530B-43
37120-98L10	530B-45
37120-98L20	530B-47
37120-98L30	530B-49
37120-98L40	530B-51
37120-98L50	530B-53
37120-98L60	530B-55
37130-98L00	543B-2
37130-98L10	540B-2
37130-98L20	520B-33
37138-98L00	530B-5
37138-98L10	530B-17
37138-98L20	530B-26
37138-98L30	530B-35
37139-96L30	535A-6
37139-98J10	530A-5
37140-98L00	522B-22
37141-98L00	530B-3-1
	530B-15-1
	530B-24-1
	530B-33-1
37141-98L10	530B-3-2
	530B-15-2
	530B-24-2
	530B-33-2
37141-98L20	530B-3-3
	530B-15-3
	530B-24-3
	530B-33-3
37141-98L30	530B-3-4
	530B-15-4
	530B-24-4
	530B-33-4
37141-98L40	530B-3-5
	530B-15-5
	530B-24-5
	530B-33-5
37141-98L50	530B-3-6
	530B-15-6
	530B-24-6
	530B-33-6
37141-98L60	530B-3-7
	530B-15-7
	530B-24-7
	530B-33-7
37141-98L70	530B-3-8
	530B-15-8
	530B-24-8
	530B-33-8
37141-98L80	530B-3-9
	530B-15-9
	530B-24-9
	530B-33-9
37141-98L90	530B-3-10
	530B-15-10
	530B-24-10
	530B-33-10
37141-98LA0	530B-3-11
	530B-15-11
	530B-24-11
	530B-33-11
37141-98LB0	530B-3-12
	530B-15-12
	530B-24-12
	530B-33-12
37141-99E00	530A-3-3
37141-99E10	530A-3-4
	530B-4-2
	530B-16-2
	530B-25-2
	530B-34-2
37141-99E20	530A-3-5
	530B-4-3
	530B-16-3
	530B-25-3
	530B-34-3
37141-99E30	530A-3-6
	530B-4-4
	530B-16-4
	530B-25-4
	530B-34-4
37141-99E40	530A-3-7
	530B-4-5
37141-99E50	530A-3-8
	530B-4-6
	530B-16-6
	530B-25-6
	530B-34-6
	535A-3-6
37141-99E60	530A-3-9
	530B-4-7
	530B-16-7
	530B-25-7
	530B-34-7
37141-99E70	530A-3-10
	530B-4-8
	530B-16-8
	530B-25-8
	530B-34-8
37141-99E80	530A-3-11
	530B-4-9
	530B-16-9
	530B-25-9
	530B-34-9
37141-99E90	530A-3-12
	530B-4-10
	530B-16-10
	530B-25-10
	530B-34-10
37141-99EA0	530A-3-1
	530B-4-11
	530B-16-11
	530B-25-11
	530B-34-11
37141-99EB0	530A-3-2
	530B-4-12
	530B-16-12
	530B-25-12
	530B-34-12
37143-96L00	535A-4
37143-99E01	530A-4
37170-96L05	535A-21-2
37170-96L15	535A-21-1
37171-96L02	331A-7-1
37171-96L12	331A-7-2
	535A-23-2
37171-98L00	331B-5-1
	535B-19-1
	535B-16-5
	535B-25-5
	535B-34-5
	535A-3-5
	530A-3-8
	530A-4-6
	530B-16-6
	530B-25-6
	530B-34-6
	535A-3-6
	530A-3-9
	530B-4-7
	530B-16-7
	530B-25-7
	530B-34-7
	530A-3-10
	530B-4-8
	530B-16-8
	530B-25-8
	530B-34-8
	530A-3-11
	530B-4-9
	530B-16-9
	530B-25-9
	530B-34-9
	530A-3-12
	530B-4-10
	530B-16-10
	530B-25-10
	530B-34-10
	530A-3-1
	530B-4-11
	530B-16-11
	530B-25-11
	530B-34-11
	530A-3-2
	530B-4-12
	530B-16-12
	530B-25-12
	530B-34-12
	535A-4
	530A-4
	535A-21-2
	535A-21-1
	331A-7-1
	535A-23-1
	331A-7-2
	535A-23-2
	331B-5-1
	535B-19-1

PART NO.	FIG.NO.-REF.NO.
37171-98L10	331B-5-2
	535B-19-2
37172-96L01	331A-8-1
	535A-24-1
37172-96L02	331B-6-1
	535B-20-1
37172-96L10	331A-8-2
	535A-24-2
37172-96L11	331B-6-2
	535B-20-2
37173-96L00	535A-27
37173-96L10	331A-9
	331B-7
	535A-16
	535B-21
37290-98L00	535B-1
37290-98L10	535B-4
37290-98L20	535B-9
37292-98L00	535B-2
37292-98L10	535B-5
37292-98L20	535B-10
37721-93J00	326A-7
	326B-7
37722-93J13	326A-16
	326B-16
37725-93J11	326A-10
	326B-10
37729-96L00	326A-3
	326B-3
37803-93J06	530A-15
37803-98L00	530B-8
37820-93J11	530A-6
	530A-17
	535A-7
37820-98J00	315A-7
	315B-7
37820-98L00	520B-31
	530B-9
	530B-18
	530B-27
	530B-36
	535B-6
	535B-11
37823-92E02	530A-7
	530A-18
	535A-8
37823-98L00	520B-32
	530B-10
	530B-19
	530B-28
	530B-37
	535B-7
	535B-12
37825-99E10	530A-16
37826-92J10	530A-8
	530A-19
	535A-9
37832-98L00	530B-11
37850-92J00	326A-11
	326B-11
37850-98J03	520A-52
	520B-29
	540A-26
	543A-25
37850-98L00	540B-3
	543B-3
37856-92J00	326A-12
	326B-12
37857-92J01	326A-13
	326B-13
37860-87L00	530A-25
37860-98L00	530B-40
37862-87L00	530A-26
37865-98L00	530B-41
38100-93J04	337A-3
	337B-3
	340A-1
38100-93L01	337C-4
	340B-1
38410-93J12	326A-19
	326B-19
38415-93J00	326A-20
	326B-20
38500-93J90	331A-10
	530A-13
	530B-6
	530B-20
	530B-29
	530B-38
	530B-57
	535A-17
	540B-27
38860-76F01	322A-10
	322A-11
	326A-30
	326B-30
38860-96L01	331A-11
	331B-8
	535A-18
	535B-22
38860-96L10	522B-21
38890-98J12	326A-25
	326B-25
38892-98J01	326A-26
	326B-26
38895-98J00	326A-27
	326B-27
38915-90J00	326A-31
	326B-31
39950-88L02	602A-26
	602B-20
40000	
41111-93J16-QTN	335A-1-3
41111-93J16-Y5S	335A-1-2
41111-93J16-YAY	335A-1-1
	335A-1-4
41111-96J40-QTN	335B-1-3
41111-96J40-Y5S	335B-1-2
41111-96J40-YAY	335B-1-1
	335B-1-4
41117-93J02	335A-3
41117-93L00	335B-18
41121-93J08-QTN	335A-2-3
41121-93J08-Y5S	335A-2-2
41121-93J08-YAY	335A-2-1
	335A-2-4
41121-96J30-QTN	335B-2-3
41121-96J30-Y5S	335B-2-2
41121-96J30-YAY	335B-2-1
	335B-2-4
41122-93J02	335A-4
41122-93L00	335B-19
41130-92J03	335B-3
41130-93J12	335A-6
41135-92J00	335B-4
41135-93J11	335A-7
41155-93J02	335A-13
	335B-10
41220-93J11	336A-13
41220-96J10	336B-15
41224-95E01	336A-15
	336B-17

PART NO.	FIG.NO.-REF.NO.
41230-96J00	336A-16
	336B-18
41233-95E10	336A-17
	336B-19
41234-93J11	336A-14
41234-96J10	336B-16
43111-93J24-QTN	336A-3-3
43111-93J24-Y5S	336A-3-2
43111-93J24-YAY	336A-3-1
	336A-3-4
43111-96J20-QTN	336B-3-3
43111-96J20-Y5S	336B-3-2
43111-96J20-YAY	336B-3-1
	336B-3-4
43114-93J00	336A-4
43117-96J00	315B-24
43118-96J00	315B-26
43211-93J11	336A-5
	336B-4
43711-97E11	336A-6
	336B-5
43750-93J03-QTN	336A-7-3
43750-93J03-Y5S	336A-7-2
43750-93J03-YAY	336A-7-1
	336A-7-4
43750-96J03-QTN	336B-6-3
43750-96J03-Y5S	336B-6-2
43750-96J03-YAY	336B-6-1
	336B-6-4
45421-87D03	335A-16
48000-93L03	337C-1
48000-98J10	337A-1
48000-98J11	337B-1
48121-93J20	337A-23
	337B-24
48121-93L00	337C-26
48125-93J10	337A-24
	337B-25
48126-93J00	337A-28
	337B-29
48128-93J11	337A-30
	337B-31
48140-93J01	335A-18
	335B-13
48144-93J00	335A-19
	335B-14
48145-93J00	335A-22
	335B-16
48311-96J10	337A-32
	337B-33
48311-96J20	337C-28
48320-93J00	337A-6
	337B-6
48321-87D03	337C-29
48321-93J00	337A-33
	337B-34
48326-95E00	337C-30
48400-98J03	337A-14
	337B-14
48401-93L00	337C-9
48405-93J00	337A-15
	337B-15
	337C-16
48427-87D00	337A-18
	337B-18
48451-93J00	337A-25
	337B-26
48452-93J00	337A-26
	337B-27
48452-93J10	337A-27
	337B-28
48500-98J12	337A-4
	337B-4
48502-96J05	337C-5
48503-93L01	337C-8
48570-95E01	337C-18
48571-93J00	337A-31
	337B-32
48572-87J10	337A-19
	337B-19
48572-95E00	337C-19
48573-93J00	337A-29
	337B-30
48582-95E01	337A-7
	337B-7
	337C-6
48583-95E00	337A-22
	337B-23
	337C-20
48585-95E00	337A-20
	337B-20
	337C-21
48585-98L00	337B-21
48588-94900	337C-22
48601-93L00	337C-10
48605-93J00	337A-8
	337B-8
48610-93J01	337A-10
	337B-10
48615-87D00	337A-9
	337B-9
48615-97E00	337C-17
48627-93J00	337A-17
	337B-17
48627-95E00	337C-11
48630-96J04	337C-12
48630-98L01	337A-11
	337B-11
48633-93J00	337A-12
	337B-12
48633-94900	337C-13
48641-93L01	337C-14
48650-93J00	337A-16
	337B-16
48650-94900	337C-15
48691-93J00	337A-13
	337B-13
48861-92J01	337C-23
48862-87J20	337A-21
	337B-22
48862-92J20	337C-24
48862-92J30	337C-25
48864-96J10	337C-7
48864-98L00	337A-5
	337B-5
50000	
51111-93J31-Y5S	401A-1-2
	401A-1-4
51111-93J31-YAY	401A-1-1
	401A-1-3
51111-93J40-Y5S	401A-1-6
51111-93J40-YAY	401A-1-5
51116-93J01	401A-5
51120-98L00	401A-11
51123-93J01	401A-14
	585A-14
51124-93J01	401A-12
51125-93J00	401A-13
51140-93J11-QTN	401A-18-5
51140-93J11-Y5S	401A-18-3
51140-93J11-YAY	401A-18-1
	401A-18-7
51140-98J00-QTN	401A-18-6
51140-98J00-Y5S	401A-18-4
51140-98J00-YAY	401A-18-2
	401A-18-8

PART NO.	FIG.NO.-REF.NO.
51142-93J00	401A-19
	585A-15
51151-93J00	401A-21
51152-93J00	401A-22
51211-93J00	401A-6
	585A-16
52111-98J00-QTN	405A-1-3
	405B-1-3
52111-98J00-Y5S	405A-1-2
	405B-1-2
52111-98J00-YAY	405A-1-1
	405A-1-4
	405B-1-1
	405B-1-4
52111-98J20-QTN	405C-1-3
52111-98J20-Y5S	405C-1-2
52111-98J20-YAY	405C-1-1
	405C-1-4
52131-93J00-QTN	405B-7-3
52131-93J00-Y5S	405B-7-2
52131-93J00-YAY	405B-7-1
	405B-7-4
54112-93J00	401A-27
	405A-11
	405B-15
	405C-10
54121-93J20	401A-33-2
54121-98J01	401A-33-1
54123-93J03	401A-25
54130-93J01	401A-26
54137-93J02	401A-30
54140-98J01	401A-34
54144-93J01	401A-41
54150-98J01	405A-9
	405B-13
	405C-8
54160-98J00	405A-10
	405B-14
	405C-9
54165-98J01	405A-18
	405B-22
	405C-17
54211-93J00-QTN	405A-15-3
	405B-19-3
	405C-14-3
54211-93J00-Y5S	405A-15-2
	405B-19-2
	405C-14-2
54211-93J00-YAY	405A-15-1
	405A-15-4
	405B-19-1
	405B-19-4
	405C-14-1
	405C-14-4
	405A-16-5
54221-93J00	405B-20-5
	405C-15-5
54221-93J00-QTN	405A-16-3
	405B-20-3
	405C-15-3
54221-93J00-Y5S	405A-16-2
	405B-20-2
	405C-15-2
54221-93J00-YAY	405A-16-1
	405A-16-4
	405B-20-1
	405B-20-4
	405C-15-1
	405C-15-4
55110-93L20-QTN	407A-1-3
	407B-1-3
55110-93L20-Y5S	407A-1-2
	407B-1-2
55110-93L20-YAY	407A-1-1
	407A-1-4
	407B-1-1
55122-93L00	206A-14
	206B-14
55125-93L00-QTN	407A-11-3
	407B-11-3
55125-93L00-Y5S	407A-11-2
	407B-11-2
55125-93L00-YAY	407A-11-1
	407A-11-4
	407B-11-1
	407B-11-4
55128-93J10	407A-13
	407B-13
55128-93L00	407A-29
	407B-29
55320-94900	335A-14
	335B-11
55321-87J01	111A-15
	140A-6
	180A-2-1
	206A-18
	206B-18
55321-87J11	180A-2-2
55321-93J01	405A-20
	405B-24
	407A-15
	407B-15
55321-94910	335A-21
	335B-17
55332-98J01	407A-17
	407B-17
55333-98J00	407A-18
	407B-18
56120-93L20	220A-25
56120-93L30	220B-25
56122-93L00	220A-40
	220B-41
56126-93L10	220A-41
	220B-42
56127-93L00	220A-42
	220B-43
56128-93L00	220A-43
	220B-44
56129-93L00	220A-44
	220B-45
56130-93J02	220A-32
	220B-32
56141-93L00	206A-15
	206B-15
56147-93L00	220A-31
	220B-32
57110-93L02	220A-1-1
	220B-1-1
57110-93L12	220A-1-2
	220B-1-2
57110-93L22	220A-1-3
	220B-1-3
57130-87D10	405A-4
	405B-4
57133-93L00	220A-2
	220B-2
57134-93J00	220A-3
	220B-3
57300-93L20	220A-6
	220B-6
57527-93L00	220A-46
	220B-47
57541-93L00	220A-47
	220B-48
57610-93L10	220A-17
	220B-17
57617-93L00	220A-22
	220B-22
57621-93L00	220A-18
	220B-18
57622-93L00	220A-36
	220B-37
57630-93L00	407A-31
	407B-31
57631-93L01	220A-20
	220B-20
57632-93L11	407A-24
	407B-24
57633-93L00	407A-25
	407B-25
58120-93L00	407A-21
	407A-23
	407B-21
	407B-23
58700-93J00	407A-20-10
	407B-20-10
58700-93J10	407A-20-11
	407B-20-11
58700-93J20	407A-20-12
	407B-20-12
58700-93J30	407A-20-13
	407B-20-13
58700-93J40	407A-20-14
	407B-20-14
58700-93L01	407A-20-1
	407B-20-1
58700-93L11	407A-20-2
	407B-20-2
58700-93L21	407A-20-3
	407B-20-3
58700-93L31	407A-20-4
	407B-20-4
58700-93L41	407A-20-5
	407B-20-5
58700-93L51	407A-20-6
	407B-20-6
58700-93L61	407A-20-8
	407B-20-7
58700-93L71	407A-20-9
	407B-20-8
58700-93L81	407A-20-7
	407B-20-9
58700-96J00	407A-22-1
	407B-22-1
58700-96J10	407A-22-2
	407B-22-2
58700-96J20	407A-22-3
	407B-22-3
58700-96J30	407A-22-4
58700-96J40	407A-22-5
	407B-22-5
58700-96J50	407A-22-6
	407B-22-6
58800-93J10	407A-20-22
	407B-20-22
58800-93J20	407A-20-23
	407B-20-23
58800-93J30	407A-20-24
	407B-20-24
58800-93J40	407A-20-25
	407B-20-25
58800-93L00	407A-20-15
	407B-20-15
58800-93L10	407A-20-16
	407B-20-16
58800-93L20	407A-20-17
	407B-20-17
58800-93L30	407A-20-18
	407B-20-18
58800-93L40	407A-20-19
	407B-20-19
58800-93L50	407A-20-20
	407B-20-20
58800-93L60	407A-20-21
	407B-20-21
58800-96J00	407A-22-7
	407B-22-7
58800-96J10	407A-22-8
	407B-22-8
58800-96J20	407A-22-9
	407B-22-9
58800-96J30	407A-22-10
	407B-22-10
58800-96J40	407A-22-11
	407B-22-11
58800-96J50	407A-22-12
	407B-22-12
59171-93L00	220A-15-1
	220B-15-1
59171-93L10	220A-15-2
	220B-15-2
59171-93L20	220A-15-3
	220B-15-3
59171-93L30	220A-15-4
	220B-15-4
59171-93L40	220A-15-5
	220B-15-5
59171-93L50	220A-15-6
	220B-15-6
59171-93L60	220A-15-7
	220B-15-7
59171-93L70	220A-15-8
	220B-15-8
59171-93L80	220A-15-9
	220B-15-9
59171-93L90	220A-15-10
	220B-15-10
59171-93LA0	220A-15-11
	220B-15-11
59171-93LB0	220A-15-12
	220B-15-12
59171-93LC0	220A-15-13
	220B-15-13

60000

PART NO.	FIG.NO.-REF.NO.
61112-98J00	410A-25
	410B-25
61124-98J20	410A-43-1
	410B-43-1
61124-98J30	410A-43-2
	410B-43-2
61131-93J01-QTN	410A-1-3
61131-93J01-Y5S	410A-1-2
61131-93J01-YAY	410A-1-1
	410A-1-4
61131-93J20-QTN	410B-1-3
61131-93J20-Y5S	410B-1-2
61131-93J20-YAY	410B-1-1
	410B-1-4
61134-93J21	410A-8
	410B-8
61137-93J01	410A-3
	410B-3
61141-93J01-QTN	410A-2-3
61141-93J01-Y5S	410A-2-2
61141-93J01-YAY	410A-2-1
	410A-2-4
61141-93J20-QTN	410B-2-3
61141-93J20-Y5S	410B-2-2
61141-93J20-YAY	410B-2-1
	410B-2-4
61155-93J20	401A-7
61420-98802-YAY	420A-1-1
	420B-1-1
61420-98812-Y5S	420A-1-2

PART NO.	FIG.NO.-REF.NO.
	420B-1-2
61420-98840-YAY	420C-1-1
	420D-1-1
61420-98850-QTN	420C-1-2
	420D-1-2
61422-93JE0	420B-32-2
61422-98J30	420A-32-2
61422-98J40	420B-32-1
61422-98J50	420A-32-1
61425-98J00	420A-28
	420B-28
	420C-28
	420D-28
61431-98J10-QTN	420C-2-2
	420D-2-2
61431-98J10-Y5S	420A-2-2
	420B-2-2
61431-98J10-YAY	420A-2-1
	420B-2-1
	420C-2-1
	420D-2-1
61432-98J01	420A-3
	420B-3
	420C-3
	420D-3
61433-98J01	420A-4
	420B-4
	420C-4
	420D-4
61434-98J02	420A-5
	420B-5
	420C-5
	420D-5
61435-93JD0	420B-33-2
61435-93JP0	420D-32-1
61435-93JQ0	420D-32-2
61435-98J30	420A-33-2
61435-98J50	420A-33-1
61435-98J60	420B-33-1
61435-98J70	420C-32-1
61435-98J80	420C-32-2
61439-98J01	420A-6
	420B-6
	420C-6
	420D-6
61439-98J11	420A-7
	420B-7
	420C-7
	420D-7
61439-98J21	420A-8

PART NO.	FIG.NO.-REF.NO.
	420B-8
	420C-8
	420D-8
61441-98L00	420A-31
	420B-31
	420C-31
	420D-31
61443-96J70	420A-29-1
	420B-29-1
61443-96J80	420A-29-2
	420B-29-2
61443-96L30	420C-29-1
	420D-29-1
61443-96L40	420C-29-2
	420D-29-2
61453-96J70	420A-30-1
	420B-30-1
61453-96J80	420A-30-2
	420B-30-2
61453-96L30	420C-30-1
	420D-30-1
61453-96L40	420C-30-2
	420D-30-2
61458-90J01	410A-45
	410B-45
61476-98J00	420A-9
	420B-9
	420C-9
	420D-9
61494-93J01	136A-19
61610-98J00	420A-16
	420B-16
	420C-16
	420D-16
61610-98J30	420A-17
	420B-17
	420C-17
	420D-17
61610-98J40	420A-18
	420B-18
	420C-18
	420D-18
61614-98J00	420A-20
	420B-20
	420C-20
61619-98J00	420A-24
	420B-24
	420C-24
	420D-24

PART NO.	FIG.NO.-REF.NO.
61621-98J02	420A-21
	420B-21
	420C-21
	420D-21
61624-98J11	420A-22
	420B-22
	420C-22
	420D-22
61625-98J11	420A-23
	420B-23
	420C-23
	420D-23
61630-98J00	410A-26
	410B-26
61633-98J10-QTN	410A-32-3
	410B-32-3
61633-98J10-Y5S	410A-32-2
	410B-32-2
61633-98J10-YAY	410A-32-1
	410A-32-4
	410B-32-1
	410B-32-4
61634-98J10-QTN	410A-33-3
	410B-33-3
61634-98J10-Y5S	410A-33-2
	410B-33-2
61634-98J10-YAY	410A-33-1
	410A-33-4
	410B-33-1
	410B-33-4
61635-98J00	410A-39
	410B-39
61636-98J00	410A-31
	410B-31
61643-98J00	410A-40
	410B-40
61645-98J00-QTN	410A-34-3
	410B-34-3
61645-98J00-Y5S	410A-34-2
	410B-34-2
61645-98J00-YAY	410A-34-1
	410A-34-4
	410B-34-1
	410B-34-4
61658-98J00	410A-41
	410B-41
61811-98J20-QTN	410A-6-3
	410B-6-3
61811-98J20-Y5S	410A-6-2
	410B-6-2

PART NO.	FIG.NO.-REF.NO.
61811-98J20-YAY	410A-6-1
	410A-6-4
	410B-6-1
	410B-6-4
61812-98J00	410A-16
	410B-16
61814-98J00	410A-17
	410B-17
61817-93J01	410A-10
	410B-10
61821-98J10-QTN	410A-7-3
	410B-7-3
61821-98J10-Y5S	410A-7-2
	410B-7-2
61821-98J10-YAY	410A-7-1
	410A-7-4
	410B-7-1
	410B-7-4
61827-93J02	410A-12
	410B-12
61831-98J02-QTN	410A-18-3
	410B-18-3
61831-98J02-Y5S	410A-18-2
	410B-18-2
61831-98J02-YAY	410A-18-1
	410A-18-4
	410B-18-1
	410B-18-4
61832-98J00	410A-15
	410B-15
63632-98J20	410A-27
	410B-27
63632-98J30	410A-28
	410B-28
65700-93J12	430A-1-1
65700-93J14	430A-1-2
65770-93J04	475A-1-2
65770-93J13	430A-2
	475A-1-1
67200-98J06	543A-1
67200-98J16	540A-1
67200-98J24	520A-1
67200-98L00	543B-1
67200-98L10	540B-1
67200-98L20	520B-1
67211-98J20	520A-18
	520B-18
	540A-2
	543A-2
67211-98J30	540A-48

PART NO.	FIG.NO.-REF.NO.
67212-98J20	543A-7
67212-98J30	540A-8
67212-98L00	543B-4
67212-98L10	540B-4
67222-98J00	520A-32
67222-98J10	540A-10
	543A-9
67222-98J20	540A-49
67223-98J00	520A-36
	540A-17
	543A-16
67226-98J00	540A-37
	540B-8
	543A-36
	543B-7
67226-98J10	520A-26
	520B-23
67227-98J00	540A-41
67227-98J10	520A-42
	540A-25
	543A-24
67227-98J20	520A-21
	520B-20
67227-98J30	520A-22
67227-98L00	520B-34
67228-98J50	520A-47
	540A-47
	543A-47
67233-98J00	520A-15
67233-98J10	540A-14
	543A-13
67234-98J00	520A-17
	520B-17
67235-98J00	520A-34
67235-98J10	540A-12
	543A-11
67236-98J00	520A-33
67236-98J10	540A-11
	543A-10
67237-98J00	520A-35
67237-98J30	543A-12
67237-98J40	540A-13
67237-98J50	540A-56
67238-98J00	520A-29
	520B-25
67239-98J00	540A-16
	543A-15
67246-98J00	520A-31
67246-98J10	540A-4
	543A-4

PART NO.	FIG.NO.-REF.NO.
67246-98J20	540A-50
67251-98J00	540A-3
	543A-3
67251-98J20	520A-12
	520B-13
67252-98J00	520A-38
67252-98J10	540A-21
	543A-20
67254-98J00	520A-14
	520B-15
67255-98J00	520A-8
	520B-9
67256-98J00	520A-10
67256-98L00	520B-11
67257-98J00	520A-54
	520B-30
	540A-43
	543A-43
67258-98J00	520A-9
	520B-10
67259-98J00	520A-11
	520B-12
67261-98J00	540A-5
	543A-5
67261-98J10	540A-6
67261-98J20	520A-5
	520B-6
67261-98J30	520A-6
	520B-7
67261-98L00	540B-9
	543B-8
67261-98L10	540B-10
	543B-9
67261-98L20	540B-11
67263-98J00	540A-7
	543A-6
67263-98J20	520A-4
	520B-5
67264-98J00	520A-3
67264-98L00	520B-3
67265-98J00	520A-7
	520B-8
67269-98J01	540A-27
	543A-26
67269-98J10	520A-53
67269-98J20	520A-19
67269-98J30	540A-44
	543A-44
67269-98L00	540B-12
	543B-10

PART NO.	FIG.NO.-REF.NO.
67271-98J20	520A-2
67271-98J30	543A-8
67271-98J40	540A-9
67271-98L00	543B-11
67271-98L10	540B-13
67272-98J00	520A-51
67272-98J10	540A-20
	543A-19
67272-98L00	543B-12
67272-98L10	540B-14
67272-98L20	520B-2
67273-98J00	543A-27
67273-98J10	540A-51
	543A-48
67273-98J20	540A-28
67273-98J30	540A-52
	543A-49
67273-98L00	543B-13
67273-98L10	540B-15
67274-98J00	543A-29
67277-98J00	540A-53
	543A-50
67277-98L00	543B-14
67277-98L10	540B-16
	543B-15
67277-98L20	540B-17
67284-98J10	540A-42
	543A-42
67284-98L00	540B-5
	543B-5
67284-98L10	540B-6
67284-98L20	520B-4
67287-92E00	540A-15
	540A-39
	540B-18
	543A-14
	543A-38
	543B-16
67287-98J00	520A-25
	520B-22
67288-92E20	540A-36
	543A-30
67288-92E50	540B-24
67288-94310	520B-28
67288-98J00	520A-44
	520B-26
	540A-35
	543A-34
67288-98J10	520A-46
	540A-45
67288-98J20	543A-45
	520A-39
	540A-22
	543A-21
67288-98J30	540A-46
	543A-46
67288-98J40	540A-34
	540B-19
	543A-40
	543B-17
67288-98J50	520A-23
	520B-21
67288-98J60	520A-27
	520B-24
67288-98J70	520A-30
67292-98J00	520A-40
	540A-23
	543A-22
67294-98J00	520A-13
	520B-14
67296-88D00	540B-25
	543B-22
67296-94300	520A-43
	540A-33
	543A-33
67296-98J00	540A-32
	543A-39
67296-98J10	520A-45
	543A-41
67296-98J20	543A-35
67296-98J30	540A-30
67296-98J50	520A-50
	540A-18
	540B-20
	543A-17
	543B-18
67296-98J60	520A-48
	520B-27
	540A-29
	543A-28
67296-98J90	540A-40
	543A-31
67296-98JA0	520A-16
	520B-16
	540A-19
	543A-18
67296-98JB0	520A-20
	520B-19
67296-98JC0	520A-24
67296-98JD0	520A-28
67296-98JE0	520A-37
67296-98JF0	540A-54
	543A-51
67296-98JG0	540A-31
	543A-32
67296-98L00	540B-21
	543B-19
67296-98L10	540B-22
	543B-20
67297-98J00	540A-55
	540B-23
	543A-52
	543B-21
67361-90J10	410A-46
	410B-46
67467-89J01	204A-25
67467-89J10	204A-31
67471-99E00	204A-26
67471-99E10	204A-32
68111-88L00	540B-7
	543B-6
69711-93E11	136A-18
70000	
77811-54GC0-0PG	420A-19
	420B-19
	420C-19
	420D-19
90000	
99011-98J91-03B	420A-35-3
	420B-35-3
99011-98J91-054	420A-35-1
	420B-35-1
99011-98J91-059	420A-35-2
	420B-35-2
99011-98JA0-03B	420C-34-1
	420D-34-1
99011-98JA0-054	420C-34-3
	420D-34-3

PART NO.	FIG.NO.-REF.NO.
99011-98JA0-059	420C-34-5
	420D-34-5
99011-98JB0-03B	420C-34-2
	420D-34-2
99011-98JB0-054	420C-34-4
	420D-34-4
99011-98JB0-059	420C-34-6
	420D-34-6
00000	
01421-08357	163A-27
01500-06167	147A-40
	147B-40
	147C-40
	147D-40
01547-06167	420A-25
	420B-25
	420C-25
	420D-25
01547-06257	111A-29-1
01547-0625C	111A-29-2
01547-06507	111A-30-1
01547-0650C	111A-30-2
01550-06127	136A-8
	144A-23-1
	144B-23-1
	147A-65
	147B-65
	162A-42-1
	180A-29-1
	303A-14-1
	310A-9-1
	322A-29
	326A-15-1
	326A-21
	326B-15-1
	326B-21
	420A-26
	420A-27
	420B-26
	420B-27
	420C-26
	420C-27
	420D-26
	420D-27
01550-0612C	144A-23-2
	144B-23-2
	147C-65
	147D-65
	162A-42-2
	180A-29-2
	303A-14-2
	310A-9-2
	322A-22
	326A-15-2
	326B-15-2
01550-06167	303A-6-1
	303A-11-1
	326A-28-1
	326B-28-1
	420A-10
	420A-12
	420A-14
	420B-10
	420B-12
	420B-14
	420C-10
	420C-12
	420C-14
	420D-10
	420D-12
	420D-14
01550-0616A	175A-11
01550-0616C	303A-6-2
	303A-11-2
	326A-28-2
	326B-28-2
01550-06207	111A-4
	111A-8
	113A-24-1
	136A-9
	136A-14-1
	136A-15-1
	162A-33-1
	162A-34-1
	204A-21-1
	310A-12-1
	420A-11
	420B-11
	420C-11
	420D-11
01550-0620A	119A-25
	119A-26
01550-0620C	113A-24-2
	136A-14-2
01550-0625C	121B-13
01550-06257	121A-13
	121C-13
	140A-10
	147A-44
	147B-44
	147C-44
	147D-44
	162A-35-1
	310A-10-1
	121D-13
	162A-35-2
	310A-10-2
01550-06357	147A-61
	147B-61
	147C-61
	147D-61
	206A-19
	206B-19
	326A-29
	326B-29
01550-06407	136A-16-1
01550-0640C	136A-16-2
01550-08127	162A-25-1
01550-0812C	162A-25-2
01550-08167	163A-10
	163A-28-1
	410A-14
	410B-14
01550-0816C	163A-28-2
01550-08207	111A-17-1
	111A-35-1
	113A-2-1
	140A-9-1
	301A-18
01550-0820C	111A-17-2
	111A-35-2
	113A-2-2
	140A-9-2
01550-08307	301A-19-1
	401A-9
	401A-23
01550-0830A	119A-13
	119A-17
	119A-21

PART NO.	FIG.NO.-REF.NO.
	401A-17
01550-08357	136A-17-1
	163A-11
	163A-29-1
01550-0835A	113A-28
01550-0835C	136A-17-2
	163A-29-2
	301A-19-2
01550-08407	144A-18-1
	144B-18-1
	147A-63
	147B-63
01550-0840C	144A-18-2
	144B-18-2
	147C-63
	147D-63
01550-08457	113A-29-1
01550-0845A	175A-12
01550-0845C	113A-29-2
01550-08557	204A-30-1
01550-0855A	119A-7
01550-0855C	204A-30-2
01550-08607	111A-18
	111A-19
	163A-30-1
	401A-24
01550-0860C	163A-30-2
01550-0865A	175A-13
01550-0885A	175A-14
01550-1025A	116A-12
01550-1050A	180A-19
02112-0406B	147A-54
	147B-54
	147C-54
	147D-54
02112-0612A	111A-28
02142-0408B	147A-28
	147C-28
02142-05107	204A-22
02162-05207	163A-12-1
03122-05169	530A-9
	530A-20
	535A-10
03142-05169	530B-7
	530B-12
	530B-21
	530B-30
	530B-39
	530B-42
	535B-3
	535B-8
	535B-13
03542-0516C	335B-20
03542-06169	420A-13
	420A-15
	420B-13
	420B-15
	420C-13
	420C-15
	420D-13
	420D-15
04211-11129	163A-13
	163A-31
04211-13149	119A-12
06111-07004	220A-23
	220B-23
06111-11004	220A-24
	220B-24
07130-0510A	113A-18
07130-05167	326A-5
	326B-5
07130-0616A	113A-17
08110-60020	175A-15
08221-16256	220A-9
	220B-9
08310-00067	322A-17
08316-10067	147C-78
	147D-78
08316-10087	163A-33-1
	322A-2
08316-1008C	163A-33-2
08321-0105A	326A-6
	326B-6
08321-01067	322A-18
08331-41359	204A-23
09100-12052	407A-4
	407B-4-1
	407B-4-2
09100-12085	335A-9-2
	335B-6-2
09100-12086	335A-9-1
	335B-6-1
09100-12092	335A-9-3
	335B-6-3
09103-05028	163A-12-2
09103-06093	315A-17
	315B-16
09103-06231	303A-12
09103-06266	111A-2-2
	111A-6-2
09103-06278	335A-20
	335B-15
09103-06281	111A-16
	140A-7
	180A-4
	206A-20
	206B-20
09103-08109	401A-15
09103-08370	163A-23
09103-08437	122A-4
09103-12125	303A-2
09106-05030	303A-8
09108-08282	122A-3
09108-10115	405B-8
09108-10150	405C-5
09108-12013	405B-9
09116-05010	315B-25
09116-06121	162A-13
	335A-15
	335B-12
09116-06202	147A-59
	147B-59
	147C-59
	147D-59
	310A-7
09116-06236	405A-21
	405B-25
	407A-16
	407B-16
09116-06525	147A-48
	147B-48
	147C-48
	147D-48
09116-08122	401A-20
09116-08126	401A-39
09116-08128	180A-20
09116-08131	160A-16
	160B-16
09116-08137	407A-12
	407B-12
09116-08174	410A-19
	410B-19
09116-10134	401A-38
09116-10135	401A-31
09116-10137	401A-35
09116-10146	180A-22
	401A-37
09116-10150	407A-5
	407B-5-1
	407B-5-2

PART NO.	FIG.NO.-REF.NO.
09116-10175	180A-21
	337A-38
	337B-39
	401A-32
	401A-36
	405A-17
	405B-21
	405C-16
09116-10176	405A-2
	405B-2
	405C-2
09116-10183	337C-31
09116-10184	180A-23
09125-05048	315A-15
	315B-14
09125-05050	337C-38
09125-06063	315A-8
	335A-5
	335A-24
	336A-8
	336A-18
	336B-7
	336B-14
	336B-20
	336B-26
	337A-42
	337A-43
	337A-44
	337B-43
	337B-44
	337B-45
	337C-37
	405A-6
	405A-8
	405B-6
	405B-12
	405C-7
	405C-20
09131-05004	530A-27
09132-04034	160A-17
	160B-17
	206A-22
	206B-22
09136-06148	410A-11
	410B-5
	410B-11
09136-06161	410B-4
09137-04004	326A-8
	326B-8
09139-06135	410A-4
09139-06136	410A-5
09140-05005	315A-14
09140-10031	337A-34
	337B-35
	337C-32
	405C-4
	407A-8
	407B-8
09140-10032	336A-19
	336B-21
09140-16026	220A-8
	220B-8
09140-48001	220A-39
	220B-40
09141-18005	407A-26
	407B-26
09159-08136	122A-5
	163A-32
09159-10116	113A-12
09159-12014	407A-9
	407B-9
09159-12062	335A-10
	335B-7
09159-14020	335A-17
09159-22006	335A-8
	335B-5
09159-28003	220A-4
	220B-4
09160-05024	540A-38
	543A-37
09160-05029	315A-16
	315B-15
	326A-4
	326B-4
09160-05053	335B-21
09160-06055	204A-27
09160-06082	336A-20
	336B-22
09160-06094	204A-10
09160-06104	520A-49
09160-06134	310A-4
09160-08082	410A-38
	410B-38
09160-08152	410A-37
	410B-37
09160-08161	122A-6
	163A-34
09160-10082	206A-10
	206B-10
09160-10104	116A-11
09160-10141	405C-6
	407A-6
	407B-6
09160-10148	204A-4
09160-10161	337C-27
09160-12066	407A-7
	407A-30
	407B-7
	407B-30
09160-13021	335A-12
	335B-8
09160-13022	335A-11
	335B-9
09160-14066	405A-19
	405B-23
	405C-18
09160-15051	401A-29
09160-16050	405A-12
	405A-14
	405B-16
	405B-18
	405C-11
	405C-13
09160-17052	410A-30
	410B-30
09160-18028	407A-27
	407B-27
09160-18031	113A-10
09160-39001	336A-9
	336B-8
09160-60012	220A-12
	220B-12
09162-10005	337A-35
	337B-36
	337C-33
09164-50002	220A-37
	220B-38
09168-10034	407A-14
	407B-14
09168-12012	180A-15
09168-12013	147A-16
	147C-16
09168-20002	160A-20
	160B-20
09169-06062	147A-58
	147B-58
	147C-58
	147D-58
	310A-5
09169-06093	147A-14

PART NO.	FIG.NO.-REF.NO.
	147B-14
	147C-14
	147D-14
09169-08038	401A-40
09169-08042	147A-62
	147B-62
	147C-62
	147D-62
09169-08050	410A-20
	410B-20
09169-28003	336B-11
09180-32006	220A-10
	220B-10
09181-12158	175A-9
09181-32035	220A-11-1
	220B-11-1
09181-32036	220A-11-2
	220B-11-2
09181-32037	220A-11-3
	220B-11-3
09181-32038	220A-11-4
	220B-11-4
09181-32039	220A-11-5
	220B-11-5
09181-32040	220A-11-6
	220B-11-6
09181-32041	220A-11-7
	220B-11-7
09181-32042	220A-11-8
	220B-11-8
09181-32043	220A-11-9
	220B-11-9
09181-32044	220A-11-10
	220B-11-10
09181-39001	336A-10
	336B-9
09181-60004	220A-7-1
	220B-7-1
09181-60005	220A-7-2
	220B-7-2
09181-60006	220A-7-3
	220B-7-3
09181-60007	220A-7-4
	220B-7-4
09181-60008	220A-7-5
	220B-7-5
09181-60009	220A-7-6
	220B-7-6
09181-60010	220A-7-7
	220B-7-7
09181-60011	220A-7-8
	220B-7-8
09181-60012	220A-7-9
	220B-7-9
09181-60013	220A-7-10
	220B-7-10
09181-93101	220A-14-1
	220B-14-1
09181-93102	220A-14-2
	220B-14-2
09181-93103	220A-14-3
	220B-14-3
09181-93104	220A-14-4
	220B-14-4
09181-93105	220A-14-5
	220B-14-5
09181-93106	220A-14-6
	220B-14-6
09181-93107	220A-14-7
	220B-14-7
09181-93108	220A-14-8
	220B-14-8
09181-93109	220A-14-9
	220B-14-9
09181-93110	220A-14-10
	220B-14-10
09181-93111	220A-14-11
	220B-14-11
09181-93112	220A-14-12
	220B-14-12
09181-93113	220A-14-13
	220B-14-13
09202-05032	121A-9
	121B-9
	121C-9
	121D-9
09202-06031	160A-18
	160B-18
	303A-3
	407A-19
	407B-19
09202-08006	180A-17
	180A-18
	405A-3
	405B-3
	405B-10
	405C-3
	407A-10
	407B-10
09202-08013	220A-19
	220B-19
09204-01006	204A-11
	336A-21
	336B-23
09204-03003	407A-28
	407B-28
09205-03004	206A-4
	206B-4
09205-10006	204A-12
09206-08001	111A-3
	111A-7
	111A-27
	401A-8
	401A-16
09206-09012	206A-21
	206B-21
09206-13019	113A-13
09206-14004	111A-20
09208-06009	410A-47-1
	410B-47-1
09208-06011	410A-47-2
	410B-47-2
09246-04009	113A-21
09247-14041	144A-11
09247-14042	144B-11
09248-12009	180A-16
09248-12011	204A-13
09248-18006	113A-11
09248-26001	113A-9
09251-09009	144A-24
	144B-24
09260-10005	204A-14
09261-05006	121A-10
	121B-10
	121C-10
	121D-10
09262-17019	204A-15
09262-40017	119A-3
09262-40021	119A-2
09263-30063	220A-26
	220B-26
09263-35048	407A-2
	407B-2
09263-80001	407A-3
	407B-3
09263-80002	220A-13
	220B-13
09265-30033	220A-16
	220B-16
09265-32003	220A-27

PART NO.	FIG.NO.-REF.NO.
	220B-27
09265-50004	220A-48
	220B-49
09265-55001	220A-49
	220B-50
09269-32002	220A-5
	220B-5
09280-00047	220A-28
	220B-28
09280-00050	220A-45
	220B-46
09280-06005	113A-20
09280-09008	180A-28
09280-10009	113A-15
	163A-9
09280-10015	113A-16
09280-22019	111A-14
	140A-8
	180A-5
09280-22020	175A-10
09280-26006	111A-32
	162A-14
09280-66004	220A-33
	220B-34
09280-70012	119A-6
09280-80001	220B-29
09282-24004	220A-34
	220B-35
09282-30006	220A-29
	220B-30
09282-39001	336A-11
	336B-12
09283-10011	206A-7
	206B-7
09283-32044	119A-4
09283-91001	116A-13
09289-05012	121A-22
	121B-22
	121C-22
	121D-22
09289-18001	204A-16
09306-06005	204A-17
09306-10001	204A-18
09306-17001	337C-34
09306-17002	410A-29
	410B-29
09306-24001	337A-36
	337B-37
09320-08062	144A-12
	144B-12
09320-08501	147A-11
	147B-11
	147C-11
	147D-11
09320-08510	322A-9
09320-08517	163A-24
09320-08520	147A-66
	147B-66
09320-09016	310A-6
09320-11023	410A-21
	410B-21
09320-12093	162A-15
09320-12094	147A-33
	147B-33
	147C-33
	147D-33
09320-12095	310A-8
09321-10049	410A-13
	410A-22
	410B-13
	410B-22
09329-14003	410A-42
	410B-42
09343-70503-600	147A-55
	147B-55
	147C-55
	147D-55
09343-75002-600	147A-9
	147A-35
	147A-46
	147B-9
	147B-35
	147B-46
	147C-9
	147C-35
	147C-46
	147D-9
	147D-35
	147D-46
09352-50003-00A	147A-72
	147B-72
09352-50003-080	147C-67
	147D-67
09352-50003-810	147C-72
	147D-72
09352-50006-00B	162A-23
	162A-24
09352-50006-600	162A-16
	162A-17
	162A-18
09360-12008	147A-17
	147C-17
09360-12013	147B-17
	147D-17
09360-14009	144A-13
09360-14014	144B-13
09363-08004	147A-18
	147C-18
09367-06002	162A-26
09380-17009	337C-35
09380-21002	337A-37
	337B-38
09380-38003	336A-12
	336B-10
09381-22010	116A-4
09381-40003	220A-30
	220A-35
	220B-31
	220B-36
09381-72003	220A-38
	220B-39
09383-04002	410A-48
	410B-48
09383-07003	206A-13
	206B-13
09383-08004	204A-19
09385-06012	204A-28
09387-38002	405A-5
	405B-5
09401-08412	147A-73
	147B-73
	147C-73
	147D-73
09401-08413	162A-27
09401-11414	147A-36
	147B-36
	147C-36
	147D-36
09401-11423	147A-56
	147B-56
	147C-56
	147D-56
09401-11425	144A-14
	144B-14
09401-13423	163A-21
	430A-3-1

PART NO.	FIG.NO.-REF.NO.
09401-14409	144A-20
	144B-20
	162A-28
	430A-3-2
09401-15414	162A-37
09401-18410	136A-7
09401-25406	162A-29
09403-07340	315A-19
	315B-18
09403-09330	326A-17-2
	326B-17
09403-11328	326A-14
	326B-14
09403-13310	163A-25
09403-13402	522A-23
	522B-20
09403-13414	303A-13
09403-14304	147A-67
	147B-67
09403-16307	144A-15
	144B-15
09403-19412	315A-9
	315B-9
09403-20308	322A-23
09403-25304	162A-30
09407-08401	530A-14
	530B-58
	540B-28
09407-10404	326A-9
	326B-9
	522A-3
	522B-3
09407-14407	315A-11
	315B-11
	322A-24-1
	322A-24-2
	326A-17-1
	331A-12
	331B-9
	535A-20
	535B-23
09407-20405	410A-44-2
	410B-44-2
09407-25402	410A-44-1
	410B-44-1
09407-30401	326A-22
	326B-22
09408-00008	162A-31
	322A-25-1
	322A-25-2
09408-00012	322A-27
09408-00021	162A-40
	310A-13
09408-00024	162A-39
	322A-28
09408-00050	147A-75
	147B-75
09408-00056	147A-74
	147B-74
	147C-74
	147D-74
	162A-32
09408-00105	144A-16
	144B-16
	147C-79
	147D-79
09408-00135	144A-21
	144B-21
09408-00155	144A-17
	144B-17
	163A-26
09408-00184	322A-26
09409-05302-5PK	410A-9
	410B-9
09420-05009	160A-19
	160A-28
	160B-19
09440-07051	204A-20
09440-19028	336A-22
	336B-24
09440-58001	220A-21
	220B-21
09443-10043	336A-23
	336B-25
09481-10501	522A-14
09481-10504	322A-4
09481-15504	322A-12
09481-30501	523A-2
	523B-2
09481-30504	322A-13
09481-40401	522A-4
	522B-4
09481-40403	322A-14
09481-60403	322A-15
09482-00427	111A-33
09800-81835	420A-34
	420B-34
	420C-33
	420D-33

PART NO.	FIG.NO.-REF.NO.

PART NO.	FIG.NO.-REF.NO.

PART NO.	FIG.NO.-REF.NO.

SUZUKI **DF300AP/250AP** PARTS CATALOGUE

SUZUKI MOTOR CORPORATION All rights reserved
No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Suzuki Motor Corporation.

SUZUKI MOTOR CORPORATION
Service Material Development Group, Automobile & Motorcycle Service Engineering Dept.
300 Takatsuka, Minami, Hamamatsu, Japan

Copyright © SUZUKI MOTOR CORPORATION 2021 All Rights Reserved

SUZUKI MOTOR CORPORATION

PRINTED IN JAPAN

9900B-45492-000