SUZUKI

PARTS CATALOGUE

DF40A/DF50A/DF60A

DF40AT/ATH/AQH/AST/ASVT
DF50AT/ATH/AVT
DF60AT/ATH/AQH/AVT/AVTH

OUTBOARD MOTOR E11/E40/E03/E01/E34

020 021 022 023

2022-5 1ST EDITION

This part catalogue supersedes all the following part catalogue with immediate effect

Model of catalogue	Parts catalogue No.
DF40A/DF50A/DF60A_022	9900B-45494-000

PREFACE

When it becomes necessary to replace parts on SUZUKI OUTBOARD MOTORS, always use SUZUKI GENUINE PARTS which have passed a strict inspection which guarantees quality and performance.

This parts catalogue covers the list of all service parts for SUZUKI DF40A/50A/60A production start from 2019 to 2022.

INSTRUCTIONS FOR QUOTING THE CATALOGUE

1. DIMENSIONS

Dimensions of the parts in this catalogue are indicated in unit millimeters.

2. ABBREVIATIONS

Abbreviations used in this catalogue are as follows:

AR	: As required	NT	: Number of teeth
ASSY	: Assembly	OPT	: Optional
E.NO.	: Engine number	OS	: Over size
F.NO.	: Frame number	STD	: Standard
D	: Diameter of material	T	: Thickness
ID	: Inside diameter	US	: Under size
OD	: Outside diameter	W	: Width
L	: Length	W/	: With
LH(PORT)	: Left hand side	L	: Transom type
RH(STBD)	: Right hand side	SUS	: Stainless steel
～031234	: Up to E.NO.06002F-031234	PTT	: Power trim and tilt
031234～	: From E.NO.06002F-031234		

12 x 34 x 5.6····· Figures in the description column
| | | show the dimensions of parts.
ID OD T(or W,L)

→12345-56781 (Parts No.) : indicates that the parts number was changed to 12345-56781 and the new parts are interchangeable with the former ones but the former ones are not interchangeable with new ones.

←12345-56781 (Parts No.) : indicates that the former and new parts are interchangeable with each other and both are usable.

3. INNER PARTS OF ASSEMBLY

Part name with a dot (.) in front as shown in the description column indicates the component of the assembly also available individually.

4. MODIFICATION NOTICE

A parts bulletin will be sent to you on all occasions when changes in parts occur, including interchangeable modifications between new parts and old ones.

5. NOTE

5-1. There are some different parts from those of production models among spare parts for the administrative reasons and common use of them with other models.

5-2. In respect of rubber hoses and vinyl tubes, please be sure to use them by cutting off according to the length mentioned on parts catalogue or what is actually required on the vehicle.

5-3. Note that the drawings on the illustration page are for ready reference of spare parts number, not to be used as an assembly manual. When assembling, use "SUZUKI SERVICE MANUAL".

6. MODEL NAME AND ENGINE NUMBER

MODEL	DESTINATION	TYPE	TRANSOM	COLOR	ENGINE No.
DF40AT_020	E01	04003F	S,L	YAY,Y5S	04003F-040001～
DF40AT_020	E03	04003F	L	YAY,Y5S	04003F-040001～
DF40AT_021	E11	04003F	S,L	YAY,QTN	04003F-140001～
DF40AT_022	E11	04003F	S,L	YAY,QTN	04003F-240001～
DF40AT_023	E11	04003F	S,L	YAY,QTN	04003F-340001～
DF40AQH_020	E01	04003F	L	YAY	04003F-040001～
DF40AQH_021	E01	04003F	L	YAY	04003F-140001～
DF40AQH_022	E01	04003F	L	YAY	04003F-240001～
DF40AQH_023	E01	04003F	L	YAY	04003F-340001～
DF40ATH_020	E01	04003F	L	YAY	04003F-040001～
DF40ATH_021	E01	04003F	L	YAY	04003F-140001～
DF40ATH_022	E01	04003F	L	YAY	04003F-240001～
DF40ATH_023	E01	04003F	L	YAY	04003F-340001～

MODEL	DESTINATION	TYPE	TRANSOM	COLOR	ENGINE No.
DF40AST_020	E34	04004F	S, L	YAY, Y5S	04004F-040001～
DF40AST_021	E34	04004F	S, L	YAY, QTN	04004F-140001～
DF40AST_022	E34	04004F	S, L	YAY, QTN	04004F-240001～
DF40AST_023	E34	04004F	S, L	YAY, QTN	04004F-340001～
DF50AT_020	E01	05003F	S, L	YAY, Y5S	05003F-040001～
DF50AT_020	E03	05003F	L	YAY, Y5S	05003F-040001～
DF50AT_021	E11	05003F	S, L	YAY, QTN	05003F-140001～
DF50AT_022	E11	05003F	S, L	YAY, QTN	05003F-240001～
DF50AT_023	E11	05003F	S, L	YAY, QTN	05003F-340001～
DF50ATH_020	E01	05003F	L	YAY	05003F-040001～
DF50ATH_021	E01	05003F	L	YAY	05003F-140001～
DF50ATH_022	E01	05003F	L	YAY	05003F-240001～
DF50ATH_023	E01	05003F	L	YAY	05003F-340001～
DF60AT_020	E01	06002F	S, L, X	YAY, Y5S	06002F-040001～
DF60AT_020	E03	06002F	L	YAY, Y5S	06002F-040001～
DF60AT_021	E11	06002F	S, L, X	YAY, QTN	06002F-140001～
DF60AT_022	E11	06002F	S, L, X	YAY, QTN	06002F-240001～
DF60AT_023	E11	06002F	S, L, X	YAY, QTN	06002F-340001～
DF60AT_020	E40	06002F	L, X	YAY, Y5S	06002F-040001～
DF60AT_021	E40	06002F	L, X	YAY, QTN	06002F-140001～
DF60AT_022	E40	06002F	L, X	YAY, QTN	06002F-240001～
DF60AT_023	E40	06002F	L, X	YAY, QTN	06002F-340001～

MODEL	DESTINATION	TYPE	TRANSOM	COLOR	ENGINE No.
DF60AQH_020	E40	06002F	L, X	YAY	06002F-040001～
DF60AQH_021	E40	06002F	L, X	YAY	06002F-140001～
DF60AQH_022	E40	06002F	L, X	YAY	06002F-240001～
DF60AQH_023	E40	06002F	L, X	YAY	06002F-340001～
DF60ATH_020	E01	06002F	L	YAY	06002F-040001～
DF60ATH_021	E01	06002F	L	YAY	06002F-140001～
DF60ATH_022	E01	06002F	L	YAY	06002F-240001～
DF60ATH_023	E01	06002F	L	YAY	06002F-340001～
DF60ATH_020	E40	06002F	L, X	YAY	06002F-040001～
DF60ATH_021	E40	06002F	L, X	YAY	06002F-140001～
DF60ATH_022	E40	06002F	L, X	YAY	06002F-240001～
DF50AVT_020	E03	05004F	L	YAY	05004F-040001～
DF50AVT_021	E03	05004F	L	YAY	05004F-140001～
DF50AVT_022	E03	05004F	L	YAY	05004F-240001～
DF50AVT_023	E03	05004F	L	YAY	05004F-340001～
DF50AVTH_020	E01	05004F	L	YAY	05004F-040001～
DF60AVT_020	E01, E40	06003F	L, X	YAY	06003F-040001～
DF60AVT_020	E03	06003F	L	YAY	06003F-040001～
DF60AVT_021	E11	06003F	L, X	YAY	06003F-140001～
DF60AVT_022	E11	06003F	L, X	YAY	06003F-240001～
DF60AVT_023	E11	06003F	L, X	YAY	06003F-340001～

MODEL	DESTINATION	TYPE	TRANSOM	COLOR	ENGINE No.
DF60AVTH_020	E40	06003F	L,X	YAY	06003F-040001～
DF60AVTH_021	E40	06003F	L,X	YAY	06003F-140001～
DF60AVTH_022	E40	06003F	L,X	YAY	06003F-240001～
DF60AVTH_023	E40	06003F	L,X	YAY	06003F-340001～
DF40ASVT_020	E34	04004F	L	YAY,Y5S	04005F-040001～
DF40ASVT_021	E34	04004F	L	YAY,QTN	04005F-140001～
DF40ASVT_022	E34	04004F	L	YAY,QTN	04005F-240001～
DF40ASVT_023	E34	04004F	L	YAY,QTN	04005F-340001～

PREFACE

Quand il devient nécessarie de remplacer des pièces sur SUZUKI MOTEURS HORSBOARD toujours utiliser les PIECES D'ORIGINE SUZUKI qui ont été soumises à des contriles de qualité sévères leur garantissant qualité et performance impeccables.

Ce catalogue de pièces détachées couvre la liste de toutes les pièces de rechange pour SUZUKI DF40A/50A/60A production start from 2019 to 2022.

INSTRUCTIONS POUR UTILISER LE CATALOGUE

1. DIMENSIONS

Les dimensions des pièces dans ce catalogue sont indiquées en unités de millimètres.

2. ABREVIATIONS

Les abréviations utilisées dans ce catalogue sont les suivantes:

AR	: Comme requis	NT	: Nombre de dents
ASSY	: Assemblage	OPT	: Sur option
E.NO.	: Numéro du moteur	OS	: Sur-dimensionné
F.NO.	: Numéro du chfssis	T	: Epaisseur
ID	: Diamètre intérieur	US	: Sous-dimensionné
OD	: Diamètre extérieur	W	: Largeur
L	: Longueur	W/	: Avec
LH(PORT)	: Côté gauche	L	: Type transom
RH(STBD)	: Côte droit	PTT	: Dispositif d'incliuaison et de revage assistés

～031234 : Jusqu'à E.No.06002F-031234
031234～ : Depuis E.No.06002F-031234

12 x 34 x 5.6…… Les chiffres dans la colonne remarques montrent les dimensions des pieces comme suit.
ID	OD	T(or W,L)

→12345-56781 (N^{O} de pieces) : indique que le numéro des pièces a été ehangé en 12345-56781 et que les nouvelles pièces sont interchange-ables avec les anciennes, mais que celles-cine sont pas interchangeables avec les nouvelles.

←12345-56781 (N^{O} de pieces) : indique que les anciennes et nouvelles pièces sont interchangeables les unes avec les autres et sont utilisables chacune.

3. PIECES INTERNES DE L'ASSEMBLAGE

Les numéros de pièces qui comportent un point (.) avant la désignation de pièce détachée indique la pièce interne se rapportant à l'assemblage.

4. AVIS DE MODIFICATION

Un bulletin de pièces détachées vous sera envoyé à tout moment opportun quand des changements de pièces ont lieu, y compris les modifications de pièces interchangeables entre les nouvelles et anciennes pièces.

5. A NOTER

5-1. II existe certaines pièces différentes de celles de rechange pour les modèles de production vu des rainsons administratives et dont l'usage est commun avec celles d'autres modèles.

5-2. Concernant les durites en caoutchouc et les tuyaux en vinyle, ne pas manquer de les couper à la bonne longueur comme indiqué dans le catalogue des pièces détachées ou selon ce qui est utile pour le véhicule affecté.

5-3. Noter que les dessins à la page d'illustration servent à titre de référence pour les numéros de pièces détachées, et non pas comme référence pour l'assemblage. Pour cette dernière opération, se reporter au "MANUEL D'ENTRETIEN SUZUKI".

6. NOM DU MODELE / NUMERODE SERIE DU MOTEUR

MODELE	DESTINATION	TYPE	HOUTEUR DE BARRE D'ARCASSE	COULEUR	Nº DELA MOTEUR
DF40AT_020	E01	04003F	S,L	YAY,Y5S	04003F-040001～
DF40AT_020	E03	04003F	L	YAY,Y5S	04003F-040001～
DF40AT_021	E11	04003F	S,L	YAY,QTN	04003F-140001～
DF40AT_022	E11	04003F	S,L	YAY,QTN	04003F-240001～
DF40AT_023	E11	04003F	S,L	YAY,QTN	04003F-340001～
DF40AQH_020	E01	04003F	L	YAY	04003F-040001～
DF40AQH_021	E01	04003F	L	YAY	04003F-140001～
DF40AQH_022	E01	04003F	L	YAY	04003F-240001～
DF40AQH_023	E01	04003F	L	YAY	04003F-340001～

MODELE	DESTINATION	TYPE	BARRE D'ARCASSE	COULEUR	Nº DELA MOTEUR
DF40ATH_020	E01	04003F	L	YAY	04003F-040001～
DF40ATH_021	E01	04003F	L	YAY	04003F-140001～
DF40ATH_022	E01	04003F	L	YAY	04003F-240001～
DF40ATH_023	E01	04003F	L	YAY	04003F-340001～
DF40AST_020	E34	04004F	S,L	YAY,Y5S	04004F-040001～
DF40AST_021	E34	04004F	S,L	YAY,QTN	04004F-140001～
DF40AST_022	E34	04004F	S,L	YAY,QTN	04004F-240001～
DF40AST_023	E34	04004F	S,L	YAY,QTN	04004F-340001～
DF50AT_020	E01	05003F	S,L	YAY,Y5S	05003F-040001～
DF50AT_020	E03	05003F	L	YAY,Y5S	05003F-040001～
DF50AT_021	E11	05003F	S,L	YAY,QTN	05003F-140001～
DF50AT_022	E11	05003F	S,L	YAY,QTN	05003F-240001～
DF50AT_023	E11	05003F	S,L	YAY,QTN	05003F-340001～
DF50ATH_020	E01	05003F	L	YAY	05003F-040001～
DF50ATH_021	E01	05003F	L	YAY	05003F-140001～
DF50ATH_022	E01	05003F	L	YAY	05003F-240001～
DF50ATH_023	E01	05003F	L	YAY	05003F-340001～
DF60AT_020	E01	06002F	S,L,X	YAY,Y5S	06002F-040001～
DF60AT_020	E03	06002F	L	YAY,Y5S	06002F-040001～
DF60AT_021	E11	06002F	S,L,X	YAY,QTN	06002F-140001～
DF60AT_022	E11	06002F	S,L,X	YAY,QTN	06002F-240001～
DF60AT_023	E11	06002F	S,L,X	YAY,QTN	06002F-340001～

MODELE	DESTINATION	TYPE	BARRE D'ARCASSE	COULEUR	N^{O} DELA MOTEUR
DF60AT_020	E40	06002F	L, X	YAY, Y5S	06002F-040001～
DF60AT_021	E40	06002F	L, X	YAY, QTN	06002F-140001～
DF60AT_022	E40	06002F	L, X	YAY, QTN	06002F-240001～
DF60AT_023	E40	06002F	L, X	YAY, QTN	06002F-340001～
DF60AQH_020	E40	06002F	L, X	YAY	06002F-040001～
DF60AQH_021	E40	06002F	L, X	YAY	06002F-140001～
DF60AQH_022	E40	06002F	L, X	YAY	06002F-240001～
DF60AQH_023	E40	06002F	L, X	YAY	06002F-340001～
DF60ATH_020	E01	06002F	L	YAY	06002F-040001～
DF60ATH_021	E01	06002F	L	YAY	06002F-140001～
DF60ATH_022	E01	06002F	L	YAY	06002F-240001～
DF60ATH_023	E01	06002F	L	YAY	06002F-340001～
DF60ATH_020	E40	06002F	L, X	YAY	06002F-040001～
DF60ATH_021	E40	06002F	L, X	YAY	06002F-140001～
DF60ATH_022	E40	06002F	L, X	YAY	06002F-240001～
DF50AVT_020	E03	05004F	L	YAY	05004F-040001～
DF50AVT_021	E03	05004F	L	YAY	05004F-140001～
DF50AVT_022	E03	05004F	L	YAY	05004F-240001～
DF50AVT_023	E03	05004F	L	YAY	05004F-340001～
DF50AVTH_020	E01	05004F	L	YAY	05004F-040001～

MODELE	DESTINATION	TYPE	BARRE D'ARCASSE	COULEUR	N^{O} DELA MOTEUR
DF60AVT_020	E01, E40	06003F	L, X	YAY	06003F-040001～
DF60AVT_020	E03	06003F	L	YAY	06003F-040001～
DF60AVT_021	E11	06003F	L, X	YAY	06003F-140001～
DF60AVT_022	E11	06003F	L, X	YAY	06003F-240001～
DF60AVT_023	E11	06003F	L, X	YAY	06003F-340001～
DF60AVTH_020	E40	06003F	L, X	YAY	06003F-040001～
DF60AVTH_021	E40	06003F	L, X	YAY	06003F-140001～
DF60AVTH_022	E40	06003F	L, X	YAY	06003F-240001～
DF60AVTH_023	E40	06003F	L, X	YAY	06003F-340001～
DF40ASVT_020	E34	04004F	L	YAY, Y5S	04005F-040001～
DF40ASVT_021	E34	04004F	L	YAY, QTN	04005F-140001～
DF40ASVT_022	E34	04004F	L	YAY, QTN	04005F-240001～
DF40ASVT_023	E34	04004F	L	YAY, QTN	04005F-340001～

COLOR CHART
TABLEAU DES COULEURS

COLOR NO. NO DE COULEUR	COLOR DESCRIPTION DESCRIPTION DE COULEUR	COLOR NO. NO DE COULEUR	COLOR DESCRIPTION DESCRIPTION DE COULEUR
QTN	SLD. SUPER COOL WHITE		
YAY	PRL.NEBULAR BLACK		
Y5S	SLD.JOHNSON WHITE		
0PG	CHROME S		
6GS	SOFT GRAY		

COLOR NO. NO DE COULEUR	COLOR DESCRIPTION DESCRIPTION DE COULEUR	COLOR NO. NO DE COULEUR	COLOR DESCRIPTION DESCRIPTION DE COULEUR

MILLIMETER → INCH CONVERSION CHART

	0	1	2	3	4	5	6	7	8	9
00	.000	.039	.079	.118	.157	.197	.236	.276	.315	.354
10	.394	.433	.472	.512	.551	.591	.630	.669	.709	.748
20	.787	.827	.866	.906	.945	.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.535
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.214	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.031	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898


How to read

	0	1	2	3	4
00	…	…	…	…	…
10	…	…	…	…	…
20	…	…	…	0.906	…
30	…	…	…	…	…

23 millimeters equal 0.906 inch


Contents are subject to change without notice or obligation.

FIG.111A




DF80A_E1_0Z2_111A
CYLINDER HEAD

FIG.111B




DF80A_E1_0Z2_111B
CYLINDER HEAD

FIG.111C




DF80A_E1_0Z2_111C
CYLINDER HEAD

FIG.113A




DF80A_E1_0Z2_113A
CYLINDER BLOCK

FIG.113B




DF80A_E1_0Z2_113B
CYLINDER BLOCK

FIG.116A




DF80A_E1_0Z2_116A
CRANKSHAFT

FIG.119A




DF80A_E1_0Z2_119A
TIMING CHAIN

FIG.121A




DF80A_E1_0Z2_121A
CAMSHAFT

FIG.124A




DF80A_E1_023_124A
INTAKE MANIFOLD/SILENCER/EXHAUST COVER

FIG.124B




DF80A_E1_023_124B
INTAKE MANIFOLD/SILENCER/EXHAUST COVER

FIG.124C




DF80A_E1_023_124C
INTAKE MANIFOLD/SILENCER/EXHAUST COVER

FIG.124D




DF80A_E1_023_124D
INTAKE MANIFOLD/SILENCER/EXHAUST COVER

FIG.124E




DF80A_E1_023_124E
INTAKE MANIFOLD/SILENCER/EXHAUST COVER

FIG.124F




DF80A_E1_023_124F
INTAKE MANIFOLD/SILENCER/EXHAUST COVER

FIG.136A




DF80A_E1_023_136A
RING GEAR COVER

FIG.143A




DF80A_E1_023_143A
FUEL VAPOR SEPARATOR

FIG.143B




DF80A_E1_0Z2_143B
FUEL VAPOR SEPARATOR

FIG.143C




DF80A_E1_0Z3_143C
FUEL VAPOR SEPARATOR

FIG.144A




DF80A_E1_0Z2_144A
FUEL INJECTOR

FIG.144B




DF80A_E1_0Z3_144B
FUEL INJECTOR

FIG.146A




DF80A_E1_0Z2_146A
FUEL PUMP

FIG.160A




DF80A_E1_0Z2_160A
WATER PUMP

FIG.160B




DF80A_E1_0Z2_160B
WATER PUMP

FIG.160C




DF80A_E1_0Z2_160C
WATER PUMP

FIG.160D




DF60A_E1_L_023_160D
WATER PUMP

FIG.160E




DF60A_E1_L_023_160E
WATER PUMP

FIG.160F




DF60A_E1_L_023_160F
WATER PUMP

FIG.160G




DF60A_E1_L_023_160G
WATER PUMP

FIG.162A




DF60A_E1_L_023_162A
THERMOSTAT

FIG.163A




DF60A_E1_L_023_163A
THROTTLE BODY

FIG.163B




DF60A_E1_L_023_163B
THROTTLE BODY

FIG.163C




DF60A_E1_L_023_163C
THROTTLE BODY

FIG.175A




DF80A_E1_0Z0_175A
OIL PUMP

FIG.180A




DF80A_E1_0Z0_180A
OIL PAN

FIG.180B




DF80A_E1_0Z0_180B
OIL PAN

FIG.204A




DF80A_E1_0Z0_204A
CLUTCH SHAFT

FIG.204B




DF80A_E1_0Z0_204B
CLUTCH SHAFT

FIG.204C




DF80A_E1_0Z0_204C
CLUTCH SHAFT

FIG.204D




DF80A_E1_0Z0_204D
CLUTCH SHAFT

FIG.204E




DF80A_E1_0Z0_204E
CLUTCH SHAFT

FIG.204F




DF80A_E11_023_204F
CLUTCH SHAFT

FIG.204G




DF80A_E11_023_204G
CLUTCH SHAFT

FIG.206A




DF80A_E11_023_206A
CLUTCH ROD

FIG.206B




DF80A_E11_023_206B
CLUTCH ROD

FIG.206C




DF80A_E11_023_206C
CLUTCH ROD

FIG.206D




DF80A_E11_023_206D
CLUTCH ROD

FIG.210A




DF80A_E11_023_210A
SHIFT ROD

FIG.220A




DF80A_E11_023_220A
TRANSMISSION

FIG.220B




DF60A_E1L_022_220B
TRANSMISSION

FIG.220C




DF60A_E1L_022_220C
TRANSMISSION

FIG.220D




DF60A_E1L_022_220D
TRANSMISSION

FIG.220E




DF60A_E1L_022_220E
TRANSMISSION

FIG.220F




DF60A_E1L_022_220F
TRANSMISSION

FIG.220G




DF60A_E1L_022_220G
TRANSMISSION

FIG.220H




DF60A_E1L_022_220H
TRANSMISSION

FIG.301A




DF60A_E1L_022_301A
STARTING MOTOR

FIG.303A




DF80A_E1_023_303A
MAGNETO

FIG.310A




DF80A_E1_023_310A
RECTIFIER/IGNITION COIL

FIG.315A




DF80A_E1_023_315A
SENSOR

FIG.315B




DF80A_E1_023_315B
SENSOR

FIG.315C




DF80A_E1_023_315C
SENSOR

FIG.322A




DF80A_E1_023_322A
HARNESS

FIG.322B




DF80A_E1_023_322B
HARNESS

FIG.322C




DF80A_E1_023_322C
HARNESS

FIG.322D




DF60A_E1_023_322D
HARNESS

FIG.326A




DF60A_E1_023_326A
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326B




DF60A_E1_023_326B
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326C




DF60A_E1_023_326C
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326D




DF60A_E1_023_326D
PTT SWITCH/ENGINE CONTROL UNIT

FIG.335A




DF60A_E1_023_335A
CLAMP BRACKET

FIG.335B




DF60A_E1_023_335B
CLAMP BRACKET

FIG.335C




DF60A_E1_023_335C
CLAMP BRACKET

FIG.335D




DF60A_E1_023_335D
CLAMP BRACKET

FIG.335E




DF60A_E1_023_335E
CLAMP BRACKET

FIG.335F




DF60A_E1_023_335F
CLAMP BRACKET

FIG.335G




DF60A_E1_023_335G
CLAMP BRACKET

FIG.336A




DF60A_E1_023_336A
SWIVEL BRACKET

FIG.336B




DF60A_E1_023_336B
SWIVEL BRACKET

FIG.336C




DF60A_E1_023_336C
SWIVEL BRACKET

FIG.336D




DF60A_E1_023_336D
SWIVEL BRACKET

FIG.336E




DF60A_E1_0Z3_336E
SWIVEL BRACKET

FIG.336F




DF60A_E1_0Z3_336F
SWIVEL BRACKET

FIG.336G




DF60A_E1_0Z3_336G
SWIVEL BRACKET

FIG.336H




DF60A_E1_0Z3_336H
SWIVEL BRACKET

FIG.337A




DF60A_E1_0Z3_337A
TRIM CYLINDER

FIG.337B




DF60A_E1_0Z3_337B
TRIM CYLINDER

FIG.337C




DF60A_E1_0Z3_337C
TRIM CYLINDER

FIG.337D




DF60A_E1_0Z3_337D
TRIM CYLINDER

FIG.337E




DF60A_E1_022_337E
TRIM CYLINDER

FIG.337F




DF60A_E1_022_337F
TRIM CYLINDER

FIG.339A




DF60A_E1_022_339A
GAS CYLINDER

FIG.340A




DF60A_E1_022_340A
PTT MOTOR

FIG.401A




DF60A_E1_022_401A
ENGINE HOLDER

FIG.401B




DF60A_E1_022_401B
ENGINE HOLDER

FIG.401C




DF60A_E1_022_401C
ENGINE HOLDER

FIG.401D




DF60A_E1_022_401D
ENGINE HOLDER

FIG.405A




DF80A_E1_021_405A
DRIVE SHAFT HOUSING

FIG.405B




DF80A_E1_021_405B
DRIVE SHAFT HOUSING

FIG.405C




DF80A_E1_021_405C
DRIVE SHAFT HOUSING

FIG.405D




DF80A_E1_021_405D
DRIVE SHAFT HOUSING

FIG.405E




DF80A_E1_021_405E
DRIVE SHAFT HOUSING

FIG.405F




DF80A_E1_021_405F
DRIVE SHAFT HOUSING

FIG.405G




DF80A_E1_021_405G
DRIVE SHAFT HOUSING

FIG.405H




DF80A_E1_021_405H
DRIVE SHAFT HOUSING

FIG.405J




DF60A_E1_0Z3_405J
DRIVE SHAFT HOUSING

FIG.407A




DF60A_E1_0Z3_407A
GEAR CASE

FIG.407B




DF60A_E1_0Z3_407B
GEAR CASE

FIG.407C




DF60A_E1_0Z3_407C
GEAR CASE

FIG.407D




DF60A_E1_0Z3_407D
GEAR CASE

FIG.407E




DF60A_E1_0Z3_407E
GEAR CASE

FIG.407F




DF60A_E1_0Z3_407F
GEAR CASE

FIG.407G




DF60A_E1_0Z3_407G
GEAR CASE

FIG.410A




DF40A_E1_0Z3_410A
SIDE COVER

FIG.410B




DF40A_E1_0Z3_410B
SIDE COVER

FIG.420A




DF40A_E1_0Z3_420A
ENGINE COVER

FIG.420B




DF40A_E1_0Z3_420B
ENGINE COVER

FIG.420C




DF40A_E1_0Z3_420C
ENGINE COVER

FIG.420D




DF40A_E1_0Z3_420D
ENGINE COVER

FIG.420E




DF40A_E1_0Z3_420E
ENGINE COVER

FIG.420F




DF40A_E1_0Z3_420F
ENGINE COVER

FIG.420G




DF40A_E1_021_420G
ENGINE COVER

FIG.420H




DF50A_E1_021_420H
ENGINE COVER

FIG.420J




DF50A_E1_021_420J
ENGINE COVER

FIG.420K




DF50A_E1_021_420K
ENGINE COVER

FIG.420L




DF60A_E1_021_420L
ENGINE COVER

FIG.420M




DF60A_E1_021_420M
ENGINE COVER

FIG.420N




DF60A_E1_021_420N
ENGINE COVER

FIG.420P




DF60A_E1_021_420P
ENGINE COVER

FIG.420R




DF60A_E1_0Z3_420R
ENGINE COVER

FIG.420S




DF60A_E1_0Z3_420S
ENGINE COVER

FIG.420T




DF60A_E1_0Z3_420T
ENGINE COVER

FIG.420U




DF60A_E1_0Z3_420U
ENGINE COVER

FIG.430A




DF60A_E1_0Z3_430A
FUEL HOSE

FIG.432A




DF60A_E1_0Z3_432A
FUEL TANK

FIG.442A




DF60A_E1_0Z3_442A
DRAG LINK

FIG.444A




DF60A_E1_0Z3_444A
TILLER HANDLE

FIG.444B




DF60A_E1_023_444B
TILLER HANDLE

FIG.444C




DF60A_E1_023_444C
TILLER HANDLE

FIG.501A




DF60A_E1_023_501A
OPT:METER

FIG.501B




DF60A_E1_023_501B
OPT:METER

FIG.507A




DF60A_E1_023_507A
OPT:HEATER PRESSURE GAUGE SUB KIT

FIG.508A




DF60A_E1_023_508A
OPT:REMOTE CONTROL

FIG.508B




DF60A_E1_023_508B
OPT:REMOTE CONTROL

FIG.508C




DF60A_E1_023_508C
OPT:REMOTE CONTROL

FIG.508D




DF60A_E1(...)02L_508D
OPT:REMOTE CONTROL

FIG.515A




DF60A_E1(...)02L_515A
OPT:REMOCON CABLE

FIG.517A




DF60A_E1(...)02L_517A
OPT:CONCEALED REMOCON (1)

FIG.518A




DF60A_E1(...)02L_518A
OPT:CONCEALED REMOCON (2)

FIG.521A




DF60A_E1(...)02L_521A
OPT:HARNESS

FIG.521B




DF60A_E1(...)02L_521B
OPT:HARNESS

FIG.521C




DF60A_E1(...)02L_521C
OPT:HARNESS

FIG.521D




DF60A_E1(...)02L_521D
OPT:HARNESS

FIG.521E




DF60A_E1_023_521E
OPT:HARNESS

FIG.521F




DF60A_E1_023_521F
OPT:HARNESS

FIG.530A




DF60A_E1_023_530A
OPT:SWITCH

FIG.530B




DF60A_E1_023_530B
OPT:SWITCH

FIG.530C




DF60A_E1_023_530C
OPT:SWITCH

FIG.544A




DF60A_E1_023_544A
OPT:REMOTE CONTROL ASSY SINGLE (1)

FIG.545A




DF60A_E1_023_545A
OPT:REMOTE CONTROL ASSY SINGLE (2)

FIG.570A




DF60A_E1_023_570A
OPT:TILLER HANDLE

FIG.570B




DF60A_E1_023_570B
OPT:TILLER HANDLE

FIG.575A




DF60A_E1_023_575A
OPT:DRAG LINK

FIG.585A




DF60A_E1_023_585A
OPT:GASKET SET

FIG.585B




DF60A_E1_023_585B
OPT:GASKET SET

FIG.600A




DF60A_E1_023_600A
OPT:MULTI FUNCTION GAUGE

FIG.600B




DF60A_E1_023_600B
OPT:MULTI FUNCTION GAUGE

FIG.600C



DF60A_E1_023_600C
OPT:MULTI FUNCTION GAUGE

FIG.600D



DF60A_E1_023_600D
OPT:MULTI FUNCTION GAUGE

FIG.111A




FIG.111A (1-B-2) CYLINDER HEAD (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11100-88L20	HEAD ASSY, CYLINDER	1	
2	11115-73G01-001	.GUIDE, VALVE (OS:0.5)	12	
3	09103-06266	.BOLT (6X40)	17	
4	09206-08001	.PIN (6.2X8X11)	14	
5	11261-93J00	COVER, PROTECTION ANODE	2	
6	09280-22019	O RING (D:1.9,ID:21.8)	2	
7-1	55321-87J01	ANODE, PROTECTION	2	
7-2	55321-87J11	ANODE, PROTECTION	1	OPT
8	09128-06094	BOLT (6X14)	2	
9	01550-0820C	BOLT	2	
10	11119-87J00	BOLT, CYLINDER HEAD (10X95)	8	
11	11141-88L00	GASKET, CYLINDER HEAD	1	
12	01550-08457	BOLT	4	
13	04211-13189	PIN (10.4X13X18)	2	
14	11382-93J00	CAP, OIL FILLER	1	
15	09280-26006	O RING (D:3.1,ID:26.4)	1	
16	11170-88L10	COVER, CYLINDER HEAD	1	
17	11189-88L00	GASKET, CYLINDER HEAD COVER	1	
18	01547-0625C	BOLT	9	
19	01547-0645C	BOLT	3	
20	11173-88L00	PLATE, BREATHER	1	
21	02142-0612A	SCREW	4	
22	11174-88L01	HOSE, BREATHER	1	
23	09401-15414	CLIP	2	
24	09403-17312	CLAMP	2	
25	01550-0612C	BOLT	2	
26	11194-88L10	GUARD, FUEL HOSE	1	
27	01550-0616C	BOLT	2	
28	09482-00446	SPARK PLUG (DCPR6E)	3	NGK
29	11115-73G01-001	GUIDE, VALVE (OS:0.5)	4	OPT

NOTE : (020,021):(DF40A,DF40AQH,DF40ATH,DF50A,DF50ATH,DF50AVT, DF50AVTH)

FIG.111B




FIG.111B (1-B-3) CYLINDER HEAD (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11100-88L20	HEAD ASSY, CYLINDER	1	
2	11115-73G01-001	.GUIDE, VALVE (OS:0.5)	12	
3	09103-06266	.BOLT (6X40)	17	
4	09206-08001	.PIN (6.2X8X11)	14	
5	11261-93J00	COVER, PROTECTION ANODE	2	
6	09280-22019	O RING (D:1.9,ID:21.8)	2	
7-1	55321-87J01	ANODE, PROTECTION	2	
7-2	55321-87J11	ANODE, PROTECTION	1	OPT
8	09128-06094	BOLT (6X14)	2	
9	01550-0820C	BOLT	2	
10	11119-87J00	BOLT, CYLINDER HEAD (10X95)	8	
11	11141-88L00	GASKET, CYLINDER HEAD	1	
12	01550-08457	BOLT	4	
13	04211-13189	PIN (10.4X13X18)	2	
14	11382-93J00	CAP, OIL FILLER	1	
15	09280-26006	O RING (D:3.1,ID:26.4)	1	
16	11170-88L10	COVER, CYLINDER HEAD	1	
17	11189-88L00	GASKET, CYLINDER HEAD COVER	1	
18	01547-0625C	BOLT	9	
19	01547-0645C	BOLT	3	
20	11173-88L00	PLATE, BREATHER	1	
21	02142-0612A	SCREW	4	
22	11174-88L01	HOSE, BREATHER	1	
23	09401-15414	CLIP	1	
24	09403-17312	CLAMP	2	
25	01550-0612C	BOLT	2	
26	11194-88L10	GUARD, FUEL HOSE	1	
27	01550-0616C	BOLT	2	
28	09482-00446	SPARK PLUG (DCPR6E)	3	NGK
29	11115-73G01-001	GUIDE, VALVE (OS:0.5)	4	OPT

NOTE : (020,021):(DF40AST,DF60A,DF60AQH,DF60ATH,DF60AVT,DF40ASVT, DF60AVTH)

FIG.111C




FIG.111C (1-B-4) CYLINDER HEAD (022,023)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11100-88L20	HEAD ASSY, CYLINDER	1	
2	11115-73G01-001	.GUIDE, VALVE (OS:0.5)	12	
3	09103-06266	.BOLT (6X40)	17	
4	09206-08001	.PIN (6.2X8X11)	14	
5	11261-93J00	COVER, PROTECTION ANODE	2	
6	09280-22019	O RING (D:1.9,ID:21.8)	2	
7-1	55321-87J01	ANODE, PROTECTION	2	
7-2	55321-87J11	ANODE, PROTECTION	1	OPT
8	09128-06094	BOLT (6X14)	2	
9	01550-0820C	BOLT	2	
10	11119-87J00	BOLT, CYLINDER HEAD (10X95)	8	
11	11141-88L00	GASKET, CYLINDER HEAD	1	
12	01550-08457	BOLT	4	
13	04211-13189	PIN (10.4X13X18)	2	
14	11382-93J00	CAP, OIL FILLER	1	
15	09280-26006	O RING (D:3.1,ID:26.4)	1	
16	11170-88L10	COVER, CYLINDER HEAD	1	
17	11189-88L00	GASKET, CYLINDER HEAD COVER	1	
18	01547-0625C	BOLT	9	
19	01547-0645C	BOLT	3	
20	11173-88L00	PLATE, BREATHER	1	
21	02112-0612A	SCREW	4	
22	11174-88L01	HOSE, BREATHER	1	
23	09401-15414	CLIP	1	
24	09403-17312	CLAMP	2	
25	01550-0612C	BOLT	2	
26	11194-88L10	GUARD, FUEL HOSE	1	
27	01550-0616C	BOLT	2	
28	09482-00446	SPARK PLUG (DCPR6E)	3	NGK
29	11115-73G01-001	GUIDE, VALVE (OS:0.5)	4	OPT

FIG.113A




FIG.113A (1-B-5) CYLINDER BLOCK (020,021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11291-88L00	HOOK, ENGINE	1	
2	01550-0820C	BOLT	2	
3	11301-88L20	BLOCK SET, CYLINDER	1	
4	11117-89J20	.BOLT, CRANKCASE INSIDE (10X98)	8	
5	09206-13019	.PIN (10.4X13X16)	4	
6	01550-08407	.BOLT	8	
7	11112-88L00	.PLUG, OIL VENTURI	1	
8	55321-87J01	ANODE, PROTECTION	1	
9	09128-06094	BOLT (6X14)	1	

DF60A_E11_023_113A
CYLINDER BLOCK

FIG.113B




FIG.113B (1-B-6) CYLINDER BLOCK (022,023)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11291-88L10	HOOK, ENGINE	1	
2	01550-0820C	BOLT	2	
3	11301-88L20	BLOCK SET, CYLINDER	1	
4	11117-89J20	.BOLT, CRANKCASE INSIDE (10X98)	8	
5	09206-13019	.PIN (10.4X13X16)	4	
6	01550-08407	.BOLT	8	
7	11112-88L00	.PLUG, OIL VENTURI	1	
8	55321-87J01	ANODE, PROTECTION	1	
9	09128-06094	BOLT (6X14)	1	

DF60A_E11_023_113B
CYLINDER BLOCK

FIG.116A




FIG.116A (1-B-7) CRANKSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12111-88L00	PISTON	3	
2	12140-88L01	RING SET, PISTON	3	
3	12151-54A50	PIN, PISTON	3	
4	09381-18002	CIRCLIP	6	
5	12160-88L01	CONNROD ASSY	3	
6	12163-69J00	.BOLT, CONNROD	6	
7	04221-04089	.PIN	6	
8-1	12100-51810-0A0	BEARING SET, CONNROD	3	GREEN
8-2	12100-51810-0B0	BEARING SET, CONNROD	3	BLACK
8-3	12100-51810-0C0	BEARING SET, CONNROD	3	NON
8-4	12100-51810-0D0	BEARING SET, CONNROD	3	YELLOW
8-5	12100-51810-0E0	BEARING SET, CONNROD	3	BLUE
9	12220-88L00	CRANKSHAFT	1	
10-1	12340-75FA0-0A0	BEARING SET, CRANKSHAFT	4	GREEN
10-2	12340-75FA0-0B0	BEARING SET, CRANKSHAFT	4	BLACK
10-3	12340-75F00-0C0	BEARING SET, CRANKSHAFT	4	NON
10-4	12340-75F00-0D0	BEARING SET, CRANKSHAFT	4	YELLOW
10-5	12340-75F00-0E0	BEARING SET, CRANKSHAFT	4	BLUE
11	09283-37005	OIL SEAL (37X49X6)	1	
12	12281-87J00	OIL SEAL, CRANKSHAFT UNDER (30X44X7)	1	LOWER
13	12100-88L01-050	PISTON SET (OS:0.5)	3	OPT
14	12140-88L01-050	.RING SET, PISTON	3	OPT

FIG.119A




FIG.119A (1-B-8) TIMING CHAIN

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12761-88L00	CHAIN, TIMING	1	
2	12771-87J00	GUIDE, TIMING CHAIN NO.1	1	
3	12776-85FA0	BOLT, TIMING CHAIN GUIDE	2	
4	12811-88L00	TENSIONER, TIMING CHAIN	1	
5	09100-08260	BOLT (8X30)	1	
6	09160-08123	WASHER (8.5X20X1.2)	1	
7	12812-73G10	SPACER, TIMING CHAIN TENSIONER	1	
8	12813-73G00	PAD, TIMING CHAIN TENSIONER	1	
9	12831-90J02	ADJUSTER ASSY, TENSIONER	1	
10	01550-0620A	BOLT	2	
11	12821-88L00	LINK, TIMING CHAIN TENSIONER	1	
12	01550-0612A	BOLT (6X12)	2	

FIG.121A




FIG.121A (1-B-9) CAMSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12710-88L00	CAMSHAFT, INTK	1	
2	12720-88L00	CAMSHAFT, EXH (NT:34)	1	
3	12741-88L00	SPROCKET, CAMSHAFT TIMING (NT:34)	1	
4	09103-10189	BOLT (10X23)	1	
5	09160-10093	WASHER (10.5X24X2.3)	1	
6	04221-05109	PIN	1	
7	12891-73G01	TAPPET	12	
8-1	12892-73G01-218	SHIM, TAPPET (T:2.18)	AR	OPT
8-2	12892-73G01-220	SHIM, TAPPET (T:2.20)	AR	OPT
8-3	12892-73G01-222	SHIM, TAPPET (T:2.22)	AR	OPT
8-4	12892-73G01-224	SHIM, TAPPET (T:2.24)	AR	OPT
8-5	12892-73G01-226	SHIM, TAPPET (T:2.26)	AR	OPT
8-6	12892-73G01-228	SHIM, TAPPET (T:2.28)	AR	OPT
8-7	12892-73G01-230	SHIM, TAPPET (T:2.30)	AR	
8-8	12892-73G01-232	SHIM, TAPPET (T:2.32)	AR	
8-9	12892-73G01-234	SHIM, TAPPET (T:2.34)	AR	
8-10	12892-73G01-236	SHIM, TAPPET (T:2.36)	AR	
8-11	12892-73G01-238	SHIM, TAPPET (T:2.38)	AR	
8-12	12892-73G01-240	SHIM, TAPPET (T:2.40)	AR	
8-13	12892-73G01-242	SHIM, TAPPET (T:2.42)	AR	
8-14	12892-73G01-244	SHIM, TAPPET (T:2.44)	AR	
8-15	12892-73G01-246	SHIM, TAPPET (T:2.46)	AR	
8-16	12892-73G01-248	SHIM, TAPPET (T:2.48)	AR	
8-17	12892-73G01-250	SHIM, TAPPET (T:2.50)	AR	
8-18	12892-73G01-252	SHIM, TAPPET (T:2.52)	AR	
8-19	12892-73G01-254	SHIM, TAPPET (T:2.54)	AR	
8-20	12892-73G01-256	SHIM, TAPPET (T:2.56)	AR	
8-21	12892-73G01-258	SHIM, TAPPET (T:2.58)	AR	
8-22	12892-73G01-260	SHIM, TAPPET (T:2.60)	AR	
8-23	12892-73G01-262	SHIM, TAPPET (T:2.62)	AR	
8-24	12892-73G01-264	SHIM, TAPPET (T:2.64)	AR	
8-25	12892-73G01-266	SHIM, TAPPET (T:2.66)	AR	
8-26	12892-73G01-268	SHIM, TAPPET (T:2.68)	AR	
8-27	12892-73G01-270	SHIM, TAPPET (T:2.70)	AR	
8-28	12892-73G01-272	SHIM, TAPPET (T:2.72)	AR	

FIG.121A




FIG.121A (1-B-10) CAMSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY		REMARKS
8-29	12892-73G01-274	SHIM, TAPPET (T:2.74)	AR		
8-30	12892-73G01-276	SHIM, TAPPET (T:2.76)	AR		
8-31	12892-73G01-278	SHIM, TAPPET (T:2.78)	AR		
8-32	12892-73G01-280	SHIM, TAPPET (T:2.80)	AR		
8-33	12892-73G01-282	SHIM, TAPPET (T:2.82)	AR	OPT	
8-34	12892-73G01-284	SHIM, TAPPET (T:2.84)	AR	OPT	
8-35	12892-73G01-286	SHIM, TAPPET (T:2.86)	AR	OPT	
8-36	12892-73G01-288	SHIM, TAPPET (T:2.88)	AR	OPT	
8-37	12892-73G01-290	SHIM, TAPPET (T:2.90)	AR	OPT	
8-38	12892-73G01-292	SHIM, TAPPET (T:2.92)	AR	OPT	
8-39	12892-73G01-294	SHIM, TAPPET (T:2.94)	AR	OPT	
8-40	12892-73G01-296	SHIM, TAPPET (T:2.96)	AR	OPT	
8-41	12892-73G01-298	SHIM, TAPPET (T:2.98)	AR	OPT	
8-42	12892-73G01-300	SHIM, TAPPET (T:3.00)	AR	OPT	
9	12911-88L00	VALVE, INTAKE	6		
10	12915-73G20	VALVE, EXHAUST	6		
11	12921-87J11	SPRING, VALVE	12		
12	12931-78G00	RETAINER, VALVE SPRING	12		
13	12932-24400	COTTER, VALVE	24		
14	12933-51E00	SEAT, VALVE SPRING	12		
15	09289-05012	OIL SEAL (5.5X11.5X9.3)	12		

FIG.124A




FIG.124A (1-B-11) INTAKE MANIFOLD/SILENCER/EXHAUST COVER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13110-88L00	MANIFOLD, INTAKE	1	
2	13119-88L00	.GASKET, INTAKE MANIFOLD	3	
3	13125-88L00	.GASKET, THROTTLE BODY	1	
4	01421-08607	STUD BOLT	2	
5	01550-0830C	BOLT	6	
6	01550-0840C	BOLT	1	
7	08316-1008C	NUT	2	
8	18137-88L02	VALVE, IAC	1	
9	02112-34167	SCREW	3	
10	13810-88L00	SILENCER	1	
11	13820-88L01	HOLDER, SILENCER	1	
12	01547-0616C	BOLT	1	
13	14141-88L00	COVER, EXHAUST	1	
14	14151-88L00	GASKET, EXH COVER	1	
15	01550-0620C	BOLT	8	
16	09160-06094	WASHER (6.5X15X1.0)	1	

NOTE : (DF40A,DF40AQH,DF40ATH):(020,021)

FIG.124B




FIG.124B (1-B-12) INTAKE MANIFOLD/SILENCER/EXHAUST COVER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13110-88L00	MANIFOLD, INTAKE	1	
2	13119-88L00	.GASKET, INTAKE MANIFOLD	3	
3	13125-88L00	.GASKET, THROTTLE BODY	1	
4	01421-08607	STUD BOLT	2	
5	01550-0830C	BOLT	6	
6	01550-0840C	BOLT	1	
7	08316-1008C	NUT	2	
8	18137-88L02	VALVE, IAC	1	
9	02112-34167	SCREW	3	
10	13810-88L00	SILENCER	1	
11	13820-88L01	HOLDER, SILENCER	1	
12	01547-0616C	BOLT	1	
13	14141-88L10	COVER, EXHAUST	1	
14	14151-88L00	GASKET, EXH COVER	1	
15	01550-0620C	BOLT	8	
16	09160-06094	WASHER (6.5X15X1.0)	1	
17	11261-93J00	COVER, PROTECTION ANODE	1	
18	09280-22019	O RING (D:1.9,ID:21.8)	1	
19	55321-87J01	ANODE, PROTECTION	1	
20	09128-06094	BOLT (6X14)	1	
21	01550-0820C	BOLT	1	

NOTE : (DF40A,DF40AQH,DF40ATH,DF40AST,DF40ASVT):(022,023)

FWD

FIG.124C




FIG.124C (1-B-13) INTAKE MANIFOLD/SILENCER/EXHAUST COVER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13110-88L00	MANIFOLD, INTAKE	1	
2	13119-88L00	.GASKET, INTAKE MANIFOLD	3	
3	13125-88L00	.GASKET, THROTTLE BODY	1	
4	01421-08607	STUD BOLT	2	
5	01550-0830C	BOLT	6	
6	01550-0840C	BOLT	1	
7	08316-1008C	NUT	2	
8	18137-88L02	VALVE, IAC	1	
9	02112-34167	SCREW	3	
10	13810-88L00	SILENCER	1	
11	13813-88L01	HOLDER, ARRESTER	1	
12	01547-0616C	BOLT	1	
13	14141-88L00	COVER, EXHAUST	1	
14	14151-88L00	GASKET, EXH COVER	1	
15	01550-0620C	BOLT	8	
16	09160-06094	WASHER (6.5X15X1.0)	1	

NOTE : (DF40AST,DF60A,DF60AQH,DF60ATH,DF60AVT,DF40ASVT,DF60AVTH):
(020,021)

FIG.124D




FIG.124D (1-B-14) INTAKE MANIFOLD/SILENCER/EXHAUST COVER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13110-88L00	MANIFOLD, INTAKE	1	
2	13119-88L00	.GASKET, INTAKE MANIFOLD	3	
3	13125-88L00	.GASKET, THROTTLE BODY	1	
4	01421-08607	STUD BOLT	2	
5	01550-0830C	BOLT	6	
6	01550-0840C	BOLT	1	
7	08316-1008C	NUT	2	
8	18137-88L02	VALVE, IAC	1	
9	02112-34167	SCREW	3	
10	13810-88L00	SILENCER	1	
11	13813-88L01	HOLDER, ARRESTER	1	
12	01547-0616C	BOLT	1	
13	14141-88L10	COVER, EXHAUST	1	
14	14151-88L00	GASKET, EXH COVER	1	
15	01550-0620C	BOLT	8	
16	09160-06094	WASHER (6.5X15X1.0)	1	
17	11261-93J00	COVER, PROTECTION ANODE	1	
18	09280-22019	O RING (D:1.9,ID:21.8)	1	
19	55321-87J01	ANODE, PROTECTION	1	
20	09128-06094	BOLT (6X14)	1	
21	01550-0820C	BOLT	1	

NOTE : (DF60A,DF60AQH,DF60ATH,DF60AVT,DF60AVTH):(022,023)

FIG.124E




FIG.124E (1-C-2) INTAKE MANIFOLD/SILENCER/EXHAUST COVER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13110-88L00	MANIFOLD, INTAKE	1	
2	13119-88L00	.GASKET, INTAKE MANIFOLD	3	
3	13125-88L00	.GASKET, THROTTLE BODY	1	
4	01421-08607	STUD BOLT	2	
5	01550-0830C	BOLT	6	
6	01550-0840C	BOLT	1	
7	08316-1008C	NUT	2	
8	18137-88L02	VALVE, IAC	1	
9	02112-34167	SCREW	3	
10	13810-88L00	SILENCER	1	
11	13820-88L11	HOLDER, SILENCER	1	
12	01547-0616C	BOLT	1	
13	14141-88L00	COVER, EXHAUST	1	
14	14151-88L00	GASKET, EXH COVER	1	
15	01550-0620C	BOLT	8	
16	09160-06094	WASHER (6.5X15X1.0)	1	

NOTE : (DF50A,DF50ATH,DF50AVT,DF50AVTH):(020,021)

FIG.124F




FIG.124F (1-C-3) INTAKE MANIFOLD/SILENCER/EXHAUST COVER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13110-88L00	MANIFOLD, INTAKE	1	
2	13119-88L00	.GASKET, INTAKE MANIFOLD	3	
3	13125-88L00	.GASKET, THROTTLE BODY	1	
4	01421-08607	STUD BOLT	2	
5	01550-0830C	BOLT	6	
6	01550-0840C	BOLT	1	
7	08316-1008C	NUT	2	
8	18137-88L02	VALVE, IAC	1	
9	02112-34167	SCREW	3	
10	13810-88L00	SILENCER	1	
11	13820-88L11	HOLDER, SILENCER	1	
12	01547-0616C	BOLT	1	
13	14141-88L10	COVER, EXHAUST	1	
14	14151-88L00	GASKET, EXH COVER	1	
15	01550-0620C	BOLT	8	
16	09160-06094	WASHER (6.5X15X1.0)	1	
17	11261-93J00	COVER, PROTECTION ANODE	1	
18	09280-22019	O RING (D:1.9,ID:21.8)	1	
19	55321-87J01	ANODE, PROTECTION	1	
20	09128-06094	BOLT (6X14)	1	
21	01550-0820C	BOLT	1	

NOTE : (DF50A,DF50ATH,DF50AVT,DF50AVTH):(022,023)

FIG.136A




FIG.136A (1-C-4) RING GEAR COVER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11510-88L00	COVER, RING GEAR	1	
2	01550-0630C	BOLT	3	
3	09320-09501	CUSHION (9X12/18X10)	1	
4	03542-06209	SCREW	3	
5	11514-88L00	PLATE, RING GEAR COVER	1	
6	11411-88L00	HOUSING, UPPER OIL SEAL	1	UPPER
7	11413-88L00	GASKET, UPPER OIL SEAL HSG	1	UPPER
8	01550-0625C	BOLT	5	
9	04221-04089	PIN	2	
10	61472-88L01	LABEL, MAG COVER	1	
11	69711-93E11	LABEL, S.I.G.P	1	
12	61494-88L02	LABEL, OIL & CLEARANCE	1	

DF60A_E11_023_136A
RING GEAR COVER

FIG.143A




FIG.143A (1-C-5) FUEL VAPOR SEPARATOR (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15600-88L05	SEPARATOR ASSY, FUEL VAPOR	1	->15600-88L14
2	13370-88L00	.VALVE ASSY, NEEDLE	1	
3	15200-88L00	.PUMP ASSY, FUEL	1	
4	15626-88L01	.SEAL	1	
5	15628-99E00	.SCREW (L:15)	5	
6	15629-99E10	.SCREW, DRAIN	1	
7	15641-88L00	.SPACER	1	
8	15642-88L00	.FILTER ASSY	1	
9	15650-99E00	.FLOAT	1	
10	15654-88L00	.PIN	1	
11	15683-87J00	.HOSE (L:120)	1	
12	15760-88L00	.REGULATOR ASSY	1	
13	15644-88L00	.O RING	1	
14	15645-88L00	.HOLDER, REGULATOR	1	
15	02112-0408A	.SCREW	1	
16	02142-0408B	.SCREW	1	
17	15643-88L10	.JOINT	1	
18	15641-88L31	.BUSH	1	
19	15641-88L51	.BUSH	1	
20	15642-88L10	.FILTER	1	
21	15612-88L00	.COVER, VAPOR SEPARATOR	1	
22	15613-88L00	.O RING	1	
23	15613-92J00	.GASKET	1	
24	15614-88L00	.SCREW	3	
25	15610-88L01	.CASE ASSY, VAPOR SEPARATOR LWR	1	LOWER
26	15620-88L00	.CASE ASSY, VAPOR SEPARATOR UPR	1	UPPER
27	01550-0630C	BOLT	3	
28	09169-06075	WASHER	3	
29	09160-06084	WASHER (6.5X18X1.6)	3	
30	09320-09059	CUSHION (9X18X14)	3	

NOTE : (020,021,022):(E01,E03,E11,E34)

DF60A_E11_023_143A
FUEL VAPOR SEPARATOR

FIG.143A




FIG.143A (1-C-6) FUEL VAPOR SEPARATOR (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
31	09352-50003-770	HOSE (5X8.2X770)	1	
32	09401-08412	CLIP	1	
33	18498-88L11	PROTECTOR, EVAP HOSE (L:730)	1	
34	09320-08517	GROMMET	1	
35	09408-00043	CLAMP (ID:11.8X2)	1	
36	09408-00121	CLAMP	1	
37	09408-00145	CLIP	1	
38	55127-87D00	UNION, SPEEDOMETER HOSE	1	

NOTE : (020,021,022):(E01,E03,E11,E34)

DF60A_E11_023_143A
FUEL VAPOR SEPARATOR

FIG.143B




FIG.143B (1-C-7) FUEL VAPOR SEPARATOR ((020,021,022):E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15600-88L14	SEPARATOR ASSY, FUEL VAPOR	1	
2	13370-88L10	.VALVE ASSY, NEEDLE	1	
3	15200-88L10	.PUMP ASSY, FUEL	1	
4	15626-88L10	.SEAL	1	
5	15628-99E00	.SCREW (L:15)	5	
6	15629-99E10	.SCREW, DRAIN	1	
7	15641-88L10	.SPACER	1	
8	15642-88L00	.FILTER ASSY	1	
9	15650-99E00	.FLOAT	1	
10	15654-88L00	.PIN	1	
11	15683-87J00	.HOSE (L:120)	1	
12	15760-88L00	.REGULATOR ASSY	1	
13	15644-88L10	.O RING	1	
14	15645-88L00	.HOLDER, REGULATOR	1	
15	13614-89J00	.SCREW	1	
16	13614-93J00	.SCREW	1	
17	15643-88L10	.JOINT	1	
18	15641-88L31	.BUSH	1	
19	15641-88L51	.BUSH	1	
20	15642-88L10	.FILTER	1	
21	15612-88L00	.COVER, VAPOR SEPARATOR	1	
22	15613-88L00	.O RING	1	
23	15613-92J00	.GASKET	1	
24	15614-88L00	.SCREW	3	
25	15610-88L01	.CASE ASSY, VAPOR SEPARATOR LWR	1	LOWER
26	15620-88L10	.CASE ASSY, VAPOR SEPARATOR UPR	1	UPPER
27	01550-0630C	BOLT	3	
28	09169-06075	WASHER	3	
29	09160-06084	WASHER (6.5X18X1.6)	3	
30	09320-09059	CUSHION (9X18X14)	3	
31	09352-50003-770	HOSE (5X8.2X770)	1	
32	09401-08412	CLIP	1	
33	18498-88L11	PROTECTOR, EVAP HOSE (L:730)	1	
34	09320-08517	GROMMET	1	

DF60A_E11_023_143B
FUEL VAPOR SEPARATOR

FIG.143B




FIG.143B (1-C-8) FUEL VAPOR SEPARATOR ((020,021,022):E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	09408-00043	CLAMP (ID:11.8X2)	1	
36	09408-00121	CLAMP	1	
37	09408-00145	CLIP	1	
38	55127-87D00	UNION, SPEEDOMETER HOSE	1	

DF60A_E11_023_143B
FUEL VAPOR SEPARATOR

FIG.143C




FIG.143C (1-C-9) FUEL VAPOR SEPARATOR (023)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15600-88L14	SEPARATOR ASSY, FUEL VAPOR	1	
2	13370-88L10	.VALVE ASSY, NEEDLE	1	
3	15200-88L10	.PUMP ASSY, FUEL	1	
4	15626-88L10	.SEAL	1	
5	15628-99E00	.SCREW (L:15)	5	
6	15629-99E10	.SCREW, DRAIN	1	
7	15641-88L10	.SPACER	1	
8	15642-88L00	.FILTER ASSY	1	
9	15650-99E00	.FLOAT	1	
10	15654-88L00	.PIN	1	
11	15683-87J00	.HOSE (L:120)	1	
12	15760-88L00	.REGULATOR ASSY	1	
13	15644-88L10	.O RING	1	
14	15645-88L00	.HOLDER, REGULATOR	1	
15	13614-89J00	.SCREW	1	
16	13614-93J00	.SCREW	1	
17	15643-88L10	.JOINT	1	
18	15641-88L31	.BUSH	1	
19	15641-88L51	.BUSH	1	
20	15642-88L10	.FILTER	1	
21	15612-88L00	.COVER, VAPOR SEPARATOR	1	
22	15613-88L00	.O RING	1	
23	15613-92J00	.GASKET	1	
24	15614-88L00	.SCREW	3	
25	15610-88L01	.CASE ASSY, VAPOR SEPARATOR LWR	1	LOWER
26	15620-88L10	.CASE ASSY, VAPOR SEPARATOR UPR	1	UPPER
27	01550-0630C	BOLT	3	
28	09169-06075	WASHER	3	
29	09160-06084	WASHER (6.5X18X1.6)	3	
30	09320-09059	CUSHION (9X18X14)	3	
31	09352-50003-770	HOSE (5X8.2X770)	1	
32	09401-08412	CLIP	1	
33	18498-88L11	PROTECTOR, EVAP HOSE (L:730)	1	
34	09320-08517	GROMMET	1	

DF60A_E11_023_143C
FUEL VAPOR SEPARATOR

FIG.143C




FIG.143C (1-C-10) FUEL VAPOR SEPARATOR (023)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	09408-00043	CLAMP (ID:11.8X2)	1	
36	09408-00121	CLAMP	1	
37	09408-00145	CLIP	1	
38	55127-87D00	UNION, SPEEDOMETER HOSE	1	

DF60A_E11_023_143C
FUEL VAPOR SEPARATOR

FIG.144A




FIG.144A (1-C-11) FUEL INJECTOR (E01,E03,E11,E34)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15710-85K00	INJECTOR ASSY, FUEL	3	
2	15716-65DT0	.GROMMET SET, FUEL INJECTOR	3	
3	09320-08062	CUSHION (8.7X16.3X5.5)	3	
4	15750-88L10	PIPE, DELIVERY	1	
5	07120-06357	BOLT	2	
6	09180-06198	SPACER (6.2X12X16)	2	
7	15681-88L10	HOSE, FUEL	1	SEPARATOR TO DLVY
8	09401-11425	CLIP	2	
9	09408-00174	CLAMP	1	

DF60A_E11_023_144A
FUEL INJECTOR

FIG.144B




FIG.144B (1-C-12) FUEL INJECTOR (E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15710-85K00	INJECTOR ASSY, FUEL	3	
2	15716-65DT0	.GROMMET SET, FUEL INJECTOR	3	
3	09320-08062	CUSHION (8.7X16.3X5.5)	3	
4	15750-88L20	PIPE, DELIVERY	1	
5	07120-06357	BOLT	2	
6	09180-06198	SPACER (6.2X12X16)	2	
7	15681-88L10	HOSE, FUEL	1	SEPARATOR TO DLVY
8	09401-11425	CLIP	2	
9	09408-00174	CLAMP	1	

FIG.146A




FIG.146A (1-C-13) FUEL PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15100-90J11	PUMP ASSY, FUEL	1	
2	01550-0625C	BOLT	2	
3	09280-26005	O RING (D:2.4,ID:26.2)	1	
4	15410-88L00	FILTER, FUEL	1	
5	15419-87J00	.CAP, FUEL FILTER	1	
6	09401-11423	.CLIP	1	
7	15422-96J01	CLAMP, FUEL FILTER	1	
8	15421-88L00	BRACKET, FUEL FILTER	1	
9	01550-0616C	BOLT	2	
10	15191-88L20	HOSE, FUEL	1	JOINT TO FILTER
11	15192-88L20	HOSE, FUEL	1	PUMP TO SEPARATOR
12	09343-70503-080	HOSE (7X12X80)	1	
13	18498-90J51	PROTECTOR, HOSE	1	
14	18498-96J31	PROTECTOR, FUEL HOSE NO.2	1	
15	15197-88L00	BRACKET, FUEL HOSE CLAMP	1	
16	01550-0612C	BOLT	1	
17	09403-11320	CLAMP	3	
18	09401-11423	CLIP	5	
19	09408-00145	CLIP	1	

FIG.160A




FIG.160A (1-C-14) WATER PUMP (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-88L00	CASE, WATER PUMP	1	
2	17413-95J00	SLEEVE, WATER PUMP CASE	1	
3	17416-95J00	SEALING, WATER PUMP CASE	1	
4	17564-88L01	BUSH, WATER PUMP CASE	1	
5	29141-93J00	NUT (M6)	4	
6	29162-93J00	WASHER (6.1X12.2X1.5)	4	
7	09108-06143	STUD BOLT (L:45)	2	
8	09108-06144	STUD BOLT (L:31)	2	
9	17461-96312	IMPELLER, WATER PUMP	1	
10	17471-95J01	PANEL, PUMP CASE UNDER	1	
11	17472-96304	GASKET, PUMP CASE UNDER	1	
12-1	17560-88L00	TUBE, WATER	1	W/TRANSOM(S)
12-2	17560-88L10	TUBE, WATER	1	W/TRANSOM(L)
12-3	17560-88L20	TUBE, WATER	1	W/TRANSOM(X)
13	17562-87L01	GROMMET, WATER TUBE UPPER	1	UPPER
14-1	17562-87L01	GROMMET, WATER TUBE UPPER	1	W/TRANSOM(L) LOWER
14-2	17562-87L01	GROMMET, WATER TUBE UPPER	1	W/TRANSOM(X) LOWER
15	09116-06236	BOLT (6X16)	1	
16	17631-96320	FILTER, WATER	2	
17	03142-04309	SCREW	2	
18-1	17635-87E00	FILTER, WATER SUB	1	
18-2	17635-87E10	PLATE, GEAR CASE	1	OPT
19	09125-05046	SCREW (5X12)	2	
20	09420-04006	KEY	1	
21	17400-88L01	KIT, WATER PUMP REPAIR	1	OPT

NOTE : (DF40A,DF40AQH,DF40ATH,DF50A,DF50ATH,DF60A,DF60ATH):E01,
(DF40A,DF50A,DF60A):E11

FIG.160B




FIG.160B (1-D-2) WATER PUMP ((DF40A,DF50A,DF60A):E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-88L00	CASE, WATER PUMP	1	
2	17413-95J00	SLEEVE, WATER PUMP CASE	1	
3	17416-95J00	SEALING, WATER PUMP CASE	1	
4	17564-88L01	BUSH, WATER PUMP CASE	1	
5	29141-93J00	NUT (M6)	4	
6	29162-93J00	WASHER (6.1X12.2X1.5)	4	
7	09108-06143	STUD BOLT (L:45)	2	
8	09108-06144	STUD BOLT (L:31)	2	
9	17461-96312	IMPELLER, WATER PUMP	1	
10	17471-95J01	PANEL, PUMP CASE UNDER	1	
11	17472-96304	GASKET, PUMP CASE UNDER	1	
12	17560-88L10	TUBE, WATER	1	
13	17562-87L01	GROMMET, WATER TUBE UPPER	1	UPPER
14	17562-87L01	GROMMET, WATER TUBE UPPER	1	LOWER
15	09116-06236	BOLT (6X16)	1	
16	17631-96320	FILTER, WATER	2	
17	03142-04309	SCREW	2	
18-1	17635-87E00	FILTER, WATER SUB	1	
18-2	17635-87E10	PLATE, GEAR CASE	1	OPT
19	09125-05046	SCREW (5X12)	2	
20	09420-04006	KEY	1	
21	17400-88L01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160C




FIG.160C (1-D-3) WATER PUMP (DF40AST:E34)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-88L00	CASE, WATER PUMP	1	
2	17413-95J00	SLEEVE, WATER PUMP CASE	1	
3	17416-95J00	SEALING, WATER PUMP CASE	1	
4	17564-88L01	BUSH, WATER PUMP CASE	1	
5	29141-93J00	NUT (M6)	4	
6	29162-93J00	WASHER (6.1X12.2X1.5)	4	
7	09108-06143	STUD BOLT (L:45)	2	
8	09108-06144	STUD BOLT (L:31)	2	
9	17461-96312	IMPELLER, WATER PUMP	1	
10	17471-95J01	PANEL, PUMP CASE UNDER	1	
11	17472-96304	GASKET, PUMP CASE UNDER	1	
12-1	17560-88L00	TUBE, WATER	1	W/TRANSOM(S)
12-2	17560-88L10	TUBE, WATER	1	W/TRANSOM(L)
13	17562-87L01	GROMMET, WATER TUBE UPPER	1	UPPER
14	17562-87L01	GROMMET, WATER TUBE UPPER	1	W/TRANSOM(L) LOWER
15	09116-06236	BOLT (6X16)	1	
16	17631-96320	FILTER, WATER	2	
17	03142-04309	SCREW	2	
18-1	17635-87E00	FILTER, WATER SUB	1	
18-2	17635-87E10	PLATE, GEAR CASE	1	OPT
19	09125-05046	SCREW (5X12)	2	
20	09420-04006	KEY	1	
21	17400-88L01	KIT, WATER PUMP REPAIR	1	OPT

DF60A_E11_023_160C
WATER PUMP

FIG.160D




FIG.160D (1-D-4) WATER PUMP ((DF60A,DF60AQH,DF60ATH):E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-88L00	CASE, WATER PUMP	1	
2-1	17413-95J00	SLEEVE, WATER PUMP CASE	1	020,021
2-2	17413-95J10	SLEEVE, WATER PUMP CASE	1	022,023
3	17416-95J00	SEALING, WATER PUMP CASE	1	
4	17564-88L01	BUSH, WATER PUMP CASE	1	
5	29141-93J00	NUT (M6)	4	
6	29162-93J00	WASHER (6.1X12.2X1.5)	4	
7	09108-06143	STUD BOLT (L:45)	2	
8	09108-06144	STUD BOLT (L:31)	2	
9	17461-96312	IMPELLER, WATER PUMP	1	
10-1	17471-95J01	PANEL, PUMP CASE UNDER	1	020,021
10-2	17471-95J10	PANEL, PUMP CASE UNDER	1	022,023
11	17472-96304	GASKET, PUMP CASE UNDER	1	
12-1	17560-88L10	TUBE, WATER	1	W/TRANSOM(L)
12-2	17560-88L20	TUBE, WATER	1	W/TRANSOM(X)
13	17562-87L01	GROMMET, WATER TUBE UPPER	1	UPPER
14	17562-87L01	GROMMET, WATER TUBE UPPER	1	LOWER
15	09116-06236	BOLT (6X16)	1	
16	17631-96320	FILTER, WATER	2	
17	03142-04309	SCREW	2	
18-1	17635-87E00	FILTER, WATER SUB	1	
18-2	17635-87E10	PLATE, GEAR CASE	1	OPT
19	09125-05046	SCREW (5X12)	2	
20	09420-04006	KEY	1	
21-1	17400-88L01	KIT, WATER PUMP REPAIR	1	020,021 OPT
21-2	17400-88L20	KIT, WATER PUMP REPAIR	1	022,023 OPT

DF60A_E11_023_160D
WATER PUMP

FIG.160E




FIG.160E (1-D-5) WATER PUMP (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-99E10	CASE, WATER PUMP	1	
2	17461-87E12	IMPELLER, WATER PUMP	1	
3	17471-99E00	PANEL, PUMP CASE UNDER	1	
4	17472-87E10	GASKET, PUMP CASE PANEL	1	
5-1	17560-88L30	TUBE, WATER	1	W/TRANSOM(L)
5-2	17560-88L40	TUBE, WATER	1	W/TRANSOM(X)
6	17562-87L01	GROMMET, WATER TUBE UPPER	1	UPPER
7	17562-87L01	GROMMET, WATER TUBE UPPER	1	LOWER
8	17564-87D00	BUSH, WATER PUMP CASE	1	
9	17631-90J00	FILTER, WATER PORT SIDE	1	PORT
10	17632-90J00	FILTER, WATER STBD SIDE	1	STBD
11	17635-90J00	PLUG, SUB WATER TUBE	1	
12	29116-93J10	BOLT (8X35)	4	
13	09125-05046	SCREW (5X12)	2	
14	09116-06236	BOLT (6X16)	1	
15	09202-06031	PIN (6X12)	2	
16	09420-04009	KEY	1	
17	09132-04034	SCREW (4X18)	2	
18	17413-99E11	SLEEVE, WATER PUMP CASE	1	
19	17416-99E11	SEALING, WATER PUMP CASE NO.1	1	
20	17400-99E12	KIT, WATER PUMP REPAIR	1	OPT
21	17635-87E10	PLATE, GEAR CASE	1	OPT
22	55321-87J11	ANODE	1	OPT

NOTE : (DF50AVTH,DF60AVT):E01,DF60AVT:E11,DF40ASVT:E34

FIG.160F




FIG.160F (1-D-6) WATER PUMP ((DF50AVT,DF60AVT):E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-99E10	CASE, WATER PUMP	1	
2	17461-87E12	IMPELLER, WATER PUMP	1	
3	17471-99E00	PANEL, PUMP CASE UNDER	1	
4	17472-87E10	GASKET, PUMP CASE PANEL	1	
5	17560-88L30	TUBE, WATER	1	
6	17562-87L01	GROMMET, WATER TUBE UPPER	1	UPPER
7	17562-87L01	GROMMET, WATER TUBE UPPER	1	LOWER
8	17564-87D00	BUSH, WATER PUMP CASE	1	
9	17631-90J00	FILTER, WATER PORT SIDE	1	PORT
10	17632-90J00	FILTER, WATER STBD SIDE	1	STBD
11	17635-90J00	PLUG, SUB WATER TUBE	1	
12	29116-93J10	BOLT (8X35)	4	
13	09125-05046	SCREW (5X12)	2	
14	09116-06236	BOLT (6X16)	1	
15	09202-06031	PIN (6X12)	2	
16	09420-04009	KEY	1	
17	09132-04034	SCREW (4X18)	2	
18	17413-99E11	SLEEVE, WATER PUMP CASE	1	
19	17416-99E11	SEALING, WATER PUMP CASE NO.1	1	
20	17400-99E12	KIT, WATER PUMP REPAIR	1	OPT
21	17635-87E10	PLATE, GEAR CASE	1	OPT
22	55321-87J11	ANODE	1	OPT

FIG.160G




FIG.160G (1-D-7) WATER PUMP ((DF60AVT,DF60AVTH):E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-99E10	CASE, WATER PUMP	1	
2	17461-87E12	IMPELLER, WATER PUMP	1	
3-1	17471-99E00	PANEL, PUMP CASE UNDER	1	020,021
3-2	17471-99E10	PANEL, PUMP CASE UNDER	1	022,023
4	17472-87E10	GASKET, PUMP CASE PANEL	1	
5-1	17560-88L30	TUBE, WATER	1	W/TRANSOM(L)
5-2	17560-88L40	TUBE, WATER	1	W/TRANSOM(X)
6	17562-87L01	GROMMET, WATER TUBE UPPER	1	UPPER
7	17562-87L01	GROMMET, WATER TUBE UPPER	1	LOWER
8	17564-87D00	BUSH, WATER PUMP CASE	1	
9	17631-90J00	FILTER, WATER PORT SIDE	1	PORT
10	17632-90J00	FILTER, WATER STBD SIDE	1	STBD
11	17635-90J00	PLUG, SUB WATER TUBE	1	
12	29116-93J10	BOLT (8X35)	4	
13	09125-05046	SCREW (5X12)	2	
14	09202-06031	PIN (6X12)	2	
15	09420-04009	KEY	1	
16	09132-04034	SCREW (4X18)	2	
17-1	17413-99E11	SLEEVE, WATER PUMP CASE	1	020,021
17-2	17413-99E21	SLEEVE, WATER PUMP CASE	1	022,023
18	17416-99E11	SEALING, WATER PUMP CASE NO.1	1	
19	17635-87E10	PLATE, GEAR CASE	1	OPT
20	55321-87J11	ANODE	1	OPT
21-1	17400-99E12	KIT, WATER PUMP REPAIR	1	DF60AVTH:(020,021) OPT
21-2	17400-99E20	KIT, WATER PUMP REPAIR	1	DF60AVTH:(022,023) OPT

DF60A_E11_023_160G
WATER PUMP

FIG.162A




FIG.162A (1-D-8) THERMOSTAT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17611-90J00	COVER, WTR PRESS VALVE	1	
2	17660-99E01	VALVE, WATER PRESSURE	1	
3	09116-06121	BOLT (6X25)	2	
4	09280-26006	O RING (D:3.1,ID:26.4)	1	
5	17670-93955	THERMOSTAT, WATER (60C)	1	
6	17681-88L00	COVER, THERMOSTAT	1	
7	01550-0620C	BOLT	2	
8	11196-88L00	HOSE, WATER RETURN	1	
9	09401-25406	CLIP	2	
10	18498-94J11	PROTECTOR, WATER HOSE	2	
11	17712-88L01	HOSE, WATER	1	SEPARATOR TO INSP
12	09352-50006-600	HOSE (5X9X600)	1	L:600->500
13	09359-50901-980	HOSE (L:980)	1	L:980->250
14	09401-08413	CLIP	4	
15	09401-10415	CLIP	1	
16	09408-00175	CLAMP	1	

DF60A_E11_023_162A
THERMOSTAT

FIG.163A




FIG.163A (1-D-9) THROTTLE BODY (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-88L02	BODY ASSY, THROTTLE	1	
2	13353-99E00	.ADJUSTER ASSY	1	
3	13315-88L00	BRACKET, THROTTLE BODY	1	
4	01550-0645C	BOLT	4	
5	01550-0616C	BOLT	2	
6	01550-0820C	BOLT	1	
7	13510-88L00	ROD, THROTTLE	1	
8	19120-88L01	LEVER, THROTTLE	1	
9	19131-95502	CONNECTOR	1	
10	09140-05005	NUT (M5)	1	
11	09160-06047	WASHER (6.5X20X2.0)	1	
12	01550-0640C	BOLT	1	

NOTE : DF40A,DF50A,DF60A,DF50AVT,DF60AVT

FIG.163B




FIG.163B (1-D-10) THROTTLE BODY (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-88L02	BODY ASSY, THROTTLE	1	
2	13353-99E00	.ADJUSTER ASSY	1	
3	13315-88L00	BRACKET, THROTTLE BODY	1	
4	01550-0645C	BOLT	4	
5	01550-0616C	BOLT	2	
6	01550-0820C	BOLT	1	
7	13510-88L00	ROD, THROTTLE	1	
8	19120-88L12	LEVER, THROTTLE	1	
9	19131-95502	CONNECTOR	1	
10	09140-05005	NUT (M5)	1	
11	09160-06047	WASHER (6.5X20X2.0)	1	
12	01550-0640C	BOLT	1	

NOTE : DF40AQH,DF40ATH,DF50ATH,DF60AQH,DF60ATH,DF50AVTH,DF60AVTH

FIG.163C




FIG.163C (1-D-11) THROTTLE BODY (DF40AST,DF40ASVT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-88L02	BODY ASSY, THROTTLE	1	
2	13353-99E00	.ADJUSTER ASSY	1	
3	13315-88L00	BRACKET, THROTTLE BODY	1	
4	01550-0645C	BOLT	4	
5	01550-0616C	BOLT	2	
6	01550-0820C	BOLT	1	
7	13510-88L00	ROD, THROTTLE	1	
8	19120-88L01	LEVER, THROTTLE	1	
9	19131-95502	CONNECTOR	1	
10	09140-05005	NUT (M5)	1	
11	09160-06047	WASHER (6.5X20X2.0)	1	
12	01550-0640C	BOLT	1	
13	13815-88L10	RESTRICTOR, INTAKE	1	020,021

FIG.175A




FIG.175A (1-D-12) OIL PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11433-88L00	GASKET, UNDER OIL SEAL	1	
2	16400-88L00	PUMP ASSY, OIL	1	
3	01547-0640A	BOLT	7	
4	04211-09109	PIN (H:10)	2	
5	16520-88L00	STRAINER, OIL	1	
6	09280-12008	O RING (D:2.4,ID:12.3)	2	
7	01570-0616A	BOLT	2	
8	16519-87L00	SEAL, ENGINE HOLDER	1	
9	16510-87J01	FILTER ASSY, OIL	1	

DF60A_E11_023_175A
OIL PUMP

FIG.180A




FIG.180A (1-D-13) OIL PAN (DF40A,DF40AST,DF50A,DF60A,DF40ASVT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11489-88L01	GASKET, OIL PAN	1	
2-1	11501-88L01-YAY	PAN, OIL (BLACK)	1	020 FOR YAY
2-2	11501-88L01-Y5S	PAN, OIL (WHITE)	1	020 FOR Y5S
2-3	11501-88L01-QTN	PAN, OIL (WHITE)	1	021 FOR QTN
2-4	11501-88L01-YAY	PAN, OIL (BLACK)	1	021 FOR QTN SEE NOTE
2-5	11501-88L01-YAY	PAN, OIL (BLACK)	1	021,022,023 FOR YAY
3	09116-08178	BOLT (8X40)	6	
4	09168-12012	GASKET (12.5X20X2.5)	1	
5	09248-12009	PLUG (12X18.65)	1	OIL DRAIN
6-1	11551-88L00-YAY	COVER, WATER JACKET OIL PAN (BLACK)	1	020
6-2	11551-88L00-Y5S	COVER, WATER JACKET OIL PAN (WHITE)	1	020
6-3	11551-88L00-QTN	COVER, WATER JACKET OIL PAN (WHITE)	1	021,022,023
6-4	11551-88L00-YAY	COVER, WATER JACKET OIL PAN (BLACK)	1	021,022,023
7	11552-88L00	GASKET, OIL PAN WTR JKT COVER	1	
8	09116-06121	BOLT (6X25)	4	
9	17913-93J00	PLUG, WATER	1	
10	17914-93J01	GASKET, WATER PLUG	1	
11	11543-88L01	SILENCER, EXHAUST	1	
12	43112-99E00	PIPE, EXHAUST	1	
13	09116-10124	BOLT (10X150)	6	
14	16910-88L00	GAUGE, OIL LEVEL	1	

NOTE : FROM 04003F-140758,FROM 05003F-140891,
FROM 06002F-140966

DF60A_E11_023_180A
OIL PAN

FIG.180A




FIG.180A (1-D-14) OIL PAN (DF40A,DF40AST,DF50A,DF60A,DF40ASVT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
15	16930-88L00	GUIDE, OIL LEVEL GAUGE	1	
16	09280-09008	O RING (D:2.1,ID:8.8)	1	
17	01550-0612C	BOLT	1	

DF60A_E11_023_180A
OIL PAN

FIG.180B




FIG.180B (1-E-2) OIL PAN (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11489-88L01	GASKET, OIL PAN	1	
2	11501-88L01-YAY	PAN, OIL (BLACK)	1	
3	09116-08178	BOLT (8X40)	6	
4	09168-12012	GASKET (12.5X20X2.5)	1	
5	09248-12009	PLUG (12X18.65)	1	OIL DRAIN
6	11551-88L00-YAY	COVER, WATER JACKET OIL PAN (BLACK)	1	
7	11552-88L00	GASKET, OIL PAN WTR JKT COVER	1	
8	09116-06121	BOLT (6X25)	4	
9	17913-93J00	PLUG, WATER	1	
10	17914-93J01	GASKET, WATER PLUG	1	
11	11543-88L01	SILENCER, EXHAUST	1	
12	43112-99E00	PIPE, EXHAUST	1	
13	09116-10124	BOLT (10X150)	6	
14	16910-88L00	GAUGE, OIL LEVEL	1	
15	16930-88L00	GUIDE, OIL LEVEL GAUGE	1	
16	09280-09008	O RING (D:2.1,ID:8.8)	1	
17	01550-0612C	BOLT	1	

NOTE : DF40AQH,DF40ATH,DF50ATH,DF60AQH,DF60ATH,DF50AVT,DF50AVTH, DF60AVT,DF60AVTH

FIG.204A




FIG.204A (1-E-3) CLUTCH SHAFT (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21126-88L00	HOLDER, CLUTCH SHAFT	1	
2	21151-88L00	HOLDER, CLUTCH LEVER	1	
3	01550-0616C	BOLT	2	
4	01550-0630C	BOLT	2	
5	21210-88L01	SHAFT, CLUTCH	1	
6-1	23111-88L01	ROD, CLUTCH	1	W/TRANSOM(S)
6-2	23111-88L11	ROD, CLUTCH	1	W/TRANSOM(L)
6-3	23111-88L11	ROD, CLUTCH	1	W/TRANSOM(X)
7	29141-93J00	NUT (M6)	1	
8	23115-88L00	LINK, CLUTCH LEVER	1	
9	23210-88L00	LEVER, CLUTCH CONTROL	1	
10	09160-06055	WASHER (7X12X1.0)	2	
11	09385-06012	CLIP	2	
12	23213-89J01	SPRING, NOTCH PLATE NO.1	1	
13	23214-89J00	SPRING, NOTCH PLATE	1	
14	01550-0612C	BOLT	1	
15	23311-95J00	CONNECTOR, CLUTCH ROD	1	
16	67341-88L01	HOLDER, REMOCON CABLE	1	
17	01550-0616C	BOLT	2	
18	67343-88L01	STOPPER, REMOCON CABLE	1	
19	09352-70104-600	HOSE (7X10.2X600)	2	L:600->14
20	01570-06167	BOLT	1	
21	67467-89J01	CONNECTOR	2	
22	09160-06055	WASHER (7X12X1.0)	2	
23	09385-06012	CLIP	2	

NOTE : (DF40A,DF40AQH,DF40ATH,DF50A,DF50ATH,DF60A,DF60ATH):E01,
(DF40A,DF50A,DF60A):E11

FIG.204B




FIG.204B (1-E-4) CLUTCH SHAFT ((DF40A,DF50A,DF60A):E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21126-88L00	HOLDER, CLUTCH SHAFT	1	
2	21151-88L00	HOLDER, CLUTCH LEVER	1	
3	01550-0616C	BOLT	2	
4	01550-0630C	BOLT	2	
5	21210-88L01	SHAFT, CLUTCH	1	
6	23111-88L11	ROD, CLUTCH	1	
7	29141-93J00	NUT (M6)	1	
8	23115-88L00	LINK, CLUTCH LEVER	1	
9	23210-88L00	LEVER, CLUTCH CONTROL	1	
10	09160-06055	WASHER (7X12X1.0)	2	
11	09385-06012	CLIP	2	
12	23213-89J01	SPRING, NOTCH PLATE NO.1	1	
13	23214-89J00	SPRING, NOTCH PLATE	1	
14	01550-0612C	BOLT	1	
15	23311-95J00	CONNECTOR, CLUTCH ROD	1	
16	67341-88L01	HOLDER, REMOCON CABLE	1	
17	01550-0616C	BOLT	2	
18	67343-88L01	STOPPER, REMOCON CABLE	1	
19	09352-70104-600	HOSE (7X10.2X600)	2	L:600->14
20	01570-06167	BOLT	1	
21	67467-89J01	CONNECTOR	2	
22	09160-06055	WASHER (7X12X1.0)	2	
23	09385-06012	CLIP	2	

FIG.204C




FIG.204C (1-E-5) CLUTCH SHAFT (DF40AST:E34)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21126-88L00	HOLDER, CLUTCH SHAFT	1	
2	21151-88L00	HOLDER, CLUTCH LEVER	1	
3	01550-0616C	BOLT	2	
4	01550-0630C	BOLT	2	
5	21210-88L01	SHAFT, CLUTCH	1	
6-1	23111-88L01	ROD, CLUTCH	1	W/TRANSOM(S)
6-2	23111-88L11	ROD, CLUTCH	1	W/TRANSOM(L)
7	29141-93J00	NUT (M6)	1	
8	23115-88L00	LINK, CLUTCH LEVER	1	
9	23210-88L00	LEVER, CLUTCH CONTROL	1	
10	09160-06055	WASHER (7X12X1.0)	2	
11	09385-06012	CLIP	2	
12	23213-89J01	SPRING, NOTCH PLATE NO.1	1	
13	23214-89J00	SPRING, NOTCH PLATE	1	
14	01550-0612C	BOLT	1	
15	23311-95J00	CONNECTOR, CLUTCH ROD	1	
16	67341-88L01	HOLDER, REMOCON CABLE	1	
17	01550-0616C	BOLT	2	
18	67343-88L01	STOPPER, REMOCON CABLE	1	
19	09352-70104-600	HOSE (7X10.2X600)	2	L:600->14
20	01570-06167	BOLT	1	
21	67467-89J01	CONNECTOR	2	
22	09160-06055	WASHER (7X12X1.0)	2	
23	09385-06012	CLIP	2	

FIG.204D




FIG.204D (1-E-6) CLUTCH SHAFT ((DF60A,DF60AQH,DF60ATH):E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21126-88L00	HOLDER, CLUTCH SHAFT	1	
2	21151-88L00	HOLDER, CLUTCH LEVER	1	
3	01550-0616C	BOLT	2	
4	01550-0630C	BOLT	2	
5	21210-88L01	SHAFT, CLUTCH	1	
6	23111-88L11	ROD, CLUTCH	1	
7	29141-93J00	NUT (M6)	1	
8	23115-88L00	LINK, CLUTCH LEVER	1	
9	23210-88L00	LEVER, CLUTCH CONTROL	1	
10	09160-06055	WASHER (7X12X1.0)	2	
11	09385-06012	CLIP	2	
12	23213-89J01	SPRING, NOTCH PLATE NO.1	1	
13	23214-89J00	SPRING, NOTCH PLATE	1	
14	01550-0612C	BOLT	1	
15	23311-95J00	CONNECTOR, CLUTCH ROD	1	
16	67341-88L01	HOLDER, REMOCON CABLE	1	
17	01550-0616C	BOLT	2	
18	67343-88L01	STOPPER, REMOCON CABLE	1	
19	09352-70104-600	HOSE (7X10.2X600)	2	L:600->14
20	01570-06167	BOLT	1	
21	67467-89J01	CONNECTOR	2	
22	09160-06055	WASHER (7X12X1.0)	2	
23	09385-06012	CLIP	2	

FIG.204E




FIG.204E (1-E-7) CLUTCH SHAFT (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21126-88L00	HOLDER, CLUTCH SHAFT	1	
2	21151-88L00	HOLDER, CLUTCH LEVER	1	
3	01550-0616C	BOLT	2	
4	01550-0630C	BOLT	2	
5	21210-88L01	SHAFT, CLUTCH	1	
6-1	23111-88L01	ROD, CLUTCH	1	W/TRANSOM(L)
6-2	23111-88L11	ROD, CLUTCH	1	W/TRANSOM(X)
7	29141-93J00	NUT (M6)	1	
8	23115-88L00	LINK, CLUTCH LEVER	1	
9	23210-88L00	LEVER, CLUTCH CONTROL	1	
10	09160-06055	WASHER (7X12X1.0)	2	
11	09385-06012	CLIP	2	
12	23213-89J01	SPRING, NOTCH PLATE NO.1	1	
13	23214-89J00	SPRING, NOTCH PLATE	1	
14	01550-0612C	BOLT	1	
15	23311-95J00	CONNECTOR, CLUTCH ROD	1	
16	67341-88L01	HOLDER, REMOCON CABLE	1	
17	01550-0616C	BOLT	2	
18	67343-88L01	STOPPER, REMOCON CABLE	1	
19	09352-70104-600	HOSE (7X10.2X600)	2	L:600->14
20	01570-06167	BOLT	1	
21	67467-89J01	CONNECTOR	2	
22	09160-06055	WASHER (7X12X1.0)	2	
23	09385-06012	CLIP	2	

NOTE : (DF50AVTH,DF60AVT):E01,DF60AVT:E11,DF40ASVT:E34

FIG.204F




FIG.204F (1-E-8) CLUTCH SHAFT ((DF50AVT,DF60AVT):E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21126-88L00	HOLDER, CLUTCH SHAFT	1	
2	21151-88L00	HOLDER, CLUTCH LEVER	1	
3	01550-0616C	BOLT	2	
4	01550-0630C	BOLT	2	
5	21210-88L01	SHAFT, CLUTCH	1	
6	23111-88L01	ROD, CLUTCH	1	
7	29141-93J00	NUT (M6)	1	
8	23115-88L00	LINK, CLUTCH LEVER	1	
9	23210-88L00	LEVER, CLUTCH CONTROL	1	
10	09160-06055	WASHER (7X12X1.0)	2	
11	09385-06012	CLIP	2	
12	23213-89J01	SPRING, NOTCH PLATE NO.1	1	
13	23214-89J00	SPRING, NOTCH PLATE	1	
14	01550-0612C	BOLT	1	
15	23311-95J00	CONNECTOR, CLUTCH ROD	1	
16	67341-88L01	HOLDER, REMOCON CABLE	1	
17	01550-0616C	BOLT	2	
18	67343-88L01	STOPPER, REMOCON CABLE	1	
19	09352-70104-600	HOSE (7X10.2X600)	2	L:600->14
20	01570-06167	BOLT	1	
21	67467-89J01	CONNECTOR	2	
22	09160-06055	WASHER (7X12X1.0)	2	
23	09385-06012	CLIP	2	

FIG.204G




FIG.204G (1-E-9) CLUTCH SHAFT ((DF60AVT,DF60AVTH):E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21126-88L00	HOLDER, CLUTCH SHAFT	1	
2	21151-88L00	HOLDER, CLUTCH LEVER	1	
3	01550-0616C	BOLT	2	
4	01550-0630C	BOLT	2	
5	21210-88L01	SHAFT, CLUTCH	1	
6-1	23111-88L01	ROD, CLUTCH	1	W/TRANSOM(L)
6-2	23111-88L11	ROD, CLUTCH	1	W/TRANSOM(X)
7	29141-93J00	NUT (M6)	1	
8	23115-88L00	LINK, CLUTCH LEVER	1	
9	23210-88L00	LEVER, CLUTCH CONTROL	1	
10	09160-06055	WASHER (7X12X1.0)	2	
11	09385-06012	CLIP	2	
12	23213-89J01	SPRING, NOTCH PLATE NO.1	1	
13	23214-89J00	SPRING, NOTCH PLATE	1	
14	01550-0612C	BOLT	1	
15	23311-95J00	CONNECTOR, CLUTCH ROD	1	
16	67341-88L01	HOLDER, REMOCON CABLE	1	
17	01550-0616C	BOLT	2	
18	67343-88L01	STOPPER, REMOCON CABLE	1	
19	09352-70104-600	HOSE (7X10.2X600)	2	L:600->14
20	01570-06167	BOLT	1	
21	67467-89J01	CONNECTOR	2	
22	09160-06055	WASHER (7X12X1.0)	2	
23	09385-06012	CLIP	2	

FIG.206A




FIG.206A (1-E-10) CLUTCH ROD (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	25111-88L00	ROD, SHIFT	1	W/TRANSOM(S)
1-2	25111-88L10	ROD, SHIFT	1	W/TRANSOM(L)
1-3	25111-88L20	ROD, SHIFT	1	W/TRANSOM(X)
2	25211-87J00	GUIDE, SHIFT ROD	1	
3	09280-08005	O RING (D:1.7,ID:7.7)	1	
4	09280-11001	O RING (D:2.4,ID:10.8)	1	
5	25212-94401	GUIDE, SHIFT ROD LOWER	1	LOWER
6	09205-02013	PIN (2.5X16)	1	
7	09205-03021	PIN (3.5X12)	1	
8	09205-02004	PIN (2.5X12)	1	
9	25223-96J00	SEAL, CLUTCH ROD	1	
10	25232-96302	MAGNETO, GEAR CASE	1	
11	25311-88L00	CAM, SHIFT	1	
12	08331-3115A	CIRCLIP	1	
13	21121-93300	PLATE, CLUTCH NOTCH	1	
14	09260-10005	BALL	1	
15	09440-07078	SPRING	1	

NOTE : (DF40A,DF40AQH,DF40ATH,DF50A,DF50ATH,DF60A,DF60ATH):E01,
(DF40A,DF50A,DF60A):E11

DF60A_E11_023_206A
CLUTCH ROD

FIG.206B




FIG.206B (1-E-11) CLUTCH ROD ((DF40A,DF50A,DF60A):E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	25111-88L10	ROD, SHIFT	1	
2	25211-87J00	GUIDE, SHIFT ROD	1	
3	09280-08005	O RING (D:1.7,ID:7.7)	1	
4	09280-11001	O RING (D:2.4,ID:10.8)	1	
5	25212-94401	GUIDE, SHIFT ROD LOWER	1	LOWER
6	09205-02013	PIN (2.5X16)	1	
7	09205-03021	PIN (3.5X12)	1	
8	09205-02004	PIN (2.5X12)	1	
9	25223-96J00	SEAL, CLUTCH ROD	1	
10	25232-96302	MAGNETO, GEAR CASE	1	
11	25311-88L00	CAM, SHIFT	1	
12	08331-3115A	CIRCLIP	1	
13	21121-93300	PLATE, CLUTCH NOTCH	1	
14	09260-10005	BALL	1	
15	09440-07078	SPRING	1	

DF60A_E11_023_206B
CLUTCH ROD

FIG.206C




FIG.206C (1-E-12) CLUTCH ROD (DF40AST:E34)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	25111-88L00	ROD, SHIFT	1	W/TRANSOM(S)
1-2	25111-88L10	ROD, SHIFT	1	W/TRANSOM(L)
2	25211-87J00	GUIDE, SHIFT ROD	1	
3	09280-08005	O RING (D:1.7,ID:7.7)	1	
4	09280-11001	O RING (D:2.4,ID:10.8)	1	
5	25212-94401	GUIDE, SHIFT ROD LOWER	1	LOWER
6	09205-02013	PIN (2.5X16)	1	
7	09205-03021	PIN (3.5X12)	1	
8	09205-02004	PIN (2.5X12)	1	
9	25223-96J00	SEAL, CLUTCH ROD	1	
10	25232-96302	MAGNETO, GEAR CASE	1	
11	25311-88L00	CAM, SHIFT	1	
12	08331-3115A	CIRCLIP	1	
13	21121-93300	PLATE, CLUTCH NOTCH	1	
14	09260-10005	BALL	1	
15	09440-07078	SPRING	1	

DF60A_E11_023_206C
CLUTCH ROD

FIG.206D




FIG.206D (1-E-13) CLUTCH ROD ((DF60A,DF60AQH,DF60ATH):E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	25111-88L10	ROD, SHIFT	1	W/TRANSOM(L)
1-2	25111-88L20	ROD, SHIFT	1	W/TRANSOM(X)
2	25211-87J00	GUIDE, SHIFT ROD	1	
3	09280-08005	O RING (D:1.7,ID:7.7)	1	
4	09280-11001	O RING (D:2.4,ID:10.8)	1	
5	25212-94401	GUIDE, SHIFT ROD LOWER	1	LOWER
6	09205-02013	PIN (2.5X16)	1	
7	09205-03021	PIN (3.5X12)	1	
8	09205-02004	PIN (2.5X12)	1	
9	25223-96J00	SEAL, CLUTCH ROD	1	
10	25232-96302	MAGNETO, GEAR CASE	1	
11	25311-88L00	CAM, SHIFT	1	
12	08331-3115A	CIRCLIP	1	
13	21121-93300	PLATE, CLUTCH NOTCH	1	
14	09260-10005	BALL	1	
15	09440-07078	SPRING	1	

DF60A_E11_023_206D
CLUTCH ROD

FIG.210A




FIG.210A (1-E-14) SHIFT ROD (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21121-93300	PLATE, CLUTCH NOTCH	1	
2-1	25111-88L30	ROD, SHIFT	1	W/TRANSOM(L)
2-2	25111-88L40	ROD, SHIFT	1	W/TRANSOM(X)
3	25141-99E03	HOUSING, SHIFT ROD GUIDE	1	
4	25205-94501	COLLAR, SHIFT ROD SPRING	1	
5	25211-94501	GUIDE, SHIFT ROD	1	
6	25230-94300	MAGNETO SET, GEAR CASE	1	
7	25311-94510	CAM, CLUTCH	1	
8	09117-06031	BOLT (6X20)	3	
9	09160-09015	WASHER (9X19X1.0)	1	
10	09160-09010	WASHER (9X30X1.6)	1	
11	09160-08122	WASHER (8.5X18X3.20)	1	
12	09205-02006	PIN (2X12)	2	
13	09205-03021	PIN (3.5X12)	2	
14	09260-10005	BALL	1	
15	09280-08008	O RING (D:3.5,ID:7.8)	2	
16	09280-15003	O RING (D:1.9,ID:14.5)	1	
17	09280-69001	O RING (D:3.1,ID:68.5)	1	
18	09284-08003	OIL SEAL (8X19X4.5)	1	
19	09440-07033	SPRING	1	
20	08331-41309	CIRCLIP	1	

NOTE : DF50AVT,DF50AVTH,DF60AVT,DF40ASVT,DF60AVTH

DF60A_E11_023_210A
SHIFT ROD

FIG.220A




FIG.220A (1-F-2) TRANSMISSION (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57110-88L02	SHAFT, DRIVE	1	W/TRANSOM(S)
1-2	57110-88L12	SHAFT, DRIVE	1	W/TRANSOM(L)
1-3	57110-88L22	SHAFT, DRIVE	1	W/TRANSOM(X)
2	57133-88L01	COLLAR, DRIVE SHAFT	1	
3	57133-94400	HOUSING, DRIVE SHAFT SPRING	1	
4	09205-03019	PIN (3X10)	1	
5	09265-20015	BEARING (20X42X15)	1	
6	57300-88810	PINION & GEAR SET	1	
7	09140-12034	NUT	1	
8-1	09181-35101	SHIM (35X42X0.50)	AR	DRIVE SHAFT ADJUST
8-2	09181-33001	SHIM (33.5X41.8X0.55)	AR	DRIVE SHAFT ADJUST
8-3	09181-33002	SHIM (33.5X41.8X0.60)	AR	DRIVE SHAFT ADJUST
8-4	09181-33003	SHIM (33.5X41.8X0.65)	AR	DRIVE SHAFT ADJUST
8-5	09181-33004	SHIM (33.5X41.8X0.70)	AR	DRIVE SHAFT ADJUST
8-6	09181-33005	SHIM (33.5X41.8X0.75)	AR	DRIVE SHAFT ADJUST
8-7	09181-33006	SHIM (33.5X41.8X0.80)	AR	DRIVE SHAFT ADJUST
8-8	09181-33007	SHIM (33.5X41.8X0.85)	AR	DRIVE SHAFT ADJUST
8-9	09181-33008	SHIM (33.5X41.8X0.90)	AR	DRIVE SHAFT ADJUST
8-10	09181-33009	SHIM (33.5X41.8X0.95)	AR	DRIVE SHAFT ADJUST
8-11	09181-35110	SHIM (35X42X1)	AR	DRIVE SHAFT ADJUST
9-1	09181-30186	SHIM (30X42X0.5)	AR	FORWARD BACKUP
9-2	09181-30187	SHIM (30X42X0.6)	AR	FORWARD BACKUP
9-3	09181-30188	SHIM (30X42X0.7)	AR	FORWARD BACKUP
9-4	09181-30190	SHIM (30X42X0.8)	AR	FORWARD BACKUP
9-5	09181-30192	SHIM (30X42X0.9)	AR	FORWARD BACKUP
10-1	08221-35455	SHIM (35X45X0.5)	AR	REVERSE BACKUP
10-2	09181-35131	SHIM (35X46X0.6)	AR	REVERSE BACKUP
10-3	09181-35132	SHIM (35X46X0.7)	AR	REVERSE BACKUP
10-4	08221-35456	SHIM (35X45X0.8)	AR	REVERSE BACKUP
10-5	09181-35136	SHIM (35X46X0.9)	AR	REVERSE BACKUP
10-6	08211-35451	SHIM (35X45X1.0)	AR	REVERSE BACKUP

NOTE : (DF40A,DF40AQH,DF40ATH,DF50A,DF50ATH,DF60A,DF60ATH):E01,
(DF40A,DF50A,DF60A):E11

FIG.220A




FIG.220A (1-F-3) TRANSMISSION (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
11-1	09160-22018	WASHER (22.5X28X1.8)	1	PROP SHAFT THRUST
11-2	09160-22019	WASHER (22.5X28X1.9)	1	PROP SHAFT THRUST
11-3	09160-22020	WASHER (22.5X28X2.0)	1	PROP SHAFT THRUST
11-4	09160-22021	WASHER (22.5X28X2.1)	1	PROP SHAFT THRUST
11-5	09160-22022	WASHER (22.5X28X2.2)	1	PROP SHAFT THRUST
11-6	09160-22023	WASHER (22.5X28X2.3)	1	PROP SHAFT THRUST
12	08211-20263	WASHER (20X26X2.0)	1	
13	57610-94403	SHAFT, PROPELLER	1	
14	57621-87J03	SHIFTER, CLUTCH DOG	1	
15	09202-05022	PIN (5.5X38.5)	1	
16	57634-88L00	PIN, PUSH	1	
17	09440-08043	SPRING	1	
18	09440-40002	SPRING	1	
19	57631-95303	ROD, PUSH	1	
20-1	56120-94321-YAY	HOUSING, PROP SHAFT BRG (BLACK)	1	(DF40A,DF50A,DF60A):E01:020
20-2	56120-94321-Y5S	HOUSING, PROP SHAFT BRG (WHITE)	1	(DF40AQH,DF40ATH,DF50ATH, DF60ATH):E01:020
20-3	56120-94321-QTN	HOUSING, PROP SHAFT BRG (WHITE)	1	(DF40A,DF50A,DF60A):E11
20-4	56120-94321-YAY	HOUSING, PROP SHAFT BRG (BLACK)	1	(DF40AQH,DF40ATH,DF50ATH, DF60ATH):E01
21	09263-22020	.BEARING (22.2X28.5X19)	1	
22	09289-22007	.OIL SEAL (22X35X5)	2	
23	09262-35070	.BEARING (35X62X14)	1	
24	09280-75001	O RING (D:3.3,ID:75)	1	
25	09116-08122	BOLT (8X30)	2	

NOTE : (DF40A,DF40AQH,DF40ATH,DF50A,DF50ATH,DF60A,DF60ATH):E01,
(DF40A,DF50A,DF60A):E11

FIG.220A




FIG.220A (1-F-4) TRANSMISSION (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
26-1	56130-87J12-YAY	HOUSING, DRIVE SFT BRG (BLACK)	1	(DF40A,DF50A,DF60A):E01:020
26-2	56130-87J12-Y5S	HOUSING, DRIVE SFT BRG (WHITE)	1	(DF40AQH,DF40ATH,DF50ATH, DF60ATH):E01:020
26-3	56130-87J12-QTN	HOUSING, DRIVE SFT BRG (WHITE)	1	(DF40A,DF50A,DF60A):E11
26-4	56130-87J12-YAY	HOUSING, DRIVE SFT BRG (BLACK)	1	(DF40AQH,DF40ATH,DF50ATH, DF60ATH):E01
27	09282-17005	.OIL SEAL (17X32X6)	2	
28	08331-41329	.CIRCLIP	1	
29	55122-88L00	RING, GEAR CASE SEAL	1	
30	09202-06025	PIN (6X17)	1	
31	09202-06027	PIN (6X23)	1	

NOTE : (DF40A,DF40AQH,DF40ATH,DF50A,DF50ATH,DF60A,DF60ATH):E01,
(DF40A,DF50A,DF60A):E11

FIG.220B




FIG.220B (1-F-5) TRANSMISSION ((DF40A,DF50A,DF60A):E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	57110-88L12	SHAFT, DRIVE	1	
2	57133-88L01	COLLAR, DRIVE SHAFT	1	
3	57133-94400	HOUSING, DRIVE SHAFT SPRING	1	
4	09205-03019	PIN (3X10)	1	
5	09265-20015	BEARING (20X42X15)	1	
6	57300-88810	PINION & GEAR SET	1	
7	09140-12034	NUT	1	
8-1	09181-35101	SHIM (35X42X0.50)	AR	DRIVE SHAFT ADJUST
8-2	09181-33001	SHIM (33.5X41.8X0.55)	AR	DRIVE SHAFT ADJUST
8-3	09181-33002	SHIM (33.5X41.8X0.60)	AR	DRIVE SHAFT ADJUST
8-4	09181-33003	SHIM (33.5X41.8X0.65)	AR	DRIVE SHAFT ADJUST
8-5	09181-33004	SHIM (33.5X41.8X0.70)	AR	DRIVE SHAFT ADJUST
8-6	09181-33005	SHIM (33.5X41.8X0.75)	AR	DRIVE SHAFT ADJUST
8-7	09181-33006	SHIM (33.5X41.8X0.80)	AR	DRIVE SHAFT ADJUST
8-8	09181-33007	SHIM (33.5X41.8X0.85)	AR	DRIVE SHAFT ADJUST
8-9	09181-33008	SHIM (33.5X41.8X0.90)	AR	DRIVE SHAFT ADJUST
8-10	09181-33009	SHIM (33.5X41.8X0.95)	AR	DRIVE SHAFT ADJUST
8-11	09181-35110	SHIM (35X42X1)	AR	DRIVE SHAFT ADJUST
9-1	09181-30186	SHIM (30X42X0.5)	AR	FORWARD BACKUP
9-2	09181-30187	SHIM (30X42X0.6)	AR	FORWARD BACKUP
9-3	09181-30188	SHIM (30X42X0.7)	AR	FORWARD BACKUP
9-4	09181-30190	SHIM (30X42X0.8)	AR	FORWARD BACKUP
9-5	09181-30192	SHIM (30X42X0.9)	AR	FORWARD BACKUP
10-1	08221-35455	SHIM (35X45X0.5)	AR	REVERSE BACKUP
10-2	09181-35131	SHIM (35X46X0.6)	AR	REVERSE BACKUP
10-3	09181-35132	SHIM (35X46X0.7)	AR	REVERSE BACKUP
10-4	08221-35456	SHIM (35X45X0.8)	AR	REVERSE BACKUP
10-5	09181-35136	SHIM (35X46X0.9)	AR	REVERSE BACKUP
10-6	08211-35451	SHIM (35X45X1.0)	AR	REVERSE BACKUP
11-1	09160-22018	WASHER (22.5X28X1.8)	1	PROP SHAFT THRUST
11-2	09160-22019	WASHER (22.5X28X1.9)	1	PROP SHAFT THRUST
11-3	09160-22020	WASHER (22.5X28X2.0)	1	PROP SHAFT THRUST
11-4	09160-22021	WASHER (22.5X28X2.1)	1	PROP SHAFT THRUST
11-5	09160-22022	WASHER (22.5X28X2.2)	1	PROP SHAFT THRUST
11-6	09160-22023	WASHER (22.5X28X2.3)	1	PROP SHAFT THRUST
12	08211-20263	WASHER (20X26X2.0)	1	

FIG.220B




FIG.220B (1-F-6) TRANSMISSION ((DF40A,DF50A,DF60A):E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
13	57610-94403	SHAFT, PROPELLER	1	
14	57621-87J03	SHIFTER, CLUTCH DOG	1	
15	09202-05022	PIN (5.5X38.5)	1	
16	57634-88L00	PIN, PUSH	1	
17	09440-08043	SPRING	1	
18	09440-40002	SPRING	1	
19	57631-95303	ROD, PUSH	1	
20-1	56120-94321-YAY	HOUSING, PROP SHAFT BRG (BLACK)	1	
20-2	56120-94321-Y5S	HOUSING, PROP SHAFT BRG (WHITE)	1	
21	09263-22020	.BEARING (22.2X28.5X19)	1	
22	09289-22007	.OIL SEAL (22X35X5)	2	
23	09262-35070	.BEARING (35X62X14)	1	
24	09280-75001	O RING (D:3.3,ID:75)	1	
25	09116-08122	BOLT (8X30)	2	
26-1	56130-87J12-YAY	HOUSING, DRIVE SFT BRG (BLACK)	1	
26-2	56130-87J12-Y5S	HOUSING, DRIVE SFT BRG (WHITE)	1	
27	09282-17005	.OIL SEAL (17X32X6)	2	
28	08331-41329	.CIRCLIP	1	
29	55122-88L00	RING, GEAR CASE SEAL	1	
30	09202-06025	PIN (6X17)	1	
31	09202-06027	PIN (6X23)	1	

FIG.220C




FIG.220C (1-F-7) TRANSMISSION (DF40AST:E34)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57110-88L02	SHAFT, DRIVE	1	W/TRANSOM(S)
1-2	57110-88L12	SHAFT, DRIVE	1	W/TRANSOM(L)
2	57133-88L01	COLLAR, DRIVE SHAFT	1	
3	57133-94400	HOUSING, DRIVE SHAFT SPRING	1	
4	09205-03019	PIN (3X10)	1	
5	09265-20015	BEARING (20X42X15)	1	
6	57300-88820	PINION & GEAR SET	1	
7	09140-12034	NUT	1	
8-1	09181-35101	SHIM (35X42X0.50)	AR	DRIVE SHAFT ADJUST
8-2	09181-33001	SHIM (33.5X41.8X0.55)	AR	DRIVE SHAFT ADJUST
8-3	09181-33002	SHIM (33.5X41.8X0.60)	AR	DRIVE SHAFT ADJUST
8-4	09181-33003	SHIM (33.5X41.8X0.65)	AR	DRIVE SHAFT ADJUST
8-5	09181-33004	SHIM (33.5X41.8X0.70)	AR	DRIVE SHAFT ADJUST
8-6	09181-33005	SHIM (33.5X41.8X0.75)	AR	DRIVE SHAFT ADJUST
8-7	09181-33006	SHIM (33.5X41.8X0.80)	AR	DRIVE SHAFT ADJUST
8-8	09181-33007	SHIM (33.5X41.8X0.85)	AR	DRIVE SHAFT ADJUST
8-9	09181-33008	SHIM (33.5X41.8X0.90)	AR	DRIVE SHAFT ADJUST
8-10	09181-33009	SHIM (33.5X41.8X0.95)	AR	DRIVE SHAFT ADJUST
8-11	09181-35110	SHIM (35X42X1)	AR	DRIVE SHAFT ADJUST
9-1	09181-30186	SHIM (30X42X0.5)	AR	FORWARD BACKUP
9-2	09181-30187	SHIM (30X42X0.6)	AR	FORWARD BACKUP
9-3	09181-30188	SHIM (30X42X0.7)	AR	FORWARD BACKUP
9-4	09181-30190	SHIM (30X42X0.8)	AR	FORWARD BACKUP
9-5	09181-30192	SHIM (30X42X0.9)	AR	FORWARD BACKUP
10-1	08221-35455	SHIM (35X45X0.5)	AR	REVERSE BACKUP
10-2	09181-35131	SHIM (35X46X0.6)	AR	REVERSE BACKUP
10-3	09181-35132	SHIM (35X46X0.7)	AR	REVERSE BACKUP
10-4	08221-35456	SHIM (35X45X0.8)	AR	REVERSE BACKUP
10-5	09181-35136	SHIM (35X46X0.9)	AR	REVERSE BACKUP
10-6	08211-35451	SHIM (35X45X1.0)	AR	REVERSE BACKUP
11-1	09160-22018	WASHER (22.5X28X1.8)	1	PROP SHAFT THRUST
11-2	09160-22019	WASHER (22.5X28X1.9)	1	PROP SHAFT THRUST
11-3	09160-22020	WASHER (22.5X28X2.0)	1	PROP SHAFT THRUST
11-4	09160-22021	WASHER (22.5X28X2.1)	1	PROP SHAFT THRUST
11-5	09160-22022	WASHER (22.5X28X2.2)	1	PROP SHAFT THRUST
11-6	09160-22023	WASHER (22.5X28X2.3)	1	PROP SHAFT THRUST

FIG.220C




FIG.220C (1-F-8) TRANSMISSION (DF40AST:E34)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
12	08211-20263	WASHER (20X26X2.0)	1	
13	57610-94403	SHAFT, PROPELLER	1	
14	57621-87J03	SHIFTER, CLUTCH DOG	1	
15	09202-05022	PIN (5.5X38.5)	1	
16	57634-88L00	PIN, PUSH	1	
17	09440-08043	SPRING	1	
18	09440-40002	SPRING	1	
19	57631-95303	ROD, PUSH	1	
20-1	56120-94321-YAY	HOUSING, PROP SHAFT BRG (BLACK)	1	020
20-2	56120-94321-Y5S	HOUSING, PROP SHAFT BRG (WHITE)	1	020
20-3	56120-94321-QTN	HOUSING, PROP SHAFT BRG (WHITE)	1	021,022,023
20-4	56120-94321-YAY	HOUSING, PROP SHAFT BRG (BLACK)	1	021,022,023
21	09263-22020	.BEARING (22.2X28.5X19)	1	
22	09289-22007	.OIL SEAL (22X35X5)	2	
23	09262-35070	.BEARING (35X62X14)	1	
24	09280-75001	O RING (D:3.3,ID:75)	1	
25	09116-08122	BOLT (8X30)	2	
26-1	56130-87J12-YAY	HOUSING, DRIVE SFT BRG (BLACK)	1	020
26-2	56130-87J12-Y5S	HOUSING, DRIVE SFT BRG (WHITE)	1	020
26-3	56130-87J12-QTN	HOUSING, DRIVE SFT BRG (WHITE)	1	021,022,023
26-4	56130-87J12-YAY	HOUSING, DRIVE SFT BRG (BLACK)	1	021,022,023
27	09282-17005	.OIL SEAL (17X32X6)	2	
28	08331-41329	.CIRCLIP	1	
29	55122-88L00	RING, GEAR CASE SEAL	1	
30	09202-06025	PIN (6X17)	1	
31	09202-06027	PIN (6X23)	1	

FIG.220D




FIG.220D (1-F-9) TRANSMISSION ((DF60A,DF60AQH,DF60ATH):E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57110-88L12	SHAFT, DRIVE	1	W/TRANSOM(L)
1-2	57110-88L22	SHAFT, DRIVE	1	W/TRANSOM(X)
2	57133-88L01	COLLAR, DRIVE SHAFT	1	
3	57133-94400	HOUSING, DRIVE SHAFT SPRING	1	
4	09205-03019	PIN (3X10)	1	
5	09265-20015	BEARING (20X42X15)	1	
6	57300-88810	PINION & GEAR SET	1	
7	09140-12034	NUT	1	
8-1	09181-35101	SHIM (35X42X0.50)	AR	DRIVE SHAFT ADJUST
8-2	09181-33001	SHIM (33.5X41.8X0.55)	AR	DRIVE SHAFT ADJUST
8-3	09181-33002	SHIM (33.5X41.8X0.60)	AR	DRIVE SHAFT ADJUST
8-4	09181-33003	SHIM (33.5X41.8X0.65)	AR	DRIVE SHAFT ADJUST
8-5	09181-33004	SHIM (33.5X41.8X0.70)	AR	DRIVE SHAFT ADJUST
8-6	09181-33005	SHIM (33.5X41.8X0.75)	AR	DRIVE SHAFT ADJUST
8-7	09181-33006	SHIM (33.5X41.8X0.80)	AR	DRIVE SHAFT ADJUST
8-8	09181-33007	SHIM (33.5X41.8X0.85)	AR	DRIVE SHAFT ADJUST
8-9	09181-33008	SHIM (33.5X41.8X0.90)	AR	DRIVE SHAFT ADJUST
8-10	09181-33009	SHIM (33.5X41.8X0.95)	AR	DRIVE SHAFT ADJUST
8-11	09181-35110	SHIM (35X42X1)	AR	DRIVE SHAFT ADJUST
9-1	09181-30186	SHIM (30X42X0.5)	AR	FORWARD BACKUP
9-2	09181-30187	SHIM (30X42X0.6)	AR	FORWARD BACKUP
9-3	09181-30188	SHIM (30X42X0.7)	AR	FORWARD BACKUP
9-4	09181-30190	SHIM (30X42X0.8)	AR	FORWARD BACKUP
9-5	09181-30192	SHIM (30X42X0.9)	AR	FORWARD BACKUP
10-1	08221-35455	SHIM (35X45X0.5)	AR	REVERSE BACKUP
10-2	09181-35131	SHIM (35X46X0.6)	AR	REVERSE BACKUP
10-3	09181-35132	SHIM (35X46X0.7)	AR	REVERSE BACKUP
10-4	08221-35456	SHIM (35X45X0.8)	AR	REVERSE BACKUP
10-5	09181-35136	SHIM (35X46X0.9)	AR	REVERSE BACKUP
10-6	08211-35451	SHIM (35X45X1.0)	AR	REVERSE BACKUP
11-1	09160-22018	WASHER (22.5X28X1.8)	1	PROP SHAFT THRUST
11-2	09160-22019	WASHER (22.5X28X1.9)	1	PROP SHAFT THRUST
11-3	09160-22020	WASHER (22.5X28X2.0)	1	PROP SHAFT THRUST
11-4	09160-22021	WASHER (22.5X28X2.1)	1	PROP SHAFT THRUST
11-5	09160-22022	WASHER (22.5X28X2.2)	1	PROP SHAFT THRUST
11-6	09160-22023	WASHER (22.5X28X2.3)	1	PROP SHAFT THRUST

FIG.220D




FIG.220D (1-F-10) TRANSMISSION ((DF60A,DF60AQH,DF60ATH):E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
12	08211-20263	WASHER (20X26X2.0)	1	
13	57610-94403	SHAFT, PROPELLER	1	
14	57621-87J03	SHIFTER, CLUTCH DOG	1	
15	09202-05022	PIN (5.5X38.5)	1	
16	57634-88L00	PIN, PUSH	1	
17	09440-08043	SPRING	1	
18	09440-40002	SPRING	1	
19	57631-95303	ROD, PUSH	1	
20-1	56120-94321-YAY	HOUSING, PROP SHAFT BRG (BLACK)	1	020
20-2	56120-94321-Y5S	HOUSING, PROP SHAFT BRG (WHITE)	1	020
20-3	56120-94321-QTN	HOUSING, PROP SHAFT BRG (WHITE)	1	021,022,023
20-4	56120-94321-YAY	HOUSING, PROP SHAFT BRG (BLACK)	1	021,022,023
21	09263-22020	.BEARING (22.2X28.5X19)	1	
22	09289-22007	.OIL SEAL (22X35X5)	2	
23	09262-35070	.BEARING (35X62X14)	1	
24	09280-75001	O RING (D:3.3,ID:75)	1	
25	09116-08122	BOLT (8X30)	2	
26-1	56130-87J12-YAY	HOUSING, DRIVE SFT BRG (BLACK)	1	020
26-2	56130-87J12-Y5S	HOUSING, DRIVE SFT BRG (WHITE)	1	020
26-3	56130-87J12-QTN	HOUSING, DRIVE SFT BRG (WHITE)	1	021,022,023
26-4	56130-87J12-YAY	HOUSING, DRIVE SFT BRG (BLACK)	1	021,022,023
27	09282-17005	.OIL SEAL (17X32X6)	2	
28	08331-41329	.CIRCLIP	1	
29	55122-88L00	RING, GEAR CASE SEAL	1	
30	09202-06025	PIN (6X17)	1	
31	09202-06027	PIN (6X23)	1	

FIG.220E




FIG.220E (1-F-11) TRANSMISSION (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57110-88L30	SHAFT, DRIVE	1	W/TRANSOM(L)
1-2	57110-88L40	SHAFT, DRIVE	1	W/TRANSOM(X)
2	57133-90J02	COLLAR, DRIVE SHAFT	1	
3	09265-25046	BEARING (25X52X19.25)	1	
4	57300-99824	PINION & GEAR SET	1	
5	09140-14024	NUT	1	
6-1	09181-40186	SHIM (T:0.50)	1	
6-2	09181-41002	SHIM (T:0.55)	1	
6-3	09181-41003	SHIM (T:0.6)	1	
6-4	09181-41004	SHIM (T:0.65)	1	
6-5	09181-41005	SHIM (T:0.7)	1	
6-6	09181-41006	SHIM (T:0.75)	1	
6-7	09181-40190	SHIM (T:0.8)	1	
6-8	09181-41008	SHIM (T:0.85)	1	
6-9	09181-41009	SHIM (T:0.9)	1	
6-10	09181-41010	SHIM (T:0.95)	1	
6-11	09181-40195	SHIM (T:1.00)	1	
6-12	09181-41012	SHIM (T:1.05)	1	
6-13	09181-41013	SHIM (T:1.1)	1	
6-14	09181-41014	SHIM (T:1.15)	1	
7	09265-50003	BEARING (50X85X26)	1	PART OF GEAR CASE
8-1	09181-50020	SHIM (T:0.45)	1	FORWARD GEAR
8-2	09181-50021	SHIM (T:0.50)	1	FORWARD GEAR
8-3	09181-50022	SHIM (T:0.55)	1	FORWARD GEAR
8-4	09181-50023	SHIM (T:0.60)	1	FORWARD GEAR
8-5	09181-50024	SHIM (T:0.65)	1	FORWARD GEAR
8-6	09181-50025	SHIM (T:0.70)	1	FORWARD GEAR
8-7	09181-50026	SHIM (T:0.75)	1	FORWARD GEAR
8-8	09181-50027	SHIM (T:0.80)	1	FORWARD GEAR
8-9	09181-50028	SHIM (T:0.85)	1	FORWARD GEAR
8-10	09181-50029	SHIM (T:0.95)	1	FORWARD GEAR

NOTE : (DF50AVTH,DF60AVT):E01,DF60AVT:E11

FIG.220E




FIG.220E (1-F-12) TRANSMISSION (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
9-1	09181-45003	SHIM (T:1.0)	1	REVERSE GEAR
9-2	09181-45004	SHIM (T:1.1)	1	REVERSE GEAR
9-3	09181-45005	SHIM (T:1.2)	1	REVERSE GEAR
9-4	09181-45006	SHIM (T:1.3)	1	REVERSE GEAR
9-5	09181-45013	SHIM (T:1.35)	1	REVERSE GEAR
9-6	09181-45007	SHIM (T:1.4)	1	REVERSE GEAR
9-7	09181-45014	SHIM (T:1.45)	1	REVERSE GEAR
9-8	09181-45008	SHIM (T:1.5)	1	REVERSE GEAR
9-9	09181-45015	SHIM (T:1.55)	1	REVERSE GEAR
9-10	09181-45009	SHIM (T:1.6)	1	REVERSE GEAR
9-11	09181-45016	SHIM (T:1.65)	1	REVERSE GEAR
9-12	09181-45017	SHIM (T:1.7)	1	REVERSE GEAR
9-13	09181-45018	SHIM (T:1.75)	1	REVERSE GEAR
10-1	09181-28015	SHIM (T:0.90)	1	PROP SHAFT REVERSE THRUST
10-2	09181-28016	SHIM (T:1.00)	1	PROP SHAFT REVERSE THRUST
10-3	09181-28017	SHIM (T:1.20)	1	PROP SHAFT REVERSE THRUST
10-4	09181-28018	SHIM (T:1.30)	1	PROP SHAFT REVERSE THRUST
10-5	09181-28019	SHIM (T:1.40)	1	PROP SHAFT REVERSE THRUST
10-6	09181-28020	SHIM (T:1.60)	1	PROP SHAFT REVERSE THRUST
11	57610-88L10	SHAFT, PROPELLER	1	
12	57621-88L00	SHIFTER, CLUTCH DOG	1	
13	09202-07002	PIN (7X48)	1	
14	57631-99E01	ROD, PUSH	1	
15	09440-11020	SPRING (L:67)	1	
16	09209-12007	PIN (ID:7)	1	
17	09181-25030	SHIM (25X32X3)	1	
18	09440-49004	SPRING	1	
19	56120-90J02-YAY	HOUSING, PROP SHAFT BRG (BLACK)	1	
20	56123-90J00	.WASHER, OIL SEAL PROTECTER	1	
21	09263-28047	.BEARING (28X37X30)	1	
22	09280-97001	.O RING (D:3.5,ID:95)	1	

NOTE : (DF50AVTH,DF60AVT):E01,DF60AVT:E11

FIG.220E




FIG.220E (1-F-13) TRANSMISSION (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
23	09282-28002	.OIL SEAL (28X50X6)	2	
24	08113-62090	.BEARING	1	
25	09387-52001	.RING SET	1	
26	09116-08122	BOLT (8X30)	2	
27	56130-87E00	HOUSING, DRIVE SHAFT OIL SEAL	1	
28	09280-46004	.O RING (D:3.5,ID:45.7)	1	
29	09282-22007	.OIL SEAL (22X36X6)	2	
30	09117-08110	BOLT (8X25)	4	
31	09181-31001	SHIM (31X46X2)	3	
32	09169-31001	WASHER (33X40X2.0)	1	
33	09164-31001	WASHER	1	

NOTE : (DF50AVTH,DF60AVT):E01,DF60AVT:E11

FIG.220F




FIG.220F (1-F-14) TRANSMISSION ((DF50AVT,DF60AVT):E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	57110-88L30	SHAFT, DRIVE	1	
2	57133-90J02	COLLAR, DRIVE SHAFT	1	
3	09265-25046	BEARING (25X52X19.25)	1	
4	57300-99824	PINION & GEAR SET	1	
5	09140-14024	NUT	1	
6-1	09181-40186	SHIM (T:0.50)	1	
6-2	09181-41002	SHIM (T:0.55)	1	
6-3	09181-41003	SHIM (T:0.6)	1	
6-4	09181-41004	SHIM (T:0.65)	1	
6-5	09181-41005	SHIM (T:0.7)	1	
6-6	09181-41006	SHIM (T:0.75)	1	
6-7	09181-40190	SHIM (T:0.8)	1	
6-8	09181-41008	SHIM (T:0.85)	1	
6-9	09181-41009	SHIM (T:0.9)	1	
6-10	09181-41010	SHIM (T:0.95)	1	
6-11	09181-40195	SHIM (T:1.00)	1	
6-12	09181-41012	SHIM (T:1.05)	1	
6-13	09181-41013	SHIM (T:1.1)	1	
6-14	09181-41014	SHIM (T:1.15)	1	
7	09265-50003	BEARING (50X85X26)	1	PART OF GEAR CASE
8-1	09181-50020	SHIM (T:0.45)	1	FORWARD GEAR
8-2	09181-50021	SHIM (T:0.50)	1	FORWARD GEAR
8-3	09181-50022	SHIM (T:0.55)	1	FORWARD GEAR
8-4	09181-50023	SHIM (T:0.60)	1	FORWARD GEAR
8-5	09181-50024	SHIM (T:0.65)	1	FORWARD GEAR
8-6	09181-50025	SHIM (T:0.70)	1	FORWARD GEAR
8-7	09181-50026	SHIM (T:0.75)	1	FORWARD GEAR
8-8	09181-50027	SHIM (T:0.80)	1	FORWARD GEAR
8-9	09181-50028	SHIM (T:0.85)	1	FORWARD GEAR
8-10	09181-50029	SHIM (T:0.95)	1	FORWARD GEAR

FIG.220F




FIG.220F (1-F-15) TRANSMISSION ((DF50AVT,DF60AVT):E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
9-1	09181-45003	SHIM (T:1.0)	1	REVERSE GEAR
9-2	09181-45004	SHIM (T:1.1)	1	REVERSE GEAR
9-3	09181-45005	SHIM (T:1.2)	1	REVERSE GEAR
9-4	09181-45006	SHIM (T:1.3)	1	REVERSE GEAR
9-5	09181-45013	SHIM (T:1.35)	1	REVERSE GEAR
9-6	09181-45007	SHIM (T:1.4)	1	REVERSE GEAR
9-7	09181-45014	SHIM (T:1.45)	1	REVERSE GEAR
9-8	09181-45008	SHIM (T:1.5)	1	REVERSE GEAR
9-9	09181-45015	SHIM (T:1.55)	1	REVERSE GEAR
9-10	09181-45009	SHIM (T:1.6)	1	REVERSE GEAR
9-11	09181-45016	SHIM (T:1.65)	1	REVERSE GEAR
9-12	09181-45017	SHIM (T:1.7)	1	REVERSE GEAR
9-13	09181-45018	SHIM (T:1.75)	1	REVERSE GEAR
10-1	09181-28015	SHIM (T:0.90)	1	PROP SHAFT REVERSE THRUST
10-2	09181-28016	SHIM (T:1.00)	1	PROP SHAFT REVERSE THRUST
10-3	09181-28017	SHIM (T:1.20)	1	PROP SHAFT REVERSE THRUST
10-4	09181-28018	SHIM (T:1.30)	1	PROP SHAFT REVERSE THRUST
10-5	09181-28019	SHIM (T:1.40)	1	PROP SHAFT REVERSE THRUST
10-6	09181-28020	SHIM (T:1.60)	1	PROP SHAFT REVERSE THRUST
11	57610-88L10	SHAFT, PROPELLER	1	
12	57621-88L00	SHIFTER, CLUTCH DOG	1	
13	09202-07002	PIN (7X48)	1	
14	57631-99E01	ROD, PUSH	1	
15	09440-11020	SPRING (L:67)	1	
16	09209-12007	PIN (ID:7)	1	
17	09181-25030	SHIM (25X32X3)	1	
18	09440-49004	SPRING	1	
19	56120-90J02-YAY	HOUSING, PROP SHAFT BRG (BLACK)	1	
20	56123-90J00	.WASHER, OIL SEAL PROTECTER	1	
21	09263-28047	.BEARING (28X37X30)	1	
22	09280-97001	.O RING (D:3.5,ID:95)	1	
23	09282-28002	.OIL SEAL (28X50X6)	2	
24	08113-62090	.BEARING	1	
25	09387-52001	.RING SET	1	
26	09116-08122	BOLT (8X30)	2	

FIG.220F




FIG.220F (1-G-2) TRANSMISSION ((DF50AVT,DF60AVT):E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
27	56130-87E00	HOUSING, DRIVE SHAFT OIL SEAL	1	
28	09280-46004	.O RING (D:3.5,ID:45.7)	1	
29	09282-22007	.OIL SEAL (22X36X6)	2	
30	09117-08110	BOLT (8X25)	4	
31	09181-31001	SHIM (31X46X2)	3	
32	09169-31001	WASHER (33X40X2.0)	1	
33	09164-31001	WASHER	1	

FIG.220G




FIG.220G (1-G-3) TRANSMISSION ((DF60AVT,DF60AVTH):E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57110-88L30	SHAFT, DRIVE	1	W/TRANSOM(L)
1-2	57110-88L40	SHAFT, DRIVE	1	W/TRANSOM(X)
2	57133-90J02	COLLAR, DRIVE SHAFT	1	
3	09265-25046	BEARING (25X52X19.25)	1	
4	57300-99824	PINION & GEAR SET	1	
5	09140-14024	NUT	1	
6-1	09181-40186	SHIM (T:0.50)	1	
6-2	09181-41002	SHIM (T:0.55)	1	
6-3	09181-41003	SHIM (T:0.6)	1	
6-4	09181-41004	SHIM (T:0.65)	1	
6-5	09181-41005	SHIM (T:0.7)	1	
6-6	09181-41006	SHIM (T:0.75)	1	
6-7	09181-40190	SHIM (T:0.8)	1	
6-8	09181-41008	SHIM (T:0.85)	1	
6-9	09181-41009	SHIM (T:0.9)	1	
6-10	09181-41010	SHIM (T:0.95)	1	
6-11	09181-40195	SHIM (T:1.00)	1	
6-12	09181-41012	SHIM (T:1.05)	1	
6-13	09181-41013	SHIM (T:1.1)	1	
6-14	09181-41014	SHIM (T:1.15)	1	
7	09265-50003	BEARING (50X85X26)	1	PART OF GEAR CASE
8-1	09181-50020	SHIM (T:0.45)	1	FORWARD GEAR
8-2	09181-50021	SHIM (T:0.50)	1	FORWARD GEAR
8-3	09181-50022	SHIM (T:0.55)	1	FORWARD GEAR
8-4	09181-50023	SHIM (T:0.60)	1	FORWARD GEAR
8-5	09181-50024	SHIM (T:0.65)	1	FORWARD GEAR
8-6	09181-50025	SHIM (T:0.70)	1	FORWARD GEAR
8-7	09181-50026	SHIM (T:0.75)	1	FORWARD GEAR
8-8	09181-50027	SHIM (T:0.80)	1	FORWARD GEAR
8-9	09181-50028	SHIM (T:0.85)	1	FORWARD GEAR
8-10	09181-50029	SHIM (T:0.95)	1	FORWARD GEAR

FIG.220G




FIG.220G (1-G-4) TRANSMISSION ((DF60AVT,DF60AVTH):E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
9-1	09181-45003	SHIM (T:1.0)	1	REVERSE GEAR
9-2	09181-45004	SHIM (T:1.1)	1	REVERSE GEAR
9-3	09181-45005	SHIM (T:1.2)	1	REVERSE GEAR
9-4	09181-45006	SHIM (T:1.3)	1	REVERSE GEAR
9-5	09181-45013	SHIM (T:1.35)	1	REVERSE GEAR
9-6	09181-45007	SHIM (T:1.4)	1	REVERSE GEAR
9-7	09181-45014	SHIM (T:1.45)	1	REVERSE GEAR
9-8	09181-45008	SHIM (T:1.5)	1	REVERSE GEAR
9-9	09181-45015	SHIM (T:1.55)	1	REVERSE GEAR
9-10	09181-45009	SHIM (T:1.6)	1	REVERSE GEAR
9-11	09181-45016	SHIM (T:1.65)	1	REVERSE GEAR
9-12	09181-45017	SHIM (T:1.7)	1	REVERSE GEAR
9-13	09181-45018	SHIM (T:1.75)	1	REVERSE GEAR
10-1	09181-28015	SHIM (T:0.90)	1	PROP SHAFT REVERSE THRUST
10-2	09181-28016	SHIM (T:1.00)	1	PROP SHAFT REVERSE THRUST
10-3	09181-28017	SHIM (T:1.20)	1	PROP SHAFT REVERSE THRUST
10-4	09181-28018	SHIM (T:1.30)	1	PROP SHAFT REVERSE THRUST
10-5	09181-28019	SHIM (T:1.40)	1	PROP SHAFT REVERSE THRUST
10-6	09181-28020	SHIM (T:1.60)	1	PROP SHAFT REVERSE THRUST
11	57610-88L10	SHAFT, PROPELLER	1	
12	57621-88L00	SHIFTER, CLUTCH DOG	1	
13	09202-07002	PIN (7X48)	1	
14	57631-99E01	ROD, PUSH	1	
15	09440-11020	SPRING (L:67)	1	
16	09209-12007	PIN (ID:7)	1	
17	09181-25030	SHIM (25X32X3)	1	
18	09440-49004	SPRING	1	
19	56120-90J02-YAY	HOUSING, PROP SHAFT BRG (BLACK)	1	
20	56123-90J00	.WASHER, OIL SEAL PROTECTER	1	
21	09263-28047	.BEARING (28X37X30)	1	
22	09280-97001	.O RING (D:3.5,ID:95)	1	
23	09282-28002	.OIL SEAL (28X50X6)	2	
24	08113-62090	.BEARING	1	
25	09387-52001	.RING SET	1	
26	09116-08122	BOLT (8X30)	2	

DF60A_E11_023_220G
TRANSMISSION

FIG.220G




FIG.220G (1-G-5) TRANSMISSION ((DF60AVT,DF60AVTH):E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
27	56130-87E00	HOUSING, DRIVE SHAFT OIL SEAL	1	
28	09280-46004	.O RING (D:3.5,ID:45.7)	1	
29	09282-22007	.OIL SEAL (22X36X6)	2	
30	09117-08110	BOLT (8X25)	4	
31	09181-31001	SHIM (31X46X2)	3	
32	09169-31001	WASHER (33X40X2.0)	1	
33	09164-31001	WASHER	1	

FIG.220H




FIG.220H (1-G-6) TRANSMISSION (DF40ASVT:E34)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	57110-88L30	SHAFT, DRIVE	1	
2	57133-90J02	COLLAR, DRIVE SHAFT	1	
3	09265-25046	BEARING (25X52X19.25)	1	
4	57300-99824	PINION & GEAR SET	1	
5	09140-14024	NUT	1	
6-1	09181-40186	SHIM (T:0.50)	1	
6-2	09181-41002	SHIM (T:0.55)	1	
6-3	09181-41003	SHIM (T:0.6)	1	
6-4	09181-41004	SHIM (T:0.65)	1	
6-5	09181-41005	SHIM (T:0.7)	1	
6-6	09181-41006	SHIM (T:0.75)	1	
6-7	09181-40190	SHIM (T:0.8)	1	
6-8	09181-41008	SHIM (T:0.85)	1	
6-9	09181-41009	SHIM (T:0.9)	1	
6-10	09181-41010	SHIM (T:0.95)	1	
6-11	09181-40195	SHIM (T:1.00)	1	
6-12	09181-41012	SHIM (T:1.05)	1	
6-13	09181-41013	SHIM (T:1.1)	1	
6-14	09181-41014	SHIM (T:1.15)	1	
7	09265-50003	BEARING (50X85X26)	1	PART OF GEAR CASE
8-1	09181-50020	SHIM (T:0.45)	1	FORWARD GEAR
8-2	09181-50021	SHIM (T:0.50)	1	FORWARD GEAR
8-3	09181-50022	SHIM (T:0.55)	1	FORWARD GEAR
8-4	09181-50023	SHIM (T:0.60)	1	FORWARD GEAR
8-5	09181-50024	SHIM (T:0.65)	1	FORWARD GEAR
8-6	09181-50025	SHIM (T:0.70)	1	FORWARD GEAR
8-7	09181-50026	SHIM (T:0.75)	1	FORWARD GEAR
8-8	09181-50027	SHIM (T:0.80)	1	FORWARD GEAR
8-9	09181-50028	SHIM (T:0.85)	1	FORWARD GEAR
8-10	09181-50029	SHIM (T:0.95)	1	FORWARD GEAR

FIG.220H




FIG.220H (1-G-7) TRANSMISSION (DF40ASVT:E34)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
9-1	09181-45003	SHIM (T:1.0)	1	REVERSE GEAR
9-2	09181-45004	SHIM (T:1.1)	1	REVERSE GEAR
9-3	09181-45005	SHIM (T:1.2)	1	REVERSE GEAR
9-4	09181-45006	SHIM (T:1.3)	1	REVERSE GEAR
9-5	09181-45013	SHIM (T:1.35)	1	REVERSE GEAR
9-6	09181-45007	SHIM (T:1.4)	1	REVERSE GEAR
9-7	09181-45014	SHIM (T:1.45)	1	REVERSE GEAR
9-8	09181-45008	SHIM (T:1.5)	1	REVERSE GEAR
9-9	09181-45015	SHIM (T:1.55)	1	REVERSE GEAR
9-10	09181-45009	SHIM (T:1.6)	1	REVERSE GEAR
9-11	09181-45016	SHIM (T:1.65)	1	REVERSE GEAR
9-12	09181-45017	SHIM (T:1.7)	1	REVERSE GEAR
9-13	09181-45018	SHIM (T:1.75)	1	REVERSE GEAR
10-1	09181-28015	SHIM (T:0.90)	1	PROP SHAFT REVERSE THRUST
10-2	09181-28016	SHIM (T:1.00)	1	PROP SHAFT REVERSE THRUST
10-3	09181-28017	SHIM (T:1.20)	1	PROP SHAFT REVERSE THRUST
10-4	09181-28018	SHIM (T:1.30)	1	PROP SHAFT REVERSE THRUST
10-5	09181-28019	SHIM (T:1.40)	1	PROP SHAFT REVERSE THRUST
10-6	09181-28020	SHIM (T:1.60)	1	PROP SHAFT REVERSE THRUST
11	57610-88L10	SHAFT, PROPELLER	1	
12	57621-88L00	SHIFTER, CLUTCH DOG	1	
13	09202-07002	PIN (7X48)	1	
14	57631-99E01	ROD, PUSH	1	
15	09440-11020	SPRING (L:67)	1	
16	09209-12007	PIN (ID:7)	1	
17	09181-25030	SHIM (25X32X3)	1	
18	09440-49004	SPRING	1	
19-1	56120-90J02-YAY	HOUSING, PROP SHAFT BRG (BLACK)	1	020
19-2	56120-90J02-Y5S	HOUSING, PROP SHAFT BRG (WHITE)	1	020
19-3	56120-90J02-QTN	HOUSING, PROP SHAFT BRG (WHITE)	1	021,022,023
19-4	56120-90J02-YAY	HOUSING, PROP SHAFT BRG (BLACK)	1	021,022,023
20	56123-90J00	.WASHER, OIL SEAL PROTECTER	1	

FIG.220H




FIG.220H (1-G-8) TRANSMISSION (DF40ASVT:E34)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
21	09263-28047	.BEARING (28X37X30)	1	
22	09280-97001	.O RING (D:3.5,ID:95)	1	
23	09282-28002	.OIL SEAL (28X50X6)	2	
24	08113-62090	.BEARING	1	
25	09387-52001	.RING SET	1	
26	09116-08122	BOLT (8X30)	2	
27	56130-87E00	HOUSING, DRIVE SHAFT OIL SEAL	1	
28	09280-46004	.O RING (D:3.5,ID:45.7)	1	
29	09282-22007	.OIL SEAL (22X36X6)	2	
30	09117-08110	BOLT (8X25)	4	
31	09181-31001	SHIM (31X46X2)	3	
32	09169-31001	WASHER (33X40X2.0)	1	
33	09164-31001	WASHER	1	

FIG.301A




FIG.301A (1-G-9) STARTING MOTOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31100-89L00	MOTOR ASSY, STARTING	1	
2	31150-98L00	.CASE, GEAR	1	
3	31170-89L00	.HOUSING, REAR	1	
4	31173-98L00	.HOLDER ASSY, BRUSH	1	
5	31191-63J00	.LEVER SET	1	
6	31220-89L00	.SWITCH ASSY	1	
7	31311-63J00	.ARMATURE	1	
8	31192-92J00	.SCREW SET	1	
9	31261-75F10	.BOLT	2	
10	31340-89L00	.CLUTCH SET, STARTING MOTOR	1	
11	31314-86030	..STOPPER SET	1	
12	31320-89L00	..PINION	1	
13	31341-89L00	..SHAFT, PINION	1	
14	31343-63J00	..INTERNAL GEAR ASSY	1	
15	31344-63J00	..GEAR ASSY	3	
16	31912-88L00	BAND, STARTER MOTOR	1	
17	31918-92J01	DAMPER, LOWER	1	LOWER
18	01550-06167	BOLT (6X16)	2	
19	01550-0830C	BOLT	2	

DF60A_E11_023_301A
STARTING MOTOR

FIG.303A




FIG.303A (1-G-10) MAGNETO

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32102-88L01	FLYWHEEL, MAGNETO	1	
2	09103-14024	BOLT (14X50)	1	
3	09160-14065	WASHER (14.5X36X4.5)	1	
4	09420-04008	KEY (B:4,D:16,H6.5)	1	
5	32120-88L00	COIL, BATTERY CHARGING	1	
6	32160-88L01	COIL, IGN TIMING	1	
7	09106-05030	BOLT (5X10)	2	
8	33220-64L10	SENSOR ASSY, POSN	1	
9	01550-0616C	BOLT	1	
10	09403-13414	CLAMP	1	
11	01550-06127	BOLT	1	
12	02112-06307	SCREW	3	

FIG.310A




FIG.310A (1-G-11) RECTIFIER/IGNITION COIL

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-88L01	RECTIFIER & REGULATOR ASSY	1	
2	01550-0625C	BOLT	2	
3	32890-88L01	HOLDER, ELECTRIC PARTS	1	
4	09116-06202	BOLT (6X25)	3	
5	09169-06062	WASHER (6.3X17X1.6)	3	
6	09320-09016	CUSHION	3	
7	33410-87L00	COIL ASSY, IGNITION	3	
8	01550-0620C	BOLT	3	

FIG.315A





FIG.315A (1-G-12) SENSOR (DF40A,DF40ATH,DF50A,DF50ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34830-87J20	SENSOR, TEMP	1	
2	34840-98J03	SENSOR ASSY, TRIM & TILT	1	
3	09125-05048	SCREW (5X16)	1	
4	09160-05029	WASHER (5.5X12X0.8)	1	
5	09103-06093	BOLT (6X20)	2	
6	37820-99E02	SWITCH ASSY, OIL PRESSURE	1	
7	09403-07340	CLAMP	1	
8	36656-88L00	GROMMET, PTT CABLE	1	
9	09407-14407	CLAMP (L:145)	3	
10	34841-88L01	LEVER, TRIM SENSOR	1	
11	34845-88L02	BRACKET, TRIM SENSOR	1	
12	29404-93J11	CLAMP (L:65)	1	

FIG.315B

FIG.315B (1-G-13) SENSOR (DF40AQH,DF60AQH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34830-87J20	SENSOR, TEMP	1	
2	37820-99E02	SWITCH ASSY, OIL PRESSURE	1	
3	36656-88L10	GROMMET, PTT CABLE	1	



DF60A_E11_023_315B
SENSOR

FIG.315C




FIG.315C (1-G-14) SENSOR (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34830-87J20	SENSOR, TEMP	1	
2	34840-98J11	SENSOR ASSY, TRIM	1	
3	09125-05046	SCREW (5X12)	1	
4	34846-87L00	WASHER, TRIM SENSOR (5.5X12X0.8)	1	
5	34841-87L10	LEVER, TRIM SENSOR	1	
6	34842-88L10	CAM, TRIM SENSOR UPPER	1	UPPER
7	34843-87L00	CAM, TRIM SENSOR LOWER	1	LOWER
8	34845-88L10	BRACKET, TRIM SENSOR	1	
9	09103-06093	BOLT (6X20)	1	
10	37820-99E02	SWITCH ASSY, OIL PRESSURE	1	
11	36617-88L00	BRACKET, PTT CABLE CLAMP	1	
12	29103-93J00	BOLT (6X12)	1	
13	09403-07340	CLAMP	1	
14	09403-11321	CLAMP	1	
15	36656-88L00	GROMMET, PTT CABLE	1	
16	09407-14407	CLAMP (L:145)	2	
17	09403-13413	CLAMP	1	
18	29103-93J00	BOLT (6X12)	1	

NOTE : DF40AST,DF60A,DF60ATH,DF50AVT,DF50AVTH,DF60AVT,DF40ASVT, DF60AVTH

DF60A_E11_023_315C
SENSOR

FIG.322A




FIG.322A (1-H-2) HARNESS (DF40A,DF40ATH,DF50A,DF50ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-88L10	CABLE ASSY, STARTER MOTOR	1	
2	08316-10087	NUT	1	
3-1	36610-88LM1	HARNESS ASSY, WIRING	1	020,021,022
3-2	36630-88L10	HARNESS ASSY, WIRING	1	023
4	33634-96J00	.CAP, SERVICE CONNECTOR	1	
5	36668-87L00	.HOLDER, CONDENSER	1	
6	09320-08510	.CUSHION (8.5X20X8)	2	
7	36737-98L00	.PULLER, FUSE	1	
8	36721-98L00	.O RING, UPR COVER	1	UPPER
9	36738-98L00	.COVER, FUSE CASE UPPER	1	UPPER
10	38860-76F01	.RELAY ASSY	1	ENG CONTROL UNIT
11	38860-76F01	.RELAY ASSY	1	STARTER MOTOR
12	09481-15504	.FUSE (15A)	3	
13	09481-30504	.FUSE (30A)	3	
14	09481-30403	.FUSE (30A)	2	
15	36612-96J01	.CAP, TERMINAL	1	
16	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
17	08310-00067	NUT	1	
18	08321-01067	LOCK WASHER	1	
19	09407-14403	CLAMP (L:125)	2	
20	09407-14407	CLAMP (L:145)	1	
21	36617-88L00	BRACKET, PTT CABLE CLAMP	2	
22	36617-93J10	BRACKET, HARNESS	2	
23	01550-0612C	BOLT	5	
24	09407-18402	CLAMP (L:165)	1	
25	36617-88L20	BRACKET, HARNESS	1	

DF60A_E11_023_322A
HARNESS

FIG.322B




FIG.322B (1-H-3) HARNESS (DF40AQH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-88L10	CABLE ASSY, STARTER MOTOR	1	
2	08316-10087	NUT	1	
3-1	36610-88LL1	HARNESS ASSY, WIRING	1	020,021,022,023
3-2	36630-88L00	HARNESS ASSY, WIRING	1	023
4	33634-96J00	.CAP, SERVICE CONNECTOR	1	
5	36668-87L00	.HOLDER, CONDENSER	1	
6	09320-08510	.CUSHION (8.5X20X8)	2	
7	36737-98L00	.PULLER, FUSE	1	
8	36721-98L00	.O RING, UPR COVER	1	UPPER
9	36738-98L00	.COVER, FUSE CASE UPPER	1	UPPER
10	38860-76F01	.RELAY ASSY	1	ENG CONTROL UNIT
11	38860-76F01	.RELAY ASSY	1	STARTER MOTOR
12	09481-15504	.FUSE (15A)	2	
13	09481-30504	.FUSE (30A)	3	
14	09481-30403	.FUSE (30A)	2	
15	36612-96J01	.CAP, TERMINAL	1	
16	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
17	08310-00067	NUT	1	
18	08321-01067	LOCK WASHER	1	
19	09407-14403	CLAMP (L:125)	2	
20	09407-14407	CLAMP (L:145)	1	
21	36617-88L00	BRACKET, PTT CABLE CLAMP	2	
22	36617-93J10	BRACKET, HARNESS	2	
23	01550-0612C	BOLT	5	
24	09407-18402	CLAMP (L:165)	1	
25	36617-88L20	BRACKET, HARNESS	1	

DF60A_E11_023_322B
HARNESS

FIG.322C




FIG.322C (1-H-4) HARNESS (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-88L10	CABLE ASSY, STARTER MOTOR	1	
2	08316-10087	NUT	1	
3-1	36610-88LN1	HARNESS ASSY, WIRING	1	(DF40AST,DF40ASVT):(020,021)
3-2	36610-88LQ1	HARNESS ASSY, WIRING	1	(DF40AST,DF40ASVT):022
3-3	36630-88L40	HARNESS ASSY, WIRING	1	(DF40AST,DF40ASVT):023
3-4	36610-88LN1	HARNESS ASSY, WIRING	1	(DF50AVT,DF50AVTH):(020,021,022)
3-5	36630-88L20	HARNESS ASSY, WIRING	1	DF50AVT:023
3-6	36610-88LQ1	HARNESS ASSY, WIRING	1	(DF60A,DF60ATH,DF60AVT,DF60AVTH):(020,021,022)
3-7	36630-88L40	HARNESS ASSY, WIRING	1	(DF60A,DF60ATH,DF60AVT,DF60AVTH):023
4	33634-96J00	.CAP, SERVICE CONNECTOR	1	
5	36668-87L00	.HOLDER, CONDENSER	1	
6	09320-08510	.CUSHION (8.5X20X8)	2	
7	36737-98L00	.PULLER, FUSE	1	
8	36721-98L00	.O RING, UPR COVER	1	UPPER
9	36738-98L00	.COVER, FUSE CASE UPPER	1	UPPER
10	38860-76F01	.RELAY ASSY	1	ENG CONTROL UNIT
11	38860-76F01	.RELAY ASSY	1	STARTER MOTOR
12	09481-15504	.FUSE (15A)	3	
13	09481-30504	.FUSE (30A)	3	
14	09481-30403	.FUSE (30A)	2	
15	36612-96J01	.CAP, TERMINAL	1	
16	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
17	36611-88L00	.HARNESS ASSY, WIRING SUB	1	
18	08310-00067	NUT	1	
19	08321-01067	LOCK WASHER	1	
20	09407-14403	CLAMP (L:125)	2	
21	09407-14407	CLAMP (L:145)	1	
22	36617-88L00	BRACKET, PTT CABLE CLAMP	2	

NOTE : DF40AST,DF40ASVT,DF50AVT,DF50AVTH,DF60A,DF60ATH,DF60AVT,
DF60AVTH

DF60A_E11_023_322C
HARNESS

FIG.322C




FIG.322C (1-H-5) HARNESS (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
23	36617-93J10	BRACKET, HARNESS	2	
24	01550-0612C	BOLT	5	
25	09407-18402	CLAMP (L:165)	1	
26	36617-88L20	BRACKET, HARNESS	1	

NOTE : DF40AST,DF40ASVT,DF50AVT,DF50AVTH,DF60A,DF60ATH,DF60AVT,
DF60AVTH

DF60A_E11_023_322C
HARNESS

FIG.322D




FIG.322D (1-H-6) HARNESS (DF60AQH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-88L10	CABLE ASSY, STARTER MOTOR	1	
2	08316-10087	NUT	1	
3-1	36610-88LP1	HARNESS ASSY, WIRING	1	020,021,022
3-2	36630-88L30	HARNESS ASSY, WIRING	1	023
4	33634-96J00	.CAP, SERVICE CONNECTOR	1	
5	36668-87L00	.HOLDER, CONDENSER	1	
6	09320-08510	.CUSHION (8.5X20X8)	2	
7	36737-98L00	.PULLER, FUSE	1	
8	36721-98L00	.O RING, UPR COVER	1	UPPER
9	36738-98L00	.COVER, FUSE CASE UPPER	1	UPPER
10	38860-76F01	.RELAY ASSY	1	ENG CONTROL UNIT
11	38860-76F01	.RELAY ASSY	1	STARTER MOTOR
12	09481-15504	.FUSE (15A)	2	
13	09481-30504	.FUSE (30A)	3	
14	09481-30403	.FUSE (30A)	2	
15	36612-96J01	.CAP, TERMINAL	1	
16	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
17	08310-00067	NUT	1	
18	08321-01067	LOCK WASHER	1	
19	09407-14403	CLAMP (L:125)	2	
20	09407-14407	CLAMP (L:145)	1	
21	36617-88L00	BRACKET, PTT CABLE CLAMP	2	
22	36617-93J10	BRACKET, HARNESS	2	
23	01550-0612C	BOLT	5	
24	09407-18402	CLAMP (L:165)	1	
25	36617-88L20	BRACKET, HARNESS	1	

DF60A_E11_023_322D
HARNESS

FIG.326A




FIG.326A (1-H-7) PTT SWITCH/ENGINE CONTROL UNIT (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37721-93J00	SWITCH ASSY, NEUTRAL	1	
2	09137-04004	SCREW (4X16)	2	
3	37725-88L00	BRACKET, NEUTRAL SWITCH	1	
4	09407-10404	CLAMP (L:100)	1	
5	09408-00184	CLAMP	1	
6	38410-93J12	RELAY ASSY, PTT	1	
7	38415-93J00	HOLDER, PTT RELAY	1	
8	01550-06127	BOLT	1	
9-1	33940-88LJ0	UNIT, ENGINE CONTROL	1	DF40A:(020,021):(E01,E03,E11)
9-2	33950-88L60	UNIT, ENGINE CONTROL	1	DF40A:022:E11
9-3	33940-88LJ0	UNIT, ENGINE CONTROL	1	DF40ATH:(020,021):E01
9-4	33950-88L60	UNIT, ENGINE CONTROL	1	DF40ATH:022:E01
9-5	33940-88LK0	UNIT, ENGINE CONTROL	1	DF40AST:(020,021):E34
9-6	33950-88L20	UNIT, ENGINE CONTROL	1	DF40AST:022:E34
9-7	33940-88LL0	UNIT, ENGINE CONTROL	1	DF50A:(020,021,022):(E01,E03,E11)
9-8	33940-88LL0	UNIT, ENGINE CONTROL	1	DF50ATH:(020,021,022):E01
9-9	33940-88LG0	UNIT, ENGINE CONTROL	1	DF60A:(020,021):(E01,E03,E11)
9-10	33950-88L00	UNIT, ENGINE CONTROL	1	DF60A:022:E11
9-11	33940-88LH0	UNIT, ENGINE CONTROL	1	DF60A:(020,021):E40
9-12	33950-88L10	UNIT, ENGINE CONTROL	1	DF60A:022:E40
9-13	33940-88LG0	UNIT, ENGINE CONTROL	1	DF60ATH:(020,021):E01
9-14	33950-88L00	UNIT, ENGINE CONTROL	1	DF60ATH:022:E01
9-15	33940-88LH0	UNIT, ENGINE CONTROL	1	DF60ATH:(020,021):E40
9-16	33950-88L10	UNIT, ENGINE CONTROL	1	DF60ATH:022:E40
9-17	33940-88LP0	UNIT, ENGINE CONTROL	1	DF50AVT:(020,021,022):E03
9-18	33940-88LM0	UNIT, ENGINE CONTROL	1	DF60AVT:(020,021):(E01,E03,E11)
9-19	33950-88L30	UNIT, ENGINE CONTROL	1	DF60AVT:022:E11
9-20	33940-88LN0	UNIT, ENGINE CONTROL	1	DF60AVT:(020,021):E40
9-21	33940-88LQ0	UNIT, ENGINE CONTROL	1	DF40ASVT:(020,021)

NOTE : (DF40A,DF40ATH,DF40AST,DF50A,DF50ATH,DF60A,DF60ATH,DF50AVT, DF60AVT,DF40ASVT,DF50AVTH,DF60AVTH):(020,021,022)

DF60A_E11_023_326A
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326A




FIG.326A (1-H-8) PTT SWITCH/ENGINE CONTROL UNIT (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
9-22	33950-88L50	UNIT, ENGINE CONTROL	1	DF40ASVT:022
9-23	33940-88LP0	UNIT, ENGINE CONTROL	1	DF50AVTH:(020,021,022):E01
9-24	33940-88LN0	UNIT, ENGINE CONTROL	1	DF60AVTH:(020,021):E40
9-25	33950-88L40	UNIT, ENGINE CONTROL	1	DF60AVTH:022:E40
10	33925-88L10	CUSHION, ENGINE CONTROL UNIT	1	
11	37850-92J00	SWITCH ASSY, PTT	1	
12	37856-92J00	.TAPE, PTT SWITCH	1	
13	37857-92J01	BUSH, PTT SWITCH	1	
14	09407-14407	CLAMP (L:145)	1	

NOTE : (DF40A,DF40ATH,DF40AST,DF50A,DF50ATH,DF60A,DF60ATH,DF50AVT, DF60AVT,DF40ASVT,DF50AVTH,DF60AVTH):(020,021,022)

DF60A_E11_023_326A
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326B




FIG.326B (1-H-9) PTT SWITCH/ENGINE CONTROL UNIT (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37721-93J00	SWITCH ASSY, NEUTRAL	1	
2	09137-04004	SCREW (4X16)	2	
3	37725-88L00	BRACKET, NEUTRAL SWITCH	1	
4	09407-10404	CLAMP (L:100)	1	
5	09408-00184	CLAMP	1	
6	38410-93J12	RELAY ASSY, PTT	1	
7	38415-93J00	HOLDER, PTT RELAY	1	
8	01550-06127	BOLT	1	
9-1	33950-88L90	UNIT, ENGINE CONTROL	1	DF40A:023:E11
9-2	33950-88L90	UNIT, ENGINE CONTROL	1	DF40ATH:023:E01
9-3	33950-88LA0	UNIT, ENGINE CONTROL	1	DF40AST:023:E34
9-4	33950-88LB0	UNIT, ENGINE CONTROL	1	DF50A:023:E11
9-5	33950-88LB0	UNIT, ENGINE CONTROL	1	DF50ATH:023:E01
9-6	33950-88L70	UNIT, ENGINE CONTROL	1	DF60A:023:E11
9-7	33950-88L80	UNIT, ENGINE CONTROL	1	DF60A:023:E40
9-8	33950-88L70	UNIT, ENGINE CONTROL	1	DF60ATH:023:E01
9-9	33950-88L80	UNIT, ENGINE CONTROL	1	DF60ATH:023:E40
9-10	33950-88LE0	UNIT, ENGINE CONTROL	1	DF50AVT:023:E03
9-11	33950-88LC0	UNIT, ENGINE CONTROL	1	DF60AVT:023:E11
9-12	33950-88LF0	UNIT, ENGINE CONTROL	1	DF40ASVT:023:E34
9-13	33950-88LD0	UNIT, ENGINE CONTROL	1	DF60AVTH:023:E40
10	33925-88L10	CUSHION, ENGINE CONTROL UNIT	1	
11	37850-92J00	SWITCH ASSY, PTT	1	
12	37856-92J00	.TAPE, PTT SWITCH	1	
13	37857-92J01	BUSH, PTT SWITCH	1	
14	09407-14407	CLAMP (L:145)	1	

NOTE : (DF40A,DF40ATH,DF40AST,DF50A,DF50ATH,DF60A,DF60ATH,DF50AVT, DF60AVT,DF40ASVT,DF60AVTH):023

DF60A_E11_023_326B
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326C




FIG.326C (1-H-10) PTT SWITCH/ENGINE CONTROL UNIT (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37721-93J00	SWITCH ASSY, NEUTRAL	1	
2	09137-04004	SCREW (4X16)	2	
3	37725-88L00	BRACKET, NEUTRAL SWITCH	1	
4	09407-10404	CLAMP (L:100)	1	
5	09408-00184	CLAMP	1	
6-1	33940-88LJ0	UNIT, ENGINE CONTROL	1	DF40AQH:(020,021):E01
6-2	33950-88L60	UNIT, ENGINE CONTROL	1	DF40AQH:022:E01
6-3	33940-88LH0	UNIT, ENGINE CONTROL	1	DF60AQH:(020,021):E40
6-4	33950-88L10	UNIT, ENGINE CONTROL	1	DF60AQH:022:E40
7	33925-88L10	CUSHION, ENGINE CONTROL UNIT	1	
8	09250-40002	CAP (OD:52)	1	

NOTE : (DF40AQH,DF60AQH):(020,021,022)

FIG.326D




FIG.326D (1-H-11) PTT SWITCH/ENGINE CONTROL UNIT (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37721-93J00	SWITCH ASSY, NEUTRAL	1	
2	09137-04004	SCREW (4X16)	2	
3	37725-88L00	BRACKET, NEUTRAL SWITCH	1	
4	09407-10404	CLAMP (L:100)	1	
5	09408-00184	CLAMP	1	
6-1	33950-88L90	UNIT, ENGINE CONTROL	1	DF40AQH:023:E01
6-2	33950-88L80	UNIT, ENGINE CONTROL	1	DF60AQH:023:E40
7	33925-88L10	CUSHION, ENGINE CONTROL UNIT	1	
8	09250-40002	CAP (OD:52)	1	

NOTE : (DF40AQH,DF60AQH):023

FIG.335A




FIG.335A (1-H-12) CLAMP BRACKET (DF40A,DF50A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	41111-88L20-YAY	BRACKET, CLAMP STBD (BLACK)	1	020 STBD
1-2	41111-88L20-Y5S	BRACKET, CLAMP STBD (WHITE)	1	020 STBD
1-3	41111-88L20-QTN	BRACKET, CLAMP STBD (WHITE)	1	021,022,023 STBD
1-4	41111-88L20-YAY	BRACKET, CLAMP STBD (BLACK)	1	021,022,023 STBD
2-1	41121-88L10-YAY	BRACKET, CLAMP PORT (BLACK)	1	020 PORT
2-2	41121-88L10-Y5S	BRACKET, CLAMP PORT (WHITE)	1	020 PORT
2-3	41121-88L10-QTN	BRACKET, CLAMP PORT (WHITE)	1	021,022,023 PORT
2-4	41121-88L10-YAY	BRACKET, CLAMP PORT (BLACK)	1	021,022,023 PORT
3	41130-87J11	SHAFT, CLAMP BRACKET	1	
4	45421-89J00	PIN, TILT LOCK	2	
5	09160-12066	WASHER (12.5X22X2.5)	2	
6	55321-87J01	ANODE, PROTECTION	2	
7	09103-06281	BOLT (6X14)	2	
8-1	09100-12093	BOLT (12X100)	4	
8-2	09100-12091	BOLT (12X115)	1	OPT
9	09159-12014	NUT (12X17)	4	
10	09159-22006	NUT (M22)	1	
11	09160-12128	WASHER (12.5X35X3)	4	
12	09160-12126	WASHER (12.5X22X3)	4	
13	09159-10050	NUT (10X14)	2	
14	09160-10082	WASHER (10.5X19X2.0)	2	
15	41135-93J00	WASHER, CLAMP BRACKET SHAFT	1	

FIG.335B




FIG.335B (1-H-13) CLAMP BRACKET (DF40AQH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89J21-YAY	BRACKET, CLAMP STBD (BLACK)	1	STBD
2	41121-89J15-YAY	BRACKET, CLAMP PORT (BLACK)	1	PORT
3	41130-87J11	SHAFT, CLAMP BRACKET	1	
4	45421-89J00	PIN, TILT LOCK	2	
5	09160-12066	WASHER (12.5X22X2.5)	2	
6	55321-87J01	ANODE, PROTECTION	2	
7	09103-06281	BOLT (6X14)	2	
8-1	09100-12093	BOLT (12X100)	4	
8-2	09100-12091	BOLT (12X115)	1	OPT
9	09159-12014	NUT (12X17)	4	
10	09159-22006	NUT (M22)	1	
11	09160-12128	WASHER (12.5X35X3)	4	
12	09160-12126	WASHER (12.5X22X3)	4	
13	09159-10050	NUT (10X14)	2	
14	09160-10082	WASHER (10.5X19X2.0)	2	
15	41135-93J00	WASHER, CLAMP BRACKET SHAFT	1	
16	43241-87J00	MARK, RELEASE LEVER	1	

DF60A_E11_023_335B
CLAMP BRACKET

FIG.335C




FIG.335C (1-H-14) CLAMP BRACKET (DF40ATH,DF50ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-88L20-YAY	BRACKET, CLAMP STBD (BLACK)	1	STBD
2	41121-88L10-YAY	BRACKET, CLAMP PORT (BLACK)	1	PORT
3	41130-87J11	SHAFT, CLAMP BRACKET	1	
4	45421-89J00	PIN, TILT LOCK	2	
5	09160-12066	WASHER (12.5X22X2.5)	2	
6	55321-87J01	ANODE, PROTECTION	2	
7	09103-06281	BOLT (6X14)	2	
8-1	09100-12093	BOLT (12X100)	4	
8-2	09100-12091	BOLT (12X115)	1	OPT
9	09159-12014	NUT (12X17)	4	
10	09159-22006	NUT (M22)	1	
11	09160-12128	WASHER (12.5X35X3)	4	
12	09160-12126	WASHER (12.5X22X3)	4	
13	09159-10050	NUT (10X14)	2	
14	09160-10082	WASHER (10.5X19X2.0)	2	
15	41135-93J00	WASHER, CLAMP BRACKET SHAFT	1	

DF60A_E11_023_335C
CLAMP BRACKET

FIG.335D




FIG.335D (1-I-2) CLAMP BRACKET (DF40AST,DF60A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	41111-88L11-YAY	BRACKET, CLAMP STBD (BLACK)	1	020 STBD
1-2	41111-88L11-Y5S	BRACKET, CLAMP STBD (WHITE)	1	020 STBD
1-3	41111-88L11-QTN	BRACKET, CLAMP STBD (WHITE)	1	021,022,023 STBD
1-4	41111-88L11-YAY	BRACKET, CLAMP STBD (BLACK)	1	021,022,023 STBD
2-1	41121-88L01-YAY	BRACKET, CLAMP PORT (BLACK)	1	020 PORT
2-2	41121-88L01-Y5S	BRACKET, CLAMP PORT (WHITE)	1	020 PORT
2-3	41121-88L01-QTN	BRACKET, CLAMP PORT (WHITE)	1	021,022,023 PORT
2-4	41121-88L01-YAY	BRACKET, CLAMP PORT (BLACK)	1	021,022,023 PORT
3	41130-88L10	SHAFT, CLAMP BRACKET	1	
4	41135-93J00	WASHER, CLAMP BRACKET SHAFT	1	
5	09116-08137	BOLT (8X22)	1	
6	09159-22006	NUT (M22)	1	
7-1	09100-12093	BOLT (12X100)	4	
7-2	09100-12091	BOLT (12X115)	1	OPT
8	09159-12014	NUT (12X17)	4	
9	09160-12126	WASHER (12.5X22X3)	4	
10	09160-12128	WASHER (12.5X35X3)	4	
11	55320-94900	ANODE SET, CLAMP BRACKET	1	
12	09116-06121	.BOLT (6X25)	2	
13	09106-10065	BOLT (10X20)	2	
14	09160-10082	WASHER (10.5X19X2.0)	2	

FIG.335E




FIG.335E (1-I-3) CLAMP BRACKET (DF60AQH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-88L20-YAY	BRACKET, CLAMP STBD (BLACK)	1	STBD
2	41121-88L10-YAY	BRACKET, CLAMP PORT (BLACK)	1	PORT
3	41130-87J11	SHAFT, CLAMP BRACKET	1	
4	45421-89J00	PIN, TILT LOCK	2	
5	09160-12066	WASHER (12.5X22X2.5)	2	
6	55321-87J01	ANODE, PROTECTION	2	
7	09103-06281	BOLT (6X14)	2	
8-1	09100-12093	BOLT (12X100)	4	
8-2	09100-12091	BOLT (12X115)	1	OPT
9	09159-12014	NUT (12X17)	4	
10	09159-22006	NUT (M22)	1	
11	09160-12128	WASHER (12.5X35X3)	4	
12	09160-12126	WASHER (12.5X22X3)	4	
13	09159-10050	NUT (10X14)	2	
14	09160-10082	WASHER (10.5X19X2.0)	2	
15	41135-93J00	WASHER, CLAMP BRACKET SHAFT	1	
16	43241-87J00	MARK, RELEASE LEVER	1	

FIG.335F




FIG.335F (1-I-4) CLAMP BRACKET (DF60ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-88L11-YAY	BRACKET, CLAMP STBD (BLACK)	1	STBD
2	41121-88L01-YAY	BRACKET, CLAMP PORT (BLACK)	1	PORT
3	41130-88L10	SHAFT, CLAMP BRACKET	1	
4	41135-93J00	WASHER, CLAMP BRACKET SHAFT	1	
5	09116-08137	BOLT (8X22)	1	
6	09159-22006	NUT (M22)	1	
7-1	09100-12093	BOLT (12X100)	4	
7-2	09100-12091	BOLT (12X115)	1	OPT
8	09159-12014	NUT (12X17)	4	
9	09160-12126	WASHER (12.5X22X3)	4	
10	09160-12128	WASHER (12.5X35X3)	4	
11	55320-94900	ANODE SET, CLAMP BRACKET	1	
12	09116-06121	.BOLT (6X25)	2	
13	09106-10065	BOLT (10X20)	2	
14	09160-10082	WASHER (10.5X19X2.0)	2	

FIG.335G




FIG.335G (1-I-5) CLAMP BRACKET (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	41111-88L11-YAY	BRACKET, CLAMP STBD (BLACK)	1	(DF50AVT,DF50AVTH,DF60AVT, DF40ASVT,DF60AVTH):020 STBD
1-2	41111-88L11-Y5S	BRACKET, CLAMP STBD (WHITE)	1	(DF50AVT,DF50AVTH,DF60AVT, DF40ASVT,DF60AVTH):020 STBD
1-3	41111-88L11-QTN	BRACKET, CLAMP STBD (WHITE)	1	(DF50AVT,DF60AVT,DF40ASVT, DF60AVTH):021,(DF40ASVT: (022,023)) STBD
1-4	41111-88L11-YAY	BRACKET, CLAMP STBD (BLACK)	1	(DF50AVT,DF60AVT,DF40ASVT, DF60AVTH):(021,022,023) STBD
2-1	41121-88L01-YAY	BRACKET, CLAMP PORT (BLACK)	1	(DF50AVT,DF50AVTH,DF60AVT, DF40ASVT,DF60AVTH):020 PORT
2-2	41121-88L01-Y5S	BRACKET, CLAMP PORT (WHITE)	1	(DF50AVT,DF50AVTH,DF60AVT, DF40ASVT,DF60AVTH):020 PORT
2-3	41121-88L01-QTN	BRACKET, CLAMP PORT (WHITE)	1	(DF50AVT,DF60AVT,DF40ASVT, DF60AVTH):021,(DF40ASVT: (022,023)) PORT
2-4	41121-88L01-YAY	BRACKET, CLAMP PORT (BLACK)	1	(DF50AVT,DF60AVT,DF40ASVT, DF60AVTH):(021,022,023) PORT
3	41130-88L10	SHAFT, CLAMP BRACKET	1	
4	41135-93J00	WASHER, CLAMP BRACKET SHAFT	1	
5	09116-08137	BOLT (8X22)	1	
6	09159-22006	NUT (M22)	1	
7-1	09100-12093	BOLT (12X100)	4	
7-2	09100-12091	BOLT (12X115)	1	OPT

NOTE : DF50AVT,DF50AVTH,DF60AVT,DF40ASVT,DF60AVTH

FIG.335G




FIG.335G (1-I-6) CLAMP BRACKET (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
8	09159-12014	NUT (12X17)	4	
9	09160-12126	WASHER (12.5X22X3)	4	
10	09160-12128	WASHER (12.5X35X3)	4	
11	55321-87J01	ANODE, PROTECTION	2	
12	09103-06281	BOLT (6X14)	2	
13	09106-10065	BOLT (10X20)	2	
14	09160-10082	WASHER (10.5X19X2.0)	2	

NOTE : DF50AVT,DF50AVTH,DF60AVT,DF40ASVT,DF60AVTH

FIG.336A




FIG.336A (1-I-7) SWIVEL BRACKET (DF40A,DF50A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	43111-88L31-YAY	BRACKET SWIVEL (BLACK)	1	020:W/TRANSOM(S)
1-2	43111-88L31-Y5S	BRACKET SWIVEL (WHITE)	1	020:W/TRANSOM(S)
1-3	43111-88L21-YAY	BRACKET SWIVEL (BLACK)	1	020:W/TRANSOM(L)
1-4	43111-88L21-Y5S	BRACKET SWIVEL (WHITE)	1	020:W/TRANSOM(L)
1-5	43111-88L31-QTN	BRACKET SWIVEL (WHITE)	1	(021,022,023):W/TRANSOM(S)
1-6	43111-88L31-YAY	BRACKET SWIVEL (BLACK)	1	(021,022,023):W/TRANSOM(S)
1-7	43111-88L21-QTN	BRACKET SWIVEL (WHITE)	1	(021,022,023):W/TRANSOM(L)
1-8	43111-88L21-YAY	BRACKET SWIVEL (BLACK)	1	(021,022,023):W/TRANSOM(L)
2	43211-87J00	BUSH, SWIVEL BRACKET	2	
3	43711-89J10	BUSH, STEERING	2	
4-1	43750-88L32-YAY	BRACKET, STEERING (BLACK)	1	020:W/TRANSOM(S)
4-2	43750-88L32-Y5S	BRACKET, STEERING (WHITE)	1	020:W/TRANSOM(S)
4-3	43750-88L22-YAY	BRACKET, STEERING (BLACK)	1	020:W/TRANSOM(L)
4-4	43750-88L22-Y5S	BRACKET, STEERING (WHITE)	1	020:W/TRANSOM(L)
4-5	43750-88L32-QTN	BRACKET, STEERING (WHITE)	1	(021,022,023):W/TRANSOM(S)
4-6	43750-88L32-YAY	BRACKET, STEERING (BLACK)	1	(021,022,023):W/TRANSOM(S)
4-7	43750-88L22-QTN	BRACKET, STEERING (WHITE)	1	(021,022,023):W/TRANSOM(L)
4-8	43750-88L22-YAY	BRACKET, STEERING (BLACK)	1	(021,022,023):W/TRANSOM(L)
5	22511-99011	NIPPLE, GREASE	3	
6	36894-95201	LEAD (L:165)	1	CLAMP TO SWIVEL
7	36895-87D01	LEAD (L:230)	1	SWIVEL TO MOUNT BRKT
8	36895-87D01	LEAD (L:230)	1	SWIVEL TO HOUSING
9	09125-06063	SCREW (6X10)	2	
10	09125-05050	SCREW (5X8)	3	
11	43755-88L00	ATTACHMENT, STEERING BRACKET	1	
12	09108-10161	STUD BOLT (10X20)	2	
13	09159-10050	NUT (10X14)	2	
14	09160-10165	WASHER	2	
15	09160-39003	WASHER (39.5X58X0.3)	2	
16	09282-39001	OIL SEAL (39X51X5)	1	
17	09160-39002	WASHER (39.5X58X1)	2	
18	09380-38003	CIRCLIP	1	
19	41226-97E00	BUSH, TILT LOCK LEVER	2	
20	41270-89J11	LEVER, TILT LOCK STBD	1	STBD
21	41280-89J04	LEVER, TILT LOCK PORT	1	PORT
22	45731-96312	BRACKET, SPRING	1	

FIG.336A




FIG.336A (1-I-8) SWIVEL BRACKET (DF40A,DF50A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
23	09116-06236	BOLT (6X16)	1	
24	41230-97E10	SPRING, TILT LOCK	1	
25	09205-03051	PIN (3X16)	1	

FIG.336B




FIG.336B (1-I-9) SWIVEL BRACKET (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	43111-88L21-YAY	BRACKET SWIVEL (BLACK)	1	
2	43211-87J00	BUSH, SWIVEL BRACKET	2	
3	43711-89J10	BUSH, STEERING	2	
4	43750-88L22-YAY	BRACKET, STEERING (BLACK)	1	
5	22511-99011	NIPPLE, GREASE	3	
6	36894-95201	LEAD (L:165)	1	CLAMP TO SWIVEL
7	36895-87D01	LEAD (L:230)	1	SWIVEL TO MOUNT BRKT
8	36895-87D01	LEAD (L:230)	1	SWIVEL TO HOUSING
9	09125-06063	SCREW (6X10)	2	
10	09125-05050	SCREW (5X8)	3	
11	09160-39003	WASHER (39.5X58X0.3)	2	
12	09282-39001	OIL SEAL (39X51X5)	1	
13	09160-39002	WASHER (39.5X58X1)	2	
14	09380-38003	CIRCLIP	1	
15	41226-97E00	BUSH, TILT LOCK LEVER	2	
16	41270-89J11	LEVER, TILT LOCK STBD	1	STBD
17	41280-89J04	LEVER, TILT LOCK PORT	1	PORT
18	45731-96312	BRACKET, SPRING	1	
19	09116-06236	BOLT (6X16)	1	
20	41230-97E10	SPRING, TILT LOCK	1	
21	09205-03051	PIN (3X16)	1	
22	43411-88L02	ADJUSTER, STEERING	1	
23	43415-88L00	PLATE, STEERING ADJUSTER	1	
24	43512-88L00	SHAFT, STRG ADJUSTER THREAD	1	
25	43513-88L00	BOLT, STEERING ADJUSTER	1	
26	43514-88L00	PLATE, STRG ADJUSTER FRICTION	2	
27	43515-88L00	WASHER, STRG ADJ FRICTION PLATE	2	
28	43516-88L00	WASHER, STRG ADJUSTER FRICTION	1	
29	43517-88L00	SPACER, STEERING ADJUSTER	1	
30	09116-06237	BOLT (6X15)	2	
31	09159-08059	NUT (M8)	1	

NOTE : DF40AQH,DF40ATH,DF50ATH,DF60AQH

FIG.336B




FIG.336B (1-I-10) SWIVEL BRACKET (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
32	09161-08011	WASHER (8.2X18X1.2)	2	
33	22511-99011	NIPPLE, GREASE	1	

NOTE : DF40AQH,DF40ATH,DF50ATH,DF60AQH

FIG.336C




FIG.336C (1-I-11) SWIVEL BRACKET (DF40AST)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	43111-88L50-YAY	BRACKET SWIVEL (BLACK)	1	020:W/TRANSOM(S)
1-2	43111-88L50-Y5S	BRACKET SWIVEL (WHITE)	1	020:W/TRANSOM(S)
1-3	43111-88L40-YAY	BRACKET SWIVEL (BLACK)	1	020:W/TRANSOM(L)
1-4	43111-88L40-Y5S	BRACKET SWIVEL (WHITE)	1	020:W/TRANSOM(L)
1-5	43111-88L50-QTN	BRACKET SWIVEL (WHITE)	1	(021,022,023):W/TRANSOM(S)
1-6	43111-88L50-YAY	BRACKET SWIVEL (BLACK)	1	(021,022,023):W/TRANSOM(S)
1-7	43111-88L40-QTN	BRACKET SWIVEL (WHITE)	1	(021,022,023):W/TRANSOM(L)
1-8	43111-88L40-YAY	BRACKET SWIVEL (BLACK)	1	(021,022,023):W/TRANSOM(L)
2	43211-88L00	BUSH, SWIVEL BRACKET	2	
3	43711-97E11	BUSH, STEERING	2	
4-1	43750-88L32-YAY	BRACKET, STEERING (BLACK)	1	020:W/TRANSOM(S)
4-2	43750-88L32-Y5S	BRACKET, STEERING (WHITE)	1	020:W/TRANSOM(S)
4-3	43750-88L22-YAY	BRACKET, STEERING (BLACK)	1	020:W/TRANSOM(L)
4-4	43750-88L22-Y5S	BRACKET, STEERING (WHITE)	1	020:W/TRANSOM(L)
4-5	43750-88L32-QTN	BRACKET, STEERING (WHITE)	1	(021,022,023):W/TRANSOM(S)
4-6	43750-88L32-YAY	BRACKET, STEERING (BLACK)	1	(021,022,023):W/TRANSOM(S)
4-7	43750-88L22-QTN	BRACKET, STEERING (WHITE)	1	(021,022,023):W/TRANSOM(L)
4-8	43750-88L22-YAY	BRACKET, STEERING (BLACK)	1	(021,022,023):W/TRANSOM(L)
5	22511-99011	NIPPLE, GREASE	4	
6	36894-87D00	LEAD (L:165)	1	CLAMP TO SWIVEL
7	36895-87D01	LEAD (L:230)	1	SWIVEL TO MOUNT BRKT
8	36895-87D01	LEAD (L:230)	1	SWIVEL TO HOUSING
9	09125-06063	SCREW (6X10)	4	
10	09125-05050	SCREW (5X8)	1	
11	43119-88L00	PLATE, SWIVEL BRKT LOWER STBD	1	LOWER,STBD
12	43119-88L10	PLATE, SWIVEL BRKT LOWER PORT	1	LOWER,PORT
13	09125-06067	SCREW (6X16)	2	
14	43114-88L00	WASHER, SWIVEL TO CLAMP BRKT	2	
15	09160-39003	WASHER (39.5X58X0.3)	2	
16	09282-39001	OIL SEAL (39X51X5)	1	
17	09160-39002	WASHER (39.5X58X1)	2	
18	09380-38003	CIRCLIP	1	
19	43755-88L00	ATTACHMENT, STEERING BRACKET	1	
20	09108-10161	STUD BOLT (10X20)	2	
21	09159-10050	NUT (10X14)	2	
22	09160-10165	WASHER	2	

FIG.336C




FIG.336C (1-I-12) SWIVEL BRACKET (DF40AST)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
23	41221-88L00	LEVER, TILT LOCK STBD	1	STBD
24	41280-88L10	LEVER, TILT LOCK PORT	1	PORT
25	41224-88L00	BUSH, TILT LOCK LEVER	2	
26	29141-93J00	NUT (M6)	1	STBD
27	41231-88L01	LINK, TILT LOCK LEVER	1	
28	41234-88L00	ARM, TILT LOCK LINK	1	
29	45731-96312	BRACKET, SPRING	1	
30	09125-06063	SCREW (6X10)	1	
31	09443-10043	SPRING	1	

FIG.336D




FIG.336D (1-I-13) SWIVEL BRACKET (DF60A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	43111-88L50-YAY	BRACKET SWIVEL (BLACK)	1	020:W/TRANSOM(S)
1-2	43111-88L50-Y5S	BRACKET SWIVEL (WHITE)	1	020:W/TRANSOM(S)
1-3	43111-88L40-YAY	BRACKET SWIVEL (BLACK)	1	020:W/TRANSOM(L)
1-4	43111-88L40-Y5S	BRACKET SWIVEL (WHITE)	1	020:W/TRANSOM(L)
1-5	43111-88L40-YAY	BRACKET SWIVEL (BLACK)	1	020:W/TRANSOM(X)
1-6	43111-88L40-Y5S	BRACKET SWIVEL (WHITE)	1	020:W/TRANSOM(X)
1-7	43111-88L50-QTN	BRACKET SWIVEL (WHITE)	1	(021,022,023):W/TRANSOM(S)
1-8	43111-88L50-YAY	BRACKET SWIVEL (BLACK)	1	(021,022,023):W/TRANSOM(S)
1-9	43111-88L40-QTN	BRACKET SWIVEL (WHITE)	1	(021,022,023):W/TRANSOM(L)
1-10	43111-88L40-YAY	BRACKET SWIVEL (BLACK)	1	(021,022,023):W/TRANSOM(L)
1-11	43111-88L40-QTN	BRACKET SWIVEL (WHITE)	1	(021,022,023):W/TRANSOM(X)
1-12	43111-88L40-YAY	BRACKET SWIVEL (BLACK)	1	(021,022,023):W/TRANSOM(X)
2	43211-88L00	BUSH, SWIVEL BRACKET	2	
3	43711-97E11	BUSH, STEERING	2	
4-1	43750-88L32-YAY	BRACKET, STEERING (BLACK)	1	020:W/TRANSOM(S)
4-2	43750-88L32-Y5S	BRACKET, STEERING (WHITE)	1	020:W/TRANSOM(S)
4-3	43750-88L22-YAY	BRACKET, STEERING (BLACK)	1	020:W/TRANSOM(L)
4-4	43750-88L22-Y5S	BRACKET, STEERING (WHITE)	1	020:W/TRANSOM(L)
4-5	43750-88L22-YAY	BRACKET, STEERING (BLACK)	1	020:W/TRANSOM(X)
4-6	43750-88L22-Y5S	BRACKET, STEERING (WHITE)	1	020:W/TRANSOM(X)
4-7	43750-88L32-QTN	BRACKET, STEERING (WHITE)	1	(021,022,023):W/TRANSOM(S)
4-8	43750-88L32-YAY	BRACKET, STEERING (BLACK)	1	(021,022,023):W/TRANSOM(S)
4-9	43750-88L22-QTN	BRACKET, STEERING (WHITE)	1	(021,022,023):W/TRANSOM(L)
4-10	43750-88L22-YAY	BRACKET, STEERING (BLACK)	1	(021,022,023):W/TRANSOM(L)
4-11	43750-88L22-QTN	BRACKET, STEERING (WHITE)	1	(021,022,023):W/TRANSOM(X)
4-12	43750-88L22-YAY	BRACKET, STEERING (BLACK)	1	(021,022,023):W/TRANSOM(X)
5	22511-99011	NIPPLE, GREASE	4	
6	36894-87D00	LEAD (L:165)	1	CLAMP TO SWIVEL
7	36895-87D01	LEAD (L:230)	1	SWIVEL TO MOUNT BRKT
8	36895-87D01	LEAD (L:230)	1	SWIVEL TO HOUSING
9	09125-06063	SCREW (6X10)	4	
10	09125-05050	SCREW (5X8)	1	
11	43119-88L00	PLATE, SWIVEL BRKT LOWER STBD	1	LOWER,STBD
12	43119-88L10	PLATE, SWIVEL BRKT LOWER PORT	1	LOWER,PORT
13	09125-06067	SCREW (6X16)	2	
14	43114-88L00	WASHER, SWIVEL TO CLAMP BRKT	2	

FIG.336D




FIG.336D (1-I-14) SWIVEL BRACKET (DF60A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
15	09160-39003	WASHER (39.5X58X0.3)	2	
16	09282-39001	OIL SEAL (39X51X5)	1	
17	09160-39002	WASHER (39.5X58X1)	2	
18	09380-38003	CIRCLIP	1	
19	43755-88L00	ATTACHMENT, STEERING BRACKET	1	
20	09108-10161	STUD BOLT (10X20)	2	
21	09159-10050	NUT (10X14)	2	
22	09160-10165	WASHER	2	
23	41221-88L00	LEVER, TILT LOCK STBD	1	STBD
24	41280-88L10	LEVER, TILT LOCK PORT	1	PORT
25	41224-88L00	BUSH, TILT LOCK LEVER	2	
26	29141-93J00	NUT (M6)	1	STBD
27	41231-88L01	LINK, TILT LOCK LEVER	1	
28	41234-88L00	ARM, TILT LOCK LINK	1	
29	45731-96312	BRACKET, SPRING	1	
30	09125-06063	SCREW (6X10)	1	
31	09443-10043	SPRING	1	

FIG.336E




FIG.336E (1-J-2) SWIVEL BRACKET (DF60ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	43111-88L40-YAY	BRACKET, SWIVEL (BLACK)	1	
2	43211-88L00	BUSH, SWIVEL BRACKET	2	
3	43711-97E11	BUSH, STEERING	2	
4	43750-88L22-YAY	BRACKET, STEERING (BLACK)	1	
5	22511-99011	NIPPLE, GREASE	4	
6	36894-87D00	LEAD (L:165)	1	CLAMP TO SWIVEL
7	36895-87D01	LEAD (L:230)	1	SWIVEL TO MOUNT BRKT
8	36895-87D01	LEAD (L:230)	1	SWIVEL TO HOUSING
9	09125-06063	SCREW (6X10)	4	
10	09125-05050	SCREW (5X8)	1	
11	43119-88L00	PLATE, SWIVEL BRKT LOWER STBD	1	LOWER,STBD
12	43119-88L10	PLATE, SWIVEL BRKT LOWER PORT	1	LOWER,PORT
13	09125-06067	SCREW (6X16)	2	
14	43114-88L00	WASHER, SWIVEL TO CLAMP BRKT	2	
15	09160-39003	WASHER (39.5X58X0.3)	2	
16	09282-39001	OIL SEAL (39X51X5)	1	
17	09160-39002	WASHER (39.5X58X1)	2	
18	09380-38003	CIRCLIP	1	
19	41221-88L00	LEVER, TILT LOCK STBD	1	STBD
20	41280-88L10	LEVER, TILT LOCK PORT	1	PORT
21	41224-88L00	BUSH, TILT LOCK LEVER	2	
22	29141-93J00	NUT (M6)	1	STBD
23	41231-88L01	LINK, TILT LOCK LEVER	1	
24	41234-88L00	ARM, TILT LOCK LINK	1	
25	45731-96312	BRACKET, SPRING	1	
26	09125-06063	SCREW (6X10)	1	
27	09443-10043	SPRING	1	

FIG.336F




FIG.336F (1-J-3) SWIVEL BRACKET (DF50AVT,DF60AVT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	43111-88L50-YAY	BRACKET SWIVEL (BLACK)	1	W/TRANSOM(L)
1-2	43111-88L40-YAY	BRACKET SWIVEL (BLACK)	1	W/TRANSOM(X)
2	43211-88L00	BUSH, SWIVEL BRACKET	2	
3	43711-97E11	BUSH, STEERING	2	
4-1	43750-88L32-YAY	BRACKET, STEERING (BLACK)	1	W/TRANSOM(L)
4-2	43750-88L22-YAY	BRACKET, STEERING (BLACK)	1	W/TRANSOM(X)
5	22511-99011	NIPPLE, GREASE	4	
6	36894-87D00	LEAD (L:165)	1	CLAMP TO SWIVEL
7	36895-87D01	LEAD (L:230)	1	SWIVEL TO MOUNT BRKT
8	36895-87D01	LEAD (L:230)	1	SWIVEL TO HOUSING
9	09125-06063	SCREW (6X10)	4	
10	09125-05050	SCREW (5X8)	1	
11	43119-88L00	PLATE, SWIVEL BRKT LOWER STBD	1	LOWER,STBD
12	43119-88L10	PLATE, SWIVEL BRKT LOWER PORT	1	LOWER,PORT
13	09125-06067	SCREW (6X16)	2	
14	43114-88L00	WASHER, SWIVEL TO CLAMP BRKT	2	
15	09160-39003	WASHER (39.5X58X0.3)	2	
16	09282-39001	OIL SEAL (39X51X5)	1	
17	09160-39002	WASHER (39.5X58X1)	2	
18	09380-38003	CIRCLIP	1	
19	43755-88L00	ATTACHMENT, STEERING BRACKET	1	
20	09108-10161	STUD BOLT (10X20)	2	
21	09159-10050	NUT (10X14)	2	
22	09160-10165	WASHER	2	
23	41221-88L00	LEVER, TILT LOCK STBD	1	STBD
24	41280-88L10	LEVER, TILT LOCK PORT	1	PORT
25	41224-88L00	BUSH, TILT LOCK LEVER	2	
26	29141-93J00	NUT (M6)	1	STBD
27	41231-88L01	LINK, TILT LOCK LEVER	1	
28	41234-88L00	ARM, TILT LOCK LINK	1	
29	45731-96312	BRACKET, SPRING	1	
30	09125-06063	SCREW (6X10)	1	
31	09443-10043	SPRING	1	

FIG.336G




FIG.336G (1-J-4) SWIVEL BRACKET (DF50AVTH,DF60AVTH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	43111-88L50-YAY	BRACKET SWIVEL (BLACK)	1	W/TRANSOM(L)
1-2	43111-88L40-YAY	BRACKET SWIVEL (BLACK)	1	W/TRANSOM(X)
2	43211-88L00	BUSH, SWIVEL BRACKET	2	
3	43711-97E11	BUSH, STEERING	2	
4-1	43750-88L32-YAY	BRACKET, STEERING (BLACK)	1	W/TRANSOM(L)
4-2	43750-88L22-YAY	BRACKET, STEERING (BLACK)	1	W/TRANSOM(X)
5	22511-99011	NIPPLE, GREASE	4	
6	36894-87D00	LEAD (L:165)	1	CLAMP TO SWIVEL
7	36895-87D01	LEAD (L:230)	1	SWIVEL TO MOUNT BRKT
8	36895-87D01	LEAD (L:230)	1	SWIVEL TO HOUSING
9	09125-06063	SCREW (6X10)	4	
10	09125-05050	SCREW (5X8)	1	
11	43119-88L00	PLATE, SWIVEL BRKT LOWER STBD	1	LOWER,STBD
12	43119-88L10	PLATE, SWIVEL BRKT LOWER PORT	1	LOWER,PORT
13	09125-06067	SCREW (6X16)	2	
14	43114-88L00	WASHER, SWIVEL TO CLAMP BRKT	2	
15	09160-39003	WASHER (39.5X58X0.3)	2	
16	09282-39001	OIL SEAL (39X51X5)	1	
17	09160-39002	WASHER (39.5X58X1)	2	
18	09380-38003	CIRCLIP	1	
19	41221-88L00	LEVER, TILT LOCK STBD	1	STBD
20	41280-88L10	LEVER, TILT LOCK PORT	1	PORT
21	41224-88L00	BUSH, TILT LOCK LEVER	2	
22	29141-93J00	NUT (M6)	1	STBD
23	41231-88L01	LINK, TILT LOCK LEVER	1	
24	41234-88L00	ARM, TILT LOCK LINK	1	
25	45731-96312	BRACKET, SPRING	1	
26	09125-06063	SCREW (6X10)	1	
27	09443-10043	SPRING	1	

FIG.336H




FIG.336H (1-J-5) SWIVEL BRACKET (DF40ASVT:E34)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	43111-88L50-YAY	BRACKET SWIVEL (BLACK)	1	020:W/TRANSOM(L)
1-2	43111-88L50-Y5S	BRACKET SWIVEL (WHITE)	1	020:W/TRANSOM(L)
1-3	43111-88L50-QTN	BRACKET SWIVEL (WHITE)	1	(021,022,023):W/TRANSOM(L)
1-4	43111-88L50-YAY	BRACKET SWIVEL (BLACK)	1	(021,022,023):W/TRANSOM(L)
2	43211-88L00	BUSH, SWIVEL BRACKET	2	
3	43711-97E11	BUSH, STEERING	2	
4-1	43750-88L32-YAY	BRACKET, STEERING (BLACK)	1	020:W/TRANSOM(L)
4-2	43750-88L32-Y5S	BRACKET, STEERING (WHITE)	1	020:W/TRANSOM(L)
4-3	43750-88L32-QTN	BRACKET, STEERING (WHITE)	1	(021,022,023):W/TRANSOM(L)
4-4	43750-88L32-YAY	BRACKET, STEERING (BLACK)	1	(021,022,023):W/TRANSOM(L)
5	22511-99011	NIPPLE, GREASE	4	
6	36894-87D00	LEAD (L:165)	1	CLAMP TO SWIVEL
7	36895-87D01	LEAD (L:230)	1	SWIVEL TO MOUNT BRKT
8	36895-87D01	LEAD (L:230)	1	SWIVEL TO HOUSING
9	09125-06063	SCREW (6X10)	4	
10	09125-05050	SCREW (5X8)	1	
11	43119-88L00	PLATE, SWIVEL BRKT LOWER STBD	1	LOWER,STBD
12	43119-88L10	PLATE, SWIVEL BRKT LOWER PORT	1	LOWER,PORT
13	09125-06067	SCREW (6X16)	2	
14	43114-88L00	WASHER, SWIVEL TO CLAMP BRKT	2	
15	09160-39003	WASHER (39.5X58X0.3)	2	
16	09282-39001	OIL SEAL (39X51X5)	1	
17	09160-39002	WASHER (39.5X58X1)	2	
18	09380-38003	CIRCLIP	1	
19	43755-88L00	ATTACHMENT, STEERING BRACKET	1	
20	09108-10161	STUD BOLT (10X20)	2	
21	09159-10050	NUT (10X14)	2	
22	09160-10165	WASHER	2	
23	41221-88L00	LEVER, TILT LOCK STBD	1	STBD
24	41280-88L10	LEVER, TILT LOCK PORT	1	PORT
25	41224-88L00	BUSH, TILT LOCK LEVER	2	
26	29141-93J00	NUT (M6)	1	STBD
27	41231-88L01	LINK, TILT LOCK LEVER	1	
28	41234-88L00	ARM, TILT LOCK LINK	1	
29	45731-96312	BRACKET, SPRING	1	
30	09125-06063	SCREW (6X10)	1	

FIG.336H




FIG.336H (1-J-6) SWIVEL BRACKET (DF40ASVT:E34)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
31	09443-10043	SPRING	1	

FIG.337A




FIG.337A (1-J-7) TRIM CYLINDER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-88L18	TRIM ASSY, POWER WITH TILT	1	->48000-88L30
2	29404-93J11	.CLAMP (L:65)	1	
3	38100-88L12	.MOTOR ASSY, PTT	1	
4	48320-87J10	.VALVE, UPPER PRESSURE	1	UPPER
5	48330-87J10	.VALVE, DOWN PRESSURE	1	
6	48510-97E00	.PUMP ASSY, GEAR	1	
7	48541-87J10	.BOLT	2	
8	48541-87J20	.BOLT	1	
9	48551-88L00	.VALVE, MANUAL	1	
10	48553-88L00	.SEAL, WASHER	1	
11	48557-87J10	.O RING SET	1	
12	48571-88L01	.TANK, RESERVOIR	1	
13	48572-87L00	.PLUG	1	
14	48582-97E01	.FILTER	1	
15	48583-87J10	.JOINT, DRIVE	1	
16	48611-88L00	.JOINT, METAL	1	
17	48681-87J11	.CIRCLIP	1	
18	48862-87J20	.BOLT, RESERVOIR	4	
19	48862-88L00	.SCREW, PTT MOTOR	4	
20	47225-87J00	COLLAR, TILT CYLINDER LOWER	1	LOWER
21	48121-89J10	SHAFT, TILT CYL LOWER	1	LOWER
22	48321-89J11	SHAFT, TILT CYLINDER UPPER	1	UPPER
23	48325-89J00	BUSH, TILT CYL UPPER	2	UPPER
24	48326-87J00	BUSH, TILT CYLINDER LOWER	1	LOWER
25	09380-12002	SNAP RING	2	
26	09116-10179	BOLT (10X35)	2	
27	55321-87J01	ANODE, PROTECTION	1	
28	09103-06281	BOLT (6X14)	1	
29	09160-10139	WASHER (10.5X35X3)	2	

NOTE : (DF40A,DF40ATH,DF50A,DF50ATH):(020,021)

DF60A_E11_023_337A
TRIM CYLINDER

FIG.337B




FIG.337B (1-J-8) TRIM CYLINDER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-88L30	TRIM ASSY, POWER WITH TILT	1	
2	29404-93J11	.CLAMP (L:65)	1	
3	38100-88L12	.MOTOR ASSY, PTT	1	
4	48320-87J10	.VALVE, UPPER PRESSURE	1	UPPER
5	48330-87J10	.VALVE, DOWN PRESSURE	1	
6	48510-97E00	.PUMP ASSY, GEAR	1	
7	48541-87J10	.BOLT	2	
8	48541-87J20	.BOLT	1	
9	48551-88L00	.VALVE, MANUAL	1	
10	48553-88L00	.SEAL, WASHER	1	
11	48557-87J10	.O RING SET	1	
12	48571-88L01	.TANK, RESERVOIR	1	
13	48572-87L00	.PLUG	1	
14	48582-97E01	.FILTER	1	
15	48583-87J10	.JOINT, DRIVE	1	
16	48611-88L10	.JOINT, METAL	1	
17	48612-88L00	.NUT	1	
18	48681-87J11	.CIRCLIP	1	
19	48862-87J20	.BOLT, RESERVOIR	4	
20	48862-88L00	.SCREW, PTT MOTOR	4	
21	47225-87J00	COLLAR, TILT CYLINDER LOWER	1	LOWER
22	48121-89J10	SHAFT, TILT CYL LOWER	1	LOWER
23	48321-89J11	SHAFT, TILT CYLINDER UPPER	1	UPPER
24	48325-89J00	BUSH, TILT CYL UPPER	2	UPPER
25	48326-87J00	BUSH, TILT CYLINDER LOWER	1	LOWER
26	09380-12002	SNAP RING	2	
27	09116-10179	BOLT (10X35)	2	
28	55321-87J01	ANODE, PROTECTION	1	
29	09103-06281	BOLT (6X14)	1	
30	09160-10139	WASHER (10.5X35X3)	2	

NOTE : (DF40A,DF40ATH,DF50A,DF50ATH):(022,023)

DF60A_E11_023_337B
TRIM CYLINDER

FIG.337C




FIG.337C (1-J-9) TRIM CYLINDER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-88L18	TRIM ASSY, POWER WITH TILT	1	->48000-88L30
2	29404-93J11	.CLAMP (L:65)	1	
3	38100-88L12	.MOTOR ASSY, PTT	1	
4	48320-87J10	.VALVE, UPPER PRESSURE	1	UPPER
5	48330-87J10	.VALVE, DOWN PRESSURE	1	
6	48510-97E00	.PUMP ASSY, GEAR	1	
7	48541-87J10	.BOLT	2	
8	48541-87J20	.BOLT	1	
9	48551-88L00	.VALVE, MANUAL	1	
10	48553-88L00	.SEAL, WASHER	1	
11	48557-87J10	.O RING SET	1	
12	48571-88L01	.TANK, RESERVOIR	1	
13	48572-87L00	.PLUG	1	
14	48582-97E01	.FILTER	1	
15	48583-87J10	.JOINT, DRIVE	1	
16	48611-88L00	.JOINT, METAL	1	
17	48681-87J11	.CIRCLIP	1	
18	48862-87J20	.BOLT, RESERVOIR	4	
19	48862-88L00	.SCREW, PTT MOTOR	4	
20	47225-88L00	COLLAR, TILT CYL LOWER	1	LOWER
21	48121-88L00	SHAFT, TILT CYL LOWER	1	LOWER
22	48321-89J11	SHAFT, TILT CYLINDER UPPER	1	UPPER
23	48325-89J00	BUSH, TILT CYL UPPER	2	UPPER
24	48326-87J00	BUSH, TILT CYLINDER LOWER	1	LOWER
25	09380-12002	SNAP RING	2	
26	09116-10179	BOLT (10X35)	2	
27	55321-87J01	ANODE, PROTECTION	1	
28	09103-06281	BOLT (6X14)	1	

NOTE : (DF40AST,DF60A,DF60ATH):(020,021)

DF60A_E11_023_337C
TRIM CYLINDER

FIG.337D




FIG.337D (1-J-10) TRIM CYLINDER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-88L30	TRIM ASSY, POWER WITH TILT	1	
2	29404-93J11	.CLAMP (L:65)	1	
3	38100-88L12	.MOTOR ASSY, PTT	1	
4	48320-87J10	.VALVE, UPPER PRESSURE	1	UPPER
5	48330-87J10	.VALVE, DOWN PRESSURE	1	
6	48510-97E00	.PUMP ASSY, GEAR	1	
7	48541-87J10	.BOLT	2	
8	48541-87J20	.BOLT	1	
9	48551-88L00	.VALVE, MANUAL	1	
10	48553-88L00	.SEAL, WASHER	1	
11	48557-87J10	.O RING SET	1	
12	48571-88L01	.TANK, RESERVOIR	1	
13	48572-87L00	.PLUG	1	
14	48582-97E01	.FILTER	1	
15	48583-87J10	.JOINT, DRIVE	1	
16	48611-88L10	.JOINT, METAL	1	
17	48612-88L00	.NUT	1	
18	48681-87J11	.CIRCLIP	1	
19	48862-87J20	.BOLT, RESERVOIR	4	
20	48862-88L00	.SCREW, PTT MOTOR	4	
21	47225-88L00	COLLAR, TILT CYL LOWER	1	LOWER
22	48121-88L00	SHAFT, TILT CYL LOWER	1	LOWER
23	48321-89J11	SHAFT, TILT CYLINDER UPPER	1	UPPER
24	48325-89J00	BUSH, TILT CYL UPPER	2	UPPER
25	48326-87J00	BUSH, TILT CYLINDER LOWER	1	LOWER
26	09380-12002	SNAP RING	2	
27	09116-10179	BOLT (10X35)	2	
28	55321-87J01	ANODE, PROTECTION	1	
29	09103-06281	BOLT (6X14)	1	

NOTE : (DF40AST,DF60A,DF60ATH):(022,023)

FIG.337E




FIG.337E (1-J-11) TRIM CYLINDER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-88L22	TRIM ASSY, POWER WITH TILT	1	->48000-88L40
2	29404-93J11	.CLAMP (L:65)	1	
3	38100-88L12	.MOTOR ASSY, PTT	1	
4	48320-87J10	.VALVE, UPPER PRESSURE	1	UPPER
5	48330-87J20	.VALVE, DOWN PRESSURE	1	
6	48510-97E10	.PUMP ASSY, GEAR	1	
7	48541-87J20	.BOLT	3	
8	48551-88L10	.VALVE, MANUAL	1	
9	48553-88L00	.SEAL, WASHER	1	
10	48557-87J10	.O RING SET	1	
11	48571-88L01	.TANK, RESERVOIR	1	
12	48572-87L00	.PLUG	1	
13	48583-87J10	.JOINT, DRIVE	1	
14	48611-88L00	.JOINT, METAL	1	
15	48681-87J11	.CIRCLIP	1	
16	48862-87J20	.BOLT, RESERVOIR	4	
17	48862-88L00	.SCREW, PTT MOTOR	4	
18	47225-88L00	COLLAR, TILT CYL LOWER	1	LOWER
19	48121-88L10	SHAFT, TILT CYLINDER LOWER	1	LOWER
20	48321-89J20	SHAFT, TILT CYLINDER UPPER	1	UPPER
21	48325-89J10	BUSH, TILT CYL UPPER	2	UPPER
22	48326-87J00	BUSH, TILT CYLINDER LOWER	1	LOWER
23	09380-12002	SNAP RING	2	
24	09116-10179	BOLT (10X35)	2	
25	55321-87J01	ANODE, PROTECTION	1	
26	09103-06281	BOLT (6X14)	1	

NOTE : (DF50AVT,DF50AVTH,DF60AVT,DF40ASVT,DF60AVTH):(020,021)

DF60A_E11_023_337E
TRIM CYLINDER

FIG.337F




FIG.337F (1-J-12) TRIM CYLINDER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-88L40	TRIM ASSY, POWER WITH TILT	1	
2	29404-93J11	.CLAMP (L:65)	1	
3	38100-88L12	.MOTOR ASSY, PTT	1	
4	48320-87J10	.VALVE, UPPER PRESSURE	1	UPPER
5	48330-87J20	.VALVE, DOWN PRESSURE	1	
6	48510-97E10	.PUMP ASSY, GEAR	1	
7	48541-87J20	.BOLT	3	
8	48551-88L10	.VALVE, MANUAL	1	
9	48553-88L00	.SEAL, WASHER	1	
10	48557-87J10	.O RING SET	1	
11	48571-88L01	.TANK, RESERVOIR	1	
12	48572-87L00	.PLUG	1	
13	48583-87J10	.JOINT, DRIVE	1	
14	48611-88L10	.JOINT, METAL	1	
15	48612-88L00	NUT	1	
16	48681-87J11	.CIRCLIP	1	
17	48862-87J20	.BOLT, RESERVOIR	4	
18	48862-88L00	.SCREW, PTT MOTOR	4	
19	47225-88L00	COLLAR, TILT CYL LOWER	1	LOWER
20	48121-88L10	SHAFT, TILT CYLINDER LOWER	1	LOWER
21	48321-89J20	SHAFT, TILT CYLINDER UPPER	1	UPPER
22	48325-89J10	BUSH, TILT CYL UPPER	2	UPPER
23	48326-87J00	BUSH, TILT CYLINDER LOWER	1	LOWER
24	09380-12002	SNAP RING	2	
25	09116-10179	BOLT (10X35)	2	
26	55321-87J01	ANODE, PROTECTION	1	
27	09103-06281	BOLT (6X14)	1	

NOTE : (DF50AVT,DF50AVTH,DF60AVT,DF40ASVT,DF60AVTH):(022,023)

DF60A_E11_023_337F
TRIM CYLINDER

FIG.339A





FIG.339A (1-J-13) GAS CYLINDER (DF40AQH,DF60AQH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	45260-89J01	LEVER, RELEASE	1	
2	47225-89J00	COLLAR, TILT CYL LOWER STBD	1	LOWER,STBD
3	47226-89J00	COLLAR, TILT CYLINDER LOWER	1	LOWER,PORT
4	47400-87J32	CYLINDER ASSY, GAS	1	
5	48121-89J10	SHAFT, TILT CYL LOWER	1	LOWER
6	48321-89J11	SHAFT, TILT CYLINDER UPPER	1	UPPER
7	48325-89J00	BUSH, TILT CYL UPPER	2	UPPER
8	48326-89J00	BUSH, TILT CYL LOWER	1	LOWER
9	55321-87J01	ANODE, PROTECTION	1	
10	09100-06184	BOLT (6X16)	1	
11	09116-10179	BOLT (10X35)	2	
12	09103-06281	BOLT (6X14)	1	
13	09140-06020	NUT	1	
14	09380-12002	SNAP RING	2	

FIG.340A



DF60A_E11_023_340A
PTT MOTOR

FIG.340A (1-J-14) PTT MOTOR (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-88L12	MOTOR ASSY, PTT	1	
2	31311-87J10	.ARMATURE	1	
3	31173-88L12	.HOLDER ASSY, BRUSH	1	
4	31123-97E10	..O RING	1	
5	31133-94910	..BRUSH	1	
6	31135-94900	..SPRING	2	
7	31136-87J11	..BREAKER	1	
8	33799-97E00	..OIL SEAL	1	
9	31111-87J10	.SCREW	3	

NOTE : DF40A,DF40ATH,DF40AST,DF50A,DF50ATH,DF60A,DF60ATH,DF50AVT,
DF50AVTH,DF60AVT,DF40ASVT,DF60AVTH

FIG.401A




FIG.401A (1-K-2) ENGINE HOLDER (DF40A,DF40AST,DF50A,DF60A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	51110-88L10-YAY	HOLDER, ENGINE (BLACK)	1	
1-2	51110-88L10-Y5S	HOLDER, ENGINE (WHITE)	1	
2	51211-88L00	GASKET, ENGINE HOLDER	1	
3	09116-08159	BOLT (8X55)	8	
4	01550-0845A	BOLT	1	
5	01550-0885A	BOLT	1	
6	09202-08006	PIN (8X12)	2	
7	09202-08006	PIN (8X12)	2	
8	51122-88L00	COVER, MOUNT CASE	1	
9	51123-88L00	GASKET, MOUNT CASE COVER	1	
10	01550-0825A	BOLT	6	
11	09202-08006	PIN (8X12)	2	
12	54137-88L00	COVER, UPPER MOUNT	1	UPPER
13	09116-10181	BOLT (10X44)	3	
14	51170-88L00	BRACKET, WATER INDICATOR	1	
15	29116-93J00	BOLT (6X20)	1	
16	09282-17011	OIL SEAL (16.5X28X6)	2	
17	54124-88L20	BRACKET, UPPER THRUST MOUNT FR	1	UPPER
18	54130-88L00	MOUNT, UPPER	2	UPPER
19	54166-95J02	BOLT, LOWER MOUNT (12X200)	2	UPPER
20	54114-90J10	WASHER, UPPER MOUNT BOLT	2	UPPER
21	09159-12014	NUT (12X17)	2	
22	09160-12110	WASHER (12.5X22X3)	2	
23	54121-88L01	MOUNT, UPR THRUST FR	2	UPPER
24	54123-88L01	MOUNT, UPR THRUST RR	1	UPPER

FIG.401B




FIG.401B (1-K-3) ENGINE HOLDER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	51110-88L10-YAY	HOLDER, ENGINE (BLACK)	1	
2	51211-88L00	GASKET, ENGINE HOLDER	1	
3	09116-08159	BOLT (8X55)	8	
4	01550-0845A	BOLT	1	
5	01550-0885A	BOLT	1	
6	09202-08006	PIN (8X12)	2	
7	09202-08006	PIN (8X12)	2	
8	51122-88L00	COVER, MOUNT CASE	1	
9	51123-88L00	GASKET, MOUNT CASE COVER	1	
10	01550-0825A	BOLT	6	
11	09202-08006	PIN (8X12)	2	
12	54137-88L00	COVER, UPPER MOUNT	1	UPPER
13	09116-10181	BOLT (10X44)	3	
14	51170-88L00	BRACKET, WATER INDICATOR	1	
15	29116-93J00	BOLT (6X20)	1	
16	09282-17011	OIL SEAL (16.5X28X6)	2	
17	54124-88L20	BRACKET, UPPER THRUST MOUNT FR	1	UPPER
18	54130-88L00	MOUNT, UPPER	2	UPPER
19	54166-95J02	BOLT, LOWER MOUNT (12X200)	2	UPPER
20	54114-90J10	WASHER, UPPER MOUNT BOLT	2	UPPER
21	09159-12014	NUT (12X17)	2	
22	09160-12110	WASHER (12.5X22X3)	2	
23	54121-88L01	MOUNT, UPR THRUST FR	2	UPPER
24	54123-88L01	MOUNT, UPR THRUST RR	1	UPPER

NOTE : DF40AQH,DF40ATH,DF50ATH,DF60AQH,DF60ATH

FIG.401C




FIG.401C (1-K-4) ENGINE HOLDER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	51110-88L10-YAY	HOLDER, ENGINE (BLACK)	1	
2	51211-88L00	GASKET, ENGINE HOLDER	1	
3	09116-08159	BOLT (8X55)	8	
4	01550-0845A	BOLT	1	
5	01550-0885A	BOLT	1	
6	09202-08006	PIN (8X12)	2	
7	09202-08006	PIN (8X12)	2	
8	51122-88L00	COVER, MOUNT CASE	1	
9	51123-88L00	GASKET, MOUNT CASE COVER	1	
10	01550-0825A	BOLT	6	
11	09202-08006	PIN (8X12)	2	
12	54137-88L00	COVER, UPPER MOUNT	1	UPPER
13	09116-10181	BOLT (10X44)	3	
14	51170-88L00	BRACKET, WATER INDICATOR	1	
15	29116-93J00	BOLT (6X20)	1	
16	09282-17011	OIL SEAL (16.5X28X6)	2	
17	54120-88L01	MOUNT, UPR THRUST	1	UPPER
18	54130-88L00	MOUNT, UPPER	2	UPPER
19	54166-95J02	BOLT, LOWER MOUNT (12X200)	2	UPPER
20	54114-90J10	WASHER, UPPER MOUNT BOLT	2	UPPER
21	09159-12014	NUT (12X17)	2	
22	09160-12110	WASHER (12.5X22X3)	2	

NOTE : DF50AVT,DF50AVTH,DF60AVT,DF60AVTH

FIG.401D




FIG.401D (1-K-5) ENGINE HOLDER (DF40ASVT:E34)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	51110-88L10-YAY	HOLDER, ENGINE (BLACK)	1	
1-2	51110-88L10-Y5S	HOLDER, ENGINE (WHITE)	1	
2	51211-88L00	GASKET, ENGINE HOLDER	1	
3	09116-08159	BOLT (8X55)	8	
4	01550-0845A	BOLT	1	
5	01550-0885A	BOLT	1	
6	09202-08006	PIN (8X12)	2	
7	09202-08006	PIN (8X12)	2	
8	51122-88L00	COVER, MOUNT CASE	1	
9	51123-88L00	GASKET, MOUNT CASE COVER	1	
10	01550-0825A	BOLT	6	
11	09202-08006	PIN (8X12)	2	
12	54137-88L00	COVER, UPPER MOUNT	1	UPPER
13	09116-10181	BOLT (10X44)	3	
14	51170-88L00	BRACKET, WATER INDICATOR	1	
15	29116-93J00	BOLT (6X20)	1	
16	09282-17011	OIL SEAL (16.5X28X6)	2	
17	54120-88L01	MOUNT, UPR THRUST	1	UPPER
18	54130-88L00	MOUNT, UPPER	2	UPPER
19	54166-95J02	BOLT, LOWER MOUNT (12X200)	2	UPPER
20	54114-90J10	WASHER, UPPER MOUNT BOLT	2	UPPER
21	09159-12014	NUT (12X17)	2	
22	09160-12110	WASHER (12.5X22X3)	2	

FIG.405A




FIG.405A (1-K-6) DRIVE SHAFT HOUSING (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	52111-88L00-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	(DF40A,DF50A):E01:020: W/TRANSOM(S)
1-2	52111-88L00-Y5S	HOUSING, DRIVE SHAFT (WHITE)	1	(DF40A,DF50A):E01:020: W/TRANSOM(S)
1-3	52111-88L10-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	(DF40A,DF50A):E01:020: W/TRANSOM(L)
1-4	52111-88L10-Y5S	HOUSING, DRIVE SHAFT (WHITE)	1	(DF40A,DF50A):E01:020: W/TRANSOM(L)
1-5	52111-88L10-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	(DF40AQH,DF40ATH,DF50ATH, DF60ATH):E01:020:W/TRANSOM(L)
1-6	52111-88L00-QTN	HOUSING, DRIVE SHAFT (WHITE)	1	(DF40A,DF50A):E11:(021,022, 023):W/TRANSOM(S)
1-7	52111-88L00-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	(DF40A,DF50A):E11:(021,022, 023):W/TRANSOM(S)
1-8	52111-88L10-QTN	HOUSING, DRIVE SHAFT (WHITE)	1	(DF40A,DF50A):E11:(021,022, 023):W/TRANSOM(L)
1-9	52111-88L10-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	(DF40A,DF50A):E11:(021,022, 023):W/TRANSOM(L)
1-10	52111-88L10-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	(DF40AQH,DF40ATH,DF50ATH, DF60ATH):E01:(021,022,023): W/TRANSOM(L)
2	09116-10181	BOLT (10X44)	8	
3	09202-08006	PIN (8X12)	2	

NOTE : (DF40A,DF40AQH,DF40ATH,DF50A,DF50ATH,DF60ATH):E01, (DF40A,DF50A):E11

FIG.405A




FIG.405A (1-K-7) DRIVE SHAFT HOUSING (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
4-1	54221-88L20-YAY	COVER, LOWER MOUNT STBD (BLACK)	1	(DF40A,DF50A):E01:020 LOWER,STBD
4-2	54221-88L20-Y5S	COVER, LOWER MOUNT STBD (WHITE)	1	(DF40A,DF50A):E01:020 LOWER,STBD
4-3	54221-88L20-YAY	COVER, LOWER MOUNT STBD (BLACK)	1	(DF40AQH,DF40ATH,DF50ATH, DF60ATH):E01:020 LOWER,STBD
4-4	54221-88L20-QTN	COVER, LOWER MOUNT STBD (WHITE)	1	(DF40A,DF50A):E11:(021,022, 023) LOWER,STBD
4-5	54221-88L20-YAY	COVER, LOWER MOUNT STBD (BLACK)	1	(DF40A,DF50A):E11:(021,022, 023) LOWER,STBD
4-6	54221-88L20-YAY	COVER, LOWER MOUNT STBD (BLACK)	1	(DF40AQH,DF40ATH,DF50ATH, DF60ATH):E01:(021,022,023) LOWER,STBD
5-1	54231-88L10-YAY	COVER, LOWER MOUNT PORT (BLACK)	1	(DF40A,DF50A):E01:020 LOWER,PORT
5-2	54231-88L10-Y5S	COVER, LOWER MOUNT PORT (WHITE)	1	(DF40A,DF50A):E01:020 LOWER,PORT
5-3	54231-88L10-YAY	COVER, LOWER MOUNT PORT (BLACK)	1	(DF40AQH,DF40ATH,DF50ATH, DF60ATH):E01:020 LOWER,PORT
5-4	54231-88L10-QTN	COVER, LOWER MOUNT PORT (WHITE)	1	(DF40A,DF50A):E11:(021,022, 023) LOWER,PORT
5-5	54231-88L10-YAY	COVER, LOWER MOUNT PORT (BLACK)	1	(DF40A,DF50A):E11:(021,022, 023) LOWER,PORT

NOTE : (DF40A,DF40AQH,DF40ATH,DF50A,DF50ATH,DF60ATH):E01, (DF40A,DF50A):E11

FIG.405A




FIG.405A (1-K-8) DRIVE SHAFT HOUSING (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
5-6	54231-88L10-YAY	COVER, LOWER MOUNT PORT (BLACK)	1	(DF40AQH,DF40ATH,DF50ATH, DF60ATH):E01:(021,022,023) LOWER,PORT
6	09116-10181	BOLT (10X44)	4	
7-1	54211-87J30-YAY	BRACKET, LOWER MOUNT (BLACK)	1	(DF40A,DF50A):E01:020 LOWER
7-2	54211-87J30-Y5S	BRACKET, LOWER MOUNT (WHITE)	1	(DF40A,DF50A):E01:020 LOWER
7-3	54211-87J30-YAY	BRACKET, LOWER MOUNT (BLACK)	1	(DF40AQH,DF40ATH,DF50ATH, DF60ATH):E01:020 LOWER
7-4	54211-87J30-QTN	BRACKET, LOWER MOUNT (WHITE)	1	(DF40A,DF50A):E11:(021,022, 023) LOWER
7-5	54211-87J30-YAY	BRACKET, LOWER MOUNT (BLACK)	1	(DF40A,DF50A):E11:(021,022, 023) LOWER
7-6	54211-87J30-YAY	BRACKET, LOWER MOUNT (BLACK)	1	(DF40AQH,DF40ATH,DF50ATH, DF60ATH):E01:(021,022,023) LOWER
8	54151-88L01	MOUNT, LOWER THRUST	1	LOWER
9	54160-88L10	MOUNT, LOWER	2	LOWER
10	54167-87L01	MOUNT, LOWER SIDE	2	LOWER
11	54180-88L01	DAMPER, FORWARD STOPPER	2	
12	54166-95J02	BOLT, LOWER MOUNT (12X200)	2	LOWER
13	09159-12014	NUT (12X17)	2	
14	09160-12110	WASHER (12.5X22X3)	2	

NOTE : (DF40A,DF40AQH,DF40ATH,DF50A,DF50ATH,DF60ATH):E01, (DF40A,DF50A):E11

FIG.405B




FIG.405B (1-K-9) DRIVE SHAFT HOUSING ((DF40A,DF50A,DF60A):E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	52111-88L10-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	
1-2	52111-88L10-Y5S	HOUSING, DRIVE SHAFT (WHITE)	1	
2	09116-10181	BOLT (10X44)	8	
3	09202-08006	PIN (8X12)	2	
4-1	54221-88L20-YAY	COVER, LOWER MOUNT STBD (BLACK)	1	LOWER,STBD
4-2	54221-88L20-Y5S	COVER, LOWER MOUNT STBD (WHITE)	1	LOWER,STBD
5-1	54231-88L10-YAY	COVER, LOWER MOUNT PORT (BLACK)	1	LOWER,PORT
5-2	54231-88L10-Y5S	COVER, LOWER MOUNT PORT (WHITE)	1	LOWER,PORT
6	09116-10181	BOLT (10X44)	4	
7-1	54211-87J30-YAY	BRACKET, LOWER MOUNT (BLACK)	1	LOWER
7-2	54211-87J30-Y5S	BRACKET, LOWER MOUNT (WHITE)	1	LOWER
8	54151-88L01	MOUNT, LOWER THRUST	1	LOWER
9	54160-88L10	MOUNT, LOWER	2	LOWER
10	54167-87L01	MOUNT, LOWER SIDE	2	LOWER
11	54180-88L01	DAMPER, FORWARD STOPPER	2	
12	54166-95J02	BOLT, LOWER MOUNT (12X200)	2	LOWER
13	09159-12014	NUT (12X17)	2	
14	09160-12110	WASHER (12.5X22X3)	2	

FIG.405C




FIG.405C (1-K-10) DRIVE SHAFT HOUSING (DF40AST:E34)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	52111-88L00-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	020:W/TRANSOM(S)
1-2	52111-88L00-Y5S	HOUSING, DRIVE SHAFT (WHITE)	1	020:W/TRANSOM(S)
1-3	52111-88L10-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	020:W/TRANSOM(L)
1-4	52111-88L10-Y5S	HOUSING, DRIVE SHAFT (WHITE)	1	020:W/TRANSOM(L)
1-5	52111-88L00-QTN	HOUSING, DRIVE SHAFT (WHITE)	1	(021,022,023):W/TRANSOM(S)
1-6	52111-88L00-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	(021,022,023):W/TRANSOM(S)
1-7	52111-88L10-QTN	HOUSING, DRIVE SHAFT (WHITE)	1	(021,022,023):W/TRANSOM(L)
1-8	52111-88L10-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	(021,022,023):W/TRANSOM(L)
2	09116-10181	BOLT (10X44)	8	
3	09202-08006	PIN (8X12)	2	
4-1	54221-88L20-YAY	COVER, LOWER MOUNT STBD (BLACK)	1	020 LOWER,STBD
4-2	54221-88L20-Y5S	COVER, LOWER MOUNT STBD (WHITE)	1	020 LOWER,STBD
4-3	54221-88L20-QTN	COVER, LOWER MOUNT STBD (WHITE)	1	021,022,023 LOWER,STBD
4-4	54221-88L20-YAY	COVER, LOWER MOUNT STBD (BLACK)	1	021,022,023 LOWER,STBD
5-1	54231-88L10-YAY	COVER, LOWER MOUNT PORT (BLACK)	1	020 LOWER,PORT
5-2	54231-88L10-Y5S	COVER, LOWER MOUNT PORT (WHITE)	1	020 LOWER,PORT
5-3	54231-88L10-QTN	COVER, LOWER MOUNT PORT (WHITE)	1	021,022,023 LOWER,PORT
5-4	54231-88L10-YAY	COVER, LOWER MOUNT PORT (BLACK)	1	021,022,023 LOWER,PORT
6	09116-10181	BOLT (10X44)	4	
7-1	54211-87J30-YAY	BRACKET, LOWER MOUNT (BLACK)	1	020 LOWER
7-2	54211-87J30-Y5S	BRACKET, LOWER MOUNT (WHITE)	1	020 LOWER
7-3	54211-87J30-QTN	BRACKET, LOWER MOUNT (WHITE)	1	021,022,023 LOWER
7-4	54211-87J30-YAY	BRACKET, LOWER MOUNT (BLACK)	1	021,022,023 LOWER
8	54151-88L01	MOUNT, LOWER THRUST	1	LOWER

FIG.405C




FIG.405C (1-K-11) DRIVE SHAFT HOUSING (DF40AST:E34)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
9	54160-88L10	MOUNT, LOWER	2	LOWER
10	54167-87L01	MOUNT, LOWER SIDE	2	LOWER
11	54180-88L01	DAMPER, FORWARD STOPPER	2	
12	54166-95J02	BOLT, LOWER MOUNT (12X200)	2	LOWER
13	09159-12014	NUT (12X17)	2	
14	09160-12110	WASHER (12.5X22X3)	2	

FIG.405D




FIG.405D (1-K-12) DRIVE SHAFT HOUSING (DF60A:(E01,E11))

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	52111-88L00-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	DF60A:E01:020:W/TRANSOM(S)
1-2	52111-88L00-Y5S	HOUSING, DRIVE SHAFT (WHITE)	1	DF60A:E01:020:W/TRANSOM(S)
1-3	52111-88L10-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	DF60A:E01:020:W/TRANSOM(L)
1-4	52111-88L10-Y5S	HOUSING, DRIVE SHAFT (WHITE)	1	DF60A:E01:020:W/TRANSOM(L)
1-5	52111-88L10-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	DF60A:E01:020:W/TRANSOM(X)
1-6	52111-88L10-Y5S	HOUSING, DRIVE SHAFT (WHITE)	1	DF60A:E01:020:W/TRANSOM(X)
1-7	52111-88L00-QTN	HOUSING, DRIVE SHAFT (WHITE)	1	DF60A:E11:(021,022,023): W/TRANSOM(S)
1-8	52111-88L00-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	DF60A:E11:(021,022,023): W/TRANSOM(S)
1-9	52111-88L10-QTN	HOUSING, DRIVE SHAFT (WHITE)	1	DF60A:E11:(021,022,023): W/TRANSOM(L)
1-10	52111-88L10-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	DF60A:E11:(021,022,023): W/TRANSOM(L)
1-11	52111-88L10-QTN	HOUSING, DRIVE SHAFT (WHITE)	1	DF60A:E11:(021,022,023): W/TRANSOM(X)
1-12	52111-88L10-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	DF60A:E11:(021,022,023): W/TRANSOM(X)
2	09116-10181	BOLT (10X44)	8	
3	09202-08006	PIN (8X12)	2	
4-1	54221-88L20-YAY	COVER, LOWER MOUNT STBD (BLACK)	1	DF60A:E01:020 LOWER,STBD
4-2	54221-88L20-Y5S	COVER, LOWER MOUNT STBD (WHITE)	1	DF60A:E01:020 LOWER,STBD
4-3	54221-88L20-QTN	COVER, LOWER MOUNT STBD (WHITE)	1	DF60A:E11:(021,022,023) LOWER,STBD
4-4	54221-88L20-YAY	COVER, LOWER MOUNT STBD (BLACK)	1	DF60A:E11:(021,022,023) LOWER,STBD
5-1	54231-88L10-YAY	COVER, LOWER MOUNT PORT (BLACK)	1	DF60A:E01:020 LOWER,PORT
5-2	54231-88L10-Y5S	COVER, LOWER MOUNT PORT (WHITE)	1	DF60A:E01:020 LOWER,PORT
5-3	54231-88L10-QTN	COVER, LOWER MOUNT PORT (WHITE)	1	DF60A:E11:(021,022,023) LOWER,PORT
5-4	54231-88L10-YAY	COVER, LOWER MOUNT PORT (BLACK)	1	DF60A:E11:(021,022,023) LOWER,PORT

DF60A_E11_023_405D
DRIVE SHAFT HOUSING

FIG.405D




FIG.405D (1-K-13) DRIVE SHAFT HOUSING (DF60A:(E01,E11))

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
6	09116-10181	BOLT (10X44)	4	
7-1	52131-88L00-YAY	CASE, EXTENSION (BLACK)	1	DF60A:E01:020:W/TRANSOM(X)
7-2	52131-88L00-Y5S	CASE, EXTENSION (WHITE)	1	DF60A:E01:020:W/TRANSOM(X)
7-3	52131-88L00-QTN	CASE, EXTENSION (WHITE)	1	DF60A:E11:(021,022,023): W/TRANSOM(X)
7-4	52131-88L00-YAY	CASE, EXTENSION (BLACK)	1	DF60A:E11:(021,022,023): W/TRANSOM(X)
8	09108-08254	STUD BOLT (8X162)	6	DF60A:(E01,E11):W/TRANSOM(X)
9	09202-06023	PIN (6X10)	2	DF60A:(E01,E11):W/TRANSOM(X)
10	57130-94301	BUSH, DRIVE SHAFT	1	DF60A:(E01,E11):W/TRANSOM(X)
11-1	54211-87J30-YAY	BRACKET, LOWER MOUNT (BLACK)	1	DF60A:E01:020 LOWER
11-2	54211-87J30-Y5S	BRACKET, LOWER MOUNT (WHITE)	1	DF60A:E01:020 LOWER
11-3	54211-87J30-QTN	BRACKET, LOWER MOUNT (WHITE)	1	DF60A:E11:(021,022,023) LOWER
11-4	54211-87J30-YAY	BRACKET, LOWER MOUNT (BLACK)	1	DF60A:E11:(021,022,023) LOWER
12	54151-88L01	MOUNT, LOWER THRUST	1	LOWER
13	54160-88L10	MOUNT, LOWER	2	LOWER
14	54167-87L01	MOUNT, LOWER SIDE	2	LOWER
15	54180-88L01	DAMPER, FORWARD STOPPER	2	
16	54166-95J02	BOLT, LOWER MOUNT (12X200)	2	LOWER
17	09159-12014	NUT (12X17)	2	
18	09160-12110	WASHER (12.5X22X3)	2	

DF60A_E11_023_405D
DRIVE SHAFT HOUSING

FIG.405E




FIG.405E (1-K-14) DRIVE SHAFT HOUSING (DF60A:E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	52111-88L10-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	020
1-2	52111-88L10-Y5S	HOUSING, DRIVE SHAFT (WHITE)	1	020
1-3	52111-88L10-QTN	HOUSING, DRIVE SHAFT (WHITE)	1	021,022,023
1-4	52111-88L10-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	021,022,023
2	09116-10181	BOLT (10X44)	8	
3	09202-08006	PIN (8X12)	2	
4-1	54221-88L20-YAY	COVER, LOWER MOUNT STBD (BLACK)	1	020 LOWER,STBD
4-2	54221-88L20-Y5S	COVER, LOWER MOUNT STBD (WHITE)	1	020 LOWER,STBD
4-3	54221-88L20-QTN	COVER, LOWER MOUNT STBD (WHITE)	1	021,022,023 LOWER,STBD
4-4	54221-88L20-YAY	COVER, LOWER MOUNT STBD (BLACK)	1	021,022,023 LOWER,STBD
5-1	54231-88L10-YAY	COVER, LOWER MOUNT PORT (BLACK)	1	020 LOWER,PORT
5-2	54231-88L10-Y5S	COVER, LOWER MOUNT PORT (WHITE)	1	020 LOWER,PORT
5-3	54231-88L10-QTN	COVER, LOWER MOUNT PORT (WHITE)	1	021,022,023 LOWER,PORT
5-4	54231-88L10-YAY	COVER, LOWER MOUNT PORT (BLACK)	1	021,022,023 LOWER,PORT
6	09116-10181	BOLT (10X44)	4	
7-1	52131-88L00-YAY	CASE, EXTENSION (BLACK)	1	020:W/TRANSOM(X)
7-2	52131-88L00-Y5S	CASE, EXTENSION (WHITE)	1	020:W/TRANSOM(X)
7-3	52131-88L00-QTN	CASE, EXTENSION (WHITE)	1	(021,022,023):W/TRANSOM(X)
7-4	52131-88L00-YAY	CASE, EXTENSION (BLACK)	1	(021,022,023):W/TRANSOM(X)
8	09108-08254	STUD BOLT (8X162)	6	W/TRANSOM(X)
9	09202-06023	PIN (6X10)	2	W/TRANSOM(X)
10	57130-94301	BUSH, DRIVE SHAFT	1	W/TRANSOM(X)

DF60A_E11_023_405E
DRIVE SHAFT HOUSING

FIG.405E




FIG.405E (1-K-15) DRIVE SHAFT HOUSING (DF60A:E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
11-1	54211-87J30-YAY	BRACKET, LOWER MOUNT (BLACK)	1	020 LOWER
11-2	54211-87J30-Y5S	BRACKET, LOWER MOUNT (WHITE)	1	020 LOWER
11-3	54211-87J30-QTN	BRACKET, LOWER MOUNT (WHITE)	1	021,022,023 LOWER
11-4	54211-87J30-YAY	BRACKET, LOWER MOUNT (BLACK)	1	021,022,023 LOWER
12	54151-88L01	MOUNT, LOWER THRUST	1	LOWER
13	54160-88L10	MOUNT, LOWER	2	LOWER
14	54167-87L01	MOUNT, LOWER SIDE	2	LOWER
15	54180-88L01	DAMPER, FORWARD STOPPER	2	
16	54166-95J02	BOLT, LOWER MOUNT (12X200)	2	LOWER
17	09159-12014	NUT (12X17)	2	
18	09160-12110	WASHER (12.5X22X3)	2	

FIG.405F




FIG.405F (1-L-2) DRIVE SHAFT HOUSING ((DF60AQH,DF60ATH):E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	52111-88L10-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	
2	09116-10181	BOLT (10X44)	8	
3	09202-08006	PIN (8X12)	2	
4	54221-88L20-YAY	COVER, LOWER MOUNT STBD (BLACK)	1	LOWER,STBD
5	54231-88L10-YAY	COVER, LOWER MOUNT PORT (BLACK)	1	LOWER,PORT
6	09116-10181	BOLT (10X44)	4	
7	52131-88L00-YAY	CASE, EXTENSION (BLACK)	1	W/TRANSOM(X)
8	09108-08254	STUD BOLT (8X162)	6	W/TRANSOM(X)
9	09202-06023	PIN (6X10)	2	W/TRANSOM(X)
10	57130-94301	BUSH, DRIVE SHAFT	1	W/TRANSOM(X)
11	54211-87J30-YAY	BRACKET, LOWER MOUNT (BLACK)	1	LOWER
12	54151-88L01	MOUNT, LOWER THRUST	1	LOWER
13	54160-88L10	MOUNT, LOWER	2	LOWER
14	54167-87L01	MOUNT, LOWER SIDE	2	LOWER
15	54180-88L01	DAMPER, FORWARD STOPPER	2	
16	54166-95J02	BOLT, LOWER MOUNT (12X200)	2	LOWER
17	09159-12014	NUT (12X17)	2	
18	09160-12110	WASHER (12.5X22X3)	2	

DF60A_E11_023_405F
DRIVE SHAFT HOUSING

FIG.405G




FIG.405G (1-L-3) DRIVE SHAFT HOUSING (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	52111-88L20-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	
2	09116-10181	BOLT (10X44)	8	
3	09202-08006	PIN (8X12)	2	
4	54221-88L20-YAY	COVER, LOWER MOUNT STBD (BLACK)	1	LOWER,STBD
5	54231-88L10-YAY	COVER, LOWER MOUNT PORT (BLACK)	1	LOWER,PORT
6	09116-10181	BOLT (10X44)	4	
7	52131-88L12-YAY	CASE, EXTENSION (BLACK)	1	
8	09116-08131	BOLT (8X45)	4	
9	09116-10134	BOLT (10X115)	2	
10	09202-06031	PIN (6X12)	2	
11	55321-87J01	ANODE, PROTECTION	1	
12	09103-06281	BOLT (6X14)	1	
13	54211-87J30-YAY	BRACKET, LOWER MOUNT (BLACK)	1	LOWER
14	54151-88L01	MOUNT, LOWER THRUST	1	LOWER
15	54160-88L10	MOUNT, LOWER	2	LOWER
16	54167-87L01	MOUNT, LOWER SIDE	2	LOWER
17	54180-88L01	DAMPER, FORWARD STOPPER	2	
18	54166-95J02	BOLT, LOWER MOUNT (12X200)	2	LOWER
19	09159-12014	NUT (12X17)	2	
20	09160-12110	WASHER (12.5X22X3)	2	

NOTE : DF50AVTH:E01,(DF50AVT,DF60AVT):E03

FIG.405H




FIG.405H (1-L-4) DRIVE SHAFT HOUSING (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	52111-88L20-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	W/TRANSOM(L)
1-2	52111-88L30-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	W/TRANSOM(X)
2	09116-10181	BOLT (10X44)	8	
3	09202-08006	PIN (8X12)	2	
4	54221-88L20-YAY	COVER, LOWER MOUNT STBD (BLACK)	1	LOWER,STBD
5	54231-88L10-YAY	COVER, LOWER MOUNT PORT (BLACK)	1	LOWER,PORT
6	09116-10181	BOLT (10X44)	4	
7	52131-88L12-YAY	CASE, EXTENSION (BLACK)	1	
8	09116-08131	BOLT (8X45)	4	
9	09116-10134	BOLT (10X115)	2	
10	09202-06031	PIN (6X12)	2	
11	57130-94301	BUSH, DRIVE SHAFT	1	W/TRANSOM(X)
12	55321-87J01	ANODE, PROTECTION	1	
13	09103-06281	BOLT (6X14)	1	
14	54211-87J30-YAY	BRACKET, LOWER MOUNT (BLACK)	1	LOWER
15	54151-88L01	MOUNT, LOWER THRUST	1	LOWER
16	54160-88L10	MOUNT, LOWER	2	LOWER
17	54167-87L01	MOUNT, LOWER SIDE	2	LOWER
18	54180-88L01	DAMPER, FORWARD STOPPER	2	
19	54166-95J02	BOLT, LOWER MOUNT (12X200)	2	LOWER
20	09159-12014	NUT (12X17)	2	
21	09160-12110	WASHER (12.5X22X3)	2	

NOTE : DF60AVT:(E01,E11),(DF60AVT,DF60AVTH):E40

FIG.405J




FIG.405J (1-L-5) DRIVE SHAFT HOUSING (DF40ASVT:E34)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	52111-88L20-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	020
1-2	52111-88L20-Y5S	HOUSING, DRIVE SHAFT (WHITE)	1	020
1-3	52111-88L20-QTN	HOUSING, DRIVE SHAFT (WHITE)	1	021,022,023
1-4	52111-88L20-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	021,022,023
2	09116-10181	BOLT (10X44)	8	
3	09202-08006	PIN (8X12)	2	
4-1	54221-88L20-YAY	COVER, LOWER MOUNT STBD (BLACK)	1	020 LOWER,STBD
4-2	54221-88L20-Y5S	COVER, LOWER MOUNT STBD (WHITE)	1	020 LOWER,STBD
4-3	54221-88L20-QTN	COVER, LOWER MOUNT STBD (WHITE)	1	021,022,023 LOWER,STBD
4-4	54221-88L20-YAY	COVER, LOWER MOUNT STBD (BLACK)	1	021,022,023 LOWER,STBD
5-1	54231-88L10-YAY	COVER, LOWER MOUNT PORT (BLACK)	1	020 LOWER,PORT
5-2	54231-88L10-Y5S	COVER, LOWER MOUNT PORT (WHITE)	1	020 LOWER,PORT
5-3	54231-88L10-QTN	COVER, LOWER MOUNT PORT (WHITE)	1	021,022,023 LOWER,PORT
5-4	54231-88L10-YAY	COVER, LOWER MOUNT PORT (BLACK)	1	021,022,023 LOWER,PORT
6	09116-10181	BOLT (10X44)	4	
7-1	52131-88L12-YAY	CASE, EXTENSION (BLACK)	1	020
7-2	52131-88L12-Y5S	CASE, EXTENSION (WHITE)	1	020
7-3	52131-88L12-QTN	CASE, EXTENSION (WHITE)	1	021,022,023
7-4	52131-88L12-YAY	CASE, EXTENSION (BLACK)	1	021,022,023
8	09116-08131	BOLT (8X45)	4	
9	09116-10134	BOLT (10X115)	2	
10	09202-06031	PIN (6X12)	2	
11	55321-87J01	ANODE, PROTECTION	1	
12	09103-06281	BOLT (6X14)	1	

FIG.405J




FIG.405J (1-L-6) DRIVE SHAFT HOUSING (DF40ASVT:E34)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
13-1	54211-87J30-YAY	BRACKET, LOWER MOUNT (BLACK)	1	020 LOWER
13-2	54211-87J30-Y5S	BRACKET, LOWER MOUNT (WHITE)	1	020 LOWER
13-3	54211-87J30-QTN	BRACKET, LOWER MOUNT (WHITE)	1	021,022,023 LOWER
13-4	54211-87J30-YAY	BRACKET, LOWER MOUNT (BLACK)	1	021,022,023 LOWER
14	54151-88L01	MOUNT, LOWER THRUST	1	LOWER
15	54160-88L10	MOUNT, LOWER	2	LOWER
16	54167-87L01	MOUNT, LOWER SIDE	2	LOWER
17	54180-88L01	DAMPER, FORWARD STOPPER	2	
18	54166-95J02	BOLT, LOWER MOUNT (12X200)	2	LOWER
19	09159-12014	NUT (12X17)	2	
20	09160-12110	WASHER (12.5X22X3)	2	

FIG.407A




FIG.407A (1-L-7) GEAR CASE (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55100-87J50-YAY	CASE, GEAR (BLACK)	1	(DF40A,DF50A):E01:020
1-2	55100-87J50-Y5S	CASE, GEAR (WHITE)	1	(DF40A,DF50A):E01:020
1-3	55100-87J50-YAY	CASE, GEAR (BLACK)	1	(DF40A,DF50A,DF60A):E03:020
1-4	55100-87J50-Y5S	CASE, GEAR (WHITE)	1	(DF40A,DF50A,DF60A):E03:020
1-5	55100-87J50-YAY	CASE, GEAR (BLACK)	1	DF40AST:E34:020
1-6	55100-87J50-Y5S	CASE, GEAR (WHITE)	1	DF40AST:E34:020
1-7	55100-87J50-QTN	CASE, GEAR (WHITE)	1	(DF40A,DF50A):E11:(021,022,023)
1-8	55100-87J50-YAY	CASE, GEAR (BLACK)	1	(DF40A,DF50A):E11:(021,022,023)
1-9	55100-87J50-QTN	CASE, GEAR (WHITE)	1	DF40AST:E34:(021,022,023)
1-10	55100-87J50-YAY	CASE, GEAR (BLACK)	1	DF40AST:E34:(021,022,023)
2	09263-22039	.BEARING (22X30X30)	1	
3	09265-30004	.BEARING (30X62X17.25)	1	
4	55125-94400	TAB, TRIM	1	
5	09117-08109	BOLT (8X16)	1	
6	09248-10008	PLUG (10X7.5)	3	
7	09168-10038	GASKET	3	
8	09116-08131	BOLT (8X45)	6	
9-1	58100-88LC0-019	PROPELLER (3X11-1/2X9)	1	
9-2	58100-88LD0-019	PROPELLER (3X11-1/2X10)	1	
9-3	58100-88LE0-019	PROPELLER (3X11-1/2X11)	1	
9-4	58100-88LA0-019	PROPELLER (3X11-5/8X12)	1	
9-5	58100-88LB0-019	PROPELLER (3X11-1/2X13)	1	
9-6	58100-88L52-019	PROPELLER (3X11-3/8X14)	1	
9-7	58100-88L62-019	PROPELLER (3X11-1/4X15)	1	
9-8	58100-88L72-019	PROPELLER (3X11-1/8X16)	1	
9-9	58100-88LF0-019	PROPELLER (3X11X17)	1	
9-10	58200-88L30	PROPELLER (3X11-1/2X16)	1	OPT
10	58120-88L01	.BUSH, PROPELLER	1	
11	57632-95320	STOPPER, PROPELLER BUSH	1	

NOTE : (DF40A,DF50A):E01,(DF40A,DF50A,DF60A):E03,
(DF40A,DF50A):E11,DF40AST:E34

FIG.407A




FIG.407A (1-L-8) GEAR CASE (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
12	57633-94301	SPACER, PROPELLER NUT	1	
13	09141-18005	NUT (M18)	1	
14	09204-03003	PIN (D:3.6,L:25)	1	
15	09160-18028	WASHER (18.5X31X1.0)	1	
16	57630-94301	KIT, PROPELLER NUT	1	OPT
17	55181-95200	ATTACHMENT, FLUSH HOSE	1	OPT
18	55300-95500	ZINC ASSY, PROTECTION	1	OPT
19	55321-87J11	ANODE	1	OPT
20	25700-88L04	KIT, GEAR CASE	1	OPT,NOT ILLUSTRATED

NOTE : (DF40A,DF50A):E01,(DF40A,DF50A,DF60A):E03,
(DF40A,DF50A):E11,DF40AST:E34

FIG.407B




FIG.407B (1-L-9) GEAR CASE (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	55100-87J50-YAY	CASE ASSY, GEAR (BLACK)	1	
2	09263-22039	.BEARING (22X30X30)	1	
3	09265-30004	.BEARING (30X62X17.25)	1	
4	55125-94400	TAB, TRIM	1	
5	09117-08109	BOLT (8X16)	1	
6	09248-10008	PLUG (10X7.5)	3	
7	09168-10038	GASKET	3	
8	09116-08131	BOLT (8X45)	6	
9-1	58100-88LC0-019	PROPELLER (3X11-1/2X9)	1	
9-2	58100-88LD0-019	PROPELLER (3X11-1/2X10)	1	
9-3	58100-88LE0-019	PROPELLER (3X11-1/2X11)	1	
9-4	58100-88LA0-019	PROPELLER (3X11-5/8X12)	1	
9-5	58100-88LB0-019	PROPELLER (3X11-1/2X13)	1	
9-6	58100-88L52-019	PROPELLER (3X11-3/8X14)	1	
9-7	58100-88L62-019	PROPELLER (3X11-1/4X15)	1	
9-8	58100-88L72-019	PROPELLER (3X11-1/8X16)	1	
9-9	58100-88LF0-019	PROPELLER (3X11X17)	1	
9-10	58200-88L30	PROPELLER (3X11-1/2X16)	1	OPT
10	58120-88L01	.BUSH, PROPELLER	1	
11	57632-95320	STOPPER, PROPELLER BUSH	1	
12	57633-94301	SPACER, PROPELLER NUT	1	
13	09141-18005	NUT (M18)	1	
14	09204-03003	PIN (D:3.6,L:25)	1	
15	09160-18028	WASHER (18.5X31X1.0)	1	
16	57630-94301	KIT, PROPELLER NUT	1	OPT
17	55181-95200	ATTACHMENT, FLUSH HOSE	1	OPT
18	55300-95500	ZINC ASSY, PROTECTION	1	OPT
19	55321-87J11	ANODE	1	OPT
20	25700-88L04	KIT, GEAR CASE	1	OPT,NOT ILLUSTRATED

NOTE : (DF40AQH,DF40ATH,DF50ATH,DF60ATH):E01

FIG.407C




FIG.407C (1-L-10) GEAR CASE (DF60A:(E01,E11))

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55100-87J50-YAY	CASE, GEAR (BLACK)	1	E01:020
1-2	55100-87J50-Y5S	CASE, GEAR (WHITE)	1	E01:020
1-3	55100-87J50-QTN	CASE, GEAR (WHITE)	1	E11:(021,022,023)
1-4	55100-87J50-YAY	CASE, GEAR (BLACK)	1	E11:(021,022,023)
2	09263-22039	.BEARING (22X30X30)	1	
3	09265-30004	.BEARING (30X62X17.25)	1	
4	55125-94400	TAB, TRIM	1	
5	09117-08109	BOLT (8X16)	1	
6	09248-10008	PLUG (10X7.5)	3	
7	09168-10038	GASKET	3	
8-1	09116-08131	BOLT (8X45)	6	W/TRANSOM(S)
8-2	09116-08131	BOLT (8X45)	6	W/TRANSOM(L)
9	09140-08016	NUT	6	W/TRANSOM(X)
10	09160-08082	WASHER (8.5X16X1.2)	6	W/TRANSOM(X)
11-1	58100-88LC0-019	PROPELLER (3X11-1/2X9)	1	
11-2	58100-88LD0-019	PROPELLER (3X11-1/2X10)	1	
11-3	58100-88LE0-019	PROPELLER (3X11-1/2X11)	1	
11-4	58100-88LA0-019	PROPELLER (3X11-5/8X12)	1	
11-5	58100-88LB0-019	PROPELLER (3X11-1/2X13)	1	
11-6	58100-88L52-019	PROPELLER (3X11-3/8X14)	1	
11-7	58100-88L62-019	PROPELLER (3X11-1/4X15)	1	
11-8	58100-88L72-019	PROPELLER (3X11-1/8X16)	1	
11-9	58100-88LF0-019	PROPELLER (3X11X17)	1	
11-10	58200-88L30	PROPELLER (3X11-1/2X16)	1	OPT
12	58120-88L01	.BUSH, PROPELLER	1	
13	57632-95320	STOPPER, PROPELLER BUSH	1	
14	57633-94301	SPACER, PROPELLER NUT	1	
15	09141-18005	NUT (M18)	1	
16	09204-03003	PIN (D:3.6,L:25)	1	
17	09160-18028	WASHER (18.5X31X1.0)	1	
18	57630-94301	KIT, PROPELLER NUT	1	OPT
19	55181-95200	ATTACHMENT, FLUSH HOSE	1	OPT
20	55300-95500	ZINC ASSY, PROTECTION	1	OPT
21	55321-87J11	ANODE	1	OPT
22	25700-88L04	KIT, GEAR CASE	1	OPT,NOT ILLUSTRATED

FIG.407D




FIG.407D (1-L-11) GEAR CASE (DF60A:E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55100-87J50-YAY	CASE, GEAR (BLACK)	1	020
1-2	55100-87J50-Y5S	CASE, GEAR (WHITE)	1	020
1-3	55100-87J50-QTN	CASE, GEAR (WHITE)	1	021,022,023
1-4	55100-87J50-YAY	CASE, GEAR (BLACK)	1	021,022,023
2	09263-22039	.BEARING (22X30X30)	1	
3	09265-30004	.BEARING (30X62X17.25)	1	
4	55125-94400	TAB, TRIM	1	
5	09117-08109	BOLT (8X16)	1	
6	09248-10008	PLUG (10X7.5)	3	
7	09168-10038	GASKET	3	
8	09116-08131	BOLT (8X45)	6	W/TRANSOM(L)
9	09140-08016	NUT	6	W/TRANSOM(X)
10	09160-08082	WASHER (8.5X16X1.2)	6	W/TRANSOM(X)
11-1	58100-88LC0-019	PROPELLER (3X11-1/2X9)	1	
11-2	58100-88LD0-019	PROPELLER (3X11-1/2X10)	1	
11-3	58100-88LE0-019	PROPELLER (3X11-1/2X11)	1	
11-4	58100-88LA0-019	PROPELLER (3X11-5/8X12)	1	
11-5	58100-88LB0-019	PROPELLER (3X11-1/2X13)	1	
11-6	58100-88L52-019	PROPELLER (3X11-3/8X14)	1	
11-7	58100-88L62-019	PROPELLER (3X11-1/4X15)	1	
11-8	58100-88L72-019	PROPELLER (3X11-1/8X16)	1	
11-9	58100-88LF0-019	PROPELLER (3X11X17)	1	
11-10	58200-88L30	PROPELLER (3X11-1/2X16)	1	OPT
12	58120-88L01	.BUSH, PROPELLER	1	
13	57632-95320	STOPPER, PROPELLER BUSH	1	
14	57633-94301	SPACER, PROPELLER NUT	1	
15	09141-18005	NUT (M18)	1	
16	09204-03003	PIN (D:3.6,L:25)	1	
17	09160-18028	WASHER (18.5X31X1.0)	1	
18	57630-94301	KIT, PROPELLER NUT	1	OPT
19	55181-95200	ATTACHMENT, FLUSH HOSE	1	OPT
20	55300-95500	ZINC ASSY, PROTECTION	1	OPT
21	55321-87J11	ANODE	1	OPT
22	25700-88L04	KIT, GEAR CASE	1	OPT,NOT ILLUSTRATED

FIG.407E




FIG.407E (1-L-12) GEAR CASE ((DF60AQH,DF60ATH):E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	55100-87J50-YAY	CASE ASSY, GEAR (BLACK)	1	
2	09263-22039	.BEARING (22X30X30)	1	
3	09265-30004	.BEARING (30X62X17.25)	1	
4	55125-94400	TAB, TRIM	1	
5	09117-08109	BOLT (8X16)	1	
6	09248-10008	PLUG (10X7.5)	3	
7	09168-10038	GASKET	3	
8	09116-08131	BOLT (8X45)	6	W/TRANSOM(L)
9	09140-08016	NUT	6	W/TRANSOM(X)
10	09160-08082	WASHER (8.5X16X1.2)	6	W/TRANSOM(X)
11-1	58100-88LC0-019	PROPELLER (3X11-1/2X9)	1	
11-2	58100-88LD0-019	PROPELLER (3X11-1/2X10)	1	
11-3	58100-88LE0-019	PROPELLER (3X11-1/2X11)	1	
11-4	58100-88LA0-019	PROPELLER (3X11-5/8X12)	1	
11-5	58100-88LB0-019	PROPELLER (3X11-1/2X13)	1	
11-6	58100-88L52-019	PROPELLER (3X11-3/8X14)	1	
11-7	58100-88L62-019	PROPELLER (3X11-1/4X15)	1	
11-8	58100-88L72-019	PROPELLER (3X11-1/8X16)	1	
11-9	58100-88LF0-019	PROPELLER (3X11X17)	1	
11-10	58200-88L30	PROPELLER (3X11-1/2X16)	1	OPT
12	58120-88L01	.BUSH, PROPELLER	1	
13	57632-95320	STOPPER, PROPELLER BUSH	1	
14	57633-94301	SPACER, PROPELLER NUT	1	
15	09141-18005	NUT (M18)	1	
16	09204-03003	PIN (D:3.6,L:25)	1	
17	09160-18028	WASHER (18.5X31X1.0)	1	
18	57630-94301	KIT, PROPELLER NUT	1	OPT
19	55181-95200	ATTACHMENT, FLUSH HOSE	1	OPT
20	55300-95500	ZINC ASSY, PROTECTION	1	OPT
21	55321-87J11	ANODE	1	OPT
22	25700-88L04	KIT, GEAR CASE	1	OPT,NOT ILLUSTRATED

FIG.407F




FIG.407F (1-L-13) GEAR CASE (DF50AVT,DF50AVTH,DF60AVT,DF60AVTH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	55110-90J16-YAY	CASE, GEAR (BLACK)	1	
2	09263-28016	.BEARING (28.6X38X31.8)	1	
3	55125-90J01	TAB, TRIM	1	
4	55127-87D00	UNION, SPEEDOMETER HOSE	1	
5	55321-90J01	ANODE, GEAR CASE	1	
6	55332-87D12	RUBBER, EXHAUST SEAL	1	
7	55333-87D10	PLATE, EXHAUST SEAL	1	
8	09100-06131	BOLT (6X12)	1	
9	09116-08137	BOLT (8X22)	1	
10	09116-10150	BOLT (10X55)	6	
11	09117-10039	BOLT (10X80)	1	
12	09160-06085	WASHER (6.5X15X1)	1	
13	09168-10038	GASKET	2	
14	09202-08006	PIN (8X12)	2	
15	09248-10008	PLUG (10X7.5)	2	
16	09355-40805-600	HOSE (4X8X600)	1	L:600->70
17	09362-09008	UNION	1	
18	09407-10404	CLAMP (L:100)	2	
19-1	58100-87LA0-019	PROPELLER (3X14X13)	1	
19-2	58100-87LB0-019	PROPELLER (3X13.875X15)	1	
19-3	58100-87LC0-019	PROPELLER (3X13.75X17)	1	
19-4	58100-87LJ0-019	PROPELLER (3X13.75X12)	1	
19-5	58100-87LH0-019	PROPELLER (3X14X11)	1	
19-6	58100-87LG1-019	PROPELLER (3X14X9)	1	
20	58105-90J00	.BUSH SET, PROPELLER	1	
21	57633-90J02	SPACER, PROPELLER NUT	1	
22	57635-90J01	STOPPER, PROPELLER BUSH	1	
23	09141-18005	NUT (M18)	1	
24	09160-18028	WASHER (18.5X31X1.0)	1	
25	09204-03003	PIN (D:3.6,L:25)	1	
26	57630-90J00	KIT, PROPELLER NUT	1	OPT
27	55300-95500	ZINC ASSY, PROTECTION	1	OPT
28	55181-95200	ATTACHMENT, FLUSH HOSE	1	OPT
29	56145-99E01	HOUSING, SHIFT CAM	1	
30	09206-09012	PIN (7.4X9X10)	2	
31	01550-0630C	BOLT	3	

DF60A_E11_023_407F
GEAR CASE

FIG.407F




FIG.407F (1-L-14) GEAR CASE (DF50AVT,DF50AVTH,DF60AVT,DF60AVTH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
32	25700-99E01	SEALING KIT, GEAR CASE	1	OPT,NOT ILLUSTRATED

DF60A_E11_023_407F
GEAR CASE

FIG.407G




FIG.407G (2-B-2) GEAR CASE (DF40ASVT:E34)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55110-90J16-YAY	CASE, GEAR (BLACK)	1	020
1-2	55110-90J16-Y5S	CASE, GEAR (WHITE)	1	020
1-3	55110-90J16-QTN	CASE, GEAR (WHITE)	1	021,022,023
1-4	55110-90J16-YAY	CASE, GEAR (BLACK)	1	021,022,023
2	09263-28016	.BEARING (28.6X38X31.8)	1	
3	55125-90J01	TAB, TRIM	1	
4	55127-87D00	UNION, SPEEDOMETER HOSE	1	
5	55321-90J01	ANODE, GEAR CASE	1	
6	55332-87D12	RUBBER, EXHAUST SEAL	1	
7	55333-87D10	PLATE, EXHAUST SEAL	1	
8	09100-06131	BOLT (6X12)	1	
9	09116-08137	BOLT (8X22)	1	
10	09116-10150	BOLT (10X55)	6	
11	09117-10039	BOLT (10X80)	1	
12	09160-06085	WASHER (6.5X15X1)	1	
13	09168-10038	GASKET	2	
14	09202-08006	PIN (8X12)	2	
15	09248-10008	PLUG (10X7.5)	2	
16	09355-40805-600	HOSE (4X8X600)	1	L:600->70
17	09362-09008	UNION	1	
18	09407-10404	CLAMP (L:100)	2	
19-1	58100-87LA0-019	PROPELLER (3X14X13)	1	
19-2	58100-87LB0-019	PROPELLER (3X13.875X15)	1	
19-3	58100-87LC0-019	PROPELLER (3X13.75X17)	1	
19-4	58100-87LJ0-019	PROPELLER (3X13.75X12)	1	
19-5	58100-87LH0-019	PROPELLER (3X14X11)	1	
19-6	58100-87LG1-019	PROPELLER (3X14X9)	1	
20	58105-90J00	.BUSH SET, PROPELLER	1	
21	57633-90J02	SPACER, PROPELLER NUT	1	
22	57635-90J01	STOPPER, PROPELLER BUSH	1	
23	09141-18005	NUT (M18)	1	
24	09160-18028	WASHER (18.5X31X1.0)	1	
25	09204-03003	PIN (D:3.6,L:25)	1	
26	57630-90J00	KIT, PROPELLER NUT	1	OPT
27	55300-95500	ZINC ASSY, PROTECTION	1	OPT
28	55181-95200	ATTACHMENT, FLUSH HOSE	1	OPT

DF60A_E11_023_407G
GEAR CASE

FIG.407G




FIG.407G (2-B-3) GEAR CASE (DF40ASVT:E34)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	56145-99E01	HOUSING, SHIFT CAM	1	
30	09206-09012	PIN (7.4X9X10)	2	
31	01550-0630C	BOLT	3	
32	25700-99E00	SEALING KIT, GEAR CASE	1	OPT,NOT ILLUSTRATED

DF60A_E11_023_407G
GEAR CASE

FIG.410A




FIG.410A (2-B-4) SIDE COVER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61112-88L10	RUBBER, SIDE COVER	1	
2	61134-88L11	SEAL, SIDE COVER	1	
3-1	61811-88L30-YAY	COVER, SIDE STBD (BLACK)	1	(DF40A,DF40AST,DF50A,DF60A): 020:W/TRANSOM(S) STBD
3-2	61811-88L30-Y5S	COVER, SIDE STBD (WHITE)	1	(DF40A,DF40AST,DF50A,DF60A): 020:W/TRANSOM(S) STBD
3-3	61811-88L20-YAY	COVER, SIDE STBD (BLACK)	1	(DF40A,DF40AQH,DF40ATH, DF40AST,DF50A,DF50ATH,DF60A, DF60AQH,DF60ATH,DF40ASVT):020: W/TRANSOM(L) STBD
3-4	61811-88L20-Y5S	COVER, SIDE STBD (WHITE)	1	(DF40A,DF40AQH,DF40ATH, DF40AST,DF50A,DF50ATH,DF60A, DF60AQH,DF60ATH,DF40ASVT):020: W/TRANSOM(L) STBD
3-5	61811-88L20-YAY	COVER, SIDE STBD (BLACK)	1	(DF60A,DF60AQH,DF60ATH):020: W/TRANSOM(X) STBD
3-6	61811-88L20-Y5S	COVER, SIDE STBD (WHITE)	1	(DF60A,DF60AQH,DF60ATH):020: W/TRANSOM(X) STBD
3-7	61811-88L30-QTN	COVER, SIDE STBD (WHITE)	1	(DF40A,DF40AST,DF50A,DF40ASVT, (DF60A:E11)):(021,022,023): W/TRANSOM(S) STBD

NOTE : DF40A,DF40AQH,DF40ATH,DF40AST,DF50A,DF50ATH,DF60A,DF60AQH, DF60ATH,DF40ASVT

DF60A_E11_023_410A
SIDE COVER

FIG.410A




FIG.410A (2-B-5) SIDE COVER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
3-8	61811-88L30-YAY	COVER, SIDE STBD (BLACK)	1	(DF40A,DF40AST,DF50A,DF40ASVT, (DF60A:E11)):(021,022,023): W/TRANSOM(S) STBD
3-9	61811-88L20-QTN	COVER, SIDE STBD (WHITE)	1	(DF40A,DF50A,DF60A): (021,022,023):W/TRANSOM(L) STBD
3-10	61811-88L20-YAY	COVER, SIDE STBD (BLACK)	1	(DF40A,DF40AQH,DF40ATH, DF40AST,DF50A,DF50ATH,DF60A, DF60AQH,DF60ATH):(021,022, 023):W/TRANSOM(L) STBD
3-11	61811-88L20-QTN	COVER, SIDE STBD (WHITE)	1	DF60A:(021,022,023): W/TRANSOM(X) STBD
3-12	61811-88L20-YAY	COVER, SIDE STBD (BLACK)	1	(DF60A,DF60AQH,DF60ATH): (021,022,023):W/TRANSOM(X) STBD
4-1	61821-88L30-YAY	COVER, SIDE PORT (BLACK)	1	(DF40A,DF40AST,DF50A,DF60A): 020:W/TRANSOM(S) PORT
4-2	61821-88L30-Y5S	COVER, SIDE PORT (WHITE)	1	(DF40A,DF40AST,DF50A,DF60A): 020:W/TRANSOM(S) PORT
4-3	61821-88L20-YAY	COVER, SIDE PORT (BLACK)	1	(DF40A,DF40AQH,DF40ATH, DF40AST,DF50A,DF50ATH,DF60A, DF60AQH,DF60ATH,DF40ASVT):020: W/TRANSOM(L) PORT

NOTE : DF40A,DF40AQH,DF40ATH,DF40AST,DF50A,DF50ATH,DF60A,DF60AQH, DF60ATH,DF40ASVT

FIG.410A




FIG.410A (2-B-6) SIDE COVER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
4-4	61821-88L20-Y5S	COVER, SIDE PORT (WHITE)	1	(DF40A,DF40AQH,DF40ATH, DF40AST,DF50A,DF50ATH,DF60A, DF60AQH,DF60ATH,DF40ASVT):020: W/TRANSOM(L) PORT
4-5	61821-88L20-YAY	COVER, SIDE PORT (BLACK)	1	(DF60A,DF60AQH,DF60ATH):020: W/TRANSOM(X) PORT
4-6	61821-88L20-Y5S	COVER, SIDE PORT (WHITE)	1	(DF60A,DF60AQH,DF60ATH):020: W/TRANSOM(X) PORT
4-7	61821-88L30-QTN	COVER, SIDE PORT (WHITE)	1	(DF40A,DF40AST,DF50A,DF40ASVT, (DF60A:E11)):(021,022,023): W/TRANSOM(S) PORT
4-8	61821-88L30-YAY	COVER, SIDE PORT (BLACK)	1	(DF40A,DF40AST,DF50A,DF40ASVT, (DF60A:E11)):(021,022,023): W/TRANSOM(S) PORT
4-9	61821-88L20-QTN	COVER, SIDE PORT (WHITE)	1	(DF40A,DF50A,DF60A): (021,022,023):W/TRANSOM(L) PORT
4-10	61821-88L20-YAY	COVER, SIDE PORT (BLACK)	1	(DF40A,DF40AQH,DF40ATH, DF40AST,DF50A,DF50ATH,DF60A, DF60AQH,DF60ATH):(021,022, 023):W/TRANSOM(L) PORT
4-11	61821-88L20-QTN	COVER, SIDE PORT (WHITE)	1	DF60A:(021,022,023): W/TRANSOM(X) PORT

NOTE : DF40A,DF40AQH,DF40ATH,DF40AST,DF50A,DF50ATH,DF60A,DF60AQH, DF60ATH,DF40ASVT

FIG.410A




FIG.410A (2-B-7) SIDE COVER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
4-12	61821-88L20-YAY	COVER, SIDE PORT (BLACK)	1	(DF60A,DF60AQH,DF60ATH): (021,022,023):W/TRANSOM(X) PORT
5-1	09136-06148	SCREW (6X35)	9	(DF40A,DF40AST,DF50A,DF60A): W/TRANSOM(S)
5-2	09136-06148	SCREW (6X35)	10	(DF40A,DF40AQH,DF40ATH, DF40AST,DF50A,DF50ATH,DF60A, DF60AQH,DF60ATH,DF40ASVT): W/TRANSOM(L)
5-3	09136-06148	SCREW (6X35)	10	(DF60A,DF60AQH,DF60ATH): W/TRANSOM(X)
6	61151-88L01	CUSHION, SIDE COVER	1	
7-1	61831-88L10-YAY	PANEL, FRONT (BLACK)	1	(DF40A,DF40AQH,DF40ATH, DF40AST,DF50A,DF50ATH,DF60A, DF60AQH,DF60ATH,DF40ASVT):020
7-2	61831-88L10-Y5S	PANEL, FRONT (WHITE)	1	(DF40A,DF40AQH,DF40ATH, DF40AST,DF50A,DF50ATH,DF60A, DF60AQH,DF60ATH,DF40ASVT):020
7-3	61831-88L10-QTN	PANEL, FRONT (WHITE)	1	(DF40A,DF40AST,DF50A,DF60A, DF40ASVT):(021,022,023)
7-4	61831-88L10-YAY	PANEL, FRONT (BLACK)	1	(DF40A,DF40AQH,DF40ATH, DF40AST,DF50A,DF50ATH,DF60A, DF60AQH,DF60ATH,DF40ASVT): (021,022,023)
8	09116-08174	BOLT (8X38)	2	
9	09169-08050	WASHER (ID:8.5)	2	
10	09320-11023	CUSHION	2	
11	61412-88L00	HOOK, FRONT PANEL	1	
12	03542-05169	SCREW	2	
13	61632-93J00	SHAFT, ENGINE COVER HOOK	1	
14	61641-88L00	HOOK, ENGINE COVER	1	

NOTE : DF40A,DF40AQH,DF40ATH,DF40AST,DF50A,DF50ATH,DF60A,DF60AQH, DF60ATH,DF40ASVT

FIG.410A




FIG.410A (2-B-8) SIDE COVER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
15	09116-06127	BOLT (6X12)	1	
16	61633-88L00	LEVER, HOOK REAR	1	
17	09160-13014	WASHER (13.2X25X1)	1	
18	09164-14008	WASHER	1	
19	09202-04022	PIN	1	
20	09306-13007	BUSH	1	
21	09352-50901-600	HOSE (5X9X600)	1	L:600->20
22	61673-93J11	LATCH, HOOK LEVER	1	
23	09103-05026	BOLT (5X10)	2	
24	61124-88L11	GROMMET, R/CON CABLE	1	
25	09407-20405	CLAMP (L:202)	1	

NOTE : DF40A,DF40AQH,DF40ATH,DF40AST,DF50A,DF50ATH,DF60A,DF60AQH,
DF60ATH,DF40ASVT

FIG.410B




FIG.410B (2-B-9) SIDE COVER (DF50AVT,DF50AVTH,DF60AVT,DF60AVTH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61112-88L10	RUBBER, SIDE COVER	1	
2	61134-88L11	SEAL, SIDE COVER	1	
3-1	61811-88L30-YAY	COVER, SIDE STBD (BLACK)	1	(DF50AVT,DF50AVTH,DF60AVT, DF60AVTH):W/TRANSOM(L) STBD
3-2	61811-88L20-YAY	COVER, SIDE STBD (BLACK)	1	(DF60AVT,DF60AVTH): W/TRANSOM(X) STBD
4-1	61821-88L30-YAY	COVER, SIDE PORT (BLACK)	1	(DF50AVT,DF50AVTH,DF60AVT, DF60AVTH):W/TRANSOM(L) PORT
4-2	61821-88L20-YAY	COVER, SIDE PORT (BLACK)	1	(DF60AVT,DF60AVTH): W/TRANSOM(X) PORT
5-1	09136-06148	SCREW (6X35)	9	(DF50AVT,DF50AVTH,DF60AVT, DF60AVTH):W/TRANSOM(L)
5-2	09136-06148	SCREW (6X35)	10	(DF60AVT,DF60AVTH): W/TRANSOM(X)
6	61151-88L01	CUSHION, SIDE COVER	1	
7	61831-88L10-YAY	PANEL, FRONT (BLACK)	1	
8	09116-08174	BOLT (8X38)	2	
9	09169-08050	WASHER (ID:8.5)	2	
10	09320-11023	CUSHION	2	
11	61412-88L00	HOOK, FRONT PANEL	1	
12	03542-05169	SCREW	2	
13	61632-93J00	SHAFT, ENGINE COVER HOOK	1	
14	61641-88L00	HOOK, ENGINE COVER	1	
15	09116-06127	BOLT (6X12)	1	
16	61633-88L00	LEVER, HOOK REAR	1	
17	09160-13014	WASHER (13.2X25X1)	1	
18	09164-14008	WASHER	1	
19	09202-04022	PIN	1	
20	09306-13007	BUSH	1	
21	09352-50901-600	HOSE (5X9X600)	1	L:600->20
22	61673-93J11	LATCH, HOOK LEVER	1	
23	09103-05026	BOLT (5X10)	2	

FIG.410B




FIG.410B (2-B-10) SIDE COVER (DF50AVT,DF50AVTH,DF60AVT,DF60AVTH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
24	61124-88L11	GROMMET, R/CON CABLE	1	
25	09407-20405	CLAMP (L:202)	1	

FIG.420A




FIG.420A (2-B-11) ENGINE COVER ((DF40A,DF40AQH,DF40ATH):E01:020)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-88822-YAY	COVER SET, ENGINE (BLACK)	1	
1-2	61400-88832-Y5S	COVER SET, ENGINE (WHITE)	1	
2-1	61431-88L10-YAY	.HANDLE, TILT UP (BLACK)	1	
2-2	61431-88L10-Y5S	.HANDLE, TILT UP (WHITE)	1	
3	61438-88L01	.SEAL, GRIP	1	
4	61439-88L01	.SEAL, TILT UP HANDLE NO.2	1	
5	03542-06169	.SCREW	5	
6	61476-88L00	.SEAL, AIR VENT	1	
7	61610-95J00	.FASTENER, REAR	1	
8	09159-06084	.NUT (M6)	1	
9-1	61443-88L20	.STRIPE, ENGINE COVER STBD	1	STBD FOR YAY
9-2	61443-88L30	.STRIPE, ENGINE COVER STBD	1	STBD FOR Y5S
10-1	61453-88L20	.STRIPE, ENGINE COVER PORT	1	PORT FOR YAY
10-2	61453-88L30	.STRIPE, ENGINE COVER PORT	1	PORT FOR Y5S
11	68111-88L10	.EMBLEM, S	1	
12	61620-95J00	.BRACKET, REAR FASTENER	1	
13	61631-88L10	.HOOK, FRONT	1	
14	09229-04018	.RIVET	2	
15	09229-04005	.RIVET	2	
16-1	61422-88L30	MARK, EMBLEM FRONT	1	FOR YAY
16-2	61422-88L60	MARK, EMBLEM FRONT	1	FOR Y5S
17-1	61435-88L60	MARK, EMBLEM REAR	1	FOR YAY
17-2	61435-88L90	MARK, EMBLEM REAR	1	FOR Y5S
18	61458-90J01	LABEL, ENGINE COVER	1	
19	09800-81812	TOOL ASSY	1	
20	18210-88L00	KNOB ASSY, STARTER	1	
21-1	99011-88L92-054	MANUAL, OWNER'S	1	
21-2	99011-88L91-059	MANUAL, OWNER'S	1	
22	17917-87L00	CONNECTOR, FLUSH WATER	1	

DF60A_E11_023_420A
ENGINE COVER

FIG.420B




FIG.420B (2-B-12) ENGINE COVER (DF40A:E03:020)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-88822-YAY	COVER SET, ENGINE (BLACK)	1	
1-2	61400-88832-Y5S	COVER SET, ENGINE (WHITE)	1	
2-1	61431-88L10-YAY	.HANDLE, TILT UP (BLACK)	1	
2-2	61431-88L10-Y5S	.HANDLE, TILT UP (WHITE)	1	
3	61438-88L01	.SEAL, GRIP	1	
4	61439-88L01	.SEAL, TILT UP HANDLE NO.2	1	
5	03542-06169	.SCREW	5	
6	61476-88L00	.SEAL, AIR VENT	1	
7	61610-95J00	.FASTENER, REAR	1	
8	09159-06084	.NUT (M6)	1	
9-1	61443-88L20	.STRIPE, ENGINE COVER STBD	1	STBD FOR YAY
9-2	61443-88L30	.STRIPE, ENGINE COVER STBD	1	STBD FOR Y5S
10-1	61453-88L20	.STRIPE, ENGINE COVER PORT	1	PORT FOR YAY
10-2	61453-88L30	.STRIPE, ENGINE COVER PORT	1	PORT FOR Y5S
11	68111-88L10	.EMBLEM, S	1	
12	61620-95J00	.BRACKET, REAR FASTENER	1	
13	61631-88L10	.HOOK, FRONT	1	
14	09229-04018	.RIVET	2	
15	09229-04005	.RIVET	2	
16-1	61422-88L30	MARK, EMBLEM FRONT	1	FOR YAY
16-2	61422-88L60	MARK, EMBLEM FRONT	1	FOR Y5S
17-1	61435-88L60	MARK, EMBLEM REAR	1	FOR YAY
17-2	61435-88L90	MARK, EMBLEM REAR	1	FOR Y5S
18	61458-90J01	LABEL, ENGINE COVER	1	
19	09800-81812	TOOL ASSY	1	
20	18210-88L00	KNOB ASSY, STARTER	1	
21-1	99011-88L92-054	MANUAL, OWNER'S	1	
21-2	99011-88L91-03B	MANUAL, OWNER'S	1	
22	17917-87L00	CONNECTOR, FLUSH WATER	1	

DF60A_E11_023_420B
ENGINE COVER

FIG.420C




FIG.420C (2-B-13) ENGINE COVER (DF40A:E11:(021,022,023))

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-88850-QTN	COVER SET, ENGINE (WHITE)	1	
1-2	61400-88840-YAY	COVER SET, ENGINE (BLACK)	1	
2-1	61431-88L10-QTN	.HANDLE, TILT UP (WHITE)	1	
2-2	61431-88L10-YAY	.HANDLE, TILT UP (BLACK)	1	
3	61438-88L01	.SEAL, GRIP	1	
4	61439-88L01	.SEAL, TILT UP HANDLE NO.2	1	
5	03542-06169	.SCREW	5	
6	61476-88L00	.SEAL, AIR VENT	1	
7	61610-95J00	.FASTENER, REAR	1	
8	09159-06084	.NUT (M6)	1	
9	68111-88L10	.EMBLEM, S	1	
10	61620-95J00	.BRACKET, REAR FASTENER	1	
11	61631-88L10	.HOOK, FRONT	1	
12	09229-04018	.RIVET	2	
13	09229-04005	.RIVET	2	
14-1	61443-88L50	.STRIPE, ENGINE COVER STBD	1	STBD FOR QTN
14-2	61443-88L40	.STRIPE, ENGINE COVER STBD	1	STBD FOR YAY
15-1	61453-88L50	.STRIPE, ENGINE COVER PORT	1	PORT FOR QTN
15-2	61453-88L40	.STRIPE, ENGINE COVER PORT	1	PORT FOR YAY
16-1	61435-88LD0	MARK, EMBLEM REAR	1	FOR QTN
16-2	61435-88LC0	MARK, EMBLEM REAR	1	FOR YAY
17	61458-90J01	LABEL, ENGINE COVER	1	
18	09800-81812	TOOL ASSY	1	
19	18210-88L00	KNOB ASSY, STARTER	1	

DF60A_E11_023_420C
ENGINE COVER

FIG.420C




FIG.420C (2-B-14) ENGINE COVER (DF40A:E11:(021,022,023))

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20-1	99011-88L92-054	MANUAL, OWNER'S	1	021
20-2	99011-88LA0-054	MANUAL, OWNER'S	1	022
20-3	99011-88LB0-054	MANUAL, OWNER'S	1	023
20-4	99011-88L91-059	MANUAL, OWNER'S	1	021
20-5	99011-88LA0-059	MANUAL, OWNER'S	1	022
20-6	99011-88LB0-059	MANUAL, OWNER'S	1	023
20-7	99011-88L91-03B	MANUAL, OWNER'S	1	021
20-8	99011-88LA0-03B	MANUAL, OWNER'S	1	022
20-9	99011-88LB0-03B	MANUAL, OWNER'S	1	023
21	17917-87L00	CONNECTOR, FLUSH WATER	1	

DF60A_E11_023_420C
ENGINE COVER

FIG.420D




FIG.420D (2-C-2) ENGINE COVER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-88840-YAY	COVER SET, ENGINE (BLACK)	1	
2	61431-88L10-YAY	.HANDLE, TILT UP (BLACK)	1	
3	61438-88L01	.SEAL, GRIP	1	
4	61439-88L01	.SEAL, TILT UP HANDLE NO.2	1	
5	03542-06169	.SCREW	5	
6	61476-88L00	.SEAL, AIR VENT	1	
7	61610-95J00	.FASTENER, REAR	1	
8	09159-06084	.NUT (M6)	1	
9	68111-88L10	.EMBLEM, S	1	
10	61620-95J00	.BRACKET, REAR FASTENER	1	
11	61631-88L10	.HOOK, FRONT	1	
12	09229-04018	.RIVET	2	
13	09229-04005	.RIVET	2	
14	61443-88L40	.STRIPE, ENGINE COVER STBD	1	STBD
15	61453-88L40	.STRIPE, ENGINE COVER PORT	1	PORT
16	61435-88LC0	MARK, EMBLEM REAR	1	
17	61458-90J01	LABEL, ENGINE COVER	1	
18	09800-81812	TOOL ASSY	1	
19	18210-88L00	KNOB ASSY, STARTER	1	
20-1	99011-88L92-054	MANUAL, OWNER'S	1	021
20-2	99011-88LA0-054	MANUAL, OWNER'S	1	022
20-3	99011-88LB0-054	MANUAL, OWNER'S	1	023
20-4	99011-88L91-059	MANUAL, OWNER'S	1	021
20-5	99011-88LA0-059	MANUAL, OWNER'S	1	022
20-6	99011-88LB0-059	MANUAL, OWNER'S	1	023
21	17917-87L00	CONNECTOR, FLUSH WATER	1	

NOTE : (DF40AQH,DF40ATH):E01:(021,022,023)

DF60A_E11_023_420D
ENGINE COVER

FIG.420E




FIG.420E (2-C-3) ENGINE COVER ((DF40AST,DF40ASVT):E34:020)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-88822-YAY	COVER SET, ENGINE (BLACK)	1	
1-2	61400-88832-Y5S	COVER SET, ENGINE (WHITE)	1	
2-1	61431-88L10-YAY	.HANDLE, TILT UP (BLACK)	1	
2-2	61431-88L10-Y5S	.HANDLE, TILT UP (WHITE)	1	
3	61438-88L01	.SEAL, GRIP	1	
4	61439-88L01	.SEAL, TILT UP HANDLE NO.2	1	
5	03542-06169	.SCREW	5	
6	61476-88L00	.SEAL, AIR VENT	1	
7	61610-95J00	.FASTENER, REAR	1	
8	09159-06084	.NUT (M6)	1	
9-1	61443-88L20	.STRIPE, ENGINE COVER STBD	1	STBD FOR YAY
9-2	61443-88L30	.STRIPE, ENGINE COVER STBD	1	STBD FOR Y5S
10-1	61453-88L20	.STRIPE, ENGINE COVER PORT	1	PORT FOR YAY
10-2	61453-88L30	.STRIPE, ENGINE COVER PORT	1	PORT FOR Y5S
11	68111-88L10	.EMBLEM, S	1	
12	61620-95J00	.BRACKET, REAR FASTENER	1	
13	61631-88L10	.HOOK, FRONT	1	
14	09229-04018	.RIVET	2	
15	09229-04005	.RIVET	2	
16-1	61422-88L30	MARK, EMBLEM FRONT	1	FOR YAY
16-2	61422-88L60	MARK, EMBLEM FRONT	1	FOR Y5S
17-1	61435-88L60	MARK, EMBLEM REAR	1	FOR YAY
17-2	61435-88L90	MARK, EMBLEM REAR	1	FOR Y5S
18	61458-90J01	LABEL, ENGINE COVER	1	
19	09800-81812	TOOL ASSY	1	
20	18210-88L00	KNOB ASSY, STARTER	1	
21	99011-88L92-054	MANUAL, OWNER'S	1	
22	17917-87L00	CONNECTOR, FLUSH WATER	1	

FIG.420F




FIG.420F (2-C-4) ENGINE COVER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-88850-QTN	COVER SET, ENGINE (WHITE)	1	
1-2	61400-88840-YAY	COVER SET, ENGINE (BLACK)	1	
2-1	61431-88L10-QTN	.HANDLE, TILT UP (WHITE)	1	
2-2	61431-88L10-YAY	.HANDLE, TILT UP (BLACK)	1	
3	61438-88L01	.SEAL, GRIP	1	
4	61439-88L01	.SEAL, TILT UP HANDLE NO.2	1	
5	03542-06169	.SCREW	5	
6	61476-88L00	.SEAL, AIR VENT	1	
7	61610-95J00	.FASTENER, REAR	1	
8	09159-06084	.NUT (M6)	1	
9	68111-88L10	.EMBLEM, S	1	
10	61620-95J00	.BRACKET, REAR FASTENER	1	
11	61631-88L10	.HOOK, FRONT	1	
12	09229-04018	.RIVET	2	
13	09229-04005	.RIVET	2	
14-1	61443-88L50	.STRIPE, ENGINE COVER STBD	1	STBD FOR QTN
14-2	61443-88L40	.STRIPE, ENGINE COVER STBD	1	STBD FOR YAY
15-1	61453-88L50	.STRIPE, ENGINE COVER PORT	1	PORT FOR QTN
15-2	61453-88L40	.STRIPE, ENGINE COVER PORT	1	PORT FOR YAY
16-1	61435-88LD0	MARK, EMBLEM REAR	1	FOR QTN
16-2	61435-88LC0	MARK, EMBLEM REAR	1	FOR YAY
17	61458-90J01	LABEL, ENGINE COVER	1	
18	09800-81812	TOOL ASSY	1	
19	18210-88L00	KNOB ASSY, STARTER	1	
20-1	99011-88L92-054	MANUAL, OWNER'S	1	021
20-2	99011-88LA0-054	MANUAL, OWNER'S	1	022
20-3	99011-88LB0-054	MANUAL, OWNER'S	1	023
21	17917-87L00	CONNECTOR, FLUSH WATER	1	

NOTE : (DF40AST,DF40ASVT):E34:(021,022,023)

DF60A_E11_023_420F
ENGINE COVER

FIG.420G




FIG.420G (2-C-5) ENGINE COVER (DF40ASVT:E34:(022,023))

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-88850-QTN	COVER SET, ENGINE (WHITE)	1	
1-2	61400-88840-YAY	COVER SET, ENGINE (BLACK)	1	
2-1	61431-88L10-QTN	.HANDLE, TILT UP (WHITE)	1	
2-2	61431-88L10-YAY	.HANDLE, TILT UP (BLACK)	1	
3	61438-88L01	.SEAL, GRIP	1	
4	61439-88L01	.SEAL, TILT UP HANDLE NO.2	1	
5	03542-06169	.SCREW	5	
6	61476-88L00	.SEAL, AIR VENT	1	
7	61610-95J00	.FASTENER, REAR	1	
8	09159-06084	.NUT (M6)	1	
9	68111-88L10	.EMBLEM, S	1	
10	61620-95J00	.BRACKET, REAR FASTENER	1	
11	61631-88L10	.HOOK, FRONT	1	
12	09229-04018	.RIVET	2	
13	09229-04005	.RIVET	2	
14-1	61443-88L50	.STRIPE, ENGINE COVER STBD	1	STBD FOR QTN
14-2	61443-88L40	.STRIPE, ENGINE COVER STBD	1	STBD FOR YAY
15-1	61453-88L50	.STRIPE, ENGINE COVER PORT	1	PORT FOR QTN
15-2	61453-88L40	.STRIPE, ENGINE COVER PORT	1	PORT FOR YAY
16-1	61435-88LD0	MARK, EMBLEM REAR	1	FOR QTN
16-2	61435-88LC0	MARK, EMBLEM REAR	1	FOR YAY
17	61458-90J01	LABEL, ENGINE COVER	1	
18	09800-81812	TOOL ASSY	1	
19	18210-88L00	KNOB ASSY, STARTER	1	
20-1	99011-88LA0-054	MANUAL, OWNER'S	1	022
20-2	99011-88LB0-054	MANUAL, OWNER'S	1	023
21	17917-87L00	CONNECTOR, FLUSH WATER	1	
22-1	61447-88L00	MARK	2	FOR YAY
22-2	61447-88L10	MARK	2	FOR QTN
23-1	61446-88L00	DECAL	1	FOR YAY
23-2	61446-88L10	DECAL	1	FOR QTN

DF60A_E11_023_420G
ENGINE COVER

FIG.420H




FIG.420H (2-C-6) ENGINE COVER ((DF50A,DF50ATH,DF50AVTH):E01:020)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-88822-YAY	COVER SET, ENGINE (BLACK)	1	
1-2	61400-88832-Y5S	COVER SET, ENGINE (WHITE)	1	
2-1	61431-88L10-YAY	.HANDLE, TILT UP (BLACK)	1	
2-2	61431-88L10-Y5S	.HANDLE, TILT UP (WHITE)	1	
3	61438-88L01	.SEAL, GRIP	1	
4	61439-88L01	.SEAL, TILT UP HANDLE NO.2	1	
5	03542-06169	.SCREW	5	
6	61476-88L00	.SEAL, AIR VENT	1	
7	61610-95J00	.FASTENER, REAR	1	
8	09159-06084	.NUT (M6)	1	
9-1	61443-88L20	.STRIPE, ENGINE COVER STBD	1	STBD FOR YAY
9-2	61443-88L30	.STRIPE, ENGINE COVER STBD	1	STBD FOR Y5S
10-1	61453-88L20	.STRIPE, ENGINE COVER PORT	1	PORT FOR YAY
10-2	61453-88L30	.STRIPE, ENGINE COVER PORT	1	PORT FOR Y5S
11	68111-88L10	.EMBLEM, S	1	
12	61620-95J00	.BRACKET, REAR FASTENER	1	
13	61631-88L10	.HOOK, FRONT	1	
14	09229-04018	.RIVET	2	
15	09229-04005	.RIVET	2	
16-1	61422-88L40	MARK, EMBLEM FRONT	1	FOR YAY
16-2	61422-88L70	MARK, EMBLEM FRONT	1	FOR Y5S
17-1	61435-88L70	MARK, EMBLEM REAR	1	FOR YAY
17-2	61435-88LA0	MARK, EMBLEM REAR	1	FOR Y5S
18	61458-90J01	LABEL, ENGINE COVER	1	
19	09800-81812	TOOL ASSY	1	
20	18210-88L00	KNOB ASSY, STARTER	1	
21-1	99011-88L92-054	MANUAL, OWNER'S	1	
21-2	99011-88L91-059	MANUAL, OWNER'S	1	
22	17917-87L00	CONNECTOR, FLUSH WATER	1	

DF60A_E11_023_420H
ENGINE COVER

FIG.420J




FIG.420J (2-C-7) ENGINE COVER ((DF50A,DF50AVT):E03:020)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-88822-YAY	COVER SET, ENGINE (BLACK)	1	
1-2	61400-88832-Y5S	COVER SET, ENGINE (WHITE)	1	
2-1	61431-88L10-YAY	.HANDLE, TILT UP (BLACK)	1	
2-2	61431-88L10-Y5S	.HANDLE, TILT UP (WHITE)	1	
3	61438-88L01	.SEAL, GRIP	1	
4	61439-88L01	.SEAL, TILT UP HANDLE NO.2	1	
5	03542-06169	.SCREW	5	
6	61476-88L00	.SEAL, AIR VENT	1	
7	61610-95J00	.FASTENER, REAR	1	
8	09159-06084	.NUT (M6)	1	
9-1	61443-88L20	.STRIPE, ENGINE COVER STBD	1	STBD FOR YAY
9-2	61443-88L30	.STRIPE, ENGINE COVER STBD	1	STBD FOR Y5S
10-1	61453-88L20	.STRIPE, ENGINE COVER PORT	1	PORT FOR YAY
10-2	61453-88L30	.STRIPE, ENGINE COVER PORT	1	PORT FOR Y5S
11	68111-88L10	.EMBLEM, S	1	
12	61620-95J00	.BRACKET, REAR FASTENER	1	
13	61631-88L10	.HOOK, FRONT	1	
14	09229-04018	.RIVET	2	
15	09229-04005	.RIVET	2	
16-1	61422-88L40	MARK, EMBLEM FRONT	1	FOR YAY
16-2	61422-88L70	MARK, EMBLEM FRONT	1	FOR Y5S
17-1	61435-88L70	MARK, EMBLEM REAR	1	FOR YAY
17-2	61435-88LA0	MARK, EMBLEM REAR	1	FOR Y5S
18	61458-90J01	LABEL, ENGINE COVER	1	
19	09800-81812	TOOL ASSY	1	
20	18210-88L00	KNOB ASSY, STARTER	1	
21-1	99011-88L92-054	MANUAL, OWNER'S	1	
21-2	99011-88L91-03B	MANUAL, OWNER'S	1	
22	17917-87L00	CONNECTOR, FLUSH WATER	1	

FIG.420K




FIG.420K (2-C-8) ENGINE COVER (DF50A:E11:(021,022,023))

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-88850-QTN	COVER SET, ENGINE (WHITE)	1	
1-2	61400-88840-YAY	COVER SET, ENGINE (BLACK)	1	
2-1	61431-88L10-QTN	.HANDLE, TILT UP (WHITE)	1	
2-2	61431-88L10-YAY	.HANDLE, TILT UP (BLACK)	1	
3	61438-88L01	.SEAL, GRIP	1	
4	61439-88L01	.SEAL, TILT UP HANDLE NO.2	1	
5	03542-06169	.SCREW	5	
6	61476-88L00	.SEAL, AIR VENT	1	
7	61610-95J00	.FASTENER, REAR	1	
8	09159-06084	.NUT (M6)	1	
9	68111-88L10	.EMBLEM, S	1	
10	61620-95J00	.BRACKET, REAR FASTENER	1	
11	61631-88L10	.HOOK, FRONT	1	
12	09229-04018	.RIVET	2	
13	09229-04005	.RIVET	2	
14-1	61443-88L50	.STRIPE, ENGINE COVER STBD	1	STBD FOR QTN
14-2	61443-88L40	.STRIPE, ENGINE COVER STBD	1	STBD FOR YAY
15-1	61453-88L50	.STRIPE, ENGINE COVER PORT	1	PORT FOR QTN
15-2	61453-88L40	.STRIPE, ENGINE COVER PORT	1	PORT FOR YAY
16-1	61435-88LF0	MARK, EMBLEM REAR	1	FOR QTN
16-2	61435-88LE0	MARK, EMBLEM REAR	1	FOR YAY
17	61458-90J01	LABEL, ENGINE COVER	1	
18	09800-81812	TOOL ASSY	1	
19	18210-88L00	KNOB ASSY, STARTER	1	

DF60A_E11_023_420K
ENGINE COVER

FIG.420K




FIG.420K (2-C-9) ENGINE COVER (DF50A:E11:(021,022,023))

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20-1	99011-88L92-054	MANUAL, OWNER'S	1	021
20-2	99011-88LA0-054	MANUAL, OWNER'S	1	022
20-3	99011-88LB0-054	MANUAL, OWNER'S	1	023
20-4	99011-88L91-059	MANUAL, OWNER'S	1	021
20-5	99011-88LA0-059	MANUAL, OWNER'S	1	022
20-6	99011-88LB0-059	MANUAL, OWNER'S	1	023
20-7	99011-88L91-03B	MANUAL, OWNER'S	1	021
20-8	99011-88LA0-03B	MANUAL, OWNER'S	1	022
20-9	99011-88LB0-03B	MANUAL, OWNER'S	1	023
21	17917-87L00	CONNECTOR, FLUSH WATER	1	

DF60A_E11_023_420K
ENGINE COVER

FIG.420L




FIG.420L (2-C-10) ENGINE COVER (DF50ATH:E01:(021,022,023))

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-88840-YAY	COVER SET, ENGINE (BLACK)	1	
2	61431-88L10-YAY	.HANDLE, TILT UP (BLACK)	1	
3	61438-88L01	.SEAL, GRIP	1	
4	61439-88L01	.SEAL, TILT UP HANDLE NO.2	1	
5	03542-06169	.SCREW	5	
6	61476-88L00	.SEAL, AIR VENT	1	
7	61610-95J00	.FASTENER, REAR	1	
8	09159-06084	.NUT (M6)	1	
9	68111-88L10	.EMBLEM, S	1	
10	61620-95J00	.BRACKET, REAR FASTENER	1	
11	61631-88L10	.HOOK, FRONT	1	
12	09229-04018	.RIVET	2	
13	09229-04005	.RIVET	2	
14	61443-88L40	.STRIPE, ENGINE COVER STBD	1	STBD
15	61453-88L40	.STRIPE, ENGINE COVER PORT	1	PORT
16	61435-88LE0	MARK, EMBLEM REAR	1	
17	61458-90J01	LABEL, ENGINE COVER	1	
18	09800-81812	TOOL ASSY	1	
19	18210-88L00	KNOB ASSY, STARTER	1	
20-1	99011-88L92-054	MANUAL, OWNER'S	1	021
20-2	99011-88LA0-054	MANUAL, OWNER'S	1	022
20-3	99011-88LB0-054	MANUAL, OWNER'S	1	023
20-4	99011-88L91-059	MANUAL, OWNER'S	1	021
20-5	99011-88LA0-059	MANUAL, OWNER'S	1	022
20-6	99011-88LB0-059	MANUAL, OWNER'S	1	023
21	17917-87L00	CONNECTOR, FLUSH WATER	1	

DF60A_E11_023_420L
ENGINE COVER

FIG.420M




FIG.420M (2-C-11) ENGINE COVER ((DF60A,DF60ATH,DF60AVT):E01:020)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-88822-YAY	COVER SET, ENGINE (BLACK)	1	
1-2	61400-88832-Y5S	COVER SET, ENGINE (WHITE)	1	
2-1	61431-88L10-YAY	.HANDLE, TILT UP (BLACK)	1	
2-2	61431-88L10-Y5S	.HANDLE, TILT UP (WHITE)	1	
3	61438-88L01	.SEAL, GRIP	1	
4	61439-88L01	.SEAL, TILT UP HANDLE NO.2	1	
5	03542-06169	.SCREW	5	
6	61476-88L00	.SEAL, AIR VENT	1	
7	61610-95J00	.FASTENER, REAR	1	
8	09159-06084	.NUT (M6)	1	
9-1	61443-88L20	.STRIPE, ENGINE COVER STBD	1	STBD FOR YAY
9-2	61443-88L30	.STRIPE, ENGINE COVER STBD	1	STBD FOR Y5S
10-1	61453-88L20	.STRIPE, ENGINE COVER PORT	1	PORT FOR YAY
10-2	61453-88L30	.STRIPE, ENGINE COVER PORT	1	PORT FOR Y5S
11	68111-88L10	.EMBLEM, S	1	
12	61620-95J00	.BRACKET, REAR FASTENER	1	
13	61631-88L10	.HOOK, FRONT	1	
14	09229-04018	.RIVET	2	
15	09229-04005	.RIVET	2	
16-1	61422-88L50	MARK, EMBLEM FRONT	1	FOR YAY
16-2	61422-88L80	MARK, EMBLEM FRONT	1	FOR Y5S
17-1	61435-88L80	MARK, EMBLEM REAR	1	FOR YAY
17-2	61435-88LB0	MARK, EMBLEM REAR	1	FOR Y5S
18	61458-90J01	LABEL, ENGINE COVER	1	
19	09800-81812	TOOL ASSY	1	
20	18210-88L00	KNOB ASSY, STARTER	1	
21-1	99011-88L92-054	MANUAL, OWNER'S	1	
21-2	99011-88L91-059	MANUAL, OWNER'S	1	
22	17917-87L00	CONNECTOR, FLUSH WATER	1	

DF60A_E11_023_420M
ENGINE COVER

FIG.420N




FIG.420N (2-C-12) ENGINE COVER ((DF60A,DF60AVT):E03:020)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-88822-YAY	COVER SET, ENGINE (BLACK)	1	
1-2	61400-88832-Y5S	COVER SET, ENGINE (WHITE)	1	
2-1	61431-88L10-YAY	.HANDLE, TILT UP (BLACK)	1	
2-2	61431-88L10-Y5S	.HANDLE, TILT UP (WHITE)	1	
3	61438-88L01	.SEAL, GRIP	1	
4	61439-88L01	.SEAL, TILT UP HANDLE NO.2	1	
5	03542-06169	.SCREW	5	
6	61476-88L00	.SEAL, AIR VENT	1	
7	61610-95J00	.FASTENER, REAR	1	
8	09159-06084	.NUT (M6)	1	
9-1	61443-88L20	.STRIPE, ENGINE COVER STBD	1	STBD FOR YAY
9-2	61443-88L30	.STRIPE, ENGINE COVER STBD	1	STBD FOR Y5S
10-1	61453-88L20	.STRIPE, ENGINE COVER PORT	1	PORT FOR YAY
10-2	61453-88L30	.STRIPE, ENGINE COVER PORT	1	PORT FOR Y5S
11	68111-88L10	.EMBLEM, S	1	
12	61620-95J00	.BRACKET, REAR FASTENER	1	
13	61631-88L10	.HOOK, FRONT	1	
14	09229-04018	.RIVET	2	
15	09229-04005	.RIVET	2	
16-1	61422-88L50	MARK, EMBLEM FRONT	1	FOR YAY
16-2	61422-88L80	MARK, EMBLEM FRONT	1	FOR Y5S
17-1	61435-88L80	MARK, EMBLEM REAR	1	FOR YAY
17-2	61435-88LB0	MARK, EMBLEM REAR	1	FOR Y5S
18	61458-90J01	LABEL, ENGINE COVER	1	
19	09800-81812	TOOL ASSY	1	
20	18210-88L00	KNOB ASSY, STARTER	1	
21-1	99011-88L92-054	MANUAL, OWNER'S	1	
21-2	99011-88L91-03B	MANUAL, OWNER'S	1	
22	17917-87L00	CONNECTOR, FLUSH WATER	1	

DF60A_E11_023_420N
ENGINE COVER

FIG.420P




FIG.420P (2-C-13) ENGINE COVER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-88822-YAY	COVER SET, ENGINE (BLACK)	1	
1-2	61400-88832-Y5S	COVER SET, ENGINE (WHITE)	1	
2-1	61431-88L10-YAY	.HANDLE, TILT UP (BLACK)	1	
2-2	61431-88L10-Y5S	.HANDLE, TILT UP (WHITE)	1	
3	61438-88L01	.SEAL, GRIP	1	
4	61439-88L01	.SEAL, TILT UP HANDLE NO.2	1	
5	03542-06169	.SCREW	5	
6	61476-88L00	.SEAL, AIR VENT	1	
7	61610-95J00	.FASTENER, REAR	1	
8	09159-06084	.NUT (M6)	1	
9-1	61443-88L20	.STRIPE, ENGINE COVER STBD	1	STBD FOR YAY
9-2	61443-88L30	.STRIPE, ENGINE COVER STBD	1	STBD FOR Y5S
10-1	61453-88L20	.STRIPE, ENGINE COVER PORT	1	PORT FOR YAY
10-2	61453-88L30	.STRIPE, ENGINE COVER PORT	1	PORT FOR Y5S
11	68111-88L10	.EMBLEM, S	1	
12	61620-95J00	.BRACKET, REAR FASTENER	1	
13	61631-88L10	.HOOK, FRONT	1	
14	09229-04018	.RIVET	2	
15	09229-04005	.RIVET	2	
16-1	61422-88L50	MARK, EMBLEM FRONT	1	FOR YAY
16-2	61422-88L80	MARK, EMBLEM FRONT	1	FOR Y5S
17-1	61435-88L80	MARK, EMBLEM REAR	1	FOR YAY
17-2	61435-88LB0	MARK, EMBLEM REAR	1	FOR Y5S
18	61458-90J01	LABEL, ENGINE COVER	1	
19	09800-81812	TOOL ASSY	1	
20	18210-88L00	KNOB ASSY, STARTER	1	
21	99011-88L91-059	MANUAL, OWNER'S	1	
22	17917-87L00	CONNECTOR, FLUSH WATER	1	

NOTE : (DF60A,DF60AQH,DF60ATH,DF60AVT,DF60AVTH):E40:020

DF60A_E11_023_420P
ENGINE COVER

FIG.420R




FIG.420R (2-C-14) ENGINE COVER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-88850-QTN	COVER SET, ENGINE (WHITE)	1	
1-2	61400-88840-YAY	COVER SET, ENGINE (BLACK)	1	
2-1	61431-88L10-QTN	.HANDLE, TILT UP (WHITE)	1	
2-2	61431-88L10-YAY	.HANDLE, TILT UP (BLACK)	1	
3	61438-88L01	.SEAL, GRIP	1	
4	61439-88L01	.SEAL, TILT UP HANDLE NO.2	1	
5	03542-06169	.SCREW	5	
6	61476-88L00	.SEAL, AIR VENT	1	
7	61610-95J00	.FASTENER, REAR	1	
8	09159-06084	.NUT (M6)	1	
9	68111-88L10	.EMBLEM, S	1	
10	61620-95J00	.BRACKET, REAR FASTENER	1	
11	61631-88L10	.HOOK, FRONT	1	
12	09229-04018	.RIVET	2	
13	09229-04005	.RIVET	2	
14-1	61443-88L50	.STRIPE, ENGINE COVER STBD	1	STBD FOR QTN
14-2	61443-88L40	.STRIPE, ENGINE COVER STBD	1	STBD FOR YAY
15-1	61453-88L50	.STRIPE, ENGINE COVER PORT	1	PORT FOR QTN
15-2	61453-88L40	.STRIPE, ENGINE COVER PORT	1	PORT FOR YAY
16-1	61435-88LH0	MARK, EMBLEM REAR	1	FOR QTN
16-2	61435-88LG0	MARK, EMBLEM REAR	1	FOR YAY
17	61458-90J01	LABEL, ENGINE COVER	1	
18	09800-81812	TOOL ASSY	1	
19	18210-88L00	KNOB ASSY, STARTER	1	

NOTE : (DF60A,DF60AVT):E11:(021,022,023)

DF60A_E11_023_420R
ENGINE COVER

FIG.420R




FIG.420R (2-C-15) ENGINE COVER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20-1	99011-88L92-054	MANUAL, OWNER'S	1	021
20-2	99011-88LA0-054	MANUAL, OWNER'S	1	022
20-3	99011-88LB0-054	MANUAL, OWNER'S	1	023
20-4	99011-88L91-059	MANUAL, OWNER'S	1	021
20-5	99011-88LA0-059	MANUAL, OWNER'S	1	022
20-6	99011-88LB0-059	MANUAL, OWNER'S	1	023
20-7	99011-88L91-03B	MANUAL, OWNER'S	1	021
20-8	99011-88LA0-03B	MANUAL, OWNER'S	1	022
20-9	99011-88LB0-03B	MANUAL, OWNER'S	1	023
21	17917-87L00	CONNECTOR, FLUSH WATER	1	

NOTE : (DF60A,DF60AVT):E11:(021,022,023)

DF60A_E11_023_420R
ENGINE COVER

FIG.420S




FIG.420S (2-D-2) ENGINE COVER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-88850-QTN	COVER SET, ENGINE (WHITE)	1	
1-2	61400-88840-YAY	COVER SET, ENGINE (BLACK)	1	
2-1	61431-88L10-QTN	.HANDLE, TILT UP (WHITE)	1	
2-2	61431-88L10-YAY	.HANDLE, TILT UP (BLACK)	1	
3	61438-88L01	.SEAL, GRIP	1	
4	61439-88L01	.SEAL, TILT UP HANDLE NO.2	1	
5	03542-06169	.SCREW	5	
6	61476-88L00	.SEAL, AIR VENT	1	
7	61610-95J00	.FASTENER, REAR	1	
8	09159-06084	.NUT (M6)	1	
9	68111-88L10	.EMBLEM, S	1	
10	61620-95J00	.BRACKET, REAR FASTENER	1	
11	61631-88L10	.HOOK, FRONT	1	
12	09229-04018	.RIVET	2	
13	09229-04005	.RIVET	2	
14-1	61443-88L50	.STRIPE, ENGINE COVER STBD	1	STBD FOR QTN
14-2	61443-88L40	.STRIPE, ENGINE COVER STBD	1	STBD FOR YAY
15-1	61453-88L50	.STRIPE, ENGINE COVER PORT	1	PORT FOR QTN
15-2	61453-88L40	.STRIPE, ENGINE COVER PORT	1	PORT FOR YAY
16-1	61435-88LH0	MARK, EMBLEM REAR	1	FOR QTN
16-2	61435-88LG0	MARK, EMBLEM REAR	1	FOR YAY
17	61458-90J01	LABEL, ENGINE COVER	1	
18	09800-81812	TOOL ASSY	1	
19	18210-88L00	KNOB ASSY, STARTER	1	
20-1	99011-88L91-059	MANUAL, OWNER'S	1	021
20-2	99011-88LA0-059	MANUAL, OWNER'S	1	022
20-3	99011-88LB0-059	MANUAL, OWNER'S	1	023
21	17917-87L00	CONNECTOR, FLUSH WATER	1	

NOTE : (DF60A,DF60AQH,DF60ATH,DF60AVTH):E40:(021,022,023)

DF60A_E11_023_420S
ENGINE COVER

FIG.420T




FIG.420T (2-D-3) ENGINE COVER (DF60ATH:E01:(021,022,023))

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-88840-YAY	COVER SET, ENGINE (BLACK)	1	
2	61431-88L10-YAY	.HANDLE, TILT UP (BLACK)	1	
3	61438-88L01	.SEAL, GRIP	1	
4	61439-88L01	.SEAL, TILT UP HANDLE NO.2	1	
5	03542-06169	.SCREW	5	
6	61476-88L00	.SEAL, AIR VENT	1	
7	61610-95J00	.FASTENER, REAR	1	
8	09159-06084	.NUT (M6)	1	
9	61443-88L40	.STRIPE, ENGINE COVER STBD	1	STBD
10	61453-88L40	.STRIPE, ENGINE COVER PORT	1	PORT
11	68111-88L10	.EMBLEM, S	1	
12	61620-95J00	.BRACKET, REAR FASTENER	1	
13	61631-88L10	.HOOK, FRONT	1	
14	09229-04018	.RIVET	2	
15	09229-04005	.RIVET	2	
16	61435-88LG0	MARK, EMBLEM REAR	1	
17	61458-90J01	LABEL, ENGINE COVER	1	
18	09800-81812	TOOL ASSY	1	
19	18210-88L00	KNOB ASSY, STARTER	1	
20-1	99011-88L92-054	MANUAL, OWNER'S	1	021
20-2	99011-88LA0-054	MANUAL, OWNER'S	1	022
20-3	99011-88LB0-054	MANUAL, OWNER'S	1	023
20-4	99011-88L91-059	MANUAL, OWNER'S	1	021
20-5	99011-88LA0-059	MANUAL, OWNER'S	1	022
20-6	99011-88LB0-059	MANUAL, OWNER'S	1	023
21	17917-87L00	CONNECTOR, FLUSH WATER	1	

DF60A_E11_023_420T
ENGINE COVER

FIG.420U




FIG.420U (2-D-4) ENGINE COVER (DF50AVT:E03:(021,022,023))

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-88840-YAY	COVER SET, ENGINE (BLACK)	1	
2	61431-88L10-YAY	.HANDLE, TILT UP (BLACK)	1	
3	61438-88L01	.SEAL, GRIP	1	
4	61439-88L01	.SEAL, TILT UP HANDLE NO.2	1	
5	03542-06169	.SCREW	5	
6	61476-88L00	.SEAL, AIR VENT	1	
7	61610-95J00	.FASTENER, REAR	1	
8	09159-06084	.NUT (M6)	1	
9	68111-88L10	.EMBLEM, S	1	
10	61620-95J00	.BRACKET, REAR FASTENER	1	
11	61631-88L10	.HOOK, FRONT	1	
12	09229-04018	.RIVET	2	
13	09229-04005	.RIVET	2	
14	61443-88L40	.STRIPE, ENGINE COVER STBD	1	STBD
15	61453-88L40	.STRIPE, ENGINE COVER PORT	1	PORT
16	61435-88LE0	MARK, EMBLEM REAR	1	
17	61458-90J01	LABEL, ENGINE COVER	1	
18	09800-81812	TOOL ASSY	1	
19	18210-88L00	KNOB ASSY, STARTER	1	
20-1	99011-88L92-054	MANUAL, OWNER'S	1	021
20-2	99011-88LA0-054	MANUAL, OWNER'S	1	022
20-3	99011-88LB0-054	MANUAL, OWNER'S	1	023
20-4	99011-88L91-03B	MANUAL, OWNER'S	1	021
20-5	99011-88LA0-03B	MANUAL, OWNER'S	1	022
20-6	99011-88LB0-03B	MANUAL, OWNER'S	1	023
21	17917-87L00	CONNECTOR, FLUSH WATER	1	

DF60A_E11_023_420U
ENGINE COVER

FIG.430A




FIG.430A (2-D-5) FUEL HOSE (E03,E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	65700-88L06	HOSE, FUEL	1	
2	65750-95501	.SOCKET, FUEL HOSE	1	
3	65770-90J04	.PUMP, SQUEEZE	1	
4	61188-88L01	GROMMET, FUEL HOSE	1	
5	09251-07003	CAP (OD:11.5)	1	
6	09367-08001	JOINT	1	
7	09401-11423	CLIP	1	
8	09409-05312-6GS	CLIP (GRAY)	1	
9	65770-90J04	PUMP, SQUEEZE	1	N/HOSE FUEL

FIG.432A




FIG.432A (2-D-6) FUEL TANK (E01,E11,E34,E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	65000-94L10	TANK ASSY, FUEL (25L)	1	
2	65520-99100	.CAP ASSY, FUEL TANK	1	
3	65561-95D00	.GASKET, TANK CAP	1	
4	65740-95D01	.PLUG, FUEL CONNECTOR	1	
5	65700-90J18	HOSE, FUEL	1	TANK TO CONN
6	65750-95501	.SOCKET, FUEL HOSE	1	
7	65770-90J13	.PUMP, SQUEEZE	1	
8	61188-88L01	GROMMET, FUEL HOSE	1	
9	09251-07003	CAP (OD:11.5)	1	
10	09367-08001	JOINT	1	
11	09401-11006	CLIP	1	
12	09409-05312-6GS	CLIP (GRAY)	1	

FIG.442A




FIG.442A (2-D-7) DRAG LINK (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-87J11	LINK ASSY, DRAG	1	
3	67721-87J00	.SPACER	1	
4	67725-99E00	.BOLT, DRAG LINK	1	
5	67726-99E00	.NUT, LOCK	2	
6	67728-99E00	.WASHER	4	

NOTE : DF40A,DF40AST,DF50A,DF50AVT,DF60A,DF60AVT,DF40ASVT

FIG.444A




FIG.444A (2-D-8) TILLER HANDLE (DF40AQH,DF60AQH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	43761-88L01-YAY	BRACKET, TILLER HANDLE (BLACK)	1	
2-1	63110-88L34-YAY	HANDLE ASSY, TILLER (BLACK)	1	->63110-88L35-YAY
2-2	63110-88L35-YAY	HANDLE ASSY, TILLER (BLACK)	1	SEE NOTE
3	21110-88L00	.LEVER, SHIFT	1	
4	23230-88L00	.CABLE, SHIFT	1	
5	36620-88L11	.WIRE ASSY, HANDLE	1	
6	37110-87L02	.SWITCH ASSY, IGNITION	1	
7-1	37141-99E00	..KEY (931)	1	
7-2	37141-99E10	..KEY (932)	1	
7-3	37141-99E20	..KEY (933)	1	
7-4	37141-99E30	..KEY (934)	1	
7-5	37141-99E40	..KEY (935)	1	
7-6	37141-99E50	..KEY (936)	1	
7-7	37141-99E60	..KEY (937)	1	
7-8	37141-99E70	..KEY (938)	1	
7-9	37141-99E80	..KEY (939)	1	
7-10	37141-99E90	..KEY (940)	1	
7-11	37141-99EA0	..KEY (941)	1	
7-12	37141-99EB0	..KEY (942)	1	
8	37143-99E01	..CAP, KEY	1	
9	37149-93J00	..CAP, CYLINDER BODY	1	
10	37820-87L11	.SWITCH ASSY, EMERGENCY	1	
11	37823-92E02	..PLATE ASSY, EMERGENCY SW LOCK	1	
12	37826-92J10	..NUT	1	
13	38500-93J90	.BUZZER, WARNING	1	
14	37852-87J00	.PLATE, TRIM SWITCH	1	
15	63121-88L10	.COVER, UNDER	1	
16	63210-88L00	.GRIP, HANDLE	1	
17	63221-88L00	.SHAFT, THROTTLE	1	
18	63223-92D00	.STOPPER, HANDLE ROD	1	
19	63225-88L00	.BUSH, HANDLE ROD	1	

NOTE : FROM 04003F-141090,FROM 06002F-142205

FIG.444A




FIG.444A (2-D-9) TILLER HANDLE (DF40AQH,DF60AQH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	63227-93200	.PIN, HANDLE ROD (L:14)	1	
21	63235-88L00	.PLATE, THROTTLE SHAFT	1	
22	63246-88L00	.STOPPER, THROTTLE ADJUST	1	
23	63250-88L00	.ARM ASSY, THROTTLE	1	
24	63251-87J00	.BOLT, SHIFT GEAR ASSY (6X12)	4	
25	63260-88L00	.GEAR ASSY, SHIFT	1	
26	63272-87J00	..PLATE, BALL GUIDE	1	
27	63273-87J00	..BALL	1	
28	63262-87J00	.BUSH, SHIFT LEVER	1	
29	63271-87J00	.PLATE, LOCK	1	
30	63248-99J00	.PLATE, THROTTLE ADJ NOTCH	1	
31	63261-87J00	.BUSH, SHIFT GEAR	1	
32	63274-87J00	.E RING	1	
33	63610-88L00	.CABLE, THROTTLE	1	
34	37853-88L90	.GROMMET, PTT SW LEAD	1	
35	63626-88L00	.GROMMET, CABLE	1	
36	67263-88L00	.CAP, SWITCH	1	
37	67292-87J00	.E RING	2	
38	09126-06015	.SCREW (6X23)	1	
39	09163-06001	.WASHER (6.4X12X0.5)	1	
40	09440-12027	.SPRING	1	
41	21112-88L10	.BOLT, SHIFT LEVER	1	
42	09125-05047	.SCREW (5X14)	6	
43	63611-88L00	.BOLT, CLAMP BRACKET	3	
44	63612-87J00	.BRACKET, CLAMP	1	
45	34200-87L00	.TACHOMETER ASSY, WITH MONITOR	1	
46	36617-88L90	.CLAMP, MAIN HARNESS	1	
47	37112-88L91	.LABEL, IGNITION SW	1	
48	37835-91J00-YAY	.LABEL, STOP (BLACK)	1	
49	37851-88L90	.BASE, PTT SW	1	
50	37861-87L11	.SWITCH, TROLLING CONTROL	1	
51	37864-88L91	.LABEL, TROLL MODE	1	
52	63244-99J00	.KNOB, THROTTLE ADJ	1	
53	63245-99J00	.BUSH, THROTTLE ADJ	1	
54	63612-88L10	.BRACKET, CLAMP SHIFT	1	
55	09260-10006	.BALL	1	

FIG.444A




FIG.444A (2-D-10) TILLER HANDLE (DF40AQH,DF60AQH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
56	63251-88L90	.BOLT	2	
57	37855-88L90	.SCREW, THROTTLE GRIP	1	
58	37854-88L90	.WASHER, THROTTLE GRIP	1	
59	63258-88L00	.WASHER	1	
60	09440-06037	.SPRING	1	
61	03522-05169	.SCREW	3	
62	63247-99J00	.PLATE, THROTTLE ADJ KNOB	1	
63	63111-88L01-YAY	.HOUSING, TILLER HANDLE (BLACK)	1	
64	22511-99011	.NIPPLE, GREASE	1	SEE NOTE
65	09116-08137	BOLT (8X22)	1	
66	09159-12014	NUT (12X17)	1	
67	09160-12066	WASHER (12.5X22X2.5)	2	
68	09160-12124	WASHER (12.5X32X1.5)	1	
69	63115-88L01	BUSH, TILLER HANDLE PIVOT	2	
70	09164-13010	WASHER	1	
71	21131-88L02	MARK, CLUTCH SHIFT	1	
72	63215-93110	MARK, HANDLE GRIP	1	
73	09116-10150	BOLT (10X55)	2	
74	63132-88L00	STOPPER, TILLER HANDLE	1	
75	43762-88L00	BOLT, TILLER HANDLE PIVOT	1	
76	43768-88L00	SPACER, TILLER HANDLE	1	
77	33834-88L00	TUBE, CABLE PROTECTOR	1	
78	65793-88L00	HOLDER, FUEL HOSE	1	
79	33833-91J00	TUBE, SWITCH LEAD (L:250)	1	L:250->150

NOTE : FROM 04003F-141090,FROM 06002F-142205

FIG.444B




FIG.444B (2-D-11) TILLER HANDLE (DF40ATH,DF50ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	43761-88L01-YAY	BRACKET, TILLER HANDLE (BLACK)	1	
2-1	63110-88L25-YAY	HANDLE ASSY, TILLER (BLACK)	1	->63110-88L26-YAY
2-2	63110-88L26-YAY	HANDLE ASSY, TILLER (BLACK)	1	SEE NOTE
3	21110-88L00	.LEVER, SHIFT	1	
4	23230-88L00	.CABLE, SHIFT	1	
5	36620-88L11	.WIRE ASSY, HANDLE	1	
6	37110-87L02	.SWITCH ASSY, IGNITION	1	
7-1	37141-99E00	..KEY (931)	1	
7-2	37141-99E10	..KEY (932)	1	
7-3	37141-99E20	..KEY (933)	1	
7-4	37141-99E30	..KEY (934)	1	
7-5	37141-99E40	..KEY (935)	1	
7-6	37141-99E50	..KEY (936)	1	
7-7	37141-99E60	..KEY (937)	1	
7-8	37141-99E70	..KEY (938)	1	
7-9	37141-99E80	..KEY (939)	1	
7-10	37141-99E90	..KEY (940)	1	
7-11	37141-99EA0	..KEY (941)	1	
7-12	37141-99EB0	..KEY (942)	1	
8	37143-99E01	..CAP, KEY	1	
9	37149-93J00	..CAP, CYLINDER BODY	1	
10	37820-87L11	.SWITCH ASSY, EMERGENCY	1	
11	37823-92E02	..PLATE ASSY, EMERGENCY SW LOCK	1	
12	37826-92J10	..NUT	1	
13	38500-93J90	.BUZZER, WARNING	1	
14	37850-87L01	.SWITCH ASSY, PTT	1	
15	37852-87J00	.PLATE, TRIM SWITCH	1	
16	63121-88L10	.COVER, UNDER	1	
17	63210-88L00	.GRIP, HANDLE	1	
18	63221-88L00	.SHAFT, THROTTLE	1	
19	63223-92D00	.STOPPER, HANDLE ROD	1	

NOTE : FROM 04003F-141090,FROM 05003F-141319

FIG.444B




FIG.444B (2-D-12) TILLER HANDLE (DF40ATH,DF50ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	63225-88L00	.BUSH, HANDLE ROD	1	
21	63227-93200	.PIN, HANDLE ROD (L:14)	1	
22	63235-88L00	.PLATE, THROTTLE SHAFT	1	
23	63246-88L00	.STOPPER, THROTTLE ADJUST	1	
24	63250-88L00	.ARM ASSY, THROTTLE	1	
25	63251-87J00	.BOLT, SHIFT GEAR ASSY (6X12)	4	
26	63260-88L00	.GEAR ASSY, SHIFT	1	
27	63272-87J00	..PLATE, BALL GUIDE	1	
28	63273-87J00	..BALL	1	
29	63262-87J00	.BUSH, SHIFT LEVER	1	
30	63271-87J00	.PLATE, LOCK	1	
31	63248-99J00	.PLATE, THROTTLE ADJ NOTCH	1	
32	63261-87J00	.BUSH, SHIFT GEAR	1	
33	63274-87J00	.E RING	1	
34	63610-88L00	.CABLE, THROTTLE	1	
35	37853-88L90	.GROMMET, PTT SW LEAD	1	
36	63626-88L00	.GROMMET, CABLE	1	
37	67292-87J00	.E RING	2	
38	09126-06015	.SCREW (6X23)	1	
39	09163-06001	.WASHER (6.4X12X0.5)	1	
40	09440-12027	.SPRING	1	
41	21112-88L00	.BOLT, SHIFT LEVER	1	
42	09125-05047	.SCREW (5X14)	6	
43	63611-88L00	.BOLT, CLAMP BRACKET	3	
44	63612-87J00	.BRACKET, CLAMP	1	
45	34200-87L00	.TACHOMETER ASSY, WITH MONITOR	1	
46	36617-88L90	.CLAMP, MAIN HARNESS	1	
47	37112-88L91	.LABEL, IGNITION SW	1	
48	37835-91J00-YAY	.LABEL, STOP (BLACK)	1	
49	37851-88L90	.BASE, PTT SW	1	
50	37852-88L90	.HARNESS GUIDE	1	
51	37861-87L11	.SWITCH, TROLLING CONTROL	1	
52	37864-88L91	.LABEL, TROLL MODE	1	
53	63244-99J00	.KNOB, THROTTLE ADJ	1	
54	63245-99J00	.BUSH, THROTTLE ADJ	1	
55	63612-88L10	.BRACKET, CLAMP SHIFT	1	

FIG.444B




FIG.444B (2-D-13) TILLER HANDLE (DF40ATH,DF50ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
56	09260-10006	.BALL	1	
57	63251-88L90	.BOLT	2	
58	37855-88L90	.SCREW, THROTTLE GRIP	1	
59	37854-88L90	.WASHER, THROTTLE GRIP	1	
60	63258-88L00	.WASHER	1	
61	09440-06037	.SPRING	1	
62	03522-05169	.SCREW	3	
63	63247-99J00	.PLATE, THROTTLE ADJ KNOB	1	
64	63111-88L01-YAY	.HOUSING, TILLER HANDLE (BLACK)	1	
65	22511-99011	.NIPPLE, GREASE	1	SEE NOTE
66	09116-08137	BOLT (8X22)	1	
67	09159-12014	NUT (12X17)	1	
68	09160-12066	WASHER (12.5X22X2.5)	2	
69	09160-12124	WASHER (12.5X32X1.5)	1	
70	63115-88L01	BUSH, TILLER HANDLE PIVOT	2	
71	09164-13010	WASHER	1	
72	21131-88L02	MARK, CLUTCH SHIFT	1	
73	63215-93110	MARK, HANDLE GRIP	1	
74	09116-10150	BOLT (10X55)	2	
75	63132-88L00	STOPPER, TILLER HANDLE	1	
76	43762-88L00	BOLT, TILLER HANDLE PIVOT	1	
77	43768-88L00	SPACER, TILLER HANDLE	1	
78	33834-88L00	TUBE, CABLE PROTECTOR	1	
79	65793-88L00	HOLDER, FUEL HOSE	1	
80	33833-91J00	TUBE, SWITCH LEAD (L:250)	1	L:250->150

NOTE : FROM 04003F-141090,FROM 05003F-141319

FIG.444C




FIG.444C (2-D-14) TILLER HANDLE (SEE NOTE 1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	43761-88L01-YAY	BRACKET, TILLER HANDLE (BLACK)	1	
2-1	63110-88L25-YAY	HANDLE ASSY, TILLER (BLACK)	1	->63110-88L26-YAY
2-2	63110-88L26-YAY	HANDLE ASSY, TILLER (BLACK)	1	SEE NOTE 2
3	21110-88L00	.LEVER, SHIFT	1	
4	23230-88L00	.CABLE, SHIFT	1	
5	36620-88L11	.WIRE ASSY, HANDLE	1	
6	37110-87L02	.SWITCH ASSY, IGNITION	1	
7-1	37141-99E00	..KEY (931)	1	
7-2	37141-99E10	..KEY (932)	1	
7-3	37141-99E20	..KEY (933)	1	
7-4	37141-99E30	..KEY (934)	1	
7-5	37141-99E40	..KEY (935)	1	
7-6	37141-99E50	..KEY (936)	1	
7-7	37141-99E60	..KEY (937)	1	
7-8	37141-99E70	..KEY (938)	1	
7-9	37141-99E80	..KEY (939)	1	
7-10	37141-99E90	..KEY (940)	1	
7-11	37141-99EA0	..KEY (941)	1	
7-12	37141-99EB0	..KEY (942)	1	
8	37143-99E01	..CAP, KEY	1	
9	37149-93J00	..CAP, CYLINDER BODY	1	
10	37820-87L11	.SWITCH ASSY, EMERGENCY	1	
11	37823-92E02	..PLATE ASSY, EMERGENCY SW LOCK	1	
12	37826-92J10	..NUT	1	
13	38500-93J90	.BUZZER, WARNING	1	
14	37850-87L01	.SWITCH ASSY, PTT	1	
15	37852-87J00	.PLATE, TRIM SWITCH	1	
16	63121-88L10	.COVER, UNDER	1	

NOTE 1 : DF60ATH,DF50AVTH,DF60AVTH,DF50AVT

NOTE 2 : FROM 05004F-140056,FROM 06002F-142205,
FROM 06003F-140202

DF60A_E11_023_444C
TILLER HANDLE

FIG.444C




FIG.444C (2-D-15) TILLER HANDLE (SEE NOTE 1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
17	63210-88L00	.GRIP, HANDLE	1	
18	63221-88L00	.SHAFT, THROTTLE	1	
19	63223-92D00	.STOPPER, HANDLE ROD	1	
20	63225-88L00	.BUSH, HANDLE ROD	1	
21	63227-93200	.PIN, HANDLE ROD (L:14)	1	
22	63235-88L00	.PLATE, THROTTLE SHAFT	1	
23	63246-88L00	.STOPPER, THROTTLE ADJUST	1	
24	63250-88L00	.ARM ASSY, THROTTLE	1	
25	63251-87J00	.BOLT, SHIFT GEAR ASSY (6X12)	4	
26	63260-88L00	.GEAR ASSY, SHIFT	1	
27	63272-87J00	..PLATE, BALL GUIDE	1	
28	63273-87J00	..BALL	1	
29	63262-87J00	.BUSH, SHIFT LEVER	1	
30	63271-87J00	.PLATE, LOCK	1	
31	63248-99J00	.PLATE, THROTTLE ADJ NOTCH	1	
32	63261-87J00	.BUSH, SHIFT GEAR	1	
33	63274-87J00	.E RING	1	
34	63610-88L00	.CABLE, THROTTLE	1	
35	37853-88L90	.GROMMET, PTT SW LEAD	1	
36	63626-88L00	.GROMMET, CABLE	1	
37	67292-87J00	.E RING	2	
38	09126-06015	.SCREW (6X23)	1	
39	09163-06001	.WASHER (6.4X12X0.5)	1	
40	09440-12027	.SPRING	1	
41	21112-88L00	.BOLT, SHIFT LEVER	1	
42	09125-05047	.SCREW (5X14)	6	
43	63611-88L00	.BOLT, CLAMP BRACKET	3	
44	63612-87J00	.BRACKET, CLAMP	1	
45	34200-87L00	.TACHOMETER ASSY, WITH MONITOR	1	
46	36617-88L90	.CLAMP, MAIN HARNESS	1	
47	37112-88L91	.LABEL, IGNITION SW	1	
48	37835-91J00-YAY	.LABEL, STOP (BLACK)	1	

NOTE 1 : DF60ATH,DF50AVTH,DF60AVTH,DF50AVT

FIG.444C




FIG.444C (2-E-2) TILLER HANDLE (SEE NOTE 1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
49	37851-88L90	.BASE, PTT SW	1	
50	37852-88L90	.HARNESS GUIDE	1	
51	37861-87L11	.SWITCH, TROLLING CONTROL	1	
52	37864-88L91	.LABEL, TROLL MODE	1	
53	63244-99J00	.KNOB, THROTTLE ADJ	1	
54	63245-99J00	.BUSH, THROTTLE ADJ	1	
55	63612-88L10	.BRACKET, CLAMP SHIFT	1	
56	09260-10006	.BALL	1	
57	63251-88L90	.BOLT	2	
58	37855-88L90	.SCREW, THROTTLE GRIP	1	
59	37854-88L90	.WASHER, THROTTLE GRIP	1	
60	63258-88L00	.WASHER	1	
61	09440-06037	.SPRING	1	
62	03522-05169	.SCREW	3	
63	63247-99J00	.PLATE, THROTTLE ADJ KNOB	1	
64	63111-88L01-YAY	.HOUSING, TILLER HANDLE (BLACK)	1	
65	22511-99011	.NIPPLE, GREASE	1	SEE NOTE 2
66	09116-08137	BOLT (8X22)	1	
67	09159-12014	NUT (12X17)	1	
68	09160-12066	WASHER (12.5X22X2.5)	2	
69	09160-12124	WASHER (12.5X32X1.5)	1	
70	63115-88L01	BUSH, TILLER HANDLE PIVOT	2	
71	09164-13010	WASHER	1	
72	21131-88L02	MARK, CLUTCH SHIFT	1	
73	63215-93110	MARK, HANDLE GRIP	1	
74	09116-10150	BOLT (10X55)	2	
75	43770-99E03	ADJUSTER ASSY, STEERING	1	
76	63132-88L00	STOPPER, TILLER HANDLE	1	

NOTE 1 : DF60ATH,DF50AVTH,DF60AVTH,DF50AVT

NOTE 2 : FROM 05004F-140056,FROM 06002F-142205,
FROM 06003F-140202

DF60A_E11_023_444C
TILLER HANDLE

FIG.444C




FIG.444C (2-E-3) TILLER HANDLE (SEE NOTE 1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
77	43762-88L00	BOLT, TILLER HANDLE PIVOT	1	
78	43768-88L00	SPACER, TILLER HANDLE	1	
79	33834-88L00	TUBE, CABLE PROTECTOR	1	
80	65793-88L00	HOLDER, FUEL HOSE	1	
81	09116-06237	BOLT (6X15)	2	
82	33833-91J00	TUBE, SWITCH LEAD (L:250)	1	L:250->150

NOTE 1 : DF60ATH,DF50AVTH,DF60AVTH,DF50AVT

DF60A_E11_023_444C
TILLER HANDLE

FIG.501A




FIG.501A (2-E-4) OPT:METER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	34800-93J02	METER ASSY, TRIM	1	BLACK
1-2	34800-93J13	METER ASSY, TRIM	1	WHITE
2	09471-12108	.BULB (12V1.7W,T6.5)	1	
3-1	34100-93J02	SPEEDOMETER ASSY (MAX 130KM/H)	1	BLACK
3-2	34100-93J13	SPEEDOMETER ASSY (MAX 130KM/H)	1	WHITE
3-3	34100-93J22	SPEEDOMETER ASSY (MAX 80KM/H)	1	BLACK
3-4	34100-93J33	SPEEDOMETER ASSY (MAX 80KM/H)	1	WHITE
3-5	34100-93J42	SPEEDOMETER ASSY (MAX 45KNOTS)	1	BLACK
3-6	34100-93J53	SPEEDOMETER ASSY (MAX 45KNOTS)	1	WHITE
3-7	34100-93J62	SPEEDOMETER ASSY (MAX 65KNOTS)	1	WHITE
4	09471-12028	.BULB (12V3.4W,T10)	1	
5	34191-92E00	.TUBE	1	
6	09407-14407	.CLAMP (L:145)	2	
7	36615-96300	.TERMINAL	2	
8-1	34600-93J02	METER ASSY, VOLTAGE	1	BLACK
8-2	34600-93J13	METER ASSY, VOLTAGE	1	WHITE
9	09471-12103	.BULB (12V3W,T6.5)	1	
10-1	34300-93J03	GAUGE ASSY, FUEL	1	BLACK
10-2	34300-93J14	GAUGE ASSY, FUEL	1	WHITE
11	34310-92E01	.LEAD ASSY, FUEL GAUGE	1	
12	34360-92E00	.ADAPTER, FUEL GAUGE	1	
13	09471-12103	.BULB (12V3W,T6.5)	1	
14-1	34500-93J02	METER ASSY, HOUR	1	BLACK
14-2	34500-93J13	METER ASSY, HOUR	1	WHITE
15	09471-12103	.BULB (12V3W,T6.5)	1	
16-1	34650-93J22	GAUGE ASSY, WATER PRESS 15PSI	1	15PSI BLACK
16-2	34650-93J33	GAUGE ASSY, WATER PRESS 15PSI	1	15PSI WHITE
17	34191-92E00	.TUBE	1	
18	09407-14407	.CLAMP (L:145)	2	
19	09471-12103	.BULB (12V3W,T6.5)	1	
20-1	34200-93J02	TACHOMETER ASSY, WITH MONITOR	1	BLACK
20-2	34200-93J14	TACHOMETER ASSY, WITH MONITOR	1	WHITE

NOTE : DF40A,DF40AST,DF50A,DF50AVT,DF60A,DF60AVT,DF40ASVT

FIG.501A




FIG.501A (2-E-5) OPT:METER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
21	09471-12077	.BULB (12V1.7W,T10)	1	
22-1	34200-93J43	TACHOMETER ASSY, WITH MONITOR	1	BLACK
22-2	34200-93J54	TACHOMETER ASSY, WITH MONITOR	1	WHITE
23	09471-12077	.BULB (12V1.7W,T10)	1	
24	34190-95500	SENDER, SPEEDOMETER	1	
25	03112-0630B	.SCREW	2	
26	34190-87D00	SENDER, SPEEDOMETER	1	

NOTE : DF40A,DF40AST,DF50A,DF50AVT,DF60A,DF60AVT,DF40ASVT

FIG.501B




FIG.501B (2-E-6) OPT:METER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	34800-93J02	METER ASSY, TRIM	1	BLACK
1-2	34800-93J13	METER ASSY, TRIM	1	WHITE
2	09471-12108	.BULB (12V1.7W,T6.5)	1	
3-1	34100-93J02	SPEEDOMETER ASSY (MAX 130KM/H)	1	BLACK
3-2	34100-93J13	SPEEDOMETER ASSY (MAX 130KM/H)	1	WHITE
3-3	34100-93J22	SPEEDOMETER ASSY (MAX 80KM/H)	1	BLACK
3-4	34100-93J33	SPEEDOMETER ASSY (MAX 80KM/H)	1	WHITE
3-5	34100-93J42	SPEEDOMETER ASSY (MAX 45KNOTS)	1	BLACK
3-6	34100-93J53	SPEEDOMETER ASSY (MAX 45KNOTS)	1	WHITE
3-7	34100-93J62	SPEEDOMETER ASSY (MAX 65KNOTS)	1	WHITE
4	09471-12028	.BULB (12V3.4W,T10)	1	
5	34191-92E00	.TUBE	1	
6	09407-14407	.CLAMP (L:145)	2	
7	36615-96300	.TERMINAL	2	
8-1	34600-93J02	METER ASSY, VOLTAGE	1	BLACK
8-2	34600-93J13	METER ASSY, VOLTAGE	1	WHITE
9	09471-12103	.BULB (12V3W,T6.5)	1	
10-1	34300-93J03	GAUGE ASSY, FUEL	1	BLACK
10-2	34300-93J14	GAUGE ASSY, FUEL	1	WHITE
11	34310-92E01	.LEAD ASSY, FUEL GAUGE	1	
12	34360-92E00	.ADAPTER, FUEL GAUGE	1	
13	09471-12103	.BULB (12V3W,T6.5)	1	
14-1	34500-93J02	METER ASSY, HOUR	1	BLACK
14-2	34500-93J13	METER ASSY, HOUR	1	WHITE
15	09471-12103	.BULB (12V3W,T6.5)	1	
16-1	34650-93J22	GAUGE ASSY, WATER PRESS 15PSI	1	15PSI BLACK
16-2	34650-93J33	GAUGE ASSY, WATER PRESS 15PSI	1	15PSI WHITE
17	34191-92E00	.TUBE	1	
18	09407-14407	.CLAMP (L:145)	2	
19	09471-12103	.BULB (12V3W,T6.5)	1	
20-1	34200-93J02	TACHOMETER ASSY, WITH MONITOR	1	BLACK
20-2	34200-93J14	TACHOMETER ASSY, WITH MONITOR	1	WHITE

NOTE : DF40AQH,DF40ATH,DF50ATH,DF60AQH,DF60ATH,DF50AVTH,DF60AVTH

FIG.501B




FIG.501B (2-E-7) OPT:METER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
21	09471-12077	.BULB (12V1.7W,T10)	1	
22	34190-95500	SENDER, SPEEDOMETER	1	
23	03112-0630B	.SCREW	2	
24	34190-87D00	SENDER, SPEEDOMETER	1	

NOTE : DF40AQH,DF40ATH,DF50ATH,DF60AQH,DF60ATH,DF50AVTH,DF60AVTH

FIG.507A




FIG.507A (2-E-8) OPT:WATER PRESSURE GAUGE SUB KIT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34660-90J05	KIT, WATER PRESS GAUGE SUB	1	
2	09352-50006-600	.HOSE (5X9X600)	1	L:600->160
3	09352-50006-600	.HOSE (5X9X600)	1	L:600->210
4	09367-06006	.3 WAY	1	
5	09401-08413	.CLIP	4	
6	18498-99EA1	.PROTECTOR (L:80)	1	
7	09407-20405	.CLAMP (L:202)	1	
8	09408-00346	.CLAMP	4	

FIG.508A




FIG.508A (2-E-9) OPT:REMOTE CONTROL (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J62	REMOTE CONTROL ASSY	1	
2	36628-92E01	.GROMMET, WIRING HARNESS	1	
3	37110-93J12	.SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E01	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37721-93J91	.SWITCH ASSY, NEUTRAL	1	
8	37820-93J11	.SWITCH ASSY, EMERGENCY	1	
9	37823-92E02	..PLATE ASSY, EMERGENCY SW LOCK	1	
10	37826-92J10	..NUT	1	
11	37850-96L00	.SWITCH ASSY, PTT	1	
12	38500-93J90	.BUZZER, WARNING	1	
13	67212-95600	.WASHER	1	
14	67296-92E11	.SCREW, NEUTRAL SWITCH (3X15)	2	
15	67220-95630	.PLATE ASSY	1	
16	67223-99E10	.KNOB, BRAKE ADJUST	1	
17	67229-95600	.ROLLER	1	
18	67232-95600	.BUSH	1	
19	67238-87D00	.GEAR, DRIVE	1	

NOTE : (DF40A:E01,DF40AST:E34,DF50A:E01,DF60A:(E01,E40),DF60AVT:(E01,E40),DF40ASVT:E34):020

DF60A_E11_023_508A
OPT:REMOTE CONTROL

FIG.508A




FIG.508A (2-E-10) OPT:REMOTE CONTROL (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67241-99E11	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-96L00	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-96L00	.NEUTRAL LOCK ARM	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-96L00	.CAP ASSY, LEVER	1	
30	77811-54GB0-0PG	..EMBLEM, RR MARK S (CHROME)	1	
31	67258-99E00	.BRACKET	1	
32	67259-87D00	.SPRING, NEUTRAL ARM	1	
33	67261-96L00	.GRIP	1	
34	67296-96L10	.SCREW	2	
35	67264-95600	.WASHER	1	
36	67267-96L00	.COVER, WIRE SUB ASSY	1	
37	67273-95601	.SPACER	1	
38	67275-95600	.END, CABLE	2	
39	67292-94300	.E RING	3	
40	67294-95600	.SPACER	3	
41	67296-90J20	.SCREW	5	
42	67296-96L00	.SCREW	2	
43	67296-95630	.SCREW	3	
44	67296-95610	.SCREW	2	
45	67297-95600	.WASHER	2	
46	09100-08232	.BOLT (8X30)	1	
47	67269-96L10	.SCREW (5X12)	2	
48	09140-06020	.NUT	3	
49	67288-94320	.WASHER (6.5X24X2)	3	
50	67224-96L00	.ARM, BRAKE ASSY	1	

NOTE : (DF40A:E01,DF40AST:E34,DF50A:E01,DF60A:(E01,E40),DF60AVT:(E01,E40),DF40ASVT:E34):020

DF60A_E11_023_508A
OPT:REMOTE CONTROL

FIG.508A




FIG.508A (2-E-11) OPT:REMOTE CONTROL (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
51	67238-96L00	.GEAR, SHIFT ASSY	1	
52	67284-94L10	.MARK, HANDLE LEVER	1	
53-1	36620-93J04	WIRE ASSY, REMOCON (L:5000)	1	
53-2	36620-93J54	WIRE ASSY, REMOCON (L:3500)	1	
53-3	36620-93J64	WIRE ASSY, REMOCON (L:6500)	1	
54	09481-10501	.FUSE (10A)	1	
55-1	67320-93J00	CABLE ASSY, REMOCON (2.4M)	2	
55-2	67320-93J10	CABLE ASSY, REMOCON (3.1M)	2	
55-3	67320-93J20	CABLE ASSY, REMOCON (3.7M)	2	
55-4	67320-93J30	CABLE ASSY, REMOCON (4.2M)	2	
55-5	67320-93J40	CABLE ASSY, REMOCON (4.8M)	2	
55-6	67320-93J50	CABLE ASSY, REMOCON (5.4M)	2	
55-7	67320-93J60	CABLE ASSY, REMOCON (6.1M)	2	
55-8	67320-93J70	CABLE ASSY, REMOCON (6.7M)	2	
55-9	67320-93J80	CABLE ASSY, REMOCON (7.3M)	2	

NOTE : (DF40A:E01,DF40AST:E34,DF50A:E01,DF60A:(E01,E40),DF60AVT:(E01,E40),DF40ASVT:E34):020

DF60A_E11_023_508A
OPT:REMOTE CONTROL

FIG.508B




FIG.508B (2-E-12) OPT:REMOTE CONTROL (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J62	REMOTE CONTROL ASSY	1	
2	36628-92E01	.GROMMET, WIRING HARNESS	1	
3	37110-93J12	.SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E01	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37721-93J91	.SWITCH ASSY, NEUTRAL	1	
8	37820-93J11	.SWITCH ASSY, EMERGENCY	1	
9	37823-92E02	..PLATE ASSY, EMERGENCY SW LOCK	1	
10	37826-92J10	..NUT	1	
11	37850-96L00	.SWITCH ASSY, PTT	1	
12	38500-93J90	.BUZZER, WARNING	1	
13	67212-95600	.WASHER	1	
14	67296-92E11	.SCREW, NEUTRAL SWITCH (3X15)	2	
15	67220-95630	.PLATE ASSY	1	
16	67223-99E10	.KNOB, BRAKE ADJUST	1	
17	67229-95600	.ROLLER	1	
18	67232-95600	.BUSH	1	
19	67238-87D00	.GEAR, DRIVE	1	

NOTE : (DF40A:E11,DF40AST:E34,DF50A:E11,DF60A:(E11,E40),DF60AVT:E11,DF40ASVT:E34):021

DF60A_E11_023_508B
OPT:REMOTE CONTROL

FIG.508B




FIG.508B (2-E-13) OPT:REMOTE CONTROL (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67241-99E11	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-96L00	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-96L00	.NEUTRAL LOCK ARM	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-96L00	.CAP ASSY, LEVER	1	
30	77811-54GB0-0PG	..EMBLEM, RR MARK S (CHROME)	1	
31	67258-99E00	.BRACKET	1	
32	67259-87D00	.SPRING, NEUTRAL ARM	1	
33	67261-96L00	.GRIP	1	
34	67296-96L10	.SCREW	2	
35	67264-95600	.WASHER	1	
36	67267-96L00	.COVER, WIRE SUB ASSY	1	
37	67273-95601	.SPACER	1	
38	67275-95600	.END, CABLE	2	
39	67292-94300	.E RING	3	
40	67294-95600	.SPACER	3	
41	67296-90J20	.SCREW	5	
42	67296-96L00	.SCREW	2	
43	67296-95630	.SCREW	3	
44	67296-95610	.SCREW	2	
45	67297-95600	.WASHER	2	
46	09100-08232	.BOLT (8X30)	1	
47	67269-96L10	.SCREW (5X12)	2	
48	09140-06020	.NUT	3	
49	67288-94320	.WASHER (6.5X24X2)	3	
50	67224-96L00	.ARM, BRAKE ASSY	1	

NOTE : (DF40A:E11,DF40AST:E34,DF50A:E11,DF60A:(E11,E40),DF60AVT:E11,DF40ASVT:E34):021

DF60A_E11_023_508B
OPT:REMOTE CONTROL

FIG.508B




FIG.508B (2-E-14) OPT:REMOTE CONTROL (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
51	67238-96L00	.GEAR, SHIFT ASSY	1	
52	67284-94L10	.MARK, HANDLE LEVER	1	
53-1	36620-93J04	WIRE ASSY, REMOCON (L:5000)	1	
53-2	36620-93J54	WIRE ASSY, REMOCON (L:3500)	1	
53-3	36620-93J64	WIRE ASSY, REMOCON (L:6500)	1	
54	09481-10501	.FUSE (10A)	1	
55-1	67320-93J00	CABLE ASSY, REMOCON (2.4M)	2	
55-2	67320-93J10	CABLE ASSY, REMOCON (3.1M)	2	
55-3	67320-93J20	CABLE ASSY, REMOCON (3.7M)	2	
55-4	67320-93J30	CABLE ASSY, REMOCON (4.2M)	2	
55-5	67320-93J40	CABLE ASSY, REMOCON (4.8M)	2	
55-6	67320-93J50	CABLE ASSY, REMOCON (5.4M)	2	
55-7	67320-93J60	CABLE ASSY, REMOCON (6.1M)	2	
55-8	67320-93J70	CABLE ASSY, REMOCON (6.7M)	2	
55-9	67320-93J80	CABLE ASSY, REMOCON (7.3M)	2	

NOTE : (DF40A:E11,DF40AST:E34,DF50A:E11,DF60A:(E11,E40),DF60AVT:E11,DF40ASVT:E34):021

DF60A_E11_023_508B
OPT:REMOTE CONTROL

FIG.508C




FIG.508C (2-F-2) OPT:REMOTE CONTROL (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J70	REMOTE CONTROL ASSY	1	
2	36628-92E01	.GROMMET, WIRING HARNESS	1	
3	37110-93J20	.SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37721-93J91	.SWITCH ASSY, NEUTRAL	1	
6	37820-93J11	.SWITCH ASSY, EMERGENCY	1	
7	37823-92E02	..PLATE ASSY, EMERGENCY SW LOCK	1	
8	37826-92J10	..NUT	1	
9	37850-96L00	.SWITCH ASSY, PTT	1	
10	38500-93J90	.BUZZER, WARNING	1	
11	67212-95600	.WASHER	1	
12	67296-92E11	.SCREW, NEUTRAL SWITCH (3X15)	2	
13	67220-95630	.PLATE ASSY	1	
14	67223-99E10	.KNOB, BRAKE ADJUST	1	
15	67229-95600	.ROLLER	1	
16	67232-95600	.BUSH	1	
17	67238-87D00	.GEAR, DRIVE	1	
18	67241-99E11	.LEVER, FREE THROTTLE	1	
19	67243-95600	.BUSH	1	

NOTE : (DF40A:E11,DF40AST:E34,DF50A:E11,DF60A:(E11,E40),DF60AVT:E11,DF40ASVT:E34):022

FIG.508C




FIG.508C (2-F-3) OPT:REMOTE CONTROL (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67244-95600	.WAVE WASHER	1	
21	67245-95600	.DRUM, FREE THROTTLE	1	
22	67251-96L00	.LEVER, HANDLE	1	
23	67252-95600	.BUSH	2	
24	67253-95600	.WASHER	1	
25	67255-96L00	.NEUTRAL LOCK ARM	1	
26	67256-95600	.HOLDER, NEUTRAL LOCK	1	
27	67257-96L00	.CAP ASSY, LEVER	1	
28	77811-54GB0-0PG	..EMBLEM, RR MARK S (CHROME)	1	
29	67258-99E00	.BRACKET	1	
30	67259-87D00	.SPRING, NEUTRAL ARM	1	
31	67261-96L00	.GRIP	1	
32	67296-96L10	.SCREW	2	
33	67264-95600	.WASHER	1	
34	67267-96L00	.COVER, WIRE SUB ASSY	1	
35	67273-95601	.SPACER	1	
36	67275-95600	.END, CABLE	2	
37	67292-94300	.E RING	3	
38	67294-95600	.SPACER	3	
39	67296-90J20	.SCREW	5	
40	67296-96L00	.SCREW	2	
41	67296-95630	.SCREW	3	
42	67296-95610	.SCREW	2	
43	67297-95600	.WASHER	2	
44	09100-08232	.BOLT (8X30)	1	
45	67269-96L10	.SCREW (5X12)	2	
46	09140-06020	.NUT	3	
47	67288-94320	.WASHER (6.5X24X2)	3	
48	67224-96L00	.ARM, BRAKE ASSY	1	
49	67238-96L00	.GEAR, SHIFT ASSY	1	
50	67284-94L10	.MARK, HANDLE LEVER	1	

NOTE : (DF40A:E11,DF40AST:E34,DF50A:E11,DF60A:(E11,E40),DF60AVT:E11,DF40ASVT:E34):022

DF60A_E11_023_508C
OPT:REMOTE CONTROL

FIG.508C




FIG.508C (2-F-4) OPT:REMOTE CONTROL (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
51-1	36620-93J70	WIRE ASSY, REMOCON (L:5000)	1	
51-2	36620-93J80	WIRE ASSY, REMOCON (L:3500)	1	
51-3	36620-93J90	WIRE ASSY, REMOCON (L:6500)	1	
52-1	67320-93J00	CABLE ASSY, REMOCON (2.4M)	2	
52-2	67320-93J10	CABLE ASSY, REMOCON (3.1M)	2	
52-3	67320-93J20	CABLE ASSY, REMOCON (3.7M)	2	
52-4	67320-93J30	CABLE ASSY, REMOCON (4.2M)	2	
52-5	67320-93J40	CABLE ASSY, REMOCON (4.8M)	2	
52-6	67320-93J50	CABLE ASSY, REMOCON (5.4M)	2	
52-7	67320-93J60	CABLE ASSY, REMOCON (6.1M)	2	
52-8	67320-93J70	CABLE ASSY, REMOCON (6.7M)	2	
52-9	67320-93J80	CABLE ASSY, REMOCON (7.3M)	2	

NOTE : (DF40A:E11,DF40AST:E34,DF50A:E11,DF60A:(E11,E40),DF60AVT:E11,DF40ASVT:E34):022

DF60A_E11_023_508C
OPT:REMOTE CONTROL

FIG.508D




FIG.508D (2-F-5) OPT:REMOTE CONTROL (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J70	REMOTE CONTROL ASSY	1	
2	36628-92E01	.GROMMET, WIRING HARNESS	1	
3	37110-93J20	.SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37721-93J91	.SWITCH ASSY, NEUTRAL	1	
6	37820-93J11	.SWITCH ASSY, EMERGENCY	1	
7	37823-92E02	..PLATE ASSY, EMERGENCY SW LOCK	1	
8	37826-92J10	..NUT	1	
9	37850-96L00	.SWITCH ASSY, PTT	1	
10	38500-93J90	.BUZZER, WARNING	1	
11	67212-95600	.WASHER	1	
12	67296-92E11	.SCREW, NEUTRAL SWITCH (3X15)	2	
13	67220-95630	.PLATE ASSY	1	
14	67223-99E10	.KNOB, BRAKE ADJUST	1	
15	67229-95600	.ROLLER	1	
16	67232-95600	.BUSH	1	
17	67238-87D00	.GEAR, DRIVE	1	
18	67241-99E11	.LEVER, FREE THROTTLE	1	
19	67243-95600	.BUSH	1	

NOTE : (DF40A:E11,DF40AST:E34,DF50A:E11,DF60A:(E11,E40),DF60AVT:E11,DF40ASVT:E34):023

FIG.508D




FIG.508D (2-F-6) OPT:REMOTE CONTROL (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67244-95600	.WAVE WASHER	1	
21	67245-95600	.DRUM, FREE THROTTLE	1	
22	67251-96L00	.LEVER, HANDLE	1	
23	67252-95600	.BUSH	2	
24	67253-95600	.WASHER	1	
25	67255-96L00	.NEUTRAL LOCK ARM	1	
26	67256-95600	.HOLDER, NEUTRAL LOCK	1	
27	67257-96L00	.CAP ASSY, LEVER	1	
28	77811-54GB0-0PG	..EMBLEM, RR MARK S (CHROME)	1	
29	67258-99E00	.BRACKET	1	
30	67259-87D00	.SPRING, NEUTRAL ARM	1	
31	67261-96L00	.GRIP	1	
32	67296-96L10	.SCREW	2	
33	67264-95600	.WASHER	1	
34	67267-96L00	.COVER, WIRE SUB ASSY	1	
35	67273-95601	.SPACER	1	
36	67275-95600	.END, CABLE	2	
37	67292-94300	.E RING	3	
38	67294-95600	.SPACER	3	
39	67296-90J20	.SCREW	5	
40	67296-96L00	.SCREW	2	
41	67296-95630	.SCREW	3	
42	67296-95610	.SCREW	2	
43	67297-95600	.WASHER	2	
44	09100-08232	.BOLT (8X30)	1	
45	67269-96L10	.SCREW (5X12)	2	
46	09140-06020	.NUT	3	
47	67288-94320	.WASHER (6.5X24X2)	3	
48	67224-96L00	.ARM, BRAKE ASSY	1	
49	67238-96L00	.GEAR, SHIFT ASSY	1	
50	67284-94L10	.MARK, HANDLE LEVER	1	

NOTE : (DF40A:E11,DF40AST:E34,DF50A:E11,DF60A:(E11,E40),DF60AVT:E11,DF40ASVT:E34):023

FIG.508D




FIG.508D (2-F-7) OPT:REMOTE CONTROL (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
51-1	36620-93JA0	WIRE ASSY, REMOCON (L:5000)	1	
51-2	36620-93JB0	WIRE ASSY, REMOCON (L:3500)	1	
51-3	36620-93JC0	WIRE ASSY, REMOCON (L:6500)	1	
52	33926-98J00	.RESISTOR, TERMINAL	1	
53	36615-96300	.TERMINAL	9	
54-1	67320-93J00	CABLE ASSY, REMOCON (2.4M)	2	
54-2	67320-93J10	CABLE ASSY, REMOCON (3.1M)	2	
54-3	67320-93J20	CABLE ASSY, REMOCON (3.7M)	2	
54-4	67320-93J30	CABLE ASSY, REMOCON (4.2M)	2	
54-5	67320-93J40	CABLE ASSY, REMOCON (4.8M)	2	
54-6	67320-93J50	CABLE ASSY, REMOCON (5.4M)	2	
54-7	67320-93J60	CABLE ASSY, REMOCON (6.1M)	2	
54-8	67320-93J70	CABLE ASSY, REMOCON (6.7M)	2	
54-9	67320-93J80	CABLE ASSY, REMOCON (7.3M)	2	

NOTE : (DF40A:E11,DF40AST:E34,DF50A:E11,DF60A:(E11,E40),DF60AVT:E11,DF40ASVT:E34):023

DF60A_E11_023_508D
OPT:REMOTE CONTROL

FIG.515A

FIG.515A (2-F-8) OPT:REMOCON CABLE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	67320-93J00	CABLE ASSY, REMOCON (2.4M)	2	
1-2	67320-93J10	CABLE ASSY, REMOCON (3.1M)	2	
1-3	67320-93J20	CABLE ASSY, REMOCON (3.7M)	2	
1-4	67320-93J30	CABLE ASSY, REMOCON (4.2M)	2	
1-5	67320-93J40	CABLE ASSY, REMOCON (4.8M)	2	
1-6	67320-93J50	CABLE ASSY, REMOCON (5.4M)	2	
1-7	67320-93J60	CABLE ASSY, REMOCON (6.1M)	2	
1-8	67320-93J70	CABLE ASSY, REMOCON (6.7M)	2	
1-9	67320-93J80	CABLE ASSY, REMOCON (7.3M)	2	




FIG.517A




FIG.517A (2-F-9) OPT:CONCEALED REMOCON (1) (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J34	REMOTE CONTROL ASSY, CONCEAL	1	
2	67298-92E50	.SPRING	1	
3	67296-94310	.SCREW	1	
4	67295-92E10	.SCREW	2	
5	37850-92E27	.SWITCH ASSY, PTT	1	
6	67288-92E60	.WASHER	1	
7	09125-04021	.SCREW	1	
8	67255-92E50	.ARM, NEUTRAL LOCK	1	
9	67251-92E50	.LEVER, HANDLE	1	
10	67261-92E50	.GRIP	1	
11	67256-92E50	.HOLDER, NEUTRAL LOCK	1	
12	67257-92E00	.CAP, LEVER	1	
13	67242-92E50	.SHAFT, FREE ACC	1	
14	67288-92E20	.WASHER	6	
15	67296-88D10	.SCREW (5X16)	4	
16	67288-92E70	.WASHER	1	
17	67296-88D20	.SCREW	3	
18	67295-92E50	.SCREW	3	
19	67287-92E50	.NUT	3	
20	09160-06104	.WASHER	3	
21	67296-88D30	.SCREW	4	
22	67254-92E50	.COVER, LOCK ARM	1	
23	36890-93J01	.WIRE, NEUTRAL & PTT SW	1	
24	67275-95600	.END, CABLE	2	
25	67273-95601	.SPACER	1	
26	67283-92E50	.DECAL, LEVER	1	
27	67284-92E50	.DECAL, CLUTCH	1	
28	67274-92E50	.BASE	1	
29	67211-92E50	.COVER	1	

NOTE : (DF40A,DF50A,DF60A,DF40AST,DF50AVT,DF60AVT):(021,022,023)

DF60A_E11_023_517A
OPT:CONCEALED REMOCON (1)

FIG.518A




FIG.518A (2-F-10) OPT:CONCEALED REMOCON (2) (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J34	REMOTE CONTROL ASSY, CONCEAL	1	
2	67222-92E50	.DUEL PLATE	1	
3	67292-94300	.E RING	3	
4	67288-92E10	.WASHER	1	
5	67291-92E00	.SNAP RING	2	
6	67223-92E50	.BRAKE ADJUST	1	
7	67221-92E50	.HOLDER ASSY	1	
8	67224-92E50	.BRAKE SHOE ASSY	1	
9	67225-92E50	.DISC, BRAKE	1	
10	09140-06020	.NUT	2	
11	67294-92E00	.SPACER	1	
12	37721-95500	.SWITCH ASSY, NEUTRAL	1	
13	67296-92E11	.SCREW, NEUTRAL SWITCH (3X15)	2	
14	67226-92E10	.BOLT, STOPPER	2	
15	67296-92E20	.SCREW (5X25)	2	
16	67240-92E50	.THROTTLE ARM ASSY	1	
17	67228-92E00	.WASHER	1	
18	67286-92E00	.BOLT (6X18)	3	
19	67230-92E00	.SHIFT ARM ASSY	1	
20	09125-05042	.SCREW (5X10)	11	
21	67234-92E00	.CASE, GEAR	1	
22	67245-92E00	.LEVER ASSY, THROTTLE	1	
23	67227-92E00	.STOPPER	1	
24	67296-88D10	.SCREW (5X16)	2	
25	67225-92E00	.SPRING	1	
26	09125-04004	.SCREW	1	
27	67233-92E00	.SPRING	1	
28	67235-92E00	.PLATE, SHIFT LOCK	1	
29	67239-92E10	.PLATE, SHIFT PIN	1	
30	67236-92E00	.ROLLER	1	
31	67237-92E01	.SPRING	5	
32	67238-92E50	.GEAR, DRIVE	1	

NOTE : (DF40A,DF50A,DF60A,DF40AST,DF50AVT,DF60AVT):(021,022,023)

FIG.518A




FIG.518A (2-F-11) OPT:CONCEALED REMOCON (2) (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
33	67239-92E00	.PIN	1	
34	67246-92E50	.SHAFT, DRIVE	1	
35	67252-92E00	.BUSH	1	
36	67291-92E10	.SNAP RING	1	
37	67253-92E10	.WASHER	1	
38	67252-92E10	.BUSH	1	
39	67253-95600	.WASHER	1	
40	67231-92E00	.GEAR, SHIFT	1	
41	67232-95600	.BUSH	1	
42	67241-92E50	.ROD, FREE ACC	1	
43	67232-92E50	.BUSH	1	

NOTE : (DF40A,DF50A,DF60A,DF40AST,DF50AVT,DF60AVT):(021,022,023)

FIG.521A




FIG.521A (2-F-12) OPT:HARNESS (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	36620-93J12	WIRE ASSY, REMOCON EXT (L:2000)	1	
1-2	36620-93J42	WIRE ASSY, REMOCON EXT (L:3000)	1	
2	36620-93J32	WIRE ASSY, R/CON ADAPTER (L:2000)	1	
3	38500-93J90	BUZZER, WARNING	1	
4-1	36620-93J04	WIRE ASSY, REMOCON (L:5000)	1	
4-2	36620-93J54	WIRE ASSY, REMOCON (L:3500)	1	
4-3	36620-93J64	WIRE ASSY, REMOCON (L:6500)	1	
5	09481-10501	.FUSE (10A)	1	
6	36990-87D00	TERMINAL & SLEEVE SET	1	
7	36682-92E00	WIRE, TRIM METER EXT (L:6500)	1	
8	36667-96L20	WIRE, GAUGE EXT	1	

NOTE : (DF40A,DF40AST,DF50A,DF60A,DF50AVT,DF60AVT,DF40ASVT): (020,021)

FIG.521B




FIG.521B (2-F-13) OPT:HARNESS (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	36620-93J12	WIRE ASSY, REMOCON EXT (L:2000)	1	
1-2	36620-93J42	WIRE ASSY, REMOCON EXT (L:3000)	1	
2	36621-93J00	WIRE, R/CON ADAPTER	1	
3	38500-93J90	BUZZER, WARNING	1	
4-1	36620-93J70	WIRE ASSY, REMOCON (L:5000)	1	
4-2	36620-93J80	WIRE ASSY, REMOCON (L:3500)	1	
4-3	36620-93J90	WIRE ASSY, REMOCON (L:6500)	1	
5	36990-87D00	TERMINAL & SLEEVE SET	1	
6	36682-92E00	WIRE, TRIM METER EXT (L:6500)	1	
7	36667-96L20	WIRE, GAUGE EXT	1	

NOTE : (DF40A,DF40AST,DF50A,DF60A,DF50AVT,DF60AVT,DF40ASVT):022

DF60A_E11_023_521B
OPT:HARNESS

FIG.521C




FIG.521C (2-F-14) OPT:HARNESS (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	36620-93JD0	WIRE ASSY, REMOCON EXT (L:2000)	1	
1-2	36620-93JE0	WIRE ASSY, REMOCON EXT (L:3000)	1	
2	36621-93J00	WIRE, R/CON ADAPTER	1	
3	38500-93J90	BUZZER, WARNING	1	
4-1	36620-93JA0	WIRE ASSY, REMOCON (L:5000)	1	
4-2	36620-93JB0	WIRE ASSY, REMOCON (L:3500)	1	
4-3	36620-93JC0	WIRE ASSY, REMOCON (L:6500)	1	
5	33926-98J00	.RESISTOR, TERMINAL	1	
6	36615-96300	.TERMINAL	9	
7	36990-87D00	TERMINAL & SLEEVE SET	1	
8	36682-92E00	WIRE, TRIM METER EXT (L:6500)	1	
9	36667-96L60	WIRE, GAUGE EXT	1	

NOTE : (DF40A,DF40AST,DF50A,DF60A,DF50AVT,DF60AVT,DF40ASVT):023

FIG.521D




FIG.521D (2-G-2) OPT:HARNESS (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38500-93J90	BUZZER, WARNING	1	
2-1	36620-93J04	WIRE ASSY, REMOCON (L:5000)	1	
2-2	36620-93J54	WIRE ASSY, REMOCON (L:3500)	1	
2-3	36620-93J64	WIRE ASSY, REMOCON (L:6500)	1	
3	09481-10501	.FUSE (10A)	1	
4	36990-87D00	TERMINAL & SLEEVE SET	1	
5	36682-92E00	WIRE, TRIM METER EXT (L:6500)	2	
6	36667-96L20	WIRE, GAUGE EXT	1	
7	36630-92E00	WIRE ASSY, INSTRUMENT	1	
8	36660-94480	WIRE, SENDER EXT (L:2000)	1	

NOTE : (DF40AQH,DF40ATH,DF50ATH,DF60AQH,DF60ATH,DF50AVTH,DF60AVTH): (020,021)

FIG.521E




FIG.521E (2-G-3) OPT:HARNESS (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38500-93J90	BUZZER, WARNING	1	
2-1	36620-93J70	WIRE ASSY, REMOCON (L:5000)	1	
2-2	36620-93J80	WIRE ASSY, REMOCON (L:3500)	1	
2-3	36620-93J90	WIRE ASSY, REMOCON (L:6500)	1	
3	36990-87D00	TERMINAL & SLEEVE SET	1	
4	36682-92E00	WIRE, TRIM METER EXT (L:6500)	2	
5	36667-96L20	WIRE, GAUGE EXT	1	
6	36630-92E00	WIRE ASSY, INSTRUMENT	1	
7	36660-94480	WIRE, SENDER EXT (L:2000)	1	

NOTE : (DF40AQH,DF40ATH,DF50ATH,DF60AQH,DF60ATH,DF50AVTH,DF60AVTH):
022

FIG.521F




FIG.521F (2-G-4) OPT:HARNESS (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38500-93J90	BUZZER, WARNING	1	
2-1	36620-93JA0	WIRE ASSY, REMOCON (L:5000)	1	
2-2	36620-93JB0	WIRE ASSY, REMOCON (L:3500)	1	
2-3	36620-93JC0	WIRE ASSY, REMOCON (L:6500)	1	
3	33926-98J00	.RESISTOR, TERMINAL	1	
4	36615-96300	.TERMINAL	9	
5	36990-87D00	TERMINAL & SLEEVE SET	1	
6	36682-92E00	WIRE, TRIM METER EXT (L:6500)	2	
7	36667-96L20	WIRE, GAUGE EXT	1	
8	36630-92E00	WIRE ASSY, INSTRUMENT	1	
9	36660-94480	WIRE, SENDER EXT (L:2000)	1	

NOTE : (DF40AQH,DF40ATH,DF50ATH,DF60AQH,DF60ATH,DF50AVTH,DF60AVTH): 023

FIG.530A




FIG.530A (2-G-5) OPT:SWITCH (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-96J01	PANEL ASSY, IGNITION SWITCH	1	
2	37110-93J02	.SWITCH ASSY, IGNITION	1	
3-1	37141-99E00	..KEY (931)	2	
3-2	37141-99E10	..KEY (932)	2	
3-3	37141-99E20	..KEY (933)	2	
3-4	37141-99E30	..KEY (934)	2	
3-5	37141-99E40	..KEY (935)	2	
3-6	37141-99E50	..KEY (936)	2	
3-7	37141-99E60	..KEY (937)	2	
3-8	37141-99E70	..KEY (938)	2	
3-9	37141-99E80	..KEY (939)	2	
3-10	37141-99E90	..KEY (940)	2	
3-11	37141-99EA0	..KEY (941)	2	
3-12	37141-99EB0	..KEY (942)	2	
4	37143-99E01	..CAP, KEY	1	
5	37149-93J00	..CAP, CYLINDER BODY	1	
6	37139-99E00	.PANEL, IGNITION SW	1	
7	38500-93J90	.BUZZER, WARNING	1	
8	09407-08401	.CLAMP (L:80)	1	
9	37803-93J06	PANEL ASSY, EMERGENCY SW	1	
10	37820-93J11	.SWITCH ASSY, EMERGENCY	1	
11	37823-92E02	..PLATE ASSY, EMERGENCY SW LOCK	1	
12	37826-92J10	..NUT	1	
13	37825-99E10	.PANEL, EMERGENCY STOP SW	1	
14	03122-05169	.SCREW	4	
15	37805-93J00	PANEL ASSY, PTT SW	1	
16	37855-99E00	.PANEL, PTT SW	1	
17	37210-93J00	PANEL ASSY, LIGHTING SW	1	
18	37212-93J00	.PANEL, LIGHTING SW	1	
19	37100-96J27	PANEL ASSY, ENGINE SWITCH	1	

NOTE : (DF40A,DF40AST,DF50A,DF60A,DF50AVT,DF60AVT,DF40ASVT): (020,021)

DF60A_E11_023_530A
OPT:SWITCH

FIG.530A




FIG.530A (2-G-6) OPT:SWITCH (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	37110-93J02	.SWITCH ASSY, IGNITION	1	
21-1	37141-99E00	..KEY (931)	2	
21-2	37141-99E10	..KEY (932)	2	
21-3	37141-99E20	..KEY (933)	2	
21-4	37141-99E30	..KEY (934)	2	
21-5	37141-99E40	..KEY (935)	2	
21-6	37141-99E50	..KEY (936)	2	
21-7	37141-99E60	..KEY (937)	2	
21-8	37141-99E70	..KEY (938)	2	
21-9	37141-99E80	..KEY (939)	2	
21-10	37141-99E90	..KEY (940)	2	
21-11	37141-99EA0	..KEY (941)	2	
21-12	37141-99EB0	..KEY (942)	2	
22	37143-99E01	..CAP, KEY	1	
23	37149-93J00	..CAP, CYLINDER BODY	1	
24	37139-99E40	.PANEL, IGNITION SWITCH	1	
25	37820-93J11	.SWITCH ASSY, EMERGENCY	1	
26	37823-92E02	..PLATE ASSY, EMERGENCY SW LOCK	1	
27	37826-92J10	..NUT	1	
28	03121-0516A	.SCREW	4	
29	38500-93J90	.BUZZER, WARNING	1	
30	09407-08401	.CLAMP (L:80)	1	
31	37860-87L00	PANEL ASSY, TROLLING CONTROL SW	1	
32	37862-87L00	.PANEL	1	
33	09131-05004	.SCREW (5X16)	4	

NOTE : (DF40A,DF40AST,DF50A,DF60A,DF50AVT,DF60AVT,DF40ASVT): (020,021)

DF60A_E11_023_530A
OPT:SWITCH

FIG.530B




FIG.530B (2-G-7) OPT:SWITCH (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-98L00	PANEL ASSY, MAIN SWITCH	1	
2	37110-98L00	.SWITCH ASSY, MAIN	1	
3-1	37141-99E00	..KEY (931)	1	
3-2	37141-99E10	..KEY (932)	1	
3-3	37141-99E20	..KEY (933)	1	
3-4	37141-99E30	..KEY (934)	1	
3-5	37141-99E40	..KEY (935)	1	
3-6	37141-99E50	..KEY (936)	1	
3-7	37141-99E60	..KEY (937)	1	
3-8	37141-99E70	..KEY (938)	1	
3-9	37141-99E80	..KEY (939)	1	
3-10	37141-99E90	..KEY (940)	1	
3-11	37141-99EA0	..KEY (941)	1	
3-12	37141-99EB0	..KEY (942)	1	
4-1	37141-98L00	..KEY (931)	1	
4-2	37141-98L10	..KEY (932)	1	
4-3	37141-98L20	..KEY (933)	1	
4-4	37141-98L30	..KEY (934)	1	
4-5	37141-98L40	..KEY (935)	1	
4-6	37141-98L50	..KEY (936)	1	
4-7	37141-98L60	..KEY (937)	1	
4-8	37141-98L70	..KEY (938)	1	
4-9	37141-98L80	..KEY (939)	1	
4-10	37141-98L90	..KEY (940)	1	
4-11	37141-98LA0	..KEY (941)	1	
4-12	37141-98LB0	..KEY (942)	1	
5	37138-98L00	.COVER, MAIN SW PANEL	1	
6	03142-05169	.SCREW	4	
7	38500-93J90	.BUZZER, WARNING	1	
8	37803-98L00	PANEL ASSY, EMERGENCY SW	1	
9	37820-98L00	.SWITCH ASSY, EMERGENCY	1	

NOTE : (DF40A,DF40AST,DF50A,DF60A,DF50AVT,DF60AVT,DF40ASVT): (022,023)

FIG.530B




FIG.530B (2-G-8) OPT:SWITCH (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
10	37823-98L01	..PLATE, EMERGENCY SW LOCK	1	
11	37832-98L00	.COVER, EMERGENCY SW PANEL	1	
12	03142-05169	.SCREW	4	
13	37100-98L10	PANEL ASSY, MAIN SWITCH	1	
14	37110-98L00	.SWITCH ASSY, MAIN	1	
15-1	37141-99E00	..KEY (931)	1	
15-2	37141-99E10	..KEY (932)	1	
15-3	37141-99E20	..KEY (933)	1	
15-4	37141-99E30	..KEY (934)	1	
15-5	37141-99E40	..KEY (935)	1	
15-6	37141-99E50	..KEY (936)	1	
15-7	37141-99E60	..KEY (937)	1	
15-8	37141-99E70	..KEY (938)	1	
15-9	37141-99E80	..KEY (939)	1	
15-10	37141-99E90	..KEY (940)	1	
15-11	37141-99EA0	..KEY (941)	1	
15-12	37141-99EB0	..KEY (942)	1	
16-1	37141-98L00	..KEY (931)	1	
16-2	37141-98L10	..KEY (932)	1	
16-3	37141-98L20	..KEY (933)	1	
16-4	37141-98L30	..KEY (934)	1	
16-5	37141-98L40	..KEY (935)	1	
16-6	37141-98L50	..KEY (936)	1	
16-7	37141-98L60	..KEY (937)	1	
16-8	37141-98L70	..KEY (938)	1	
16-9	37141-98L80	..KEY (939)	1	
16-10	37141-98L90	..KEY (940)	1	
16-11	37141-98LA0	..KEY (941)	1	
16-12	37141-98LB0	..KEY (942)	1	
17	37138-98L10	.COVER, MAIN SW PANEL VERT	1	
18	37820-98L00	.SWITCH ASSY, EMERGENCY	1	

NOTE : (DF40A,DF40AST,DF50A,DF60A,DF50AVT,DF60AVT,DF40ASVT): (022,023)

DF60A_E11_023_530B
OPT:SWITCH

FIG.530B




FIG.530B (2-G-9) OPT:SWITCH (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
19	37823-98L00	..PLATE, EMERGENCY SW LOCK	1	
20	03142-05169	.SCREW	4	
21	38500-93J90	.BUZZER, WARNING	1	
22	37100-98L20	PANEL ASSY, MAIN SWITCH HORIZ	1	
23	37110-98L00	.SWITCH ASSY, MAIN	1	
24-1	37141-99E00	..KEY (931)	1	
24-2	37141-99E10	..KEY (932)	1	
24-3	37141-99E20	..KEY (933)	1	
24-4	37141-99E30	..KEY (934)	1	
24-5	37141-99E40	..KEY (935)	1	
24-6	37141-99E50	..KEY (936)	1	
24-7	37141-99E60	..KEY (937)	1	
24-8	37141-99E70	..KEY (938)	1	
24-9	37141-99E80	..KEY (939)	1	
24-10	37141-99E90	..KEY (940)	1	
24-11	37141-99EA0	..KEY (941)	1	
24-12	37141-99EB0	..KEY (942)	1	
25-1	37141-98L00	..KEY (931)	1	
25-2	37141-98L10	..KEY (932)	1	
25-3	37141-98L20	..KEY (933)	1	
25-4	37141-98L30	..KEY (934)	1	
25-5	37141-98L40	..KEY (935)	1	
25-6	37141-98L50	..KEY (936)	1	
25-7	37141-98L60	..KEY (937)	1	
25-8	37141-98L70	..KEY (938)	1	
25-9	37141-98L80	..KEY (939)	1	
25-10	37141-98L90	..KEY (940)	1	
25-11	37141-98LA0	..KEY (941)	1	
25-12	37141-98LB0	..KEY (942)	1	
26	37138-98L20	.COVER, MAIN SW PANEL HORIZ	1	
27	37820-98L00	.SWITCH ASSY, EMERGENCY	1	

NOTE : (DF40A,DF40AST,DF50A,DF60A,DF50AVT,DF60AVT,DF40ASVT): (022,023)

DF60A_E11_023_530B
OPT:SWITCH

FIG.530B




FIG.530B (2-G-10) OPT:SWITCH (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	37823-98L00	..PLATE, EMERGENCY SW LOCK	1	
29	03142-05169	.SCREW	4	
30	38500-93J90	.BUZZER, WARNING	1	
31	37860-98L00	PANEL ASSY, TROLLING CONTROL SW	1	
32	37865-98L00	.COVER, TROLLING CONTROL SW	1	
33	03142-05169	.SCREW	4	
34	37805-88L00	PANEL ASSY, PTT SW	1	
35	37850-88L40	.SWITCH, PTT	1	
36	37865-88L00	.COVER, PTT SW	1	
37	03142-05169	.SCREW	4	
38	37210-93J00	PANEL ASSY, LIGHTING SW	1	
39	37212-93J00	.PANEL, LIGHTING SW	1	

NOTE : (DF40A,DF40AST,DF50A,DF60A,DF50AVT,DF60AVT,DF40ASVT): (022,023)

DF60A_E11_023_530B
OPT:SWITCH

FIG.530C




FIG.530C (2-G-11) OPT:SWITCH (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-98L00	PANEL ASSY, MAIN SWITCH	1	
2	37110-98L00	.SWITCH ASSY, MAIN	1	
3-1	37141-99E00	..KEY (931)	1	
3-2	37141-99E10	..KEY (932)	1	
3-3	37141-99E20	..KEY (933)	1	
3-4	37141-99E30	..KEY (934)	1	
3-5	37141-99E40	..KEY (935)	1	
3-6	37141-99E50	..KEY (936)	1	
3-7	37141-99E60	..KEY (937)	1	
3-8	37141-99E70	..KEY (938)	1	
3-9	37141-99E80	..KEY (939)	1	
3-10	37141-99E90	..KEY (940)	1	
3-11	37141-99EA0	..KEY (941)	1	
3-12	37141-99EB0	..KEY (942)	1	
4-1	37141-98L00	..KEY (931)	1	
4-2	37141-98L10	..KEY (932)	1	
4-3	37141-98L20	..KEY (933)	1	
4-4	37141-98L30	..KEY (934)	1	
4-5	37141-98L40	..KEY (935)	1	
4-6	37141-98L50	..KEY (936)	1	
4-7	37141-98L60	..KEY (937)	1	
4-8	37141-98L70	..KEY (938)	1	
4-9	37141-98L80	..KEY (939)	1	
4-10	37141-98L90	..KEY (940)	1	
4-11	37141-98LA0	..KEY (941)	1	
4-12	37141-98LB0	..KEY (942)	1	
5	37138-98L00	.COVER, MAIN SW PANEL	1	
6	03142-05169	.SCREW	4	
7	38500-93J90	.BUZZER, WARNING	1	
8	37803-98L00	PANEL ASSY, EMERGENCY SW	1	
9	37820-98L00	.SWITCH ASSY, EMERGENCY	1	

NOTE : (DF40AQH,DF40ATH,DF50ATH,DF60A,DF50AVT,DF60AQH,DF60ATH, DF60AVTH):(022,023)

FIG.530C




FIG.530C (2-G-12) OPT:SWITCH (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
10	37823-98L01	..PLATE, EMERGENCY SW LOCK	1	
11	37832-98L00	.COVER, EMERGENCY SW PANEL	1	
12	03142-05169	.SCREW	4	
13	37100-98L10	PANEL ASSY, MAIN SWITCH	1	
14	37110-98L00	.SWITCH ASSY, MAIN	1	
15-1	37141-99E00	..KEY (931)	1	
15-2	37141-99E10	..KEY (932)	1	
15-3	37141-99E20	..KEY (933)	1	
15-4	37141-99E30	..KEY (934)	1	
15-5	37141-99E40	..KEY (935)	1	
15-6	37141-99E50	..KEY (936)	1	
15-7	37141-99E60	..KEY (937)	1	
15-8	37141-99E70	..KEY (938)	1	
15-9	37141-99E80	..KEY (939)	1	
15-10	37141-99E90	..KEY (940)	1	
15-11	37141-99EA0	..KEY (941)	1	
15-12	37141-99EB0	..KEY (942)	1	
16-1	37141-98L00	..KEY (931)	1	
16-2	37141-98L10	..KEY (932)	1	
16-3	37141-98L20	..KEY (933)	1	
16-4	37141-98L30	..KEY (934)	1	
16-5	37141-98L40	..KEY (935)	1	
16-6	37141-98L50	..KEY (936)	1	
16-7	37141-98L60	..KEY (937)	1	
16-8	37141-98L70	..KEY (938)	1	
16-9	37141-98L80	..KEY (939)	1	
16-10	37141-98L90	..KEY (940)	1	
16-11	37141-98LA0	..KEY (941)	1	
16-12	37141-98LB0	..KEY (942)	1	
17	37138-98L10	.COVER, MAIN SW PANEL VERT	1	
18	37820-98L00	.SWITCH ASSY, EMERGENCY	1	

NOTE : (DF40AQH,DF40ATH,DF50ATH,DF60A,DF50AVT,DF60AQH,DF60ATH, DF60AVTH):(022,023)

FIG.530C




FIG.530C (2-G-13) OPT:SWITCH (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
19	37823-98L00	..PLATE, EMERGENCY SW LOCK	1	
20	03142-05169	.SCREW	4	
21	38500-93J90	.BUZZER, WARNING	1	
22	37100-98L20	PANEL ASSY, MAIN SWITCH HORIZ	1	
23	37110-98L00	.SWITCH ASSY, MAIN	1	
24-1	37141-99E00	..KEY (931)	1	
24-2	37141-99E10	..KEY (932)	1	
24-3	37141-99E20	..KEY (933)	1	
24-4	37141-99E30	..KEY (934)	1	
24-5	37141-99E40	..KEY (935)	1	
24-6	37141-99E50	..KEY (936)	1	
24-7	37141-99E60	..KEY (937)	1	
24-8	37141-99E70	..KEY (938)	1	
24-9	37141-99E80	..KEY (939)	1	
24-10	37141-99E90	..KEY (940)	1	
24-11	37141-99EA0	..KEY (941)	1	
24-12	37141-99EB0	..KEY (942)	1	
25-1	37141-98L00	..KEY (931)	1	
25-2	37141-98L10	..KEY (932)	1	
25-3	37141-98L20	..KEY (933)	1	
25-4	37141-98L30	..KEY (934)	1	
25-5	37141-98L40	..KEY (935)	1	
25-6	37141-98L50	..KEY (936)	1	
25-7	37141-98L60	..KEY (937)	1	
25-8	37141-98L70	..KEY (938)	1	
25-9	37141-98L80	..KEY (939)	1	
25-10	37141-98L90	..KEY (940)	1	
25-11	37141-98LA0	..KEY (941)	1	
25-12	37141-98LB0	..KEY (942)	1	
26	37138-98L20	.COVER, MAIN SW PANEL HORIZ	1	
27	37820-98L00	.SWITCH ASSY, EMERGENCY	1	

NOTE : (DF40AQH,DF40ATH,DF50ATH,DF60A,DF50AVT,DF60AQH,DF60ATH, DF60AVTH):(022,023)

FIG.530C




FIG.530C (2-G-14) OPT:SWITCH (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	37823-98L00	..PLATE, EMERGENCY SW LOCK	1	
29	03142-05169	.SCREW	4	
30	38500-93J90	.BUZZER, WARNING	1	
31	37860-98L00	PANEL ASSY, TROLLING CONTROL SW	1	
32	37865-98L00	.COVER, TROLLING CONTROL SW	1	
33	03142-05169	.SCREW	4	
34	37805-88L00	PANEL ASSY, PTT SW	1	
35	37850-88L40	.SWITCH, PTT	1	
36	37865-88L00	.COVER, PTT SW	1	
37	03142-05169	.SCREW	4	

NOTE : (DF40AQH,DF40ATH,DF50ATH,DF60A,DF50AVT,DF60AQH,DF60ATH, DF60AVTH):(022,023)

FIG.544A




FIG.544A (2-H-2) OPT:REMOTE CONTROL ASSY SINGLE (1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-88L01	REMOTE CONTROL ASSY, SINGLE	1	
2	67261-88L10	.GRIP, REMOCON NO.2	1	
3	67261-88L00	.GRIP, REMOCON NO.1	1	
4	37850-88L00	.SWITCH ASSY, GRIP PTT	1	
5	67296-88L00	.SCREW	3	
6	67288-92E20	.WASHER	3	
7	67212-88L00	.COVER, PLUG	1	
8	68111-88L00	.EMBLEM, MARK	1	
9	67257-88L00	.CAP, REMOCON LEVER	1	
10	67281-88L00	.DECAL	1	
11	67296-92E60	.SCREW	2	
12	67288-92E60	.WASHER	2	
13	67253-92E00	.WASHER	1	
14	67275-95600	.END, CABLE	2	
15	67273-95601	.SPACER	1	
16	67271-88L10	.COVER, REMOCON LEVER LOWER	1	LOWER
17	67211-88L00	.COVER	1	
18	67264-88L00	.COVER, LEVER DESIGN	1	
19	67264-88L10	.COVER, LEVER PLATING	1	
20	67251-88L00	.LEVER, HANDLE	1	
21	67500-88L00	KIT, R/CON SPACER SINGLE	1	
22	09125-05135	.SCREW (5X65)	4	
23	09160-05029	.WASHER (5.5X12X0.8)	4	
24	09140-05005	.NUT (M5)	4	
25	67273-88L00	.GROMMET, R/CON SINGLE	1	

FIG.545A




FIG.545A (2-H-3) OPT:REMOTE CONTROL ASSY SINGLE (2)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-88L01	REMOTE CONTROL ASSY, SINGLE	1	
2	67222-92E00	.DUEL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67272-88L00	.GOM SEAL, WATERPROOF	1	
7	67291-92E00	.SNAP RING	1	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	09140-06020	.NUT	2	
11	37721-88L01	.SWITCH ASSY, NEUTRAL	1	
12	67236-92E00	.ROLLER	1	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER	1	
16	67226-92E10	.BOLT, STOPPER	1	
17	67240-92E00	.THROTTLE ARM ASSY	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-88L00	.ARM ASSY, REMOCON SHIFT	1	
21	09125-05042	.SCREW (5X10)	10	
22	67234-88L00	.CASE, REMOCON GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67237-92E01	.SPRING	5	
29	67269-92E01	.BRACKET	1	
30	67296-88D10	.SCREW (5X16)	1	
31	67238-88L00	.GEAR, REMOCON DRIVE	1	
32	67231-88L00	.GEAR, REMOCON SHIFT	1	
33	67232-88L00	.BUSH, SHIFT GEAR	1	
34	67241-88L00	.ROD, REMOCON FREE ACCEL	1	
35	67239-92E00	.PIN	1	
36	67246-88L00	.SHAFT, REMOCON DRIVE	1	

DF60A_E11_023_545A
OPT:REMOTE CONTROL ASSY SINGLE (2)

FIG.545A




FIG.545A (2-H-4) OPT:REMOTE CONTROL ASSY SINGLE (2)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
37	67291-92E10	.SNAP RING	1	
38	67243-92E00	.CAP, HOLE	1	
39	67252-88L00	.BUSH, REMOCON DRIVE SHAFT	1	
40	67253-88L00	.WASHER, REMOCON DRIVE SHAFT	1	
41	67239-92E10	.PLATE, SHIFT PIN	1	
42	67274-88L00	.FLANGE, COVER BASE	2	
43	67296-95610	.SCREW	4	
44	67296-92E30	.SCREW	4	
45	09160-05024	.WASHER (5.5X16X1.5)	4	
46	67287-92E00	.NUT (M5)	4	
47	67273-88L00	.GROMMET, R/CON SINGLE	1	

DF60A_E11_023_545A
OPT:REMOTE CONTROL ASSY SINGLE (2)

FIG.570A




FIG.570A (2-H-5) OPT:TILLER HANDLE (DF40A,DF50A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	63002-88L28-YAY	KIT, TILLER HANDLE (BLACK)	1	->63002-88L2A-YAY
1-2	63002-88L2A-YAY	KIT, TILLER HANDLE (BLACK)	1	SEE NOTE
2	21110-88L00	.LEVER, SHIFT	1	
3	23230-88L00	.CABLE, SHIFT	1	
4	36620-88L11	.WIRE ASSY, HANDLE	1	
5	37110-87L02	.SWITCH ASSY, IGNITION	1	
6-1	37141-99E00	..KEY (931)	1	
6-2	37141-99E10	..KEY (932)	1	
6-3	37141-99E20	..KEY (933)	1	
6-4	37141-99E30	..KEY (934)	1	
6-5	37141-99E40	..KEY (935)	1	
6-6	37141-99E50	..KEY (936)	1	
6-7	37141-99E60	..KEY (937)	1	
6-8	37141-99E70	..KEY (938)	1	
6-9	37141-99E80	..KEY (939)	1	
6-10	37141-99E90	..KEY (940)	1	
6-11	37141-99EA0	..KEY (941)	1	
6-12	37141-99EB0	..KEY (942)	1	
7	37143-99E01	..CAP, KEY	1	
8	37149-93J00	..CAP, CYLINDER BODY	1	
9	37820-87L11	.SWITCH ASSY, EMERGENCY	1	
10	37823-92E02	..PLATE ASSY, EMERGENCY SW LOCK	1	
11	37826-92J10	..NUT	1	
12	38500-93J90	.BUZZER, WARNING	1	
13	37850-87L01	.SWITCH ASSY, PTT	1	
14	37852-87J00	.PLATE, TRIM SWITCH	1	
15	63121-88L10	.COVER, UNDER	1	
16	63210-88L00	.GRIP, HANDLE	1	
17	63221-88L00	.SHAFT, THROTTLE	1	
18	63223-92D00	.STOPPER, HANDLE ROD	1	
19	63225-88L00	.BUSH, HANDLE ROD	1	

NOTE : FROM 04003F-141090,FROM 05003F-141319

FIG.570A




FIG.570A (2-H-6) OPT:TILLER HANDLE (DF40A,DF50A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	63227-93200	.PIN, HANDLE ROD (L:14)	1	
21	63235-88L00	.PLATE, THROTTLE SHAFT	1	
22	63246-88L00	.STOPPER, THROTTLE ADJUST	1	
23	63250-88L00	.ARM ASSY, THROTTLE	1	
24	63251-87J00	.BOLT, SHIFT GEAR ASSY (6X12)	4	
25	63260-88L00	.GEAR ASSY, SHIFT	1	
26	63272-87J00	..PLATE, BALL GUIDE	1	
27	63273-87J00	..BALL	1	
28	63262-87J00	.BUSH, SHIFT LEVER	1	
29	63271-87J00	.PLATE, LOCK	1	
30	63248-99J00	.PLATE, THROTTLE ADJ NOTCH	1	
31	63261-87J00	.BUSH, SHIFT GEAR	1	
32	63274-87J00	.E RING	1	
33	63610-88L00	.CABLE, THROTTLE	1	
34	37853-88L90	.GROMMET, PTT SW LEAD	1	
35	63626-88L00	.GROMMET, CABLE	1	
36	67292-87J00	.E RING	2	
37	09126-06015	.SCREW (6X23)	1	
38	09163-06001	.WASHER (6.4X12X0.5)	1	
39	09440-12027	.SPRING	1	
40	21112-88L00	.BOLT, SHIFT LEVER	1	
41	09125-05047	.SCREW (5X14)	6	
42	63611-88L00	.BOLT, CLAMP BRACKET	3	
43	63612-87J00	.BRACKET, CLAMP	1	
44	34200-87L00	.TACHOMETER ASSY, WITH MONITOR	1	
45	36617-88L90	.CLAMP, MAIN HARNESS	1	
46	37112-88L91	.LABEL, IGNITION SW	1	
47	37835-91J00-YAY	.LABEL, STOP (BLACK)	1	
48	37851-88L90	.BASE, PTT SW	1	
49	37852-88L90	.HARNESS GUIDE	1	
50	37861-87L11	.SWITCH, TROLLING CONTROL	1	
51	37864-88L91	.LABEL, TROLL MODE	1	
52	63244-99J00	.KNOB, THROTTLE ADJ	1	
53	63245-99J00	.BUSH, THROTTLE ADJ	1	
54	63612-88L10	.BRACKET, CLAMP SHIFT	1	
55	09260-10006	.BALL	1	

FIG.570A




FIG.570A (2-H-7) OPT:TILLER HANDLE (DF40A,DF50A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
56	19120-88L12	.LEVER, THROTTLE	1	
57	21131-88L02	.MARK, CLUTCH SHIFT	1	
58	43761-88L01-YAY	.BRACKET, TILLER HANDLE (BLACK)	1	
59	43762-88L00	.BOLT, TILLER HANDLE PIVOT	1	
60	43768-88L00	.SPACER, TILLER HANDLE	1	
61	09116-08137	.BOLT (8X22)	1	
62	09159-12014	.NUT (12X17)	1	
63	09160-12066	.WASHER (12.5X22X2.5)	2	
64	09160-12124	.WASHER (12.5X32X1.5)	1	
65	63115-88L01	.BUSH, TILLER HANDLE PIVOT	2	
66	09164-13010	.WASHER	1	
67	63215-93110	.MARK, HANDLE GRIP	1	
68	09116-10150	.BOLT (10X55)	2	
69	63132-88L00	.STOPPER, TILLER HANDLE	1	
70	63251-88L90	.BOLT	2	
71	37855-88L90	.SCREW, THROTTLE GRIP	1	
72	37854-88L90	.WASHER, THROTTLE GRIP	1	
73	63258-88L00	.WASHER	1	
74	09440-06037	.SPRING	1	
75	03522-05169	.SCREW	3	
76	63247-99J00	.PLATE, THROTTLE ADJ KNOB	1	
77	63111-88L01-YAY	.HOUSING, TILLER HANDLE (BLACK)	1	
78	33834-88L00	.TUBE, CABLE PROTECTOR	1	
79	65793-88L00	.HOLDER, FUEL HOSE	1	
80	09116-06237	.BOLT (6X15)	2	
81	22511-99011	.NIPPLE, GREASE	1	
82	43411-88L02	.ADJUSTER, STEERING	1	
83	43415-88L00	.PLATE, STEERING ADJUSTER	1	
84	43512-88L00	.SHAFT, STRG ADJUSTER THREAD	1	
85	43513-88L00	.BOLT, STEERING ADJUSTER	1	
86	43514-88L00	.PLATE, STRG ADJUSTER FRICTION	2	
87	43515-88L00	.WASHER, STRG ADJ FRICTION PLATE	2	

DF60A_E11_023_570A
OPT:TILLER HANDLE

FIG.570A




FIG.570A (2-H-8) OPT:TILLER HANDLE (DF40A,DF50A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
88	43516-88L00	.WASHER, STRG ADJUSTER FRICTION	1	
89	43517-88L00	.SPACER, STEERING ADJUSTER	1	
90	09159-08059	.NUT (M8)	1	
91	09161-08011	.WASHER (8.2X18X1.2)	2	
92	22511-99011	.NIPPLE, GREASE	1	SEE NOTE

NOTE : FROM 04003F-141090,FROM 05003F-141319

FIG.570B




FIG.570B (2-H-9) OPT:TILLER HANDLE (SEE NOTE 1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	63002-88L17-YAY	KIT, TILLER HANDLE (BLACK)	1	->63002-88L18-YAY
1-2	63002-88L18-YAY	KIT, TILLER HANDLE (BLACK)	1	SEE NOTE 2
2	21110-88L00	.LEVER, SHIFT	1	
3	23230-88L00	.CABLE, SHIFT	1	
4	36620-88L11	.WIRE ASSY, HANDLE	1	
5	37110-87L02	.SWITCH ASSY, IGNITION	1	
6-1	37141-99E00	..KEY (931)	1	
6-2	37141-99E10	..KEY (932)	1	
6-3	37141-99E20	..KEY (933)	1	
6-4	37141-99E30	..KEY (934)	1	
6-5	37141-99E40	..KEY (935)	1	
6-6	37141-99E50	..KEY (936)	1	
6-7	37141-99E60	..KEY (937)	1	
6-8	37141-99E70	..KEY (938)	1	
6-9	37141-99E80	..KEY (939)	1	
6-10	37141-99E90	..KEY (940)	1	
6-11	37141-99EA0	..KEY (941)	1	
6-12	37141-99EB0	..KEY (942)	1	
7	37143-99E01	..CAP, KEY	1	
8	37149-93J00	..CAP, CYLINDER BODY	1	
9	37820-87L11	.SWITCH ASSY, EMERGENCY	1	
10	37823-92E02	..PLATE ASSY, EMERGENCY SW LOCK	1	
11	37826-92J10	..NUT	1	
12	38500-93J90	.BUZZER, WARNING	1	
13	37850-87L01	.SWITCH ASSY, PTT	1	
14	37852-87J00	.PLATE, TRIM SWITCH	1	
15	63121-88L10	.COVER, UNDER	1	

NOTE 1 : DF40AST,DF60A,DF50AVT,DF60AVT,DF40ASVT

NOTE 2 : FROM 04004F-140214,FROM 04005F-140360,
FROM 05004F-140056,FROM 06002F-142205,
FROM 06003F-140202

DF60A_E11_023_570B
OPT:TILLER HANDLE

FIG.570B




FIG.570B (2-H-10) OPT:TILLER HANDLE (SEE NOTE 1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
16	63210-88L00	.GRIP, HANDLE	1	
17	63221-88L00	.SHAFT, THROTTLE	1	
18	63223-92D00	.STOPPER, HANDLE ROD	1	
19	63225-88L00	.BUSH, HANDLE ROD	1	
20	63227-93200	.PIN, HANDLE ROD (L:14)	1	
21	63235-88L00	.PLATE, THROTTLE SHAFT	1	
22	63246-88L00	.STOPPER, THROTTLE ADJUST	1	
23	63250-88L00	.ARM ASSY, THROTTLE	1	
24	63251-87J00	.BOLT, SHIFT GEAR ASSY (6X12)	4	
25	63260-88L00	.GEAR ASSY, SHIFT	1	
26	63272-87J00	..PLATE, BALL GUIDE	1	
27	63273-87J00	..BALL	1	
28	63262-87J00	.BUSH, SHIFT LEVER	1	
29	63271-87J00	.PLATE, LOCK	1	
30	63248-99J00	.PLATE, THROTTLE ADJ NOTCH	1	
31	63261-87J00	.BUSH, SHIFT GEAR	1	
32	63274-87J00	.E RING	1	
33	63610-88L00	.CABLE, THROTTLE	1	
34	37853-88L90	.GROMMET, PTT SW LEAD	1	
35	63626-88L00	.GROMMET, CABLE	1	
36	67292-87J00	.E RING	2	
37	09126-06015	.SCREW (6X23)	1	
38	09163-06001	.WASHER (6.4X12X0.5)	1	
39	09440-12027	.SPRING	1	
40	21112-88L00	.BOLT, SHIFT LEVER	1	
41	09125-05047	.SCREW (5X14)	6	
42	63611-88L00	.BOLT, CLAMP BRACKET	3	
43	63612-87J00	.BRACKET, CLAMP	1	
44	34200-87L00	.TACHOMETER ASSY, WITH MONITOR	1	
45	36617-88L90	.CLAMP, MAIN HARNESS	1	
46	37112-88L91	.LABEL, IGNITION SW	1	
47	37835-91J00-YAY	.LABEL, STOP (BLACK)	1	

NOTE 1 : DF40AST,DF60A,DF50AVT,DF60AVT,DF40ASVT

DF60A_E11_023_570B
OPT:TILLER HANDLE

FIG.570B




FIG.570B (2-H-11) OPT:TILLER HANDLE (SEE NOTE 1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
48	37851-88L90	.BASE, PTT SW	1	
49	37852-88L90	.HARNESS GUIDE	1	
50	37861-87L11	.SWITCH, TROLLING CONTROL	1	
51	37864-88L91	.LABEL, TROLL MODE	1	
52	63244-99J00	.KNOB, THROTTLE ADJ	1	
53	63245-99J00	.BUSH, THROTTLE ADJ	1	
54	63612-88L10	.BRACKET, CLAMP SHIFT	1	
55	09260-10006	.BALL	1	
56	19120-88L12	.LEVER, THROTTLE	1	
57	21131-88L02	.MARK, CLUTCH SHIFT	1	
58	43761-88L01-YAY	.BRACKET, TILLER HANDLE (BLACK)	1	
59	43762-88L00	.BOLT, TILLER HANDLE PIVOT	1	
60	43768-88L00	.SPACER, TILLER HANDLE	1	
61	09116-08137	.BOLT (8X22)	1	
62	09159-12014	.NUT (12X17)	1	
63	09160-12066	.WASHER (12.5X22X2.5)	2	
64	09160-12124	.WASHER (12.5X32X1.5)	1	
65	63115-88L01	.BUSH, TILLER HANDLE PIVOT	2	
66	09164-13010	.WASHER	1	
67	63215-93110	.MARK, HANDLE GRIP	1	
68	09116-10150	.BOLT (10X55)	2	
69	43770-99E03	.ADJUSTER ASSY, STEERING	1	
70	63132-88L00	.STOPPER, TILLER HANDLE	1	
71	63251-88L90	.BOLT	2	
72	37855-88L90	.SCREW, THROTTLE GRIP	1	
73	37854-88L90	.WASHER, THROTTLE GRIP	1	
74	63258-88L00	.WASHER	1	
75	09440-06037	.SPRING	1	
76	03522-05169	.SCREW	3	
77	63247-99J00	.PLATE, THROTTLE ADJ KNOB	1	

NOTE 1 : DF40AST,DF60A,DF50AVT,DF60AVT,DF40ASVT

FIG.570B




FIG.570B (2-H-12) OPT:TILLER HANDLE (SEE NOTE 1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
78	63111-88L01-YAY	.HOUSING, TILLER HANDLE (BLACK)	1	
79	33834-88L00	.TUBE, CABLE PROTECTOR	1	
80	65793-88L00	.HOLDER, FUEL HOSE	1	
81	09116-06237	.BOLT (6X15)	2	
82	22511-99011	.NIPPLE, GREASE	1	SEE NOTE 2

NOTE 1 : DF40AST,DF60A,DF50AVT,DF60AVT,DF40ASVT

NOTE 2 : FROM 04004F-140214,FROM 04005F-140360,
FROM 05004F-140056,FROM 06002F-142205,
FROM 06003F-140202

FIG.575A




FIG.575A (2-H-13) OPT:DRAG LINK (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67700-93J00	LINK SET, DRAG	1	
2	41161-94400	.SEAL, STEERING CABLE	1	
3	67701-87J11	.LINK ASSY, DRAG	1	
4	67721-87J00	..SPACER	1	
5	67725-99E00	..BOLT, DRAG LINK	1	
6	67726-99E00	..NUT, LOCK	2	
7	67728-99E00	..WASHER	4	

NOTE : DF40AQH,DF40ATH,DF50ATH,DF60AQH,DF60ATH,DF50AVTH,DF60AVTH

DF60A_E11_023_575A
OPT:DRAG LINK

FIG.585A




FIG.585A (2-H-14) OPT:GASKET SET (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11400-88872	GASKET SET	1	
2	11141-88L00	.GASKET, CYLINDER HEAD	1	
3	11189-88L00	.GASKET, CYLINDER HEAD COVER	1	
4	11413-88L00	.GASKET, UPPER OIL SEAL HSG	1	UPPER
5	14151-88L00	.GASKET, EXH COVER	1	
6	17472-96304	.GASKET, PUMP CASE UNDER	1	
7	11433-88L00	.GASKET, UNDER OIL SEAL	1	
8	11489-88L01	.GASKET, OIL PAN	1	
9	51211-88L00	.GASKET, ENGINE HOLDER	1	
10	51123-88L00	.GASKET, MOUNT CASE COVER	1	
11	11552-88L00	.GASKET, OIL PAN WTR JKT COVER	1	

NOTE : DF40A,DF40AQH,DF40ATH,DF40AST,DF50A,DF50ATH,DF60A,DF60AQH, DF60ATH

DF60A_E11_023_585A
OPT:GASKET SET

FIG.585B




FIG.585B (2-I-2) OPT:GASKET SET (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11400-88890	GASKET SET	1	
2	11141-88L00	.GASKET, CYLINDER HEAD	1	
3	11189-88L00	.GASKET, CYLINDER HEAD COVER	1	
4	11413-88L00	.GASKET, UPPER OIL SEAL HSG	1	UPPER
5	14151-88L00	.GASKET, EXH COVER	1	
6	17472-87E10	.GASKET, PUMP CASE PANEL	1	
7	11433-88L00	.GASKET, UNDER OIL SEAL	1	
8	11489-88L01	.GASKET, OIL PAN	1	
9	51211-88L00	.GASKET, ENGINE HOLDER	1	
10	51123-88L00	.GASKET, MOUNT CASE COVER	1	
11	11552-88L00	.GASKET, OIL PAN WTR JKT COVER	1	

NOTE : DF50AVT,DF50AVTH,DF60AVT,DF60AVTH,DF40ASVT

DF60A_E11_023_585B
OPT:GASKET SET

FIG.600A




FIG.600A (2-I-3) OPT:MULTI FUNCTION GAUGE (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34000-96L49	KIT, SINGLE GAUGE MECH	1	
2	34011-96L40	.GAUGE SET, MULTI	1	
3	34112-96L00	..NUT, GAUGE	1	
4	34193-96L00	..BEZEL, GAUGE	1	
5	34211-96L00	..COVER, GAUGE	1	
6	34825-96L00	..PACKING, GAUGE	1	
7	36661-96L30	.ADAPTER, GAUGE	1	
8	36615-96300	..TERMINAL	5	
9	36001-88L00	SET, WIRE	1	
10	36662-88L10	.WIRE, 2 EXTENSION	1	
11	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
12	36664-88L00	.CONNECTOR, BRANCH	1	
13	36665-88L00	.UNIT, RESISTOR FEMALE	1	
14	36665-88L10	.UNIT, RESISTOR MALE	1	
15	34190-88L00	SENSOR ASSY, PAD WHEEL	1	
16	36662-88L10	WIRE, 2 EXTENSION	1	
17	36662-88L20	WIRE, 6 EXTENSION	1	
18	36662-88L30	WIRE, 15 EXTENSION	1	
19	36662-88L00	WIRE, 25 EXTENSION	1	
20	39950-88L02	MODULE ASSY, GPS RECEIVER	1	
21	36663-88L00	HARNESS ASSY, NETWORK POWER	1	
22	36665-88L00	UNIT, RESISTOR FEMALE	1	
23	36665-88L10	UNIT, RESISTOR MALE	1	
24	36664-88L00	CONNECTOR, BRANCH	1	

NOTE : (DF40A,DF40AST,DF50A,DF50AVT,DF60A,DF60AVT,DF40ASVT): (020,021)

DF60A_E11_023_600A
OPT:MULTI FUNCTION GAUGE

FIG.600B




FIG.600B (2-I-4) OPT:MULTI FUNCTION GAUGE (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34011-96L42	GAUGE SET, MULTI	1	
2	34112-96L00	.NUT, GAUGE	1	
3	34193-96L00	.BEZEL, GAUGE	1	
4	34211-96L00	.COVER, GAUGE	1	
5	34825-96L00	.PACKING, GAUGE	1	
6	36661-96L30	ADAPTER, GAUGE	1	
7	36615-96300	.TERMINAL	5	
8	34011-96L52	GAUGE SET, MULTI	1	
9	34112-96L00	.NUT, GAUGE	1	
10	34193-96L00	.BEZEL, GAUGE	1	
11	34211-96L00	.COVER, GAUGE	1	
12	34825-96L00	.PACKING, GAUGE	1	
13	36661-96L30	ADAPTER, GAUGE	1	
14	36615-96300	.TERMINAL	5	
15	34190-88L00	SENSOR ASSY, PAD WHEEL	1	
16	36662-88L10	WIRE, 2 EXTENSION	1	
17	36662-88L20	WIRE, 6 EXTENSION	1	
18	36662-88L30	WIRE, 15 EXTENSION	1	
19	36662-88L00	WIRE, 25 EXTENSION	1	
20	39950-88L02	MODULE ASSY, GPS RECEIVER	1	
21	36001-88L00	SET, WIRE	1	
22	36662-88L10	.WIRE, 2 EXTENSION	1	
23	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
24	36664-88L00	.CONNECTOR, BRANCH	1	
25	36665-88L00	.UNIT, RESISTOR FEMALE	1	
26	36665-88L10	.UNIT, RESISTOR MALE	1	

NOTE : (DF40A,DF40AST,DF50A,DF50AVT,DF60A,DF60AVT,DF40ASVT):
(022,023)

DF60A_E11_023_600B
OPT:MULTI FUNCTION GAUGE

FIG.600C




FIG.600C (2-I-5) OPT:MULTI FUNCTION GAUGE (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34011-96L40	GAUGE SET, MULTI	1	
2	34112-96L00	.NUT, GAUGE	1	
3	34193-96L00	.BEZEL, GAUGE	1	
4	34211-96L00	.COVER, GAUGE	1	
5	34825-96L00	.PACKING, GAUGE	1	
6	34190-88L00	SENSOR ASSY, PAD WHEEL	1	
7	36662-88L10	WIRE, 2 EXTENSION	1	
8	36662-88L20	WIRE, 6 EXTENSION	1	
9	36662-88L30	WIRE, 15 EXTENSION	1	
10	36662-88L00	WIRE, 25 EXTENSION	1	
11	39950-88L02	MODULE ASSY, GPS RECEIVER	1	
12	36663-88L00	HARNESS ASSY, NETWORK POWER	1	
13	36665-88L00	UNIT, RESISTOR FEMALE	1	
14	36665-88L10	UNIT, RESISTOR MALE	1	
15	36664-88L00	CONNECTOR, BRANCH	1	

NOTE : (DF40AQH,DF40ATH,DF50ATH,DF60AQH,DF60ATH,DF50AVTH,DF60AVTH): (020,021)

DF60A_E11_023_600C
OPT:MULTI FUNCTION GAUGE

FIG.600D




FIG.600D (2-I-6) OPT:MULTI FUNCTION GAUGE (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34011-96L42	GAUGE SET, MULTI	1	
2	34112-96L00	.NUT, GAUGE	1	
3	34193-96L00	.BEZEL, GAUGE	1	
4	34211-96L00	.COVER, GAUGE	1	
5	34825-96L00	.PACKING, GAUGE	1	
6	34011-96L52	GAUGE SET, MULTI	1	
7	34112-96L00	.NUT, GAUGE	1	
8	34193-96L00	.BEZEL, GAUGE	1	
9	34211-96L00	.COVER, GAUGE	1	
10	34825-96L00	.PACKING, GAUGE	1	
11	34190-88L00	SENSOR ASSY, PAD WHEEL	1	
12	36662-88L10	WIRE, 2 EXTENSION	1	
13	36662-88L20	WIRE, 6 EXTENSION	1	
14	36662-88L30	WIRE, 15 EXTENSION	1	
15	36662-88L00	WIRE, 25 EXTENSION	1	
16	39950-88L02	MODULE ASSY, GPS RECEIVER	1	
17	36663-88L00	HARNESS ASSY, NETWORK POWER	1	
18	36664-88L00	CONNECTOR, BRANCH	1	
19	36665-88L00	UNIT, RESISTOR FEMALE	1	
20	36665-88L10	UNIT, RESISTOR MALE	1	

NOTE : (DF40AQH,DF40ATH,DF50ATH,DF60AQH,DF60ATH,DF50AVT,DF60AVTH): (022,023)

PART NO.	FIG.NO.-REF.NO.
10000	
11100-88L20	111A-1
	111B-1
	111C-1
11112-88L00	113A-7
	113B-7
11115-73G01-001	111A-2
	111A-29
	111B-2
	111B-29
	111C-2
	111C-29
11117-89J20	113A-4
	113B-4
11119-87J00	111A-10
	111B-10
	111C-10
11141-88L00	111A-11
	111B-11
	111C-11
	585A-2
	585B-2
11170-88L10	111A-16
	111B-16
	111C-16
11173-88L00	111A-20
	111B-20
	111C-20
11174-88L01	111A-22
	111B-22
	111C-22
11189-88L00	111A-17
	111B-17
	111C-17
	585A-3
	585B-3
11194-88L10	111A-26
	111B-26
	111C-26
11196-88L00	162A-8
11261-93J00	111A-5
	111B-5
	111C-5
	124B-17
	124D-17
	124F-17
11291-88L00	113A-1
11291-88L10	113B-1
11301-88L20	113A-3
	113B-3
11382-93J00	111A-14
	111B-14
	111C-14
11400-88872	585A-1
11400-88890	585B-1
11411-88L00	136A-6
11413-88L00	136A-7
	585A-4
	585B-4
11433-88L00	175A-1
	585A-7
	585B-7
11489-88L01	180A-1
	180B-1
	585A-8
	585B-8
11501-88L01-QTN	180A-2-3
11501-88L01-Y5S	180A-2-2
11501-88L01-YAY	180A-2-1
	180A-2-4
	180A-2-5
	180B-2
11510-88L00	136A-1
11514-88L00	136A-5
11543-88L01	180A-11
	180B-11
11551-88L00-QTN	180A-6-3
11551-88L00-Y5S	180A-6-2
11551-88L00-YAY	180A-6-1
	180A-6-4
	180B-6
11552-88L00	180A-7
	180B-7
	585A-11
	585B-11
12100-51810-0A0	116A-8-1
12100-51810-0B0	116A-8-2
12100-51810-0C0	116A-8-3
12100-51810-0D0	116A-8-4
12100-51810-0E0	116A-8-5
12100-88L01-050	116A-13
12111-88L00	116A-1
12140-88L01	116A-2
12140-88L01-050	116A-14
12151-54A50	116A-3
12160-88L01	116A-5
12163-69J00	116A-6
12220-88L00	116A-9
12281-87J00	116A-12
12340-75F00-0C0	116A-10-3
12340-75F00-0D0	116A-10-4
12340-75F00-0E0	116A-10-5
12340-75FA0-0A0	116A-10-1
12340-75FA0-0B0	116A-10-2
12710-88L00	121A-1
12720-88L00	121A-2
12741-88L00	121A-3
12761-88L00	119A-1
12771-87J00	119A-2
12776-85FA0	119A-3
12811-88L00	119A-4
12812-73G10	119A-7
12813-73G00	119A-8
12821-88L00	119A-11
12831-90J02	119A-9
12891-73G01	121A-7
12892-73G01-218	121A-8-1
12892-73G01-220	121A-8-2
12892-73G01-222	121A-8-3
12892-73G01-224	121A-8-4
12892-73G01-226	121A-8-5
12892-73G01-228	121A-8-6
12892-73G01-230	121A-8-7
12892-73G01-232	121A-8-8
12892-73G01-234	121A-8-9
12892-73G01-236	121A-8-10
12892-73G01-238	121A-8-11
12892-73G01-240	121A-8-12
12892-73G01-242	121A-8-13
12892-73G01-244	121A-8-14
12892-73G01-246	121A-8-15
12892-73G01-248	121A-8-16
12892-73G01-250	121A-8-17
12892-73G01-252	121A-8-18
12892-73G01-254	121A-8-19
12892-73G01-256	121A-8-20
12892-73G01-258	121A-8-21
12892-73G01-260	121A-8-22
12892-73G01-262	121A-8-23
12892-73G01-264	121A-8-24
12892-73G01-266	121A-8-25
12892-73G01-268	121A-8-26
12892-73G01-270	121A-8-27
12892-73G01-272	121A-8-28
12892-73G01-274	121A-8-29
12892-73G01-276	121A-8-30

PART NO.	FIG.NO.-REF.NO.
12892-73G01-278	121A-8-31
12892-73G01-280	121A-8-32
12892-73G01-282	121A-8-33
12892-73G01-284	121A-8-34
12892-73G01-286	121A-8-35
12892-73G01-288	121A-8-36
12892-73G01-290	121A-8-37
12892-73G01-292	121A-8-38
12892-73G01-294	121A-8-39
12892-73G01-296	121A-8-40
12892-73G01-298	121A-8-41
12892-73G01-300	121A-8-42
12911-88L00	121A-9
12915-73G20	121A-10
12921-87J11	121A-11
12931-78G00	121A-12
12932-24400	121A-13
12933-51E00	121A-14
13110-88L00	124A-1
	124B-1
	124C-1
	124D-1
	124E-1
	124F-1
13119-88L00	124A-2
	124B-2
	124C-2
	124D-2
	124E-2
	124F-2
13125-88L00	124A-3
	124B-3
	124C-3
	124D-3
	124E-3
	124F-3
13300-88L02	163A-1
	163B-1
	163C-1
13315-88L00	163A-3
	163B-3
	163C-3
13353-99E00	163A-2
	163B-2
	163C-2
13370-88L00	143A-2
13370-88L10	143B-2
	143C-2
13510-88L00	163A-7
	163B-7
13614-89J00	143B-15
	143C-15
13614-93J00	143B-16
	143C-16
13810-88L00	124A-10
	124B-10
	124C-10
	124D-10
	124E-10
	124F-10
13813-88L01	124C-11
	124D-11
13815-88L10	163C-13
13820-88L01	124A-11
	124B-11
13820-88L11	124E-11
	124F-11
14141-88L00	124A-13
	124C-13
	124E-13
14141-88L10	124B-13
	124D-13
	124F-13
14151-88L00	124A-14
	124B-14
	124C-14
	124D-14
	124E-14
	124F-14
	585A-5
	585B-5
15100-90J11	146A-1
15191-88L20	146A-10
15192-88L20	146A-11
15197-88L00	146A-15
15200-88L00	143A-3
15200-88L10	143B-3
	143C-3
15410-88L00	146A-4
15419-87J00	146A-5
15421-88L00	146A-8
15422-96J01	146A-7
15600-88L05	143A-1
15600-88L14	143B-1
	143C-1
15610-88L01	143A-25
	143B-25
	143C-25
15612-88L00	143A-21
	143C-7
15613-88L00	143A-22
	143B-22
	143C-22
15613-92J00	143A-23
	143B-23
	143C-23
15614-88L00	143A-24
	143B-24
	143C-24
15620-88L00	143A-26
15620-88L10	143B-26
	143C-26
15626-88L01	143A-4
15626-88L10	143B-4
	143C-4
15628-99E00	143A-5
	143B-5
	143C-5
15629-99E10	143A-6
	143B-6
	143C-6
15641-88L00	143A-7
15641-88L10	143B-7
	143C-7
15641-88L31	143A-18
	143B-18
	143C-18
15641-88L51	143A-19
	143B-19
	143C-19
15642-88L00	143A-8
	143B-8
	143C-8
15642-88L10	143A-20
	143B-20
	143C-20
15643-88L10	143A-17
	143B-17
	143C-17
15644-88L00	143A-13
15644-88L10	143B-13
	143C-13
15645-88L00	143A-14
	143B-14
	143C-14
15650-99E00	143A-9
	143B-9
	143C-9

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
15654-88L00	143A-10	17416-95J00	160A-3		160C-13
	143B-10		160B-3		160C-14
	143C-10		160C-3		160D-13
15681-88L10	144A-7		160D-3		160D-14
	144B-7	17416-99E11	160E-19		160E-6
15683-87J00	143A-11		160F-19		160E-7
	143B-11		160G-18		160F-6
	143C-11	17461-87E12	160E-2		160F-7
15710-85K00	144A-1		160F-2		160G-6
	144B-1		160G-2		160G-7
15716-65DT0	144A-2	17461-96312	160A-9	17564-87D00	160E-8
	144B-2		160B-9		160F-8
15750-88L10	144A-4		160C-9		160G-8
15750-88L20	144B-4		160D-9	17564-88L01	160A-4
15760-88L00	143A-12	17471-95J01	160A-10		160B-4
	143B-12		160B-10		160C-4
	143C-12		160C-10		160D-4
16400-88L00	175A-2		160D-10-1	17611-90J00	162A-1
16510-87J01	175A-9	17471-95J10	160D-10-2	17631-90J00	160E-9
16519-87L00	175A-8	17471-99E00	160E-3		160F-9
16520-88L00	175A-5		160F-3		160G-9
16910-88L00	180A-14		160G-3-1	17631-96320	160A-16
	180B-14	17471-99E10	160G-3-2		160B-16
16930-88L00	180A-15	17472-87E10	160E-4		160C-16
	180B-15		160F-4		160D-16
17400-88L01	160A-21		160G-4	17632-90J00	160E-10
	160B-21		585B-6		160F-10
	160C-21	17472-96304	160A-11		160G-10
	160D-21-1		160B-11	17635-87E00	160A-18-1
17400-88L20	160D-21-2		160C-11		160B-18-1
17400-99E12	160E-20		160D-11		160C-18-1
	160F-20		585A-6		160D-18-1
	160G-21-1	17560-88L00	160A-12-1	17635-87E10	160A-18-2
17400-99E20	160G-21-2		160C-12-1		160B-18-2
17410-88L00	160A-1	17560-88L10	160A-12-2		160C-18-2
	160B-1		160B-12		160D-18-2
	160C-1		160C-12-2		160E-21
	160D-1		160D-12-1		160F-21
17410-99E10	160E-1	17560-88L20	160A-12-3		160G-19
	160F-1		160D-12-2	17635-90J00	160E-11
	160G-1	17560-88L30	160E-5-1		160F-11
17413-95J00	160A-2		160F-5		160G-11
	160B-2		160G-5-1	17660-99E01	162A-2
	160C-2	17560-88L40	160E-5-2	17670-93955	162A-5
	160D-2-1		160G-5-2	17681-88L00	162A-6
17413-95J10	160D-2-2	17562-87L01	160A-13	17712-88L01	162A-11
17413-99E11	160E-18		160A-14-1	17913-93J00	180A-9
	160F-18		160A-14-2		180B-9
	160G-17-1		160B-13	17914-93J01	180A-10
17413-99E21	160G-17-2		160B-14		180B-10

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
17917-87L00	420A-22		163C-8		204B-5
	420B-22	19120-88L12	163B-8		204C-5
	420C-21		570A-56		204D-5
	420D-21		570B-56		204E-5
	420E-22	19131-95502	163A-9		204F-5
	420F-21		163B-9		204G-5
	420G-21		163C-9	22511-99011	336A-5
	420H-22				336B-5
	420J-22				336B-33
	420K-21				336C-5
	420L-21				336D-5
	420M-22				336E-5
	420N-22		20000		336F-5
	420P-22				336G-5
	420R-21				336H-5
	420S-21	21110-88L00	444A-3		444A-64
	420T-21		444B-3		444B-65
	420U-21		444C-3		444C-65
18137-88L02	124A-8		570A-2		570A-81
	124B-8		570B-2		570A-92
	124C-8	21112-88L00	444B-41		570B-82
	124D-8		444C-41	23111-88L01	204A-6-1
	124E-8		570A-40		204C-6-1
	124F-8		570B-40		204E-6-1
18210-88L00	420A-20	21112-88L10	444A-41		204F-6
	420B-20	21121-93300	206A-13		204G-6-1
	420C-19		206B-13	23111-88L11	204A-6-2
	420D-19		206C-13		204A-6-3
	420E-20		206D-13		204B-6
	420F-19		210A-1		204C-6-2
	420G-19	21126-88L00	204A-1		204D-6
	420H-20		204B-1		204E-6-2
	420J-20		204C-1		204G-6-2
	420K-19		204D-1	23115-88L00	204A-8
	420L-19		204E-1		204B-8
	420M-20		204F-1		204C-8
	420N-20		204G-1		204D-8
	420P-20	21131-88L02	444A-71		204E-8
	420R-19		444B-72		204F-8
	420S-19		444C-72		204G-8
	420T-19		570A-57	23210-88L00	204A-9
	420U-19		570B-57		204B-9
18498-88L11	143A-33	21151-88L00	204A-2		204C-9
	143B-33		204B-2		204D-9
	143C-33		204C-2		204E-9
18498-90J51	146A-13		204D-2		204F-9
18498-94J11	162A-10		204E-2		204G-9
18498-96J31	146A-14		204F-2	23213-89J01	204A-12
18498-99EA1	507A-6		204G-2		204B-12
19120-88L01	163A-8	21210-88L01	204A-5		204C-12

PART NO.	FIG.NO.-REF.NO.
	204D-12
	204E-12
	204F-12
	204G-12
23214-89J00	204A-13
	204B-13
	204C-13
	204D-13
	204E-13
	204F-13
	204G-13
23230-88L00	444A-4
	444B-4
	444C-4
	570A-3
	570B-3
23311-95J00	204A-15
	204B-15
	204C-15
	204D-15
	204E-15
	204F-15
	204G-15
25111-88L00	206A-1-1
	206C-1-1
25111-88L10	206A-1-2
	206B-1
	206C-1-2
	206D-1-1
25111-88L20	206A-1-3
	206D-1-2
25111-88L30	210A-2-1
25111-88L40	210A-2-2
25141-99E03	210A-3
25205-94501	210A-4
25211-87J00	206A-2
	206B-2
	206C-2
	206D-2
25211-94501	210A-5
25212-94401	206A-5
	206B-5
	206C-5
	206D-5
25223-96J00	206A-9
	206B-9
	206C-9
	206D-9
25230-94300	210A-6
25232-96302	206A-10
	206B-10
	206C-10
	206D-10
25311-88L00	206A-11
	206B-11
	206C-11
	206D-11
25311-94510	210A-7
25700-88L04	407A-20
	407B-20
	407C-22
	407D-22
	407E-22
25700-99E00	407G-32
25700-99E01	407F-32
29103-93J00	315C-12
	315C-18
29116-93J00	401A-15
	401B-15
	401C-15
	401D-15
29116-93J10	160E-12
	160F-12
	160G-12
29141-93J00	160A-5
	160B-5
	160C-5
	160D-5
	204A-7
	204B-7
	204C-7
	204D-7
	204E-7
	204F-7
	204G-7
	336C-26
	336D-26
	336E-22
	336F-26
	336G-22
	336H-26
29162-93J00	160A-6
	160B-6
	160C-6
	160D-6
29404-93J11	315A-12
	337A-2
	337B-2
	337C-2
	337D-2
	337E-2
	337F-2
30000	
31100-89L00	301A-1
31111-87J10	340A-9
31123-97E10	340A-4
31133-94910	340A-5
31135-94900	340A-6
31136-87J11	340A-7
31150-98L00	301A-2
31170-89L00	301A-3
31173-88L12	340A-3
31173-98L00	301A-4
31191-63J00	301A-5
31192-92J00	301A-8
31220-89L00	301A-6
31261-75F10	301A-9
31311-63J00	301A-7
31311-87J10	340A-2
31314-86030	301A-11
31320-89L00	301A-12
31340-89L00	301A-10
31341-89L00	301A-13
31343-63J00	301A-14
31344-63J00	301A-15
31912-88L00	301A-16
31918-92J01	301A-17
32102-88L01	303A-1
32120-88L00	303A-5
32160-88L01	303A-6
32800-88L01	310A-1
32890-88L01	310A-3
33220-64L10	303A-8
33410-87L00	310A-7
33634-96J00	322A-4
	322B-4
	322C-4
	322D-4
33799-97E00	340A-8
33810-88L10	322A-1
	322B-1
	322C-1
	322D-1

PART NO.	FIG.NO.-REF.NO.
33833-91J00	444A-79
	444B-80
	444C-82
33834-88L00	444A-77
	444B-78
	444C-79
	570A-78
	570B-79
33925-88L10	326A-10
	326B-10
	326C-7
	326D-7
33926-98J00	508D-52
	521C-5
	521F-3
33940-88LG0	326A-9-9
	326A-9-13
33940-88LH0	326A-9-11
	326A-9-15
	326C-6-3
33940-88LJ0	326A-9-1
	326A-9-3
	326C-6-1
33940-88LK0	326A-9-5
33940-88LL0	326A-9-7
	326A-9-8
33940-88LM0	326A-9-18
33940-88LN0	326A-9-20
	326A-9-24
33940-88LP0	326A-9-17
	326A-9-23
33940-88LQ0	326A-9-21
33950-88L00	326A-9-10
	326A-9-14
33950-88L10	326A-9-12
	326A-9-16
	326C-6-4
33950-88L20	326A-9-6
33950-88L30	326A-9-19
33950-88L40	326A-9-25
33950-88L50	326A-9-22
33950-88L60	326A-9-2
	326A-9-4
	326C-6-2
33950-88L70	326B-9-6
	326B-9-8
33950-88L80	326B-9-7
	326B-9-9
	326D-6-2
33950-88L90	326B-9-1
	326B-9-2
	326D-6-1
	326B-9-3
	326B-9-4
	326B-9-5
	326B-9-11
	326B-9-13
	326B-9-10
	326B-9-12
34000-96L49	600A-1
34011-96L40	600A-2
	600C-1
34011-96L42	600B-1
	600D-1
34011-96L52	600B-8
	600D-6
34100-93J02	501A-3-1
	501B-3-1
34100-93J13	501A-3-2
	501B-3-2
34100-93J22	501A-3-3
	501B-3-3
34100-93J33	501A-3-4
	501B-3-4
34100-93J42	501A-3-5
	501B-3-5
34100-93J53	501A-3-6
	501B-3-6
34100-93J62	501A-3-7
	501B-3-7
34112-96L00	600A-3
	600B-2
	600B-9
	600C-2
	600D-2
	600D-7
34190-87D00	501A-26
	501B-24
34190-88L00	600A-15
	600B-15
	600C-6
	600D-11
34190-95500	501A-24
	501B-22
34191-92E00	501A-5
	501A-17
	501B-5
	501B-17
34193-96L00	600A-4
	600B-3
	600B-10
	600C-3
	600D-3
	600D-8
34200-87L00	444A-45
	444B-45
	444C-45
	570A-44
	570B-44
34200-93J02	501A-20-1
	501B-20-1
34200-93J14	501A-20-2
	501B-20-2
34200-93J43	501A-22-1
34200-93J54	501A-22-2
34211-96L00	600A-5
	600B-4
	600B-11
	600C-4
	600D-4
	600D-9
34300-93J03	501A-10-1
	501B-10-1
34300-93J14	501A-10-2
	501B-10-2
34310-92E01	501A-11
	501B-11
34360-92E00	501A-12
	501B-12
34500-93J02	501A-14-1
	501B-14-1
34500-93J13	501A-14-2
	501B-14-2
34600-93J02	501A-8-1
	501B-8-1
34600-93J13	501A-8-2
	501B-8-2
34650-93J22	501A-16-1
	501B-16-1
34650-93J33	501A-16-2
	501B-16-2
34660-90J05	507A-1
34800-93J02	501A-1-1
	501B-1-1
34800-93J13	501A-1-2
	501B-1-2
34825-96L00	600A-6
	600B-5
	600B-12
	600C-5

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	600D-5	36617-93J10	322A-22	36621-93J00	521B-2
	600D-10		322B-22		521C-2
34830-87J20	315A-1		322C-23	36628-92E01	508A-2
	315B-1		322D-22		508B-2
	315C-1	36618-43410	322A-16		508C-2
34840-98J03	315A-2		322B-16		508D-2
34840-98J11	315C-2		322C-16	36630-88L00	322B-3-2
34841-87L10	315C-5		322D-16	36630-88L10	322A-3-2
34841-88L01	315A-10	36620-88L11	444A-5	36630-88L20	322C-3-5
34842-88L10	315C-6		444B-5	36630-88L30	322D-3-2
34843-87L00	315C-7		444C-5	36630-88L40	322C-3-3
34845-88L02	315A-11		570A-4		322C-3-7
34845-88L10	315C-8		570B-4	36630-92E00	521D-7
34846-87L00	315C-4	36620-93J04	508A-53-1		521E-6
36001-88L00	600A-9		508B-53-1		521F-8
	600B-21		521A-4-1	36656-88L00	315A-8
36610-88LL1	322B-3-1		521D-2-1		315C-15
36610-88LM1	322A-3-1	36620-93J12	521A-1-1	36656-88L10	315B-3
36610-88LN1	322C-3-1		521B-1-1	36660-94480	521D-8
	322C-3-4	36620-93J32	521A-2		521E-7
36610-88LP1	322D-3-1	36620-93J42	521A-1-2		521F-9
36610-88LQ1	322C-3-2		521B-1-2	36661-96L30	600A-7
	322C-3-6	36620-93J54	508A-53-2		600B-6
36611-88L00	322C-17		508B-53-2		600B-13
36612-96J01	322A-15		521A-4-2	36662-88L00	600A-19
	322B-15		521D-2-2		600B-19
	322C-15	36620-93J64	508A-53-3		600C-10
	322D-15		508B-53-3		600D-15
36615-96300	501A-7		521A-4-3	36662-88L10	600A-10
	501B-7		521D-2-3		600A-16
	508D-53	36620-93J70	508C-51-1		600B-16
	521C-6		521B-4-1		600B-22
	521F-4		521E-2-1		600C-7
	600A-8	36620-93J80	508C-51-2		600D-12
	600B-7		521B-4-2	36662-88L20	600A-17
	600B-14		521E-2-2		600B-17
36617-88L00	315C-11	36620-93J90	508C-51-3		600C-8
	322A-21		521B-4-3		600D-13
	322B-21		521E-2-3	36662-88L30	600A-18
	322C-22	36620-93JA0	508D-51-1		600B-18
	322D-21		521C-4-1		600C-9
36617-88L20	322A-25		521F-2-1		600D-14
	322B-25	36620-93JB0	508D-51-2	36663-88L00	600A-11
	322C-26		521C-4-2		600A-21
	322D-25		521F-2-2		600B-23
36617-88L90	444A-46	36620-93JC0	508D-51-3		600C-12
	444B-46		521C-4-3		600D-17
	444C-46		521F-2-3	36664-88L00	600A-12
	570A-45	36620-93JD0	521C-1-1		600A-24
	570B-45	36620-93JE0	521C-1-2		600B-24

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	600C-15		336A-8		570B-46
	600D-18		336B-7	37138-98L00	530B-5
36665-88L00	600A-13		336B-8		530C-5
	600A-22		336C-7	37138-98L10	530B-17
	600B-25		336C-8		530C-17
	600C-13		336D-7	37138-98L20	530B-26
	600D-19		336D-8		530C-26
36665-88L10	600A-14		336E-7	37139-99E00	530A-6
	600A-23		336E-8	37139-99E40	530A-24
	600B-26		336F-7	37141-98L00	530B-4-1
	600C-14		336F-8		530B-16-1
	600D-20		336G-7		530B-25-1
36667-96L20	521A-8		336G-8		530C-4-1
	521B-7		336H-7		530C-16-1
	521D-6		336H-8		530C-25-1
	521E-5	36990-87D00	521A-6	37141-98L10	530B-4-2
	521F-7		521B-5		530B-16-2
36667-96L60	521C-9		521C-7		530B-25-2
36668-87L00	322A-5		521D-4		530C-4-2
	322B-5		521E-3		530C-16-2
	322C-5		521F-5		530C-25-2
	322D-5	37100-96J01	530A-1	37141-98L20	530B-4-3
36682-92E00	521A-7	37100-96J27	530A-19		530B-16-3
	521B-6	37100-98L00	530B-1		530B-25-3
	521C-8		530C-1		530C-4-3
	521D-5	37100-98L10	530B-13		530C-16-3
	521E-4		530C-13		530C-25-3
	521F-6	37100-98L20	530B-22	37141-98L30	530B-4-4
36721-98L00	322A-8		530C-22		530B-16-4
	322B-8	37110-87L02	444A-6		530B-25-4
	322C-8		444B-6		530C-4-4
	322D-8		444C-6		530C-16-4
36737-98L00	322A-7		570A-5		530C-25-4
	322B-7		570B-5	37141-98L40	530B-4-5
	322C-7	37110-93J02	530A-2		530B-16-5
	322D-7		530A-20		530B-25-5
36738-98L00	322A-9	37110-93J12	508A-3		530C-4-5
	322B-9		508B-3		530C-16-5
	322C-9	37110-93J20	508C-3		530C-25-5
	322D-9		508D-3	37141-98L50	530B-4-6
36890-93J01	517A-23	37110-98L00	530B-2		530B-16-6
36894-87D00	336C-6		530B-14		530B-25-6
	336D-6		530B-23		530C-4-6
	336E-6		530C-2		530C-16-6
	336F-6		530C-14		530C-25-6
	336G-6		530C-23	37141-98L60	530B-4-7
	336H-6	37112-88L91	444A-47		530B-16-7
36894-95201	336A-6		444B-47		530B-25-7
	336B-6		444C-47		530C-4-7
36895-87D01	336A-7		570A-46		530C-16-7

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	530C-25-7		444C-7-2		444B-7-5
37141-98L70	530B-4-8		508A-4-2		444C-7-5
	530B-16-8		508B-4-2		508A-4-5
	530B-25-8		508C-4-2		508B-4-5
	530C-4-8		508D-4-2		508C-4-5
	530C-16-8		530A-3-2		508D-4-5
	530C-25-8		530A-21-2		530A-3-5
37141-98L80	530B-4-9		530B-3-2		530A-21-5
	530B-16-9		530B-15-2		530B-3-5
	530B-25-9		530B-24-2		530B-15-5
	530C-4-9		530C-3-2		530B-24-5
	530C-16-9		530C-15-2		530C-3-5
	530C-25-9		530C-24-2		530C-15-5
37141-98L90	530B-4-10		570A-6-2		530C-24-5
	530B-16-10		570B-6-2		570A-6-5
	530B-25-10	37141-99E20	444A-7-3		570B-6-5
	530C-4-10		444B-7-3	37141-99E50	444A-7-6
	530C-16-10		444C-7-3		444B-7-6
	530C-25-10		508A-4-3		444C-7-6
37141-98LA0	530B-4-11		508B-4-3		508A-4-6
	530B-16-11		508C-4-3		508B-4-6
	530B-25-11		508D-4-3		508C-4-6
	530C-4-11		530A-3-3		508D-4-6
	530C-16-11		530A-21-3		530A-3-6
	530C-25-11		530B-3-3		530A-21-6
37141-98LB0	530B-4-12		530B-15-3		530B-3-6
	530B-16-12		530B-24-3		530B-15-6
	530B-25-12		530C-3-3		530B-24-6
	530C-4-12		530C-15-3		530C-3-6
	530C-16-12		530C-24-3		530C-15-6
	530C-25-12		570A-6-3		530C-24-6
37141-99E00	444A-7-1		570B-6-3		570A-6-6
	444B-7-1	37141-99E30	444A-7-4		570B-6-6
	444C-7-1		444B-7-4	37141-99E60	444A-7-7
	508A-4-1		444C-7-4		444B-7-7
	508B-4-1		508A-4-4		444C-7-7
	508C-4-1		508B-4-4		508A-4-7
	508D-4-1		508C-4-4		508B-4-7
	530A-3-1		508D-4-4		508C-4-7
	530A-21-1		530A-3-4		508D-4-7
	530B-3-1		530A-21-4		530A-3-7
	530B-15-1		530B-3-4		530A-21-7
	530B-24-1		530B-15-4		530B-3-7
	530C-3-1		530B-24-4		530B-15-7
	530C-15-1		530C-3-4		530B-24-7
	530C-24-1		530C-15-4		530C-3-7
	570A-6-1		530C-24-4		530C-15-7
	570B-6-1		570A-6-4		530C-24-7
37141-99E10	444A-7-2		570B-6-4		570A-6-7
	444B-7-2	37141-99E40	444A-7-5		570B-6-7

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
37141-99E70	444A-7-8		570B-6-10		530A-23
	444B-7-8	37141-99EA0	444A-7-11		570A-8
	444C-7-8		444B-7-11		570B-8
	508A-4-8		444C-7-11	37210-93J00	530A-17
	508B-4-8		508A-4-11		530B-38
	508C-4-8		508B-4-11	37212-93J00	530A-18
	508D-4-8		508C-4-11		530B-39
	530A-3-8		508D-4-11	37721-88L01	545A-11
	530A-21-8		530A-3-11	37721-93J00	326A-1
	530B-3-8		530A-21-11		326B-1
	530B-15-8		530B-3-11		326C-1
	530B-24-8		530B-15-11		326D-1
	530C-3-8		530B-24-11	37721-93J91	508A-7
	530C-15-8		530C-3-11		508B-7
	530C-24-8		530C-15-11		508C-5
	570A-6-8		530C-24-11		508D-5
	570B-6-8		570A-6-11	37721-95500	518A-12
37141-99E80	444A-7-9		570B-6-11	37725-88L00	326A-3
	444B-7-9	37141-99EB0	444A-7-12		326B-3
	444C-7-9		444B-7-12		326C-3
	508A-4-9		444C-7-12		326D-3
	508B-4-9		508A-4-12	37803-93J06	530A-9
	508C-4-9		508B-4-12	37803-98L00	530B-8
	508D-4-9		508C-4-12		530C-8
	530A-3-9		508D-4-12	37805-88L00	530B-34
	530A-21-9		530A-3-12		530C-34
	530B-3-9		530A-21-12	37805-93J00	530A-15
	530B-15-9		530B-3-12	37820-87L11	444A-10
	530B-24-9		530B-15-12		444B-10
	530C-3-9		530B-24-12		444C-10
	530C-15-9		530C-3-12		570A-9
	530C-24-9		530C-15-12		570B-9
	570A-6-9		530C-24-12	37820-93J11	508A-8
	570B-6-9		570A-6-12		508B-8
37141-99E90	444A-7-10		570B-6-12		508C-6
	444B-7-10	37143-99E01	444A-8		508D-6
	444C-7-10		444B-8		530A-10
	508A-4-10		444C-8		530A-25
	508B-4-10		508A-5	37820-98L00	530B-9
	508C-4-10		508B-5		530B-18
	508D-4-10		530A-4		530B-27
	530A-3-10		530A-22		530C-9
	530A-21-10		570A-7		530C-18
	530B-3-10		570B-7		530C-27
	530B-15-10	37149-93J00	444A-9	37820-99E02	315A-6
	530B-24-10		444B-9		315B-2
	530C-3-10		444C-9		315C-10
	530C-15-10		508A-6	37823-92E02	444A-11
	530C-24-10		508B-6		444B-11
	570A-6-10		530A-5		444C-11

PART NO.	FIG.NO.-REF.NO.
	508A-9
	508B-9
	508C-7
	508D-7
	530A-11
	530A-26
	570A-10
	570B-10
37823-98L00	530B-19
	530B-28
	530C-19
	530C-28
37823-98L01	530B-10
	530C-10
37825-99E10	530A-13
37826-92J10	444A-12
	444B-12
	444C-12
	508A-10
	508B-10
	508C-8
	508D-8
	530A-12
	530A-27
	570A-11
	570B-11
37832-98L00	530B-11
	530C-11
37835-91J00-YAY	444A-48
	444B-48
	444C-48
	570A-47
	570B-47
37850-87L01	444B-14
	444C-14
	570A-13
	570B-13
37850-88L00	544A-4
37850-88L40	530B-35
	530C-35
37850-92E27	517A-5
37850-92J00	326A-11
	326B-11
37850-96L00	508A-11
	508B-11
	508C-9
	508D-9
37851-88L90	444A-49
	444B-49
	444C-49
	570A-48
	570B-48
37852-87J00	444A-14
	444B-15
	444C-15
	570A-14
	570B-14
37852-88L90	444B-50
	444C-50
	570A-49
	570B-49
37853-88L90	444A-34
	444B-35
	444C-35
	570A-34
	570B-34
37854-88L90	444A-58
	444B-59
	444C-59
	570A-72
	570B-73
37855-88L90	444A-57
	444B-58
	444C-58
	570A-71
	570B-72
37855-99E00	530A-16
37856-92J00	326A-12
	326B-12
37857-92J01	326A-13
	326B-13
37860-87L00	530A-31
37860-98L00	530B-31
	530C-31
37861-87L11	444A-50
	444B-51
	444C-51
	570A-50
	570B-50
37862-87L00	530A-32
37864-88L91	444A-51
	444B-52
	444C-52
	570A-51
	570B-51
37865-88L00	530B-36
	530C-36
37865-98L00	530B-32
	530C-32
38100-88L12	337A-3
	337B-3
	337C-3
	337D-3
	337E-3
	337F-3
	340A-1
38410-93J12	326A-6
	326B-6
38415-93J00	326A-7
	326B-7
38500-93J90	444A-13
	444B-13
	444C-13
	508A-12
	508B-12
	508C-10
	508D-10
	521A-3
	521B-3
	521C-3
	521D-1
	521E-1
	521F-1
	530A-7
	530A-29
	530B-7
	530B-21
	530B-30
	530C-7
	530C-21
	530C-30
	570A-12
	570B-12
38860-76F01	322A-10
	322A-11
	322B-10
	322B-11
	322C-10
	322C-11
	322D-10
	322D-11
39950-88L02	600A-20
	600B-20
	600C-11
	600D-16

40000

PART NO.	FIG.NO.-REF.NO.
41111-88L11-QTN	335D-1-3
	335G-1-3
41111-88L11-Y5S	335D-1-2
	335G-1-2
41111-88L11-YAY	335D-1-1
	335D-1-4
	335F-1
	335G-1-1
	335G-1-4
41111-88L20-QTN	335A-1-3
41111-88L20-Y5S	335A-1-2
41111-88L20-YAY	335A-1-1
	335A-1-4
	335C-1
	335E-1
41111-89J21-YAY	335B-1
41121-88L01-QTN	335D-2-3
	335G-2-3
41121-88L01-Y5S	335D-2-2
	335G-2-2
41121-88L01-YAY	335D-2-1
	335D-2-4
	335F-2
	335G-2-1
	335G-2-4
41121-88L10-QTN	335A-2-3
41121-88L10-Y5S	335A-2-2
41121-88L10-YAY	335A-2-1
	335A-2-4
	335C-2
	335E-2
41121-89J15-YAY	335B-2
41130-87J11	335A-3
	335B-3
	335C-3
	335E-3
41130-88L10	335D-3
	335F-3
	335G-3
41135-93J00	335A-15
	335B-15
	335C-15
	335D-4
	335E-15
	335F-4
	335G-4
41161-94400	442A-1
	575A-2
41221-88L00	336C-23
	336D-23
	336E-19
	336F-23
	336G-19
	336H-23
41224-88L00	336C-25
	336D-25
	336E-21
	336F-25
	336G-21
	336H-25
41226-97E00	336A-19
	336B-15
41230-97E10	336A-24
	336B-20
41231-88L01	336C-27
	336D-27
	336E-23
	336F-27
	336G-23
	336H-27
41234-88L00	336C-28
	336D-28
	336E-24
	336F-28
	336G-24
	336H-28
41270-89J11	336A-20
	336B-16
41280-88L10	336C-24
	336D-24
	336E-20
	336F-24
	336G-20
	336H-24
41280-89J04	336A-21
	336B-17
43111-88L21-QTN	336A-1-7
43111-88L21-Y5S	336A-1-4
43111-88L21-YAY	336A-1-3
	336A-1-8
	336B-1
43111-88L31-QTN	336A-1-5
43111-88L31-Y5S	336A-1-2
43111-88L31-YAY	336A-1-1
	336A-1-6
43111-88L40-QTN	336C-1-7
	336D-1-9
	336D-1-11
43111-88L40-Y5S	336C-1-4
	336D-1-4
43111-88L40-YAY	336C-1-3
	336C-1-8
	336D-1-3
	336D-1-5
	336D-1-10
	336D-1-12
	336E-1
	336F-1-2
	336G-1-2
43111-88L50-QTN	336C-1-5
	336D-1-7
	336H-1-3
43111-88L50-Y5S	336C-1-2
	336D-1-2
	336H-1-2
43111-88L50-YAY	336C-1-1
	336C-1-6
	336D-1-1
	336D-1-8
	336F-1-1
	336G-1-1
	336H-1-1
	336H-1-4
43112-99E00	180A-12
	180B-12
43114-88L00	336C-14
	336D-14
	336E-14
	336F-14
	336G-14
	336H-14
43119-88L00	336C-11
	336D-11
	336E-11
	336F-11
	336G-11
	336H-11
43119-88L10	336C-12
	336D-12
	336E-12
	336F-12
	336G-12
	336H-12
43211-87J00	336A-2
	336B-2
43211-88L00	336C-2
	336D-2
	336E-2
	336F-2

PART NO.	FIG.NO.-REF.NO.
	336G-2
	336H-2
43241-87J00	335B-16
	335E-16
43411-88L02	336B-22
	570A-82
43415-88L00	336B-23
	570A-83
43512-88L00	336B-24
	570A-84
43513-88L00	336B-25
	570A-85
43514-88L00	336B-26
	570A-86
43515-88L00	336B-27
	570A-87
43516-88L00	336B-28
	570A-88
43517-88L00	336B-29
	570A-89
43711-89J10	336A-3
	336B-3
43711-97E11	336C-3
	336D-3
	336E-3
	336F-3
	336G-3
	336H-3
43750-88L22-QTN	336A-4-7
	336C-4-7
	336D-4-9
	336D-4-11
43750-88L22-Y5S	336A-4-4
	336C-4-4
	336D-4-4
	336D-4-6
43750-88L22-YAY	336A-4-3
	336A-4-8
	336B-4
	336C-4-3
	336C-4-8
	336D-4-3
	336D-4-5
	336D-4-10
	336D-4-12
	336E-4
	336F-4-2
	336G-4-2
43750-88L32-QTN	336A-4-5
	336C-4-5
	336D-4-7
	336H-4-3
43750-88L32-Y5S	336A-4-2
	336C-4-2
	336D-4-2
	336H-4-2
43750-88L32-YAY	336A-4-1
	336A-4-6
	336C-4-1
	336C-4-6
	336D-4-1
	336D-4-8
	336F-4-1
	336G-4-1
	336H-4-1
	336H-4-4
43755-88L00	336A-11
	336C-19
	336D-19
	336F-19
	336H-19
43761-88L01-YAY	444A-1
	444B-1
	444C-1
	570A-58
	570B-58
43762-88L00	444A-75
	444B-76
	444C-77
	570A-59
	570B-59
43768-88L00	444A-76
	444B-77
	444C-78
	570A-60
	570B-60
43770-99E03	444C-75
	570B-69
45260-89J01	339A-1
45421-89J00	335A-4
	335B-4
	335C-4
	335E-4
45731-96312	336A-22
	336B-18
	336C-29
	336D-29
	336E-25
	336F-29
	336G-25
	336H-29
47225-87J00	337A-20
	337B-21
47225-88L00	337C-20
	337D-21
	337E-18
47225-89J00	339A-2
47226-89J00	339A-3
47400-87J32	339A-4
48000-88L18	337A-1
	337C-1
48000-88L22	337E-1
48000-88L30	337B-1
	337D-1
48000-88L40	337F-1
48121-88L00	337C-21
	337D-22
48121-88L10	337E-19
	337F-20
48121-89J10	337A-21
	337B-22
	339A-5
48320-87J10	337A-4
	337B-4
	337C-4
	337D-4
	337E-4
	337F-4
48321-89J11	337A-22
	337B-23
	337C-22
	337D-23
	339A-6
48321-89J20	337E-20
	337F-21
48325-89J00	337A-23
	337B-24
	337C-23
	337D-24
48325-89J10	337E-21
	337F-22
48326-87J00	337A-24
	337B-25
	337C-24
	337D-25
	337E-22
	337F-23
48326-89J00	339A-8

PART NO.	FIG.NO.-REF.NO.
48330-87J10	337A-5
	337B-5
	337C-5
	337D-5
48330-87J20	337E-5
	337F-5
48510-97E00	337A-6
	337B-6
	337C-6
	337D-6
48510-97E10	337E-6
	337F-6
48541-87J10	337A-7
	337B-7
	337C-7
	337D-7
48541-87J20	337A-8
	337B-8
	337C-8
	337D-8
	337E-7
	337F-7
48551-88L00	337A-9
	337B-9
	337C-9
	337D-9
48551-88L10	337E-8
	337F-8
48553-88L00	337A-10
	337B-10
	337C-10
	337D-10
	337E-9
	337F-9
48557-87J10	337A-11
	337B-11
	337C-11
	337D-11
	337E-10
	337F-10
48571-88L01	337A-12
	337B-12
	337C-12
	337D-12
	337E-11
	337F-11
48572-87L00	337A-13
	337B-13
	337C-13
	337D-13
	337E-12
	337F-12
48582-97E01	337A-14
	337B-14
	337C-14
	337D-14
48583-87J10	337A-15
	337B-15
	337C-15
	337D-15
	337E-13
	337F-13
48611-88L00	337A-16
	337C-16
	337E-14
48611-88L10	337B-16
	337D-16
	337F-14
48612-88L00	337B-17
	337D-17
	337F-15
48681-87J11	337A-17
	337B-18
	337C-17
	337D-18
	337E-15
	337F-16
48862-87J20	337A-18
	337B-19
	337C-18
	337D-19
	337E-16
	337F-17
48862-88L00	337A-19
	337B-20
	337C-19
	337D-20
	337E-17
	337F-18
51110-88L10-Y5S	401A-1-2
	401D-1-2
51110-88L10-YAY	401A-1-1
	401B-1
	401C-1
51122-88L00	401A-8
	401B-8
	401C-8
	401D-8
51123-88L00	401A-9
	401B-9
	401C-9
	401D-9
	585A-10
	585B-10
51170-88L00	401A-14
	401B-14
	401C-14
	401D-14
51211-88L00	401A-2
	401B-2
	401C-2
	401D-2
	585A-9
	585B-9
52111-88L00-QTN	405A-1-6
	405C-1-5
	405D-1-7
52111-88L00-Y5S	405A-1-2
	405C-1-2
	405D-1-2
52111-88L00-YAY	405A-1-1
	405A-1-7
	405C-1-1
	405C-1-6
	405D-1-1
	405D-1-8
52111-88L10-QTN	405A-1-8
	405C-1-7
	405D-1-9
	405D-1-11
	405E-1-3
52111-88L10-Y5S	405A-1-4
	405B-1-2
	405C-1-4
	405D-1-4
	405D-1-6
	405E-1-2
52111-88L10-YAY	405A-1-3
	405A-1-5
	405A-1-9
	405A-1-10
	405B-1-1
	405C-1-3

PART NO.	FIG.NO.-REF.NO.
	405C-1-8
	405D-1-3
	405D-1-5
	405D-1-10
	405D-1-12
	405E-1-1
	405E-1-4
	405F-1
52111-88L20-QTN	405J-1-3
52111-88L20-Y5S	405J-1-2
52111-88L20-YAY	405G-1
	405H-1-1
	405J-1-1
	405J-1-4
52111-88L30-YAY	405H-1-2
52131-88L00-QTN	405D-7-3
	405E-7-3
52131-88L00-Y5S	405D-7-2
	405E-7-2
52131-88L00-YAY	405D-7-1
	405D-7-4
	405E-7-1
	405E-7-4
	405F-7
52131-88L12-QTN	405J-7-3
52131-88L12-Y5S	405J-7-2
52131-88L12-YAY	405G-7
	405H-7
	405J-7-1
	405J-7-4
54114-90J10	401A-20
	401B-20
	401C-20
	401D-20
54120-88L01	401C-17
	401D-17
54121-88L01	401A-23
	401B-23
54123-88L01	401A-24
	401B-24
54124-88L20	401A-17
	401B-17
54130-88L00	401A-18
	401B-18
	401C-18
	401D-18
54137-88L00	401A-12
	401B-12
	401C-12
	401D-12
54151-88L01	405A-8
	405B-8
	405C-8
	405D-12
	405E-12
	405F-12
	405G-14
	405H-15
	405J-14
54160-88L10	405A-9
	405B-9
	405C-9
	405D-13
	405E-13
	405F-13
	405G-15
	405H-16
	405J-15
54166-95J02	401A-19
	401B-19
	401C-19
	401D-19
	405A-12
	405B-12
	405C-12
	405D-16
	405E-16
	405F-16
	405G-18
	405H-19
	405J-18
54167-87L01	405A-10
	405B-10
	405C-10
	405D-14
	405E-14
	405F-14
	405G-16
	405H-17
	405J-16
54180-88L01	405A-11
	405B-11
	405C-11
	405D-15
	405E-15
	405F-15
	405G-17
	405H-18
	405J-17
54211-87J30-QTN	405A-7-4
54211-87J30-Y5S	405A-7-2
	405B-7-2
	405C-7-2
	405D-11-2
	405E-11-2
	405J-13-2
54211-87J30-YAY	405A-7-1
	405A-7-3
	405A-7-5
	405A-7-6
	405B-7-1
	405C-7-1
	405C-7-4
	405D-11-1
	405D-11-4
	405E-11-1
	405E-11-4
	405F-11
	405G-13
	405H-14
	405J-13-1
	405J-13-4
54221-88L20-QTN	405A-4-4
	405C-4-3
	405D-4-3
	405E-4-3
54221-88L20-Y5S	405A-4-2
	405B-4-2
	405C-4-2
	405D-4-2
	405E-4-2
	405J-4-2
54221-88L20-YAY	405A-4-1
	405A-4-3
	405A-4-5
	405A-4-6
	405B-4-1
	405C-4-1
	405C-4-4
	405D-4-1
	405D-4-4
	405E-4-1
	405E-4-4
	405F-4
	405G-4
	405H-4
	405J-4-1
	405J-4-4
54231-88L10-QTN	405A-5-4
	405C-5-3
	405D-5-3
	405E-5-3
	405J-5-3
54231-88L10-Y5S	405A-5-2
	405B-5-2
	405C-5-2
	405D-5-2
	405E-5-2
	405J-5-2
54231-88L10-YAY	405A-5-1
	405A-5-3
	405A-5-5
	405A-5-6
	405B-5-1
	405C-5-1
	405C-5-4
	405D-5-1
	405D-5-4
	405E-5-1
	405E-5-4
	405F-5
	405G-5
	405H-5
	405J-5-1
	405J-5-4
55100-87J50-QTN	407A-1-7
	407A-1-9
	407C-1-3
	407D-1-3
55100-87J50-Y5S	407A-1-2
	407A-1-4
	407A-1-6
	407C-1-2
	407D-1-2
55100-87J50-YAY	407A-1-1
	407A-1-3
	407A-1-5
	407A-1-8
	407A-1-10
	407B-1
	407C-1-1
	407C-1-4
	407D-1-1
	407D-1-4
	407E-1
55110-90J16-QTN	407G-1-3
55110-90J16-Y5S	407G-1-2
55110-90J16-YAY	407F-1
	407G-1-1
	407G-1-4
55122-88L00	220A-29
	220B-29
	220C-29
	220D-29
55125-90J01	407F-3
	407G-3
55125-94400	407A-4
	407B-4
	407C-4
	407D-4
	407E-4
55127-87D00	143A-38
	143B-38
	143C-38
	407F-4
	407G-4
55181-95200	407A-17
	407B-17
	407C-19
	407D-19
	407E-19
	407F-28
	407G-28
55300-95500	407A-18
	407B-18
	407C-20
	407D-20
	407E-20
	407F-27
	407G-27
55320-94900	335D-11
	335F-11
55321-87J01	111A-7-1
	111B-7-1
	111C-7-1
	113A-8
	113B-8
	124B-19
	124D-19
	124F-19
	335A-6
	335B-6
	335C-6
	335E-6
	335G-11
55321-87J11	111A-7-2
	111B-7-2
	111C-7-2
	160E-22
	160F-22
	160G-20
	407A-19
	407B-19
	407C-21
	407D-21
	407E-21
55321-90J01	407F-5
	407G-5
55332-87D12	407F-6
	407G-6
55333-87D10	407F-7
	407G-7
56120-90J02-QTN	220H-19-3
56120-90J02-Y5S	220H-19-2
56120-90J02-YAY	220E-19
	220F-19
	220G-19
	220H-19-1
	220H-19-4
56120-94321-QTN	220A-20-3
	220C-20-3
	220D-20-3
56120-94321-Y5S	220A-20-2
	220B-20-2
	220C-20-2
	220D-20-2
56120-94321-YAY	220A-20-1
	220A-20-4
	220B-20-1
	220C-20-1
	220C-20-4
	220D-20-1
	220D-20-4
56123-90J00	220E-20
	220F-20

PART NO.	FIG.NO.-REF.NO.
	220G-20
	220H-20
56130-87E00	220E-27
	220F-27
	220G-27
	220H-27
56130-87J12-QTN	220A-26-3
	220C-26-3
	220D-26-3
56130-87J12-Y5S	220A-26-2
	220B-26-2
	220C-26-2
	220D-26-2
56130-87J12-YAY	220A-26-1
	220A-26-4
	220B-26-1
	220C-26-1
	220C-26-4
	220D-26-1
	220D-26-4
56145-99E01	407F-29
	407G-29
57110-88L02	220A-1-1
	220C-1-1
57110-88L12	220A-1-2
	220B-1
	220C-1-2
	220D-1-1
57110-88L22	220A-1-3
	220D-1-2
57110-88L30	220E-1-1
	220F-1
	220G-1-1
	220H-1
57110-88L40	220E-1-2
	220G-1-2
57130-94301	405D-10
	405E-10
	405F-10
	405H-11
57133-88L01	220A-2
	220B-2
	220C-2
	220D-2
57133-90J02	220E-2
	220F-2
	220G-2
	220H-2
57133-94400	220A-3
	220B-3
	220C-3
	220D-3
57300-88810	220A-6
	220B-6
	220D-6
57300-88820	220C-6
57300-99824	220E-4
	220F-4
	220G-4
	220H-4
57610-88L10	220E-11
	220F-11
	220G-11
	220H-11
57610-94403	220A-13
	220B-13
	220C-13
	220D-13
57621-87J03	220A-14
	220B-14
	220C-14
	220D-14
57621-88L00	220E-12
	220F-12
	220G-12
	220H-12
57630-90J00	407F-26
	407G-26
57630-94301	407A-16
	407B-16
	407C-18
	407D-18
	407E-18
57631-95303	220A-19
	220B-19
	220C-19
	220D-19
57631-99E01	220E-14
	220F-14
	220G-14
	220H-14
57632-95320	407A-11
	407B-11
	407C-13
	407D-13
	407E-13
57633-90J02	407F-21
	407G-21
57633-94301	407A-12
	407B-12
57634-88L00	220A-16
	220B-16
	220C-16
	220D-16
57635-90J01	407F-22
	407G-22
58100-87LA0-019	407F-19-1
	407G-19-1
58100-87LB0-019	407F-19-2
	407G-19-2
58100-87LC0-019	407F-19-3
	407G-19-3
58100-87LG1-019	407F-19-6
	407G-19-6
58100-87LH0-019	407F-19-5
	407G-19-5
58100-87LJ0-019	407F-19-4
	407G-19-4
58100-88L52-019	407A-9-6
	407B-9-6
	407C-11-6
	407D-11-6
	407E-11-6
58100-88L62-019	407A-9-7
	407B-9-7
	407C-11-7
	407D-11-7
	407E-11-7
58100-88L72-019	407A-9-8
	407B-9-8
	407C-11-8
	407D-11-8
	407E-11-8
58100-88LA0-019	407A-9-4
	407B-9-4
	407C-11-4
	407D-11-4
	407E-11-4
58100-88LB0-019	407A-9-5
	407B-9-5
	407C-11-5
	407D-11-5
	407E-11-5
58100-88LC0-019	407A-9-1
	407B-9-1
	407C-11-1
	407D-11-1

PART NO.	FIG.NO.-REF.NO.
	407E-11-1
58100-88LD0-019	407A-9-2
	407B-9-2
	407C-11-2
	407D-11-2
	407E-11-2
58100-88LE0-019	407A-9-3
	407B-9-3
	407C-11-3
	407D-11-3
	407E-11-3
58100-88LF0-019	407A-9-9
	407B-9-9
	407C-11-9
	407D-11-9
	407E-11-9
58105-90J00	407F-20
	407G-20
58120-88L01	407A-10
	407B-10
	407C-12
	407D-12
	407E-12
58200-88L30	407A-9-10
	407B-9-10
	407C-11-10
	407D-11-10
	407E-11-10
60000	
61112-88L10	410A-1
	410B-1
61124-88L11	410A-24
	410B-24
61134-88L11	410A-2
	410B-2
61151-88L01	410A-6
	410B-6
61188-88L01	430A-4
	432A-8
61400-88822-YAY	420A-1-1
	420B-1-1
	420E-1-1
	420H-1-1
	420J-1-1
	420M-1-1
	420N-1-1
	420P-1-1
61400-88832-Y5S	420A-1-2
	420B-1-2
	420E-1-2
	420H-1-2
	420M-1-2
	420N-1-2
	420P-1-2
61400-88840-YAY	420C-1-2
	420D-1
	420F-1-2
	420G-1-2
	420K-1-2
	420L-1
	420R-1-2
	420S-1-2
	420T-1
	420U-1
61400-88850-QTN	420C-1-1
	420F-1-1
	420G-1-1
	420K-1-1
	420R-1-1
	420S-1-1
61412-88L00	410A-11
	410B-11
61422-88L30	420A-16-1
	420B-16-1
	420E-16-1
61422-88L40	420H-16-1
	420J-16-1
61422-88L50	420M-16-1
	420N-16-1
61422-88L60	420A-16-2
	420B-16-2
	420E-16-2
61422-88L70	420H-16-2
	420J-16-2
61422-88L80	420M-16-2
	420N-16-2
	420P-16-2
61431-88L10-QTN	420C-2-1
	420F-2-1
	420G-2-1
	420K-2-1
	420R-2-1
	420S-2-1
61431-88L10-Y5S	420A-2-2
	420B-2-2
	420E-2-2
	420H-2-2
	420J-2-2
	420M-2-2
	420N-2-2
	420P-2-2
61431-88L10-YAY	420A-2-1
	420B-2-1
	420C-2-2
	420D-2
	420E-2-1
	420F-2-2
	420G-2-2
	420H-2-1
	420J-2-1
	420K-2-2
	420L-2
	420M-2-1
	420N-2-1
	420P-2-1
	420R-2-2
	420S-2-2
	420T-2
	420U-2
61435-88L60	420A-17-1
	420B-17-1
	420E-17-1
61435-88L70	420H-17-1
	420J-17-1
61435-88L80	420M-17-1
	420N-17-1
	420P-17-1
61435-88L90	420A-17-2
	420B-17-2
	420E-17-2
61435-88LA0	420H-17-2
	420J-17-2
61435-88LB0	420M-17-2
	420N-17-2
	420P-17-2
61435-88LC0	420C-16-2
	420D-16
	420F-16-2
	420G-16-2
61435-88LD0	420C-16-1
	420F-16-1
	420G-16-1

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
61435-88LE0	420K-16-2		420M-9-1		420G-15-2
	420L-16		420N-9-1		420K-15-2
	420U-16		420P-9-1		420L-15
61435-88LF0	420K-16-1	61443-88L30	420A-9-2		420R-15-2
61435-88LG0	420R-16-2		420B-9-2		420S-15-2
	420S-16-2		420E-9-2		420T-10
	420T-16		420H-9-2		420U-15
61435-88LH0	420R-16-1		420J-9-2	61453-88L50	420C-15-1
	420S-16-1		420M-9-2		420F-15-1
61438-88L01	420A-3		420N-9-2		420G-15-1
	420B-3		420P-9-2		420K-15-1
	420C-3	61443-88L40	420C-14-2		420R-15-1
	420D-3		420D-14		420S-15-1
	420E-3		420F-14-2	61458-90J01	420A-18
	420F-3		420G-14-2		420B-18
	420G-3		420K-14-2		420C-17
	420H-3		420L-14		420D-17
	420J-3		420R-14-2		420E-18
	420K-3		420S-14-2		420F-17
	420L-3		420T-9		420G-17
	420M-3		420U-14		420H-18
	420N-3	61443-88L50	420C-14-1		420J-18
	420P-3		420F-14-1		420K-17
	420R-3		420G-14-1		420L-17
	420S-3		420K-14-1		420M-18
	420T-3		420R-14-1		420N-18
	420U-3		420S-14-1		420P-18
61439-88L01	420A-4	61446-88L00	420G-23-1		420R-17
	420B-4	61446-88L10	420G-23-2		420S-17
	420C-4	61447-88L00	420G-22-1		420T-17
	420D-4	61447-88L10	420G-22-2		420U-17
	420E-4	61453-88L20	420A-10-1	61472-88L01	136A-10
	420F-4		420B-10-1	61476-88L00	420A-6
	420G-4		420E-10-1		420B-6
	420H-4		420H-10-1		420C-6
	420J-4		420J-10-1		420D-6
	420K-4		420M-10-1		420E-6
	420L-4		420N-10-1		420F-6
	420M-4		420P-10-1		420G-6
	420N-4	61453-88L30	420A-10-2		420H-6
	420P-4		420B-10-2		420J-6
	420R-4		420E-10-2		420K-6
	420S-4		420H-10-2		420L-6
	420T-4		420J-10-2		420M-6
	420U-4		420M-10-2		420N-6
61443-88L20	420A-9-1		420N-10-2		420P-6
	420B-9-1		420P-10-2		420R-6
	420E-9-1	61453-88L40	420C-15-2		420S-6
	420H-9-1		420D-15		420T-6
	420J-9-1		420F-15-2		420U-6

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
61494-88L02	136A-12		420P-13	63110-88L25-YAY	444B-2-1
61610-95J00	420A-7		420R-11		444C-2-1
	420B-7		420S-11	63110-88L26-YAY	444B-2-2
	420C-7		420T-13		444C-2-2
	420D-7		420U-11	63110-88L34-YAY	444A-2-1
	420E-7	61632-93J00	410A-13	63110-88L35-YAY	444A-2-2
	420F-7		410B-13	63111-88L01-YAY	444A-63
	420G-7	61633-88L00	410A-16		444B-64
	420H-7		410B-16		444C-64
	420J-7	61641-88L00	410A-14		570A-77
	420K-7		410B-14		570B-78
	420L-7	61673-93J11	410A-22	63115-88L01	444A-69
	420M-7		410B-22		444B-70
	420N-7	61811-88L20-QTN	410A-3-9		444C-70
	420P-7		410A-3-11		570A-65
	420R-7	61811-88L20-Y5S	410A-3-4		570B-65
	420S-7		410A-3-6	63121-88L10	444A-15
	420T-7	61811-88L20-YAY	410A-3-3		444B-16
	420U-7		410A-3-5		444C-16
61620-95J00	420A-12		410A-3-10		570A-15
	420B-12		410A-3-12		570B-15
	420C-10		410B-3-2	63132-88L00	444A-74
	420D-10	61811-88L30-QTN	410A-3-7		444B-75
	420E-12	61811-88L30-Y5S	410A-3-2		444C-76
	420F-10	61811-88L30-YAY	410A-3-1		570A-69
	420G-10		410A-3-8		570B-70
	420H-12		410B-3-1	63210-88L00	444A-16
	420J-12	61821-88L20-QTN	410A-4-9		444B-17
	420K-10		410A-4-11		444C-17
	420L-10	61821-88L20-Y5S	410A-4-4		570A-16
	420M-12		410A-4-6		570B-16
	420N-12	61821-88L20-YAY	410A-4-3	63215-93110	444A-72
	420P-12		410A-4-5		444B-73
	420R-10		410A-4-10		444C-73
	420S-10		410A-4-12		570A-67
	420T-12		410B-4-2		570B-67
	420U-10	61821-88L30-QTN	410A-4-7	63221-88L00	444A-17
61631-88L10	420A-13	61821-88L30-Y5S	410A-4-2		444B-18
	420B-13	61821-88L30-YAY	410A-4-1		444C-18
	420C-11		410A-4-8		570A-17
	420D-11		410B-4-1		570B-17
	420E-13	61831-88L10-QTN	410A-7-3	63223-92D00	444A-18
	420F-11	61831-88L10-Y5S	410A-7-2		444B-19
	420G-11	61831-88L10-YAY	410A-7-1		444C-19
	420H-13		410A-7-4		570A-18
	420J-13		410B-7		570B-18
	420K-11	63002-88L17-YAY	570B-1-1	63225-88L00	444A-19
	420L-11	63002-88L18-YAY	570B-1-2		444B-20
	420M-13	63002-88L28-YAY	570A-1-1		444C-20
	420N-13	63002-88L2A-YAY	570A-1-2		570A-19

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	570B-19		570B-71		570B-42
63227-93200	444A-20	63258-88L00	444A-59	63612-87J00	444A-44
	444B-21		444B-60		444B-44
	444C-21		444C-60		444C-44
	570A-20		570A-73		570A-43
	570B-20		570B-74		570B-43
63235-88L00	444A-21	63260-88L00	444A-25	63612-88L10	444A-54
	444B-22		444B-26		444B-55
	444C-22		444C-26		444C-55
	570A-21		570A-25		570A-54
	570B-21		570B-25		570B-54
63244-99J00	444A-52	63261-87J00	444A-31	63626-88L00	444A-35
	444B-53		444B-32		444B-36
	444C-53		444C-32		444C-36
	570A-52		570A-31		570A-35
	570B-52		570B-31		570B-35
63245-99J00	444A-53	63262-87J00	444A-28	65000-94L10	432A-1
	444B-54		444B-29	65520-99100	432A-2
	444C-54		444C-29	65561-95D00	432A-3
	570A-53		570A-28	65700-88L06	430A-1
	570B-53		570B-28	65700-90J18	432A-5
63246-88L00	444A-22	63271-87J00	444A-29	65740-95D01	432A-4
	444B-23		444B-30	65750-95501	430A-2
	444C-23		444C-30		432A-6
	570A-22		570A-29	65770-90J04	430A-3
	570B-22		570B-29		430A-9
63247-99J00	444A-62	63272-87J00	444A-26	65770-90J13	432A-7
	444B-63		444B-27	65793-88L00	444A-78
	444C-63		444C-27		444B-79
	570A-76		570A-26		444C-80
	570B-77		570B-26		570A-79
63248-99J00	444A-30	63273-87J00	444A-27		570B-80
	444B-31		444B-28	67200-88L01	544A-1
	444C-31		444C-28		545A-1
	570A-30		570A-27	67200-93J34	517A-1
	570B-30		570B-27		518A-1
63250-88L00	444A-23	63274-87J00	444A-32	67200-93J62	508A-1
	444B-24		444B-33		508B-1
	444C-24		444C-33	67200-93J70	508C-1
	570A-23		570A-32		508D-1
	570B-23		570B-32	67211-88L00	544A-17
63251-87J00	444A-24	63610-88L00	444A-33	67211-92E50	517A-29
	444B-25		444B-34	67212-88L00	544A-7
	444C-25		444C-34	67212-95600	508A-13
	570A-24		570A-33		508B-13
	570B-24		570B-33		508C-11
63251-88L90	444A-56	63611-88L00	444A-43		508D-11
	444B-57		444B-43	67220-95630	508A-15
	444C-57		444C-43		508B-15
	570A-70		570A-42		508C-13

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	508D-13		545A-28	67252-95600	508A-25
67221-92E00	545A-8	67238-87D00	508A-19		508B-25
67221-92E50	518A-7		508B-19		508C-23
67222-92E00	545A-2		508C-17		508D-23
67222-92E50	518A-2		508D-17	67253-88L00	545A-40
67223-92E00	545A-3	67238-88L00	545A-31	67253-92E00	544A-13
67223-92E50	518A-6	67238-92E50	518A-32	67253-92E10	518A-37
67223-99E10	508A-16	67238-96L00	508A-51	67253-95600	508A-26
	508B-16		508B-51		508B-26
	508C-14		508C-49		508C-24
	508D-14		508D-49		508D-24
67224-92E00	545A-9	67239-92E00	518A-33		518A-39
67224-92E50	518A-8		545A-35	67254-92E50	517A-22
67224-96L00	508A-50	67239-92E10	518A-29	67255-92E50	517A-8
	508B-50		545A-41	67255-96L00	508A-27
	508C-48	67240-92E00	545A-17		508B-27
	508D-48	67240-92E50	518A-16		508C-25
67225-92E00	518A-25	67241-88L00	545A-34		508D-25
67225-92E50	518A-9	67241-92E50	518A-42	67256-92E50	517A-11
67226-92E00	545A-15	67241-99E11	508A-20	67256-95600	508A-28
67226-92E10	518A-14		508B-20		508B-28
	545A-16		508C-18		508C-26
67227-92E00	518A-23		508D-18		508D-26
	545A-24	67242-92E50	517A-13	67257-88L00	544A-9
67228-92E00	518A-17	67243-92E00	545A-38	67257-92E00	517A-12
	545A-18	67243-95600	508A-21	67257-96L00	508A-29
67229-95600	508A-17		508B-21		508B-29
	508B-17		508C-19		508C-27
	508C-15		508D-19		508D-27
	508D-15	67244-95600	508A-22	67258-99E00	508A-31
67230-88L00	545A-20		508B-22		508B-31
67230-92E00	518A-19		508C-20		508C-29
67231-88L00	545A-32		508D-20		508D-29
67231-92E00	518A-40	67245-92E00	518A-22	67259-87D00	508A-32
67232-88L00	545A-33		545A-23		508B-32
67232-92E50	518A-43	67245-95600	508A-23		508C-30
67232-95600	508A-18		508B-23		508D-30
	508B-18		508C-21	67261-88L00	544A-3
	508C-16		508D-21	67261-88L10	544A-2
	508D-16	67246-88L00	545A-36	67261-92E50	517A-10
	518A-41	67246-92E50	518A-34	67261-96L00	508A-33
67233-92E00	518A-27	67251-88L00	544A-20		508B-33
	545A-26	67251-92E50	517A-9		508C-31
67234-88L00	545A-22	67251-96L00	508A-24		508D-31
67234-92E00	518A-21		508B-24	67263-88L00	444A-36
67235-92E00	518A-28		508C-22	67264-88L00	544A-18
	545A-27		508D-22	67264-88L10	544A-19
67236-92E00	518A-30	67252-88L00	545A-39	67264-95600	508A-35
	545A-12	67252-92E00	518A-35		508B-35
67237-92E01	518A-31	67252-92E10	518A-38		508C-33

PART NO.	FIG.NO.-REF.NO.
	508D-33
67267-96L00	508A-36
	508B-36
	508C-34
	508D-34
67269-92E01	545A-29
67269-96L10	508A-47
	508B-47
	508C-45
	508D-45
67271-88L10	544A-16
67272-88L00	545A-6
67273-88L00	544A-25
	545A-47
67273-95601	508A-37
	508B-37
	508C-35
	508D-35
	517A-25
	544A-15
67274-88L00	545A-42
67274-92E50	517A-28
67275-95600	508A-38
	508B-38
	508C-36
	508D-36
	517A-24
	544A-14
67281-88L00	544A-10
67283-92E50	517A-26
67284-92E50	517A-27
67284-94L10	508A-52
	508B-52
	508C-50
	508D-50
67286-92E00	518A-18
	545A-19
67287-92E00	545A-46
67287-92E50	517A-19
67288-92E00	545A-4
67288-92E10	518A-4
67288-92E20	517A-14
	544A-6
67288-92E60	517A-6
	544A-12
67288-92E70	517A-16
67288-94320	508A-49
	508B-49
	508C-47
	508D-47
67291-92E00	518A-5
	545A-7
67291-92E10	518A-36
	545A-37
67292-87J00	444A-37
	444B-37
	444C-37
	570A-36
	570B-36
67292-94300	508A-39
	508B-39
	508C-37
	508D-37
	518A-3
	545A-5
67294-92E00	518A-11
67294-95600	508A-40
	508B-40
	508C-38
	508D-38
67295-92E10	517A-4
67295-92E50	517A-18
67296-88D10	517A-15
	518A-24
	545A-13
	545A-30
67296-88D20	517A-17
67296-88D30	517A-21
67296-88L00	544A-5
67296-90J20	508A-41
	508B-41
	508C-39
	508D-39
67296-92E11	508A-14
	508B-14
	508C-12
	508D-12
	518A-13
67296-92E20	518A-15
	545A-14
67296-92E30	545A-44
67296-92E60	544A-11
67296-94310	517A-3
67296-95610	508A-44
	508B-44
	508C-42
	508D-42
	545A-43
67296-95630	508A-43
	508B-43
	508C-41
	508D-41
67296-96L00	508A-42
	508B-42
	508C-40
	508D-40
67296-96L10	508A-34
	508B-34
	508C-32
	508D-32
67297-95600	508A-45
	508B-45
	508C-43
	508D-43
67298-92E50	517A-2
67320-93J00	508A-55-1
	508B-55-1
	508C-52-1
	508D-54-1
67320-93J10	508A-55-2
	508B-55-2
	508C-52-2
	508D-54-2
67320-93J20	508A-55-3
	508B-55-3
	508C-52-3
	508D-54-3
	515A-1-3
67320-93J30	508A-55-4
	508B-55-4
	508C-52-4
	508D-54-4
	515A-1-4
67320-93J40	508A-55-5
	508B-55-5
	508C-52-5
	508D-54-5
	515A-1-5
67320-93J50	508A-55-6
	508B-55-6
	508C-52-6
	508D-54-6
	515A-1-6
67320-93J60	508A-55-7
	508B-55-7
	508C-52-7
	508D-54-7
	515A-1-7

PART NO.	FIG.NO.-REF.NO.
67320-93J70	508A-55-8
	508B-55-8
	508C-52-8
	508D-54-8
	515A-1-8
67320-93J80	508A-55-9
	508B-55-9
	508C-52-9
	508D-54-9
	515A-1-9
67341-88L01	204A-16
	204B-16
	204C-16
	204D-16
	204E-16
	204F-16
	204G-16
67343-88L01	204A-18
	204B-18
	204C-18
	204D-18
	204E-18
	204F-18
	204G-18
67467-89J01	204A-21
	204B-21
	204C-21
	204D-21
	204E-21
	204F-21
	204G-21
67500-88L00	544A-21
67700-93J00	575A-1
67701-87J11	442A-2
	575A-3
67721-87J00	442A-3
	575A-4
67725-99E00	442A-4
	575A-5
67726-99E00	442A-5
	575A-6
67728-99E00	442A-6
	575A-7
68111-88L00	544A-8
68111-88L10	420A-11
	420B-11
	420C-9
	420D-9
	420E-11
	420F-9
	420G-9
	420H-11
	420J-11
	420K-9
	420L-9
	420M-11
	420N-11
	420P-11
	420R-9
	420S-9
	420T-11
	420U-9
69711-93E11	136A-11
70000	
77811-54GB0-0PG	508A-30
	508B-30
	508C-28
	508D-28
90000	
99011-88L91-03B	420B-21-2
	420C-20-7
	420J-21-2
	420K-20-7
	420N-21-2
	420R-20-7
	420U-20-4
99011-88L91-059	420A-21-2
	420C-20-4
	420D-20-4
	420H-21-2
	420K-20-4
	420L-20-4
	420M-21-2
	420P-21
	420R-20-4
	420S-20-1
	420T-20-4
99011-88L92-054	420A-21-1
	420B-21-1
	420C-20-1
	420D-20-1
	420E-21
	420F-20-1
	420H-21-1
	420J-21-1
	420K-20-1
	420L-20-1
	420M-21-1
	420N-21-1
	420R-20-1
	420T-20-1
	420U-20-1
99011-88LA0-03B	420C-20-8
	420K-20-8
	420R-20-8
	420U-20-5
99011-88LA0-054	420C-20-2
	420D-20-2
	420F-20-2
	420G-20-1
	420K-20-2
	420L-20-2
	420R-20-2
	420T-20-2
	420U-20-2
99011-88LA0-059	420C-20-5
	420D-20-5
	420K-20-5
	420L-20-5
	420R-20-5
	420S-20-2
	420T-20-5
99011-88LB0-03B	420C-20-9
	420K-20-9
	420R-20-9
	420U-20-6
99011-88LB0-054	420C-20-3
	420D-20-3
	420F-20-3
	420G-20-2
	420K-20-3
	420L-20-3
	420R-20-3
	420T-20-3
	420U-20-3
99011-88LB0-059	420C-20-6
	420D-20-6
	420K-20-6
	420L-20-6

PART NO.	FIG.NO.-REF.NO.
	420R-20-6
	420S-20-3
	420T-20-6
00000	
01421-08607	124A-4
	124B-4
	124C-4
	124D-4
	124E-4
	124F-4
01547-0616C	124A-12
	124B-12
	124C-12
	124D-12
	124E-12
	124F-12
01547-0625C	111A-18
	111B-18
	111C-18
01547-0640A	175A-3
01547-0645C	111A-19
	111B-19
	111C-19
01550-06127	303A-11
	326A-8
	326B-8
01550-0612A	119A-12
01550-0612C	111A-25
	111B-25
	111C-25
	146A-16
	180A-17
	180B-17
	204A-14
	204B-14
	204C-14
	204D-14
	204E-14
	204F-14
	204G-14
	322A-23
	322B-23
	322C-24
	322D-23
01550-06167	301A-18
01550-0616C	111A-27
	111B-27
	111C-27
	146A-9
	163A-5
	163B-5
	163C-5
	204A-3
	204A-17
	204B-3
	204B-17
	204C-3
	204C-17
	204D-3
	204D-17
	204E-3
	204E-17
	204F-3
	204F-17
	204G-3
	204G-17
	303A-9
01550-0620A	119A-10
01550-0620C	124A-15
	124B-15
	124C-15
	124D-15
	124E-15
	124F-15
	162A-7
	310A-8
01550-0625C	136A-8
	146A-2
	310A-2
01550-0630C	136A-2
	143A-27
	143B-27
	143C-27
	204A-4
	204B-4
	204C-4
	204D-4
	204E-4
	204F-4
	204G-4
	407F-31
	407G-31
01550-0640C	163A-12
	163B-12
	163C-12
01550-0645C	163A-4
	163B-4
	163C-4
01550-0820C	111A-9
	111B-9
	111C-9
	113A-2
	113B-2
	124B-21
	124D-21
	124F-21
	163A-6
	163B-6
	163C-6
01550-0825A	401A-10
	401B-10
	401C-10
	401D-10
01550-0830C	124A-5
	124B-5
	124C-5
	124D-5
	124E-5
	124F-5
	301A-19
01550-08407	113A-6
	113B-6
01550-0840C	124A-6
	124B-6
	124C-6
	124D-6
	124E-6
	124F-6
01550-08457	111A-12
	111B-12
	111C-12
01550-0845A	401A-4
	401B-4
	401C-4
	401D-4
01550-0885A	401A-5
	401B-5
	401C-5
	401D-5
01570-06167	204A-20
	204B-20
	204C-20
	204D-20
	204E-20

PART NO.	FIG.NO.-REF.NO.
	204F-20
	204G-20
01570-0616A	175A-7
02112-0408A	143A-15
02112-0612A	111C-21
02112-06307	303A-12
02112-34167	124A-9
	124B-9
	124C-9
	124D-9
	124E-9
	124F-9
02142-0408B	143A-16
02142-0612A	111A-21
	111B-21
03112-0630B	501A-25
	501B-23
03121-0516A	530A-28
03122-05169	530A-14
03142-04309	160A-17
	160B-17
	160C-17
	160D-17
03142-05169	530B-6
	530B-12
	530B-20
	530B-29
	530B-33
	530B-37
	530C-6
	530C-12
	530C-20
	530C-29
	530C-33
	530C-37
03522-05169	444A-61
	444B-62
	444C-62
	570A-75
	570B-76
03542-05169	410A-12
	410B-12
03542-06169	420A-5
	420B-5
	420C-5
	420D-5
	420E-5
	420F-5
	420G-5
	420H-5
	420J-5
	420K-5
	420L-5
	420M-5
	420N-5
	420P-5
	420R-5
	420S-5
	420T-5
	420U-5
03542-06209	136A-4
04211-09109	175A-4
04211-13189	111A-13
04221-04089	111B-13
	111C-13
	116A-7
	136A-9
04221-05109	121A-6
07120-06357	144A-5
	144B-5
08113-62090	220E-24
	220F-24
	220G-24
	220H-24
08211-20263	220A-12
	220B-12
	220C-12
	220D-12
08211-35451	220A-10-6
	220B-10-6
	220C-10-6
	220D-10-6
08221-35455	220A-10-1
	220B-10-1
	220C-10-1
	220D-10-1
08221-35456	220A-10-4
	220B-10-4
	220C-10-4
	220D-10-4
08310-00067	322A-17
	322B-17
	322C-18
	322D-17
08316-10087	322A-2
	322B-2
	322C-2
	322D-2
08316-1008C	124A-7
	124B-7
08321-01067	322A-18
	322B-18
	322C-19
	322D-18
08331-3115A	206A-12
	206B-12
	206C-12
	206D-12
08331-41309	210A-20
08331-41329	220A-28
	220B-28
	220C-28
	220D-28
09100-06131	407F-8
	407G-8
09100-06184	339A-10
09100-08232	508A-46
	508B-46
	508C-44
	508D-44
09100-08260	119A-5
09100-12091	335A-8-2
	335B-8-2
	335C-8-2
	335D-7-2
	335E-8-2
	335F-7-2
	335G-7-2
09100-12093	335A-8-1
	335B-8-1
	335C-8-1
	335D-7-1
	335E-8-1
	335F-7-1
	335G-7-1
09103-05026	410A-23
	410B-23
09103-06093	315A-5
	315C-9
09103-06266	111A-3
	111B-3
	111C-3
09103-06281	335A-7
	335B-7
	335C-7
	335E-7

PART NO.	FIG.NO.-REF.NO.
	335G-12
	337A-28
	337B-29
	337C-28
	337D-29
	337E-26
	337F-27
	339A-12
	405G-12
	405H-13
	405J-12
09103-10189	121A-4
09103-14024	303A-2
09106-05030	303A-7
09106-10065	335D-13
	335F-13
	335G-13
09108-06143	160A-7
	160B-7
	160C-7
	160D-7
09108-06144	160A-8
	160B-8
	160C-8
	160D-8
09108-08254	405D-8
	405E-8
	405F-8
09108-10161	336A-12
	336C-20
	336D-20
	336F-20
	336H-20
09116-06121	162A-3
	180A-8
	180B-8
	335D-12
	335F-12
09116-06127	410A-15
	410B-15
09116-06202	310A-4
09116-06236	160A-15
	160B-15
	160C-15
	160D-15
	160E-14
	160F-14
	336A-23
	336B-19
09116-06237	336B-30

PART NO.	FIG.NO.-REF.NO.
	444C-81
	570A-80
	570B-81
09116-08122	220A-25
	220B-25
	220C-25
	220D-25
	220E-26
	220F-26
	220G-26
	220H-26
09116-08131	405G-8
	405H-8
	405J-8
	407A-8
	407B-8
	407C-8-1
	407C-8-2
	407D-8
	407E-8
09116-08137	335D-5
	335F-5
	335G-5
	407F-9
	407G-9
	444A-65
	444B-66
	444C-66
	570A-61
	570B-61
09116-08159	401A-3
	401B-3
	401C-3
	401D-3
09116-08174	410A-8
	410B-8
09116-08178	180A-3
	180B-3
09116-10124	180A-13
	180B-13
09116-10134	405G-9
	405H-9
	405J-9
09116-10150	407F-10
	407G-10
	444A-73
	444B-74
	444C-74
	570A-68
	570B-68

PART NO.	FIG.NO.-REF.NO.
09116-10179	337A-26
	337B-27
	337C-26
	337D-27
	337E-24
	337F-25
	339A-11
09116-10181	401A-13
	401B-13
	401C-13
	401D-13
	405A-2
	405A-6
	405B-2
	405B-6
	405C-2
	405C-6
	405D-2
	405D-6
	405E-2
	405E-6
	405F-2
	405F-6
	405G-2
	405G-6
	405H-2
	405H-6
	405J-2
	405J-6
09117-06031	210A-8
09117-08109	407A-5
	407B-5
	407C-5
	407D-5
	407E-5
09117-08110	220E-30
	220F-30
	220G-30
	220H-30
09117-10039	407F-11
	407G-11
09125-04004	518A-26
09125-04021	517A-7
09125-05042	518A-20
	545A-21
09125-05046	160A-19
	160B-19
	160C-19
	160D-19
	160E-13

PART NO.	FIG.NO.-REF.NO.
	160F-13
	160G-13
	315C-3
09125-05047	444A-42
	444B-42
	444C-42
	570A-41
	570B-41
09125-05048	315A-3
09125-05050	336A-10
	336B-10
	336C-10
	336D-10
	336E-10
	336F-10
	336G-10
	336H-10
09125-05135	544A-22
09125-06063	336A-9
	336B-9
	336C-9
	336C-30
	336D-9
	336D-30
	336E-9
	336E-26
	336F-9
	336F-30
	336G-9
	336G-26
	336H-9
	336H-30
09125-06067	336C-13
	336D-13
	336E-13
	336F-13
	336G-13
	336H-13
09126-06006	545A-25
09126-06015	444A-38
	444B-38
	444C-38
	570A-37
	570B-37
09128-06094	111A-8
	111B-8
	111C-8
	113A-9
	113B-9
	124B-20

PART NO.	FIG.NO.-REF.NO.
	124D-20
	124F-20
09131-05004	530A-33
09132-04034	160E-17
	160F-17
	160G-16
09136-06148	410A-5-1
	410A-5-2
	410A-5-3
	410B-5-1
	410B-5-2
09137-04004	326A-2
	326B-2
	326C-2
	326D-2
09140-05005	163A-10
	163B-10
	163C-10
	544A-24
09140-06020	339A-13
	508A-48
	508B-48
	508C-46
	508D-46
	518A-10
	545A-10
09140-08016	407C-9
	407D-9
	407E-9
09140-12034	220A-7
	220B-7
	220C-7
	220D-7
09140-14024	220E-5
	220F-5
	220G-5
	220H-5
09141-18005	407A-13
	407B-13
	407C-15
	407D-15
	407E-15
	407F-23
	407G-23
09159-06084	420A-8
	420B-8
	420C-8
	420D-8
	420E-8
	420F-8

PART NO.	FIG.NO.-REF.NO.
	420G-8
	420H-8
	420J-8
	420K-8
	420L-8
	420M-8
	420N-8
	420P-8
	420R-8
	420S-8
	420T-8
	420U-8
09159-08059	336B-31
	570A-90
09159-10050	335A-13
	335B-13
	335C-13
	335E-13
	336A-13
	336C-21
	336D-21
	336F-21
	336H-21
09159-12014	335A-9
	335B-9
	335C-9
	335D-8
	335E-9
	335F-8
	335G-8
	401A-21
	401B-21
	401C-21
	401D-21
	405A-13
	405B-13
	405C-13
	405D-17
	405E-17
	405F-17
	405G-19
	405H-20
	405J-19
	444A-66
	444B-67
	444C-67
	570A-62
	570B-62
09159-22006	335A-10
	335B-10

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	335C-10		335G-14	09160-13014	410A-17
	335D-6	09160-10093	121A-5		410B-17
	335E-10	09160-10139	337A-29	09160-14065	303A-3
	335F-6		337B-30	09160-18028	407A-15
	335G-6	09160-10165	336A-14		407B-15
09160-05024	545A-45		336C-22		407C-17
09160-05029	315A-4		336D-22		407D-17
	544A-23		336F-22		407E-17
09160-06047	163A-11		336H-22		407F-24
	163B-11	09160-12066	335A-5		407G-24
	163C-11		335B-5	09160-22018	220A-11-1
09160-06055	204A-10		335C-5		220B-11-1
	204A-22		335E-5		220C-11-1
	204B-10		444A-67		220D-11-1
	204B-22		444B-68	09160-22019	220A-11-2
	204C-10		444C-68		220B-11-2
	204C-22		570A-63		220C-11-2
	204D-10		570B-63		220D-11-2
	204D-22	09160-12110	401A-22	09160-22020	220A-11-3
	204E-10		401B-22		220B-11-3
	204E-22		401C-22		220C-11-3
	204F-10		401D-22		220D-11-3
	204F-22		405A-14	09160-22021	220A-11-4
	204G-10		405B-14		220B-11-4
	204G-22		405C-14		220C-11-4
09160-06084	143A-29		405D-18		220D-11-4
	143B-29		405E-18	09160-22022	220A-11-5
	143C-29		405F-18		220B-11-5
09160-06085	407F-12		405G-20		220C-11-5
	407G-12		405H-21		220D-11-5
09160-06094	124A-16		405J-20	09160-22023	220A-11-6
	124B-16	09160-12124	444A-68		220B-11-6
	124C-16		444B-69		220C-11-6
	124D-16		444C-69		220D-11-6
	124E-16		570A-64	09160-39002	336A-17
	124F-16		570B-64		336B-13
09160-06104	517A-20	09160-12126	335A-12		336C-17
09160-08082	407C-10		335B-12		336D-17
	407D-10		335C-12		336E-17
	407E-10		335D-9		336F-17
09160-08122	210A-11		335E-12		336G-17
09160-08123	119A-6		335F-9		336H-17
09160-09010	210A-10		335G-9	09160-39003	336A-15
09160-09015	210A-9	09160-12128	335A-11		336B-11
09160-10082	335A-14		335B-11		336C-15
	335B-14		335C-11		336D-15
	335C-14		335D-10		336E-15
	335D-14		335E-11		336F-15
	335E-14		335F-10		336G-15
	335F-14		335G-10		336H-15

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09161-08011	336B-32		220H-10-2		220B-8-4
	570A-91	09181-28017	220E-10-3		220C-8-4
09163-06001	444A-39		220F-10-3		220D-8-4
	444B-39		220G-10-3	09181-33004	220A-8-5
	444C-39		220H-10-3		220B-8-5
	570A-38	09181-28018	220E-10-4		220C-8-5
	570B-38		220F-10-4		220D-8-5
09164-13010	444A-70		220G-10-4	09181-33005	220A-8-6
	444B-71		220H-10-4		220B-8-6
	444C-71	09181-28019	220E-10-5		220C-8-6
	570A-66		220F-10-5		220D-8-6
	570B-66		220G-10-5	09181-33006	220A-8-7
09164-14008	410A-18		220H-10-5		220B-8-7
	410B-18	09181-28020	220E-10-6		220C-8-7
09164-31001	220E-33		220F-10-6		220D-8-7
	220F-33		220G-10-6	09181-33007	220A-8-8
	220G-33		220H-10-6		220B-8-8
	220H-33	09181-30186	220A-9-1		220C-8-8
09168-10038	407A-7		220B-9-1		220D-8-8
	407B-7		220C-9-1	09181-33008	220A-8-9
	407C-7		220D-9-1		220B-8-9
	407D-7	09181-30187	220A-9-2		220C-8-9
	407E-7		220B-9-2		220D-8-9
	407F-13		220C-9-2	09181-33009	220A-8-10
	407G-13		220D-9-2		220B-8-10
09168-12012	180A-4	09181-30188	220A-9-3		220C-8-10
	180B-4		220B-9-3		220D-8-10
09169-06062	310A-5		220C-9-3	09181-35101	220A-8-1
09169-06075	143A-28		220D-9-3		220B-8-1
	143B-28	09181-30190	220A-9-4		220C-8-1
	143C-28		220B-9-4		220D-8-1
09169-08050	410A-9		220C-9-4	09181-35110	220A-8-11
	410B-9		220D-9-4		220B-8-11
09169-31001	220E-32	09181-30192	220A-9-5		220C-8-11
	220F-32		220B-9-5		220D-8-11
	220G-32		220C-9-5	09181-35131	220A-10-2
	220H-32		220D-9-5		220B-10-2
09180-06198	144A-6	09181-31001	220E-31		220C-10-2
	144B-6		220F-31		220D-10-2
09181-25030	220E-17		220G-31	09181-35132	220A-10-3
	220F-17		220H-31		220B-10-3
	220G-17	09181-33001	220A-8-2		220C-10-3
	220H-17		220B-8-2		220D-10-3
09181-28015	220E-10-1		220C-8-2	09181-35136	220A-10-5
	220F-10-1		220D-8-2		220B-10-5
	220G-10-1	09181-33002	220A-8-3		220C-10-5
	220H-10-1		220B-8-3		220D-10-5
09181-28016	220E-10-2		220C-8-3	09181-40186	220E-6-1
	220F-10-2		220D-8-3		220F-6-1
	220G-10-2	09181-33003	220A-8-4		220G-6-1

PART NO.	FIG.NO.-REF.NO.
	220H-6-1
09181-40190	220E-6-7
	220F-6-7
	220G-6-7
	220H-6-7
09181-40195	220E-6-11
	220F-6-11
	220G-6-11
	220H-6-11
09181-41002	220E-6-2
	220F-6-2
	220G-6-2
	220H-6-2
09181-41003	220E-6-3
	220F-6-3
	220G-6-3
	220H-6-3
09181-41004	220E-6-4
	220F-6-4
	220G-6-4
	220H-6-4
09181-41005	220E-6-5
	220F-6-5
	220G-6-5
	220H-6-5
09181-41006	220E-6-6
	220F-6-6
	220G-6-6
	220H-6-6
09181-41008	220E-6-8
	220F-6-8
	220G-6-8
	220H-6-8
09181-41009	220E-6-9
	220F-6-9
	220G-6-9
	220H-6-9
09181-41010	220E-6-10
	220F-6-10
	220G-6-10
	220H-6-10
09181-41012	220E-6-12
	220F-6-12
	220G-6-12
	220H-6-12
09181-41013	220E-6-13
	220F-6-13
	220G-6-13
	220H-6-13
09181-41014	220E-6-14
	220F-6-14
	220G-6-14
	220H-6-14
09181-45003	220E-9-1
	220F-9-1
	220G-9-1
	220H-9-1
09181-45004	220E-9-2
	220F-9-2
	220G-9-2
	220H-9-2
09181-45005	220E-9-3
	220F-9-3
	220G-9-3
	220H-9-3
09181-45006	220E-9-4
	220F-9-4
	220G-9-4
	220H-9-4
09181-45007	220E-9-6
	220F-9-6
	220G-9-6
	220H-9-6
09181-45008	220E-9-8
	220F-9-8
	220G-9-8
	220H-9-8
09181-45009	220E-9-10
	220F-9-10
	220G-9-10
	220H-9-10
09181-45013	220E-9-5
	220F-9-5
	220G-9-5
	220H-9-5
09181-45014	220E-9-7
	220F-9-7
	220G-9-7
	220H-9-7
09181-45015	220E-9-9
	220F-9-9
	220G-9-9
	220H-9-9
09181-45016	220E-9-11
	220F-9-11
	220G-9-11
	220H-9-11
09181-45017	220E-9-12
	220F-9-12
	220G-9-12
	220H-9-12
09181-45018	220E-9-13
	220F-9-13
	220G-9-13
	220H-9-13
09181-50020	220E-8-1
	220F-8-1
	220G-8-1
	220H-8-1
09181-50021	220E-8-2
	220F-8-2
	220G-8-2
	220H-8-2
09181-50022	220E-8-3
	220F-8-3
	220G-8-3
	220H-8-3
09181-50023	220E-8-4
	220F-8-4
	220G-8-4
	220H-8-4
09181-50024	220E-8-5
	220F-8-5
	220G-8-5
	220H-8-5
09181-50025	220E-8-6
	220F-8-6
	220G-8-6
	220H-8-6
09181-50026	220E-8-7
	220F-8-7
	220G-8-7
	220H-8-7
09181-50027	220E-8-8
	220F-8-8
	220G-8-8
	220H-8-8
09181-50028	220E-8-9
	220F-8-9
	220G-8-9
	220H-8-9
09181-50029	220E-8-10
	220F-8-10
	220G-8-10
	220H-8-10
09202-04022	410A-19
	410B-19
09202-05022	220A-15
	220B-15
	220C-15

PART NO.	FIG.NO.-REF.NO.
	220D-15
09202-06023	405D-9
	405E-9
	405F-9
09202-06025	220A-30
	220B-30
	220C-30
	220D-30
09202-06027	220A-31
	220B-31
	220C-31
	220D-31
09202-06031	160E-15
	160F-15
	160G-14
	405G-10
	405H-10
	405J-10
09202-07002	220E-13
	220F-13
	220G-13
	220H-13
09202-08006	401A-6
	401A-7
	401A-11
	401B-6
	401B-7
	401B-11
	401C-6
	401C-7
	401C-11
	401D-6
	401D-7
	401D-11
	405A-3
	405B-3
	405C-3
	405D-3
	405E-3
	405F-3
	405G-3
	405H-3
	405J-3
	407F-14
	407G-14
09204-03003	407A-14
	407B-14
	407C-16
	407D-16
	407E-16
	407F-25
	407G-25
09205-02004	206A-8
	206B-8
	206C-8
	206D-8
09205-02006	210A-12
09205-02013	206A-6
	206B-6
	206C-6
	206D-6
09205-03019	220A-4
	220B-4
	220C-4
	220D-4
09205-03021	206A-7
	206B-7
	206C-7
	206D-7
	210A-13
09205-03051	336A-25
	336B-21
09206-08001	111A-4
	111B-4
	111C-4
09206-09012	407F-30
	407G-30
09206-13019	113A-5
	113B-5
09209-12007	220E-16
	220F-16
	220G-16
	220H-16
09229-04005	420A-15
	420B-15
	420C-13
	420D-13
	420E-15
	420F-13
	420G-13
	420H-15
	420J-15
	420K-13
	420L-13
	420M-15
	420N-15
	420P-15
	420R-13
	420S-13
	420T-15
	420U-13
09229-04018	420A-14
	420B-14
	420C-12
	420D-12
	420E-14
	420F-12
	420G-12
	420H-14
	420J-14
	420K-12
	420L-12
	420M-14
	420N-14
	420P-14
	420R-12
	420S-12
	420T-14
	420U-12
09248-10008	407A-6
	407B-6
	407C-6
	407D-6
	407E-6
	407F-15
	407G-15
09248-12009	180A-5
	180B-5
09250-40002	326C-8
	326D-8
09251-07003	430A-5
	432A-9
09260-10005	206A-14
	206B-14
	206C-14
	206D-14
	210A-14
09260-10006	444A-55
	444B-56
	444C-56
	570A-55
	570B-55
09262-35070	220A-23
	220B-23
	220C-23
	220D-23
09263-22020	220A-21
	220B-21
	220C-21
	220D-21

PART NO.	FIG.NO.-REF.NO.
09263-22039	407A-2
	407B-2
	407C-2
	407D-2
	407E-2
09263-28016	407F-2
	407G-2
09263-28047	220E-21
	220F-21
	220G-21
	220H-21
09265-20015	220A-5
	220B-5
	220C-5
	220D-5
09265-25046	220E-3
	220F-3
	220G-3
	220H-3
09265-30004	407A-3
	407B-3
	407C-3
	407D-3
	407E-3
09265-50003	220E-7
	220F-7
	220G-7
	220H-7
09280-08005	206A-3
	206B-3
	206C-3
	206D-3
09280-08008	210A-15
09280-09008	180A-16
	180B-16
09280-11001	206A-4
	206B-4
	206C-4
	206D-4
09280-12008	175A-6
09280-15003	210A-16
09280-22019	111A-6
	111B-6
	111C-6
	124B-18
	124D-18
	124F-18
09280-26005	146A-3
09280-26006	111A-15
	111B-15
	111C-15
	162A-4
09280-46004	220E-28
	220F-28
	220G-28
	220H-28
09280-69001	210A-17
09280-75001	220A-24
	220B-24
	220C-24
	220D-24
09280-97001	220E-22
	220F-22
	220G-22
	220H-22
09282-17005	220A-27
	220B-27
	220C-27
	220D-27
09282-17011	401A-16
	401B-16
	401C-16
	401D-16
09282-22007	220E-29
	220F-29
	220G-29
	220H-29
09282-28002	220E-23
	220F-23
	220G-23
	220H-23
09282-39001	336A-16
	336B-12
	336C-16
	336D-16
	336E-16
	336F-16
	336G-16
	336H-16
09283-37005	116A-11
09284-08003	210A-18
09289-05012	121A-15
09289-22007	220A-22
	220B-22
	220C-22
	220D-22
09306-13007	410A-20
	410B-20
09320-08062	144A-3
	144B-3
09320-08510	322A-6
	322B-6
	322C-6
	322D-6
09320-08517	143A-34
	143B-34
	143C-34
09320-09016	310A-6
09320-09059	143A-30
	143B-30
	143C-30
09320-09501	136A-3
09320-11023	410A-10
	410B-10
09343-70503-080	146A-12
09352-50003-770	143A-31
	143B-31
	143C-31
09352-50006-600	162A-12
	507A-2
	507A-3
09352-50901-600	410A-21
	410B-21
09352-70104-600	204A-19
	204B-19
	204C-19
	204D-19
	204E-19
	204F-19
	204G-19
09355-40805-600	407F-16
	407G-16
09359-50901-980	162A-13
09362-09008	407F-17
	407G-17
09367-06006	507A-4
09367-08001	430A-6
	432A-10
09380-12002	337A-25
	337B-26
	337C-25
	337D-26
	337E-23
	337F-24
	339A-14
09380-38003	336A-18
	336B-14
	336C-18
	336D-18
	336E-18

PART NO.	FIG.NO.-REF.NO.
	336F-18
	336G-18
	336H-18
09381-18002	116A-4
09385-06012	204A-11
	204A-23
	204B-11
	204B-23
	204C-11
	204C-23
	204D-11
	204D-23
	204E-11
	204E-23
	204F-11
	204F-23
	204G-11
	204G-23
09387-52001	220E-25
	220F-25
	220G-25
	220H-25
09401-08412	143A-32
	143B-32
	143C-32
09401-08413	162A-14
	507A-5
09401-10415	162A-15
09401-11006	432A-11
09401-11423	146A-6
	146A-18
	430A-7
09401-11425	144A-8
	144B-8
09401-15414	111A-23
	111B-23
	111C-23
09401-25406	162A-9
09403-07340	315A-7
	315C-13
09403-11320	146A-17
09403-11321	315C-14
09403-13413	315C-17
09403-13414	303A-10
09403-17312	111A-24
	111B-24
	111C-24
09407-08401	530A-8
	530A-30
09407-10404	326A-4
	326B-4
	326C-4
	326D-4
	407F-18
	407G-18
09407-14403	322A-19
	322B-19
	322C-20
	322D-19
09407-14407	315A-9
	315C-16
	322A-20
	322B-20
	322C-21
	322D-20
	326A-14
	326B-14
	501A-6
	501A-18
	501B-6
	501B-18
09407-18402	322A-24
	322B-24
	322C-25
	322D-24
09407-20405	410A-25
	410B-25
	507A-7
09408-00043	143A-35
	143B-35
	143C-35
09408-00121	143A-36
	143B-36
	143C-36
09408-00145	143A-37
	143B-37
	143C-37
	146A-19
09408-00174	144A-9
	144B-9
09408-00175	162A-16
09408-00184	326A-5
	326B-5
	326C-5
	326D-5
09408-00346	507A-8
09409-05312-6GS	430A-8
	432A-12
09420-04006	160A-20
	160B-20
	160C-20
	160D-20
09420-04008	303A-4
09420-04009	160E-16
	160F-16
	160G-15
09440-06037	444A-60
	444B-61
	444C-61
	570A-74
	570B-75
09440-07033	210A-19
09440-07078	206A-15
	206B-15
	206C-15
	206D-15
09440-08043	220A-17
	220B-17
	220C-17
	220D-17
09440-11020	220E-15
	220F-15
	220G-15
	220H-15
09440-12027	444A-40
	444B-40
	444C-40
	570A-39
	570B-39
09440-40002	220A-18
	220B-18
	220C-18
	220D-18
09440-49004	220E-18
	220F-18
	220G-18
	220H-18
09443-10043	336C-31
	336D-31
	336E-27
	336F-31
	336G-27
	336H-31
09471-12028	501A-4
	501B-4
09471-12077	501A-21
	501A-23
	501B-21
09471-12103	501A-9
	501A-13

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	501A-15				
	501A-19				
	501B-9				
	501B-13				
	501B-15				
	501B-19				
09471-12108	501A-2				
	501B-2				
09481-10501	508A-54				
	508B-54				
	521A-5				
	521D-3				
09481-15504	322A-12				
	322B-12				
	322C-12				
	322D-12				
09481-30403	322A-14				
	322B-14				
	322C-14				
	322D-14				
09481-30504	322A-13				
	322B-13				
	322C-13				
	322D-13				
09482-00446	111A-28				
	111B-28				
	111C-28				
09800-81812	420A-19				
	420B-19				
	420C-18				
	420D-18				
	420E-19				
	420F-18				
	420G-18				
	420H-19				
	420J-19				
	420K-18				
	420L-18				
	420M-19				
	420N-19				
	420P-19				
	420R-18				
	420S-18				
	420T-18				
	420U-18				

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.

SUZUKI **DF40A/DF50A/DF60A** PARTS CATALOGUE

SUZUKI MOTOR CORPORATION All rights reserved
No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Suzuki Motor Corporation.

SUZUKI MOTOR CORPORATION
Service Material Development Group, Automobile & Motorcycle Service Engineering Dept.
300 Takatsuka, Minami, Hamamatsu, Japan

Copyright © SUZUKI MOTOR CORPORATION 2022 All Rights Reserved

SUZUKI MOTOR CORPORATION

PRINTED IN JAPAN

9900B-45517-000