SUZUKI

PARTS CATALOGUE

DF40A/50A/60A

DF40A
DF50A
DF60A
DF50AV
DF60AV

SUZUKI Way of Life!

OUTBOARD MOTOR

E03

2016-6

1ST EDITION

PREFACE

When it becomes necessary to replace parts on SUZUKI OUTBOARD MOTORS, always use SUZUKI GENUINE PARTS which have passed a strict inspection which guarantees quality and performance.

This parts catalogue covers the list of all service parts for SUZUKI DF40A/50A/60A production start 2016.

INSTRUCTIONS FOR QUOTING THE CATALOGUE

1. DIMENSIONS

Dimensions of the parts in this catalogue are indicated in unit millimeters.

2. ABBREVIATIONS

Abbreviations used in this catalogue are as follows:

AR	: As required	NT	: Number of teeth
ASSY	: Assembly	OPT	: Optional
E.NO.	: Engine number	OS	: Over size
F.NO.	: Frame number	STD	: Standard
D	: Diameter of material	T	: Thickness
ID	: Inside diameter	US	: Under size
OD	: Outside diameter	W	: Width
L	: Length	W/	: With
LH(PORT)	: Left hand side	L	: Transom type
RH(STBD)	: Right hand side	SUS	: Stainless steel
～031234	: Up to E.NO.06002F-031234	PTT	: Power trim and tilt
031234～	: From E.NO.06002F-031234		

12 x 34 x 5.6····· Figures in the description column show the dimensions of parts.
ID OD T(or W,L)

→12345-56781 (Parts No.) : indicates that the parts number was changed to 12345-56781 and the new parts are interchangeable with the former ones but the former ones are not interchangeable with new ones.

←12345-56781 (Parts No.) : indicates that the former and new parts are interchangeable with each other and both are usable.

3. INNER PARTS OF ASSEMBLY

Part name with a dot (.) in front as shown in the description column indicates the component of the assembly also available individually.

4. MODIFICATION NOTICE

A parts bulletin will be sent to you on all occasions when changes in parts occur, including interchangeable modifications between new parts and old ones.

5. NOTE

5-1. There are some different parts from those of production models among spare parts for the administrative reasons and common use of them with other models.

5-2. In respect of rubber hoses and vinyl tubes, please be sure to use them by cutting off according to the length mentioned on parts catalogue or what is actually required on the vehicle.

5-3. Note that the drawings on the illustration page are for ready reference of spare parts number, not to be used as an assembly manual. When assembling, use "SUZUKI SERVICE MANUAL".

6. MODEL NAME AND ENGINE NUMBER

MODEL	DESTINATION	TYPE	TRANSOM	COLOR	ENGINE No.
DF40AT	E03	04003F	L	YAY,Y5S	04003F-710001～
DF50AT	E03	05003F	L	YAY,Y5S	05003F-710001～
DF60AT	E03	06002F	L	YAY,Y5S	06002F-710001～
DF50AVT	E03	05004F	L	YAY	05004F-710001～
DF60AVT	E03	06003F	L	YAY	06003F-710001～

PREFACE

Quand il devient nécessarie de remplacer des pièces sur SUZUKI MOTEURS HORSBOARD toujours utiliser les PIECES D'ORIGINE SUZUKI qui ont été soumises à des contriles de qualité sévères leur garantissant qualité et performance impeccables.

Ce catalogue de pièces détachées couvre la liste de toutes les pièces de rechange pour SUZUKI DF40A/50A/60A production start 2016.

INSTRUCTIONS POUR UTILISER LE CATALOGUE

1. DIMENSIONS

Les dimensions des pièces dans ce catalogue sont indiquées en unités de millimètres.

2. ABREVIATIONS

Les abréviations utilisées dans ce catalogue sont les suivantes:

AR	: Comme requis	NT	: Nombre de dents
ASSY	: Assemblage	OPT	: Sur option
E.NO.	: Numéro du moteur	OS	: Sur-dimensionné
F.NO.	: Numéro du chfssis	T	: Epaisseur
ID	: Diamètre intérieur	US	: Sous-dimensionné
OD	: Diamètre extérieur	W	: Largeur
L	: Longueur	W/	: Avec
LH(PORT)	: Côté gauche	L	: Type transom
RH(STBD)	: Côte droit	PTT	: Dispositif d'incliuaison et de revage assistés

～031234 : Jusqu'à E.No.06002F-031234
031234～ : Depuis E.No.06002F-031234
12 x 34 x 5.6…… Les chiffres dans la colonne
| | | remarques montrent les dimensions
ID OD T(or W,L) des pieces comme suit.

→12345-56781 (N^{O} de pieces) : indique que le numéro des pièces a été ehangé en 12345-56781 et que les nouvelles pièces sont interchange-ables avec les anciennes, mais que celles-cine sont pas interchangeables avec les nouvelles.

←12345-56781 (N^{O} de pieces) : indique que les anciennes et nouvelles pièces sont interchangeables les unes avec les autres et sont utilisables chacune.

3. PIECES INTERNES DE L'ASSEMBLAGE

Les numéros de pièces qui comportent un point (.) avant la désignation de pièce détachée indique la pièce interne se rapportant à l'assemblage.

4. AVIS DE MODIFICATION

Un bulletin de pièces détachées vous sera envoyé à tout moment opportun quand des changements de pièces ont lieu, y compris les modifications de pièces interchangeables entre les nouvelles et anciennes pièces.

5. A NOTER

5-1. Il existe certaines pièces différentes de celles de rechange pour les modèles de production vu des rainsons administratives et dont l'usage est commun avec celles d'autres modèles.

5-2. Concernant les durites en caoutchouc et les tuyaux en vinyle, ne pas manquer de les couper à la bonne longueur comme indiqué dans le catalogue des pièces détachées ou selon ce qui est utile pour le véhicule affecté.

5-3. Noter que les dessins à la page d'illustration servent à titre de référence pour les numéros de pièces détachées, et non pas comme référence pour l'assemblage. Pour cette dernière opération, se reporter au "MANUEL D'ENTRETIEN SUZUKI".

6. NOM DU MODELE / NUMERODE SERIE DU MOTEUR

MODELE	DESTINATION	TYPE	HOUTEUR DE BARRE D'ARCASSE	COULEUR	N^{O} DELA MOTEUR
DF40AT	E03	04003F	L	YAY, Y5S	04003F-710001～
DF50AT	E03	05003F	L	YAY, Y5S	05003F-710001～
DF60AT	E03	06002F	L	YAY, Y5S	06002F-710001～
DF50AVT	E03	05004F	L	YAY	05004F-710001～
DF60AVT	E03	06003F	L	YAY	06003F-710001～

MILLIMETER → INCH CONVERSION CHART
TABLEAU DE CONVERSION DE MILLIMETRES → POUCES

	0	1	2	3	4	5	6	7	8	9
00	.000	.039	.079	.118	.157	.197	.236	.276	.315	.354
10	.394	.433	.472	.512	.551	.591	.630	.669	.709	.748
20	.787	.827	.866	.906	.945	.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.535
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.214	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.031	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

How to read
Mode de lecture


	0	1	2	3	4
00	…	…	…	…	…
10	…	…	…	…	…
20	…	…	…	0.906	…
30	…	…	…	…	…

23 millimeters equal 0.906 in
23 millimètres égalent 0.906 pouce

Contents are subject to change without notice or obligation.


Les matières traitées sont susceptibles d'être modifiées sans préavis obligation de notre part.

FIG.111A




DF80A_E03_017_111A
CYLINDER HEAD

FIG.111B




DF80A_E03_017_111B
CYLINDER HEAD

FIG.111C




DF80A_E03_017_111C
CYLINDER HEAD

FIG.111D




DF80A_E03_017_111D
CYLINDER HEAD

FIG.111E




DF80A_E03_017_111E
CYLINDER HEAD

FIG.113A




DF80A_E03_017_113A
CYLINDER BLOCK

FIG.116A




DF80A_E03_017_116A
CRANKSHAFT

FIG.119A




DF80A_E03_017_119A
TIMING CHAIN

FIG.121A




DF8RA_E03_017_121A
CAMSHAFT

FIG.124A




DF8RA_E03_017_124A
INTAKE MANIFOLD/SILENCER/EXHAUST COVER

FIG.124B




DF8RA_E03_017_124B
INTAKE MANIFOLD/SILENCER/EXHAUST COVER

FIG.124C




DF8RA_E03_017_124C
INTAKE MANIFOLD/SILENCER/EXHAUST COVER

FIG.124D




DF8RA_E03_017_124D
INTAKE MANIFOLD/SILENCER/EXHAUST COVER

FIG.124E




DF8RA_E03_017_124E
INTAKE MANIFOLD/SILENCER/EXHAUST COVER

FIG.136A




DF8RA_E03_017_136A
RING GEAR COVER

FIG.143A




DF8RA_E03_017_143A
FUEL VAPOR SEPARATOR

FIG.144A




DF6RA_E03_017_144A
FUEL INJECTOR

FIG.146A




DF6RA_E03_017_146A
FUEL PUMP

FIG.160A




DF6RA_E03_017_160A
WATER PUMP

FIG.160B




DF6RA_E03_017_160B
WATER PUMP

FIG.160C




DF6RA_E03_017_160C
WATER PUMP

FIG.160D




DF6RA_E03_017_160D
WATER PUMP

FIG.160E




DF6RA_E03_017_160E
WATER PUMP

FIG.162A




DF6RA_E03_017_162A
THERMOSTAT

FIG.162B




DF80A_E03_017_162B
THERMOSTAT

FIG.162C




DF80A_E03_017_162C
THERMOSTAT

FIG.162D




DF80A_E03_017_162D
THERMOSTAT

FIG.162E




DF80A_E03_017_162E
THERMOSTAT

FIG.163A




DF80A_E03_017_163A
THROTTLE BODY

FIG.175A




DF80A_E03_017_175A
OIL PUMP

FIG.180A




DF80A_E03_017_180A
OIL PAN

FIG.180B




DF80A_E03_017_180B
OIL PAN

FIG.180C




DF8RA_E03_017_180C
OIL PAN

FIG.180D




DF8RA_E03_017_180D
OIL PAN

FIG.180E




DF8RA_E03_017_180E
OIL PAN

FIG.204A




DF8RA_E03_017_204A
CLUTCH SHAFT

FIG.204B




DF8RA_E03_017_204B
CLUTCH SHAFT

FIG.204C




DF8RA_E03_017_204C
CLUTCH SHAFT

FIG.204D




DF8RA_E03_017_204D
CLUTCH SHAFT

FIG.204E




DF8RA_E03_017_204E
CLUTCH SHAFT

FIG.206A




DF6RA_E03_017_206A
CLUTCH ROD

FIG.206B




DF6RA_E03_017_206B
CLUTCH ROD

FIG.206C




DF6RA_E03_017_206C
CLUTCH ROD

FIG.210A




DF6RA_E03_017_210A
SHIFT ROD

FIG.210B




DF6RA_E03_017_210B
SHIFT ROD

FIG.220A




DF6RA_E03_017_220A
TRANSMISSION

FIG.220B




DF6RA_E03_017_220B
TRANSMISSION

FIG.220C




DF6RA_E03_017_220C
TRANSMISSION

FIG.220D




DF8RA_E03_017_220D
TRANSMISSION

FIG.220E




DF8RA_E03_017_220E
TRANSMISSION

FIG.301A




DF8RA_E03_017_301A
STARTING MOTOR

FIG.303A




DF8RA_E03_017_303A
MAGNETO

FIG.310A




DF8RA_E03_017_310A
RECTIFIER/IGNITION COIL

FIG.315A




DF8RA_E03_017_315A
SENSOR

FIG.315B




DF8RA_E03_017_315B
SENSOR

FIG.315C




DF8RA_E03_017_315C
SENSOR

FIG.315D




DF8RA_E03_017_315D
SENSOR

FIG.315E




DF8RA_E03_017_315E
SENSOR

FIG.322A




DF8RA_E03_017_322A
HARNESS

FIG.322B




DF8RA_E03_017_322B
HARNESS

FIG.322C




DF8RA_E03_017_322C
HARNESS

FIG.322D




DF8RA_E03_017_322D
HARNESS

FIG.322E




DF8RA_E03_017_322E
HARNESS

FIG.326A




DF8RA_E03_017_326A
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326B




DF8SA_E03_017_326B
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326C




DF8SA_E03_017_326C
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326D




DF8SA_E03_017_326D
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326E




DF8SA_E03_017_326E
PTT SWITCH/ENGINE CONTROL UNIT

FIG.335A




DF8SA_E03_017_335A
CLAMP BRACKET

FIG.335B




DF8SA_E03_017_335B
CLAMP BRACKET

FIG.335C




DF8SA_E03_017_335C
CLAMP BRACKET

FIG.335D




DF8SA_E03_017_335D
CLAMP BRACKET

FIG.335E




DF6RA_E03_017_335E
CLAMP BRACKET

FIG.336A




DF6RA_E03_017_336A
SWIVEL BRACKET

FIG.336B




DF6RA_E03_017_336B
SWIVEL BRACKET

FIG.336C




DF6RA_E03_017_336C
SWIVEL BRACKET

FIG.336D




DF6RA_E03_017_336D
SWIVEL BRACKET

FIG.336E




DF6RA_E03_017_336E
SWIVEL BRACKET

FIG.337A




DF6RA_E03_017_337A
TRIM CYLINDER

FIG.337B




DF6RA_E03_017_337B
TRIM CYLINDER

FIG.337C




DF8RA_E03_017_337C
TRIM CYLINDER

FIG.337D




DF8RA_E03_017_337D
TRIM CYLINDER

FIG.337E




DF8RA_E03_017_337E
TRIM CYLINDER

FIG.340A




DF8RA_E03_017_340A
PIT MOTOR

FIG.401A




DF8RA_E03_017_401A
ENGINE HOLDER

FIG.401B




DF8RA_E03_017_401B
ENGINE HOLDER

FIG.401C




DF8RA_E03_017_401C
ENGINE HOLDER

FIG.401D




DF8RA_E03_017_401D
ENGINE HOLDER

FIG.401E




DF8RA_E03_017_401E
ENGINE HOLDER

FIG.405A




DF8RA_E03_017_405A
DRIVE SHAFT HOUSING

FIG.405B




DF8RA_E03_017_405B
DRIVE SHAFT HOUSING

FIG.405C




DF8RA_E03_017_405C
DRIVE SHAFT HOUSING

FIG.405D




DF8RA_E03_017_405D
DRIVE SHAFT HOUSING

FIG.405E




DF8RA_E03_017_405E
DRIVE SHAFT HOUSING

FIG.407A




DF8RA_E03_017_407A
GEAR CASE

FIG.407B




DF8RA_E03_017_407B
GEAR CASE

FIG.407C




DF80A_E03_017_407C
GEAR CASE

FIG.407D




DF80A_E03_017_407D
GEAR CASE

FIG.407E




DF80A_E03_017_407E
GEAR CASE

FIG.410A




DF80A_E03_017_410A
SIDE COVER

FIG.410B




DF80A_E03_017_410B
SIDE COVER

FIG.410C




DF80A_E03_017_410C
SIDE COVER

FIG.410D




DF80A_E03_017_410D
SIDE COVER

FIG.410E




DF80A_E03_017_410E
SIDE COVER

FIG.420A




DF8RA_E03_017_420A
ENGINE COVER

FIG.420B




DF8RA_E03_017_420B
ENGINE COVER

FIG.420C




DF8RA_E03_017_420C
ENGINE COVER

FIG.420D




DF8RA_E03_017_420D
ENGINE COVER

FIG.420E




DF8RA_E03_017_420E
ENGINE COVER

FIG.430A




DF8RA_E03_017_430A
FUEL HOSE

FIG.442A




DF8RA_E03_017_442A
DRAG LINK

FIG.501A




DF8RA_E03_017_501A
DRIFT METER

FIG.507A




DF8A_E03_017_507A
OPT:WATER PRESSURE GAUGE SUB KIT

FIG.515A




DF8A_E03_017_515A
OPT:REMOCON CABLE

FIG.521A




DF8A_E03_017_521A
OPT:HARNESS

FIG.530A




DF8A_E03_017_530A
OPT:SWITCH

FIG.544A




DF8A_E03_017_544A
OPT:REMOTE CONTROL ASSY SINGLE (1)

FIG.545A




DF8A_E03_017_545A
OPT:REMOTE CONTROL ASSY SINGLE (2)

FIG.570A




DF8A_E03_017_570A
OPT:TILLER HANDLE

FIG.570B




DF8A_E03_017_570B
OPT:TILLER HANDLE

FIG.570C




DF60A_E03_017_570C
OPT:TILLER HANDLE

FIG.570D




DF60A_E03_017_570D
OPT:TILLER HANDLE

FIG.570E




DF60A_E03_017_570E
OPT:TILLER HANDLE

FIG.585A



DF60A_E03_017_585A
OPT:GASKET SET

FIG.600A



DF60A_E03_017_600A
OPT:MULTI FUNCTION GAUGE

FIG.111A




FIG.111A (1-B-2) CYLINDER HEAD (DF40A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11100-88L10	HEAD ASSY, CYLINDER	1	
2	11115-73G01-001	.GUIDE, VALVE	12	
3	09103-06266	.BOLT (6X40)	17	
4	09206-08001	.PIN (8X11)	14	
5	11261-93J00	COVER, PROTECTION ANODE	2	
6	09280-22019	O RING (D:1.9,ID:21.8)	2	
7-1	55321-87J01	ANODE, PROTECTION	2	
7-2	55321-87J11	ANODE (MAGNESIUM)	1	OPT
8	09103-06281	BOLT (6X14)	2	
9	01550-08207	BOLT	2	
10	11119-87J00	BOLT, CYLINDER HEAD (10X95)	8	
11	11141-88L00	GASKET, CYLINDER HEAD	1	
12	01550-08457	BOLT	4	
13	04211-13189	PIN	2	
14	11382-93J00	CAP, OIL FILLER	1	
15	09280-26006	O RING (D:3.1,ID:26.4)	1	
16	11170-88L10	COVER, CYLINDER HEAD	1	
17	11189-88L00	GASKET, CYLINDER HEAD COVER	1	
18	01547-06257	BOLT	9	
19	01547-06457	BOLT	3	
20	11173-88L00	PLATE, BREATHER	1	
21	02142-0612A	SCREW	4	
22	11174-88L00	HOSE, BREATHER	1	
23	09401-15414	CLIP	2	
24	09403-17303	CLAMP	2	
25	01550-06127	BOLT	2	
26	11194-88L10	GUARD, FUEL HOSE	1	
27	01550-06167	BOLT	2	
28	09482-00446	SPARK PLUG (DCPR6E)	3	NGK
29	11115-73G01-001	GUIDE, VALVE (OS)	4	OPT

DF60A_E03_017_111A
CYLINDER HEAD

FIG.111B




FIG.111B (1-B-3) CYLINDER HEAD (DF50A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11100-88L10	HEAD ASSY, CYLINDER	1	
2	11115-73G01-001	.GUIDE, VALVE	12	
3	09103-06266	.BOLT (6X40)	17	
4	09206-08001	.PIN (8X11)	14	
5	11261-93J00	COVER, PROTECTION ANODE	2	
6	09280-22019	O RING (D:1.9,ID:21.8)	2	
7-1	55321-87J01	ANODE, PROTECTION	2	
7-2	55321-87J11	ANODE (MAGNESIUM)	1	OPT
8	09103-06281	BOLT (6X14)	2	
9	01550-08207	BOLT	2	
10	11119-87J00	BOLT, CYLINDER HEAD (10X95)	8	
11	11141-88L00	GASKET, CYLINDER HEAD	1	
12	01550-08457	BOLT	4	
13	04211-13189	PIN	2	
14	11382-93J00	CAP, OIL FILLER	1	
15	09280-26006	O RING (D:3.1,ID:26.4)	1	
16	11170-88L10	COVER, CYLINDER HEAD	1	
17	11189-88L00	GASKET, CYLINDER HEAD COVER	1	
18	01547-06257	BOLT	9	
19	01547-06457	BOLT	3	
20	11173-88L00	PLATE, BREATHER	1	
21	02142-0612A	SCREW	4	
22	11174-88L00	HOSE, BREATHER	1	
23	09401-15414	CLIP	2	
24	09403-17303	CLAMP	2	
25	01550-06127	BOLT	2	
26	11194-88L10	GUARD, FUEL HOSE	1	
27	01550-06167	BOLT	2	
28	09482-00446	SPARK PLUG (DCPR6E)	3	NGK
29	11115-73G01-001	GUIDE, VALVE (OS)	4	OPT

DF60A_E03_017_111B
CYLINDER HEAD

FIG.111C




FIG.111C (1-B-4) CYLINDER HEAD (DF60A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11100-88L10	HEAD ASSY, CYLINDER	1	
2	11115-73G01-001	.GUIDE, VALVE	12	
3	09103-06266	.BOLT (6X40)	17	
4	09206-08001	.PIN (8X11)	14	
5	11261-93J00	COVER, PROTECTION ANODE	2	
6	09280-22019	O RING (D:1.9,ID:21.8)	2	
7-1	55321-87J01	ANODE, PROTECTION	2	
7-2	55321-87J11	ANODE (MAGNESIUM)	1	OPT
8	09103-06281	BOLT (6X14)	2	
9	01550-08207	BOLT	2	
10	11119-87J00	BOLT, CYLINDER HEAD (10X95)	8	
11	11141-88L00	GASKET, CYLINDER HEAD	1	
12	01550-08457	BOLT	4	
13	04211-13189	PIN	2	
14	11382-93J00	CAP, OIL FILLER	1	
15	09280-26006	O RING (D:3.1,ID:26.4)	1	
16	11170-88L10	COVER, CYLINDER HEAD	1	
17	11189-88L00	GASKET, CYLINDER HEAD COVER	1	
18	01547-06257	BOLT	9	
19	01547-06457	BOLT	3	
20	11173-88L00	PLATE, BREATHER	1	
21	02142-0612A	SCREW	4	
22	11174-88L00	HOSE, BREATHER	1	
23	09401-15414	CLIP	1	
24	09403-17303	CLAMP	2	
25	01550-06127	BOLT	2	
26	11194-88L10	GUARD, FUEL HOSE	1	
27	01550-06167	BOLT	2	
28	09482-00446	SPARK PLUG (DCPR6E)	3	NGK
29	11115-73G01-001	GUIDE, VALVE (OS)	4	OPT

DF60A_E03_017_111C
CYLINDER HEAD

FIG.111D




FIG.111D (1-B-5) CYLINDER HEAD (DF50AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11100-88L10	HEAD ASSY, CYLINDER	1	
2	11115-73G01-001	.GUIDE, VALVE	12	
3	09103-06266	.BOLT (6X40)	17	
4	09206-08001	.PIN (8X11)	14	
5	11261-93J00	COVER, PROTECTION ANODE	2	
6	09280-22019	O RING (D:1.9,ID:21.8)	2	
7-1	55321-87J01	ANODE, PROTECTION	2	
7-2	55321-87J11	ANODE (MAGNESIUM)	1	OPT
8	09103-06281	BOLT (6X14)	2	
9	01550-08207	BOLT	2	
10	11119-87J00	BOLT, CYLINDER HEAD (10X95)	8	
11	11141-88L00	GASKET, CYLINDER HEAD	1	
12	01550-08457	BOLT	4	
13	04211-13189	PIN	2	
14	11382-93J00	CAP, OIL FILLER	1	
15	09280-26006	O RING (D:3.1,ID:26.4)	1	
16	11170-88L10	COVER, CYLINDER HEAD	1	
17	11189-88L00	GASKET, CYLINDER HEAD COVER	1	
18	01547-06257	BOLT	9	
19	01547-06457	BOLT	3	
20	11173-88L00	PLATE, BREATHER	1	
21	02142-0612A	SCREW	4	
22	11174-88L00	HOSE, BREATHER	1	
23	09401-15414	CLIP	2	
24	09403-17303	CLAMP	2	
25	01550-06127	BOLT	2	
26	11194-88L10	GUARD, FUEL HOSE	1	
27	01550-06167	BOLT	2	
28	09482-00446	SPARK PLUG (DCPR6E)	3	NGK
29	11115-73G01-001	GUIDE, VALVE (OS)	4	OPT

DF60A_E03_017_111D
CYLINDER HEAD

FIG.111E




FIG.111E (1-B-6) CYLINDER HEAD (DF60AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11100-88L10	HEAD ASSY, CYLINDER	1	
2	11115-73G01-001	.GUIDE, VALVE	12	
3	09103-06266	.BOLT (6X40)	17	
4	09206-08001	.PIN (8X11)	14	
5	11261-93J00	COVER, PROTECTION ANODE	2	
6	09280-22019	O RING (D:1.9,ID:21.8)	2	
7-1	55321-87J01	ANODE, PROTECTION	2	
7-2	55321-87J11	ANODE (MAGNESIUM)	1	OPT
8	09103-06281	BOLT (6X14)	2	
9	01550-08207	BOLT	2	
10	11119-87J00	BOLT, CYLINDER HEAD (10X95)	8	
11	11141-88L00	GASKET, CYLINDER HEAD	1	
12	01550-08457	BOLT	4	
13	04211-13189	PIN	2	
14	11382-93J00	CAP, OIL FILLER	1	
15	09280-26006	O RING (D:3.1,ID:26.4)	1	
16	11170-88L10	COVER, CYLINDER HEAD	1	
17	11189-88L00	GASKET, CYLINDER HEAD COVER	1	
18	01547-06257	BOLT	9	
19	01547-06457	BOLT	3	
20	11173-88L00	PLATE, BREATHER	1	
21	02142-0612A	SCREW	4	
22	11174-88L00	HOSE, BREATHER	1	
23	09401-15414	CLIP	1	
24	09403-17303	CLAMP	2	
25	01550-06127	BOLT	2	
26	11194-88L10	GUARD, FUEL HOSE	1	
27	01550-06167	BOLT	2	
28	09482-00446	SPARK PLUG (DCPR6E)	3	NGK
29	11115-73G01-001	GUIDE, VALVE (OS)	4	OPT

DF60A_E03_017_111E
CYLINDER HEAD

FIG.113A




FIG.113A (1-B-7) CYLINDER BLOCK

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11291-88L00	HOOK, ENGINE	1	
2	01550-08207	BOLT	2	
3	11301-88L10	BLOCK ASSY, CYLINDER	1	
4	11117-89J20	.BOLT, CRANKCASE INSIDE	8	
5	09206-13019	.PIN (10.4X13X16)	4	
6	01550-08407	.BOLT	8	
7	11112-88L00	.PLUG, OIL VENTURI	1	
8	55321-87J01	ANODE, PROTECTION	1	
9	09103-06281	BOLT (6X14)	1	

FIG.116A




FIG.116A (1-B-8) CRANKSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12111-88L00	PISTON	3	
2	12140-88L00	RING SET, PISTON	3	
3	12151-54A50	PIN, PISTON	3	
4	09381-18002	SNAP RING	6	
5	12160-88L01	CONNROD ASSY	3	
6	12163-69J00	.BOLT, CONNROD	6	
7	04221-04089	.PIN	6	
8-1	12100-51810-0A0	BEARING SET, CONNROD (GREEN)	3	
8-2	12100-51810-0B0	BEARING SET, CONNROD (BLACK)	3	
8-3	12100-51810-0C0	BEARING SET, CONNROD (NON)	3	
8-4	12100-51810-0D0	BEARING SET, CONNROD (YELLOW)	3	
8-5	12100-51810-0E0	BEARING SET, CONNROD (BLUE)	3	
9	12220-88L00	CRANKSHAFT	1	
10-1	12340-75FA0-0A0	BEARING SET, CRANKSHAFT	4	GREEN
10-2	12340-75FA0-0B0	BEARING SET, CRANKSHAFT	4	BLACK
10-3	12340-75F00-0C0	BEARING SET, CRANKSHAFT	4	NON
10-4	12340-75F00-0D0	BEARING SET, CRANKSHAFT	4	YELLOW
10-5	12340-75F00-0E0	BEARING SET, CRANKSHAFT	4	BLUE
11	09283-37005	OIL SEAL (37X49X6)	1	
12	12281-87J00	SEAL, LOWER OIL (29.3X44X7)	1	
13	12100-88L00-050	PISTON SET (OS:0.50)	3	OPT
14	12140-88L00-050	.RING SET, PISTON (OS:0.50)	3	OPT

FIG.119A




FIG.119A (1-B-9) TIMING CHAIN

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12761-88L00	CHAIN, TIMING	1	
2	12771-87J00	GUIDE, TIMING CHAIN NO.1	1	
3	12776-85FA0	BOLT, TIMING CHAIN GUIDE	2	
4	12811-88L00	TENSIONER, TIMING CHAIN	1	
5	09100-08260	BOLT (8X30)	1	
6	09160-08123	WASHER (8.5X20X1.2)	1	
7	12812-73G10	SPACER, TIMING CHAIN TENSIONER	1	
8	12813-73G00	PAD, TIMING CHAIN TENSIONER	1	
9	12831-90J02	ADJUSTER ASSY, TENSIONER	1	
10	01550-0620A	BOLT	2	
11	12821-88L00	LINK, TIMING CHAIN TENSIONER	1	
12	01550-0612A	BOLT	2	

FIG.121A




FIG.121A (1-B-10) CAMSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY		REMARKS
1	12710-88L00	CAMSHAFT, INTAKE	1		
2	12720-88L00	CAMSHAFT, EXHAUST (NT:34)	1		
3	12741-88L00	SPROCKET, CAMSHAFT TIMING (NT:34)	1		
4	09103-10189	BOLT (10X23)	1		
5	09160-10093	WASHER (10.5X24X2.3)	1		
6	04221-05109	PIN	1		
7	12891-73G01	TAPPET	12		
8-1	12892-73G01-218	SHIM, TAPPET (T:2.18)	AR	OPT	
8-2	12892-73G01-220	SHIM, TAPPET (T:2.20)	AR	OPT	
8-3	12892-73G01-222	SHIM, TAPPET (T:2.22)	AR	OPT	
8-4	12892-73G01-224	SHIM, TAPPET (T:2.24)	AR	OPT	
8-5	12892-73G01-226	SHIM, TAPPET (T:2.26)	AR	OPT	
8-6	12892-73G01-228	SHIM, TAPPET (T:2.28)	AR	OPT	
8-7	12892-73G01-230	SHIM, TAPPET (T:2.30)	AR		
8-8	12892-73G01-232	SHIM, TAPPET (T:2.32)	AR		
8-9	12892-73G01-234	SHIM, TAPPET (T:2.34)	AR		
8-10	12892-73G01-236	SHIM, TAPPET (T:2.36)	AR		
8-11	12892-73G01-238	SHIM, TAPPET (T:2.38)	AR		
8-12	12892-73G01-240	SHIM, TAPPET (T:2.40)	AR		
8-13	12892-73G01-242	SHIM, TAPPET (T:2.42)	AR		
8-14	12892-73G01-244	SHIM, TAPPET (T:2.44)	AR		
8-15	12892-73G01-246	SHIM, TAPPET (T:2.46)	AR		
8-16	12892-73G01-248	SHIM, TAPPET (T:2.48)	AR		
8-17	12892-73G01-250	SHIM, TAPPET (T:2.50)	AR		
8-18	12892-73G01-252	SHIM, TAPPET (T:2.52)	AR		
8-19	12892-73G01-254	SHIM, TAPPET (T:2.54)	AR		
8-20	12892-73G01-256	SHIM, TAPPET (T:2.56)	AR		
8-21	12892-73G01-258	SHIM, TAPPET (T:2.58)	AR		
8-22	12892-73G01-260	SHIM, TAPPET (T:2.60)	AR		
8-23	12892-73G01-262	SHIM, TAPPET (T:2.62)	AR		
8-24	12892-73G01-264	SHIM, TAPPET (T:2.64)	AR		
8-25	12892-73G01-266	SHIM, TAPPET (T:2.66)	AR		
8-26	12892-73G01-268	SHIM, TAPPET (T:2.68)	AR		

FIG.121A




FIG.121A (1-B-11) CAMSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
8-27	12892-73G01-270	SHIM, TAPPET (T:2.70)	AR	
8-28	12892-73G01-272	SHIM, TAPPET (T:2.72)	AR	
8-29	12892-73G01-274	SHIM, TAPPET (T:2.74)	AR	
8-30	12892-73G01-276	SHIM, TAPPET (T:2.76)	AR	
8-31	12892-73G01-278	SHIM, TAPPET (T:2.78)	AR	
8-32	12892-73G01-280	SHIM, TAPPET (T:2.80)	AR	
8-33	12892-73G01-282	SHIM, TAPPET (T:2.82)	AR	OPT
8-34	12892-73G01-284	SHIM, TAPPET (T:2.84)	AR	OPT
8-35	12892-73G01-286	SHIM, TAPPET (T:2.86)	AR	OPT
8-36	12892-73G01-288	SHIM, TAPPET (T:2.88)	AR	OPT
8-37	12892-73G01-290	SHIM, TAPPET (T:2.90)	AR	OPT
8-38	12892-73G01-292	SHIM, TAPPET (T:2.92)	AR	OPT
8-39	12892-73G01-294	SHIM, TAPPET (T:2.94)	AR	OPT
8-40	12892-73G01-296	SHIM, TAPPET (T:2.96)	AR	OPT
8-41	12892-73G01-298	SHIM, TAPPET (T:2.98)	AR	OPT
8-42	12892-73G01-300	SHIM, TAPPET (T:3.00)	AR	OPT
9	12911-88L00	VALVE, INTAKE	6	
10	12915-73G20	VALVE, EXHAUST	6	
11	12921-87J10	SPRING, VALVE	12	
12	12931-78G00	RETAINER, VALVE SPRING	12	
13	12932-24400	COTTER, VALVE	24	
14	12933-51E00	SEAT, VALVE SPRING	12	
15	09289-05012	OIL SEAL (5.5X11.5X9.3)	12	

FIG.124A




FIG.124A (1-B-12) INTAKE MANIFOLD/SILENCER/EXHAUST COVER (DF40A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13110-88L00	MANIFOLD, INTAKE	1	
2	13119-88L00	.GASKET, INTAKE MANIFOLD	3	
3	13125-88L00	.GASKET, THROTTLE BODY	1	
4	01421-08607	STUD BOLT	2	
5	01550-08307	BOLT	6	
6	01550-08407	BOLT	1	
7	08316-10087	NUT	2	
8	18137-88L01	VALVE, IAC	1	
9	02112-34167	SCREW	3	
10	13810-88L00	SILENCER	1	
11	13820-88L00	HOLDER, SILENCER	1	
12	01547-06167	BOLT	1	
13	14141-88L00	COVER, EXHAUST	1	
14	14151-88L00	GASKET, EXHAUST COVER	1	
15	01550-06207	BOLT	8	
16	09160-06094	WASHER (6.5X15X1.0)	1	

FIG.124B




FIG.124B (1-B-13) INTAKE MANIFOLD/SILENCER/EXHAUST COVER (DF50A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13110-88L00	MANIFOLD, INTAKE	1	
2	13119-88L00	.GASKET, INTAKE MANIFOLD	3	
3	13125-88L00	.GASKET, THROTTLE BODY	1	
4	01421-08607	STUD BOLT	2	
5	01550-08307	BOLT	6	
6	01550-08407	BOLT	1	
7	08316-10087	NUT	2	
8	18137-88L01	VALVE, IAC	1	
9	02112-34167	SCREW	3	
10	13810-88L00	SILENCER	1	
11	13820-88L10	HOLDER, SILENCER	1	
12	01547-06167	BOLT	1	
13	14141-88L00	COVER, EXHAUST	1	
14	14151-88L00	GASKET, EXHAUST COVER	1	
15	01550-06207	BOLT	8	
16	09160-06094	WASHER (6.5X15X1.0)	1	

FIG.124C




FIG.124C (1-B-14) INTAKE MANIFOLD/SILENCER/EXHAUST COVER (DF60A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13110-88L00	MANIFOLD, INTAKE	1	
2	13119-88L00	.GASKET, INTAKE MANIFOLD	3	
3	13125-88L00	.GASKET, THROTTLE BODY	1	
4	01421-08607	STUD BOLT	2	
5	01550-08307	BOLT	6	
6	01550-08407	BOLT	1	
7	08316-10087	NUT	2	
8	18137-88L01	VALVE, IAC	1	
9	02112-34167	SCREW	3	
10	13810-88L00	SILENCER	1	
11	13813-88L00	HOLDER, SILENCER	1	
12	01547-06167	BOLT	1	
13	14141-88L00	COVER, EXHAUST	1	
14	14151-88L00	GASKET, EXHAUST COVER	1	
15	01550-06207	BOLT	8	
16	09160-06094	WASHER (6.5X15X1.0)	1	

FIG.124D




FIG.124D (1-B-15) INTAKE MANIFOLD/SILENCER/EXHAUST COVER (DF50AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13110-88L00	MANIFOLD, INTAKE	1	
2	13119-88L00	.GASKET, INTAKE MANIFOLD	3	
3	13125-88L00	.GASKET, THROTTLE BODY	1	
4	01421-08607	STUD BOLT	2	
5	01550-08307	BOLT	6	
6	01550-08407	BOLT	1	
7	08316-10087	NUT	2	
8	18137-88L01	VALVE, IAC	1	
9	02112-34167	SCREW	3	
10	13810-88L00	SILENCER	1	
11	13820-88L10	HOLDER, SILENCER	1	
12	01547-06167	BOLT	1	
13	14141-88L00	COVER, EXHAUST	1	
14	14151-88L00	GASKET, EXHAUST COVER	1	
15	01550-06207	BOLT	8	
16	09160-06094	WASHER (6.5X15X1.0)	1	

FIG.124E




FIG.124E (1-C-2) INTAKE MANIFOLD/SILENCER/EXHAUST COVER (DF60AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13110-88L00	MANIFOLD, INTAKE	1	
2	13119-88L00	.GASKET, INTAKE MANIFOLD	3	
3	13125-88L00	.GASKET, THROTTLE BODY	1	
4	01421-08607	STUD BOLT	2	
5	01550-08307	BOLT	6	
6	01550-08407	BOLT	1	
7	08316-10087	NUT	2	
8	18137-88L01	VALVE, IAC	1	
9	02112-34167	SCREW	3	
10	13810-88L00	SILENCER	1	
11	13813-88L00	HOLDER, SILENCER	1	
12	01547-06167	BOLT	1	
13	14141-88L00	COVER, EXHAUST	1	
14	14151-88L00	GASKET, EXHAUST COVER	1	
15	01550-06207	BOLT	8	
16	09160-06094	WASHER (6.5X15X1.0)	1	

FIG.136A




FIG.136A (1-C-3) RING GEAR COVER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11510-88L00	COVER, RING GEAR	1	
2	01550-06307	BOLT	3	
3	09320-09501	CUSHION	1	
4	03542-06209	SCREW	3	
5	11514-88L00	PLATE, RING GEAR COVER	1	
6	11411-88L00	HOUSING, UPPER OIL SEAL	1	
7	11413-88L00	GASKET, UPPER OIL SEAL	1	
8	01550-06257	BOLT	5	
9	04221-04089	PIN	2	
10	61472-88L00	LABEL, MAG COVER	1	
11	69711-93E10	LABEL (S.I.G.P.)	1	
12	61494-88L01	LABEL, OIL & CLEARANCE	1	

DF60A_E03_017_136A
RING GEAR COVER

FIG.143A




FIG.143A (1-C-4) FUEL VAPOR SEPARATOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15600-88L03	SEPARATOR ASSY, FUEL VAPOR	1	
2	13370-88L00	.VALVE ASSY, NEEDLE	1	
3	15200-88L00	.PUMP ASSY, FUEL	1	
4	15626-88L00	.SEAL	1	
5	15628-99E00	.SCREW (L:15)	5	
6	15629-99E10	.SCREW, DRAIN	1	
7	15641-88L00	.SPACER	1	
8	15642-88L00	.FILTER ASSY	1	
9	15650-99E00	.FLOAT	1	
10	15654-88L00	.PIN	1	
11	15683-87J00	.HOSE, DRAIN (L:120)	1	
12	15760-88L00	.REGULATOR ASSY	1	
13	15644-88L00	.O RING	1	
14	15645-88L00	.HOLDER, REGULATOR	1	
15	02112-0408A	.SCREW	1	
16	02142-0408B	.SCREW	1	
17	15643-88L00	.JOINT	1	
18	15641-88L31	.BUSH	1	
19	15641-88L51	.BUSH	1	
20	15642-88L10	.FILTER	1	
21	15612-88L00	.COVER	1	
22	15613-88L00	.O RING	1	
23	15613-92J00	.GASKET	1	
24	15614-88L00	.SCREW	3	
25	01550-06307	BOLT	3	
26	09169-06075	WASHER	3	
27	09160-06084	WASHER (6.5X18X1.6)	3	
28	09320-09039	CUSHION	3	
29	09352-50003-770	HOSE (5X8.2X770)	1	
30	09401-08412	CLIP	1	
31	18498-88L10	PROTECTOR, EVAP HOSE (L:730)	1	
32	09320-08076	GROMMET	1	
33	09408-00043	CLAMP	1	
34	09408-00121	CLAMP	1	
35	09408-00145	CLIP	1	
36	55127-87D00	PLUG, EVAPORATION HOSE	1	

DF60A_E03_017_143A
FUEL VAPOR SEPARATOR

FIG.144A




FIG.144A (1-C-5) FUEL INJECTOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15710-85K00	INJECTOR ASSY, FUEL	3	
2	15716-65DT0	.GROMMET SET	3	
3	09320-08062	CUSHION	3	
4	15750-88L10	PIPE, DELIVERY	1	
5	07120-06357	BOLT	2	
6	09180-06198	SPACER (6.2X12X16)	2	
7	15681-88L10	HOSE (SEPARATOR TO DLVY)	1	
8	09401-11425	CLIP	2	
9	09408-00174	CLAMP	1	

FIG.146A




FIG.146A (1-C-6) FUEL PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15100-90J11	PUMP ASSY, FUEL	1	
2	01550-06257	BOLT	2	
3	09280-26005	O RING (D:2.4,ID:26.2)	1	
4	15410-88L00	FILTER, FUEL	1	
5	15419-87J00	.CAP, FUEL FILTER	1	
6	09401-11423	.CLIP	1	
7	15422-96J00	CLAMP, FILTER	1	
8	15421-88L00	BRACKET, FUEL FILTER	1	
9	01550-06167	BOLT	2	
10	15191-88L20	HOSE, FUEL (JOINT TO FILTER))	1	
11	15192-88L20	HOSE, FUEL (PUMP TO SEPARATOR)	1	
12	09343-70503-080	HOSE (7X12X80)	1	
13	18498-99E10	PROTECTOR, FUEL HOSE NO.1	1	L:610->230
14	18498-96J20	PROTECTOR, FUEL HOSE NO.2	1	L:370->95
15	15197-88L00	BRACKET, FUEL HOSE CLAMP	1	
16	01550-06127	BOLT	1	
17	09403-11320	CLAMP	3	
18	09401-11423	CLIP	5	
19	09408-00145	CLIP	1	

FIG.160A




FIG.160A (1-C-7) WATER PUMP (DF40A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-88L00	CASE, WATER PUMP	1	
2	17413-95J00	SLEEVE, WATER PUMP CASE	1	
3	17416-95J00	SEALING, WATER PUMP CASE	1	
4	17564-88L00	BUSH, WATER PUMP CASE	1	
5	29141-93J00	NUT	4	
6	29162-93J00	WASHER, LOCK	4	
7	09108-06143	STUD BOLT	2	
8	09108-06144	STUD BOLT	2	
9	17461-96312	IMPELLER, WATER PUMP	1	
10	17471-95J01	PANEL, PUMP CASE UNDER	1	
11	17472-96303	GASKET, PUMP CASE UNDER	1	
12	17560-88L10	TUBE, WATER (L)	1	
13	17562-87L00	GROMMET, WATER TUBE UPPER	1	
14	17562-87L00	GROMMET, WATER TUBE LOWER	1	
15	09116-06236	BOLT (6X16)	1	
16	17631-96320	FILTER, WATER	2	
17	03142-04309	SCREW	2	
18-1	17635-87E00	FILTER, SUB WATER	1	
18-2	17635-87E10	PLATE, GEAR CASE	1	OPT
19	09125-05046	SCREW (5X12)	2	
20	09420-04006	KEY	1	
21	17400-88L00	WATER PUMP REPAIR KIT	1	OPT

FIG.160B




FIG.160B (1-C-8) WATER PUMP (DF50A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-88L00	CASE, WATER PUMP	1	
2	17413-95J00	SLEEVE, WATER PUMP CASE	1	
3	17416-95J00	SEALING, WATER PUMP CASE	1	
4	17564-88L00	BUSH, WATER PUMP CASE	1	
5	29141-93J00	NUT	4	
6	29162-93J00	WASHER, LOCK	4	
7	09108-06143	STUD BOLT	2	
8	09108-06144	STUD BOLT	2	
9	17461-96312	IMPELLER, WATER PUMP	1	
10	17471-95J01	PANEL, PUMP CASE UNDER	1	
11	17472-96303	GASKET, PUMP CASE UNDER	1	
12	17560-88L10	TUBE, WATER (L)	1	
13	17562-87L00	GROMMET, WATER TUBE UPPER	1	
14	17562-87L00	GROMMET, WATER TUBE LOWER	1	
15	09116-06236	BOLT (6X16)	1	
16	17631-96320	FILTER, WATER	2	
17	03142-04309	SCREW	2	
18-1	17635-87E00	FILTER, SUB WATER	1	
18-2	17635-87E10	PLATE, GEAR CASE	1	OPT
19	09125-05046	SCREW (5X12)	2	
20	09420-04006	KEY	1	
21	17400-88L00	WATER PUMP REPAIR KIT	1	OPT

FIG.160C




FIG.160C (1-C-9) WATER PUMP (DF60A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-88L00	CASE, WATER PUMP	1	
2	17413-95J00	SLEEVE, WATER PUMP CASE	1	
3	17416-95J00	SEALING, WATER PUMP CASE	1	
4	17564-88L00	BUSH, WATER PUMP CASE	1	
5	29141-93J00	NUT	4	
6	29162-93J00	WASHER, LOCK	4	
7	09108-06143	STUD BOLT	2	
8	09108-06144	STUD BOLT	2	
9	17461-96312	IMPELLER, WATER PUMP	1	
10	17471-95J01	PANEL, PUMP CASE UNDER	1	
11	17472-96303	GASKET, PUMP CASE UNDER	1	
12	17560-88L10	TUBE, WATER (L)	1	
13	17562-87L00	GROMMET, WATER TUBE UPPER	1	
14	17562-87L00	GROMMET, WATER TUBE LOWER	1	
15	09116-06236	BOLT (6X16)	1	
16	17631-96320	FILTER, WATER	2	
17	03142-04309	SCREW	2	
18-1	17635-87E00	FILTER, SUB WATER	1	
18-2	17635-87E10	PLATE, GEAR CASE	1	OPT
19	09125-05046	SCREW (5X12)	2	
20	09420-04006	KEY	1	
21	17400-88L00	WATER PUMP REPAIR KIT	1	OPT

FIG.160D




FIG.160D (1-C-10) WATER PUMP (DF50AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-99E10	CASE, WATER PUMP	1	
2	17461-87E12	IMPELLER, WATER PUMP	1	
3	17471-99E00	PANEL, PUMP CASE UNDER	1	
4	17472-87E10	GASKET, PUMP CASE PANEL	1	
5	17560-88L30	TUBE, WATER (L)	1	
6	17562-87L00	BUSH, WATER TUBE UPPER	1	
7	17562-87L00	BUSH, WATER TUBE LOWER	1	
8	17564-87D00	BUSH, WATER PUMP CASE	1	
9	17631-90J00	FILTER, WATER PORT SIDE	1	
10	17632-90J00	FILTER, WATER STBD SIDE	1	
11	17635-90J00	PLUG, SUB WATER TUBE	1	
12	29116-93J10	BOLT	4	
13	09125-05046	SCREW (5X12)	2	
14	09116-06236	BOLT (6X16)	1	
15	09202-06031	PIN (6X12)	2	
16	09420-04009	KEY	1	
17	09132-04034	SCREW (4X18)	2	
18	17413-99E11	SLEEVE, WATER PUMP CASE	1	
19	17416-99E10	SEALING, WATER PUMP CASE	1	
20	17400-99E10	KIT, WATER PUMP REPAIR	1	OPT
21	17635-87E10	PLATE, GEAR CASE	1	OPT
22	55321-87J11	ANODE (MAGNESIUM)	1	OPT

DF60A_E03_017_160D
WATER PUMP

FIG.160E




FIG.160E (1-C-11) WATER PUMP (DF60AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-99E10	CASE, WATER PUMP	1	
2	17461-87E12	IMPELLER, WATER PUMP	1	
3	17471-99E00	PANEL, PUMP CASE UNDER	1	
4	17472-87E10	GASKET, PUMP CASE PANEL	1	
5	17560-88L30	TUBE, WATER (L)	1	
6	17562-87L00	BUSH, WATER TUBE UPPER	1	
7	17562-87L00	BUSH, WATER TUBE LOWER	1	
8	17564-87D00	BUSH, WATER PUMP CASE	1	
9	17631-90J00	FILTER, WATER PORT SIDE	1	
10	17632-90J00	FILTER, WATER STBD SIDE	1	
11	17635-90J00	PLUG, SUB WATER TUBE	1	
12	29116-93J10	BOLT	4	
13	09125-05046	SCREW (5X12)	2	
14	09116-06236	BOLT (6X16)	1	
15	09202-06031	PIN (6X12)	2	
16	09420-04009	KEY	1	
17	09132-04034	SCREW (4X18)	2	
18	17413-99E11	SLEEVE, WATER PUMP CASE	1	
19	17416-99E10	SEALING, WATER PUMP CASE	1	
20	17400-99E10	KIT, WATER PUMP REPAIR	1	OPT
21	17635-87E10	PLATE, GEAR CASE	1	OPT
22	55321-87J11	ANODE (MAGNESIUM)	1	OPT

DF60A_E03_017_160E
WATER PUMP

FIG.162A




FIG.162A (1-C-12) THERMOSTAT (DF40A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	17611-90J00-YAY	COVER, WATER PRESS VALVE (BLACK)	1	
1-2	17611-90J00-Y5S	COVER, WATER PRESS VALVE (WHITE)	1	
2	17660-99E01	VALVE, WATER PRESSURE	1	
3	09116-06121	BOLT (6X25)	2	
4	09280-26006	O RING (D:3.1,ID:26.4)	1	
5	17670-93953	THERMOSTAT (60C)	1	
6	17681-88L00	COVER, THERMOSTAT	1	
7	01550-06207	BOLT	2	
8	11196-88L00	HOSE, WATER RETURN	1	
9	09401-25406	CLIP	2	
10	18498-94J20	PROTECTOR, WATER HOSE	2	L:320->50
11	17712-88L00	HOSE (SEPARATOR TO INSP)	1	
12	09352-50903-600	HOSE (5X9X600)	1	L:600->500
13	09359-50901-980	HOSE	1	L:980->250
14	09401-08413	CLIP	4	
15	09401-10415	CLIP	1	
16	09408-00175	CLAMP	1	

DF60A_E03_017_162A
THERMOSTAT

FIG.162B




FIG.162B (1-C-13) THERMOSTAT (DF50A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	17611-90J00-YAY	COVER, WATER PRESS VALVE (BLACK)	1	
1-2	17611-90J00-Y5S	COVER, WATER PRESS VALVE (WHITE)	1	
2	17660-99E01	VALVE, WATER PRESSURE	1	
3	09116-06121	BOLT (6X25)	2	
4	09280-26006	O RING (D:3.1,ID:26.4)	1	
5	17670-93953	THERMOSTAT (60C)	1	
6	17681-88L00	COVER, THERMOSTAT	1	
7	01550-06207	BOLT	2	
8	11196-88L00	HOSE, WATER RETURN	1	
9	09401-25406	CLIP	2	
10	18498-94J20	PROTECTOR, WATER HOSE	2	L:320->50
11	17712-88L00	HOSE (SEPARATOR TO INSP)	1	
12	09352-50903-600	HOSE (5X9X600)	1	L:600->500
13	09359-50901-980	HOSE	1	L:980->250
14	09401-08413	CLIP	4	
15	09401-10415	CLIP	1	
16	09408-00175	CLAMP	1	

DF60A_E03_017_162B
THERMOSTAT

FIG.162C




FIG.162C (1-C-14) THERMOSTAT (DF60A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	17611-90J00-YAY	COVER, WATER PRESS VALVE (BLACK)	1	
1-2	17611-90J00-Y5S	COVER, WATER PRESS VALVE (WHITE)	1	
2	17660-99E01	VALVE, WATER PRESSURE	1	
3	09116-06121	BOLT (6X25)	2	
4	09280-26006	O RING (D:3.1,ID:26.4)	1	
5	17670-93953	THERMOSTAT (60C)	1	
6	17681-88L00	COVER, THERMOSTAT	1	
7	01550-06207	BOLT	2	
8	11196-88L00	HOSE, WATER RETURN	1	
9	09401-25406	CLIP	2	
10	18498-94J20	PROTECTOR, WATER HOSE	2	L:320->50
11	17712-88L00	HOSE (SEPARATOR TO INSP)	1	
12	09352-50903-600	HOSE (5X9X600)	1	L:600->500
13	09359-50901-980	HOSE	1	L:980->250
14	09401-08413	CLIP	4	
15	09401-10415	CLIP	1	
16	09408-00175	CLAMP	1	

DF60A_E03_017_162C
THERMOSTAT

FIG.162D




FIG.162D (1-C-15) THERMOSTAT (DF50AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17611-90J00-YAY	COVER, WATER PRESS VALVE (BLACK)	1	
2	17660-99E01	VALVE, WATER PRESSURE	1	
3	09116-06121	BOLT (6X25)	2	
4	09280-26006	O RING (D:3.1,ID:26.4)	1	
5	17670-93953	THERMOSTAT (60C)	1	
6	17681-88L00	COVER, THERMOSTAT	1	
7	01550-06207	BOLT	2	
8	11196-88L00	HOSE, WATER RETURN	1	
9	09401-25406	CLIP	2	
10	18498-94J20	PROTECTOR, WATER HOSE	2	L:320->50
11	17712-88L00	HOSE (SEPARATOR TO INSP)	1	
12	09352-50903-600	HOSE (5X9X600)	1	L:600->500
13	09359-50901-980	HOSE	1	L:980->250
14	09401-08413	CLIP	4	
15	09401-10415	CLIP	1	
16	09408-00175	CLAMP	1	

FIG.162E




FIG.162E (1-D-2) THERMOSTAT (DF60AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17611-90J00-YAY	COVER, WATER PRESS VALVE (BLACK)	1	
2	17660-99E01	VALVE, WATER PRESSURE	1	
3	09116-06121	BOLT (6X25)	2	
4	09280-26006	O RING (D:3.1,ID:26.4)	1	
5	17670-93953	THERMOSTAT (60C)	1	
6	17681-88L00	COVER, THERMOSTAT	1	
7	01550-06207	BOLT	2	
8	11196-88L00	HOSE, WATER RETURN	1	
9	09401-25406	CLIP	2	
10	18498-94J20	PROTECTOR, WATER HOSE	2	L:320->50
11	17712-88L00	HOSE (SEPARATOR TO INSP)	1	
12	09352-50903-600	HOSE (5X9X600)	1	L:600->500
13	09359-50901-980	HOSE	1	L:980->250
14	09401-08413	CLIP	4	
15	09401-10415	CLIP	1	
16	09408-00175	CLAMP	1	

FIG.163A




FIG.163A (1-D-3) THROTTLE BODY

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-88L01	BODY ASSY, THROTTLE	1	
2	13315-88L00	BRACKET, THROTTLE BODY	1	
3	01550-06457	BOLT	4	
4	01550-06167	BOLT	2	
5	01550-08207	BOLT	1	
6	13510-88L00	ROD, THROTTLE	1	
7	19120-88L01	LEVER, THROTTLE	1	
8	19131-95502	CONNECTOR, THROTTLE ROD	1	
9	09140-05005	NUT	1	
10	09160-06047	WASHER (6.5X20X2)	1	
11	01550-06407	BOLT	1	

FIG.175A




FIG.175A (1-D-4) OIL PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11433-88L00	GASKET, UNDER OIL SEAL	1	
2	16400-88L00	PUMP ASSY, OIL	1	
3	01547-0640A	BOLT	7	
4	04211-09109	PIN	2	
5	16520-88L00	STRAINER, OIL PUMP	1	
6	09280-12008	O RING (D:2.4,ID:12.3)	2	
7	01570-0616A	BOLT	2	
8	16519-87L00	SEAL, ENGINE HOLDER	1	
9	16510-87J00	FILTER ASSY, OIL	1	

FIG.180A




FIG.180A (1-D-5) OIL PAN (DF40A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11489-88L01	GASKET, OIL PAN	1	
2-1	11501-88L01-YAY	PAN, OIL (BLACK)	1	
2-2	11501-88L01-Y5S	PAN, OIL (WHITE)	1	
3	09116-08128	BOLT (8X40)	6	
4	09168-12012	GASKET (12.5X20X2.5)	1	
5	09248-12009	PLUG (12X18.65)	1	OIL DRAIN
6-1	11551-88L00-YAY	COVER, WATER JACKET OIL PAN (BLACK)	1	
6-2	11551-88L00-Y5S	COVER, WATER JACKET OIL PAN (WHITE)	1	
7	11552-88L00	GASKET, OIL PAN WTR JKT COV	1	
8	09116-06121	BOLT (6X25)	4	
9	17913-93J00	PLUG, WATER	1	
10	17914-93J00	GASKET, WATER PLUG	1	
11	11543-88L00	SILENCER, EXHAUST	1	
12	43112-99E00	PIPE, EXHAUST	1	
13	09116-10124	BOLT (10X150)	6	
14	16910-88L00	GAUGE, OIL LEVEL	1	
15	16930-88L00	GUIDE, OIL LEVEL GAUGE	1	
16	09280-09008	O RING (D:2.1,ID:8.8)	1	
17	01550-06127	BOLT	1	

FIG.180B




FIG.180B (1-D-6) OIL PAN (DF50A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11489-88L01	GASKET, OIL PAN	1	
2-1	11501-88L01-YAY	PAN, OIL (BLACK)	1	
2-2	11501-88L01-Y5S	PAN, OIL (WHITE)	1	
3	09116-08128	BOLT (8X40)	6	
4	09168-12012	GASKET (12.5X20X2.5)	1	
5	09248-12009	PLUG (12X18.65)	1	OIL DRAIN
6-1	11551-88L00-YAY	COVER, WATER JACKET OIL PAN (BLACK)	1	
6-2	11551-88L00-Y5S	COVER, WATER JACKET OIL PAN (WHITE)	1	
7	11552-88L00	GASKET, OIL PAN WTR JKT COV	1	
8	09116-06121	BOLT (6X25)	4	
9	17913-93J00	PLUG, WATER	1	
10	17914-93J00	GASKET, WATER PLUG	1	
11	11543-88L00	SILENCER, EXHAUST	1	
12	43112-99E00	PIPE, EXHAUST	1	
13	09116-10124	BOLT (10X150)	6	
14	16910-88L00	GAUGE, OIL LEVEL	1	
15	16930-88L00	GUIDE, OIL LEVEL GAUGE	1	
16	09280-09008	O RING (D:2.1,ID:8.8)	1	
17	01550-06127	BOLT	1	

FIG.180C




FIG.180C (1-D-7) OIL PAN (DF60A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11489-88L01	GASKET, OIL PAN	1	
2-1	11501-88L01-YAY	PAN, OIL (BLACK)	1	
2-2	11501-88L01-Y5S	PAN, OIL (WHITE)	1	
3	09116-08128	BOLT (8X40)	6	
4	09168-12012	GASKET (12.5X20X2.5)	1	
5	09248-12009	PLUG (12X18.65)	1	OIL DRAIN
6-1	11551-88L00-YAY	COVER, WATER JACKET OIL PAN (BLACK)	1	
6-2	11551-88L00-Y5S	COVER, WATER JACKET OIL PAN (WHITE)	1	
7	11552-88L00	GASKET, OIL PAN WTR JKT COV	1	
8	09116-06121	BOLT (6X25)	4	
9	17913-93J00	PLUG, WATER	1	
10	17914-93J00	GASKET, WATER PLUG	1	
11	11543-88L00	SILENCER, EXHAUST	1	
12	43112-99E00	PIPE, EXHAUST	1	
13	09116-10124	BOLT (10X150)	6	
14	16910-88L00	GAUGE, OIL LEVEL	1	
15	16930-88L00	GUIDE, OIL LEVEL GAUGE	1	
16	09280-09008	O RING (D:2.1,ID:8.8)	1	
17	01550-06127	BOLT	1	

FIG.180D




FIG.180D (1-D-8) OIL PAN (DF50AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11489-88L01	GASKET, OIL PAN	1	
2	11501-88L01-YAY	PAN, OIL (BLACK)	1	
3	09116-08128	BOLT (8X40)	6	
4	09168-12012	GASKET (12.5X20X2.5)	1	
5	09248-12009	PLUG (12X18.65)	1	OIL DRAIN
6	11551-88L00-YAY	COVER, WATER JACKET OIL PAN (BLACK)	1	
7	11552-88L00	GASKET, OIL PAN WTR JKT COV	1	
8	09116-06121	BOLT (6X25)	4	
9	17913-93J00	PLUG, WATER	1	
10	17914-93J00	GASKET, WATER PLUG	1	
11	11543-88L00	SILENCER, EXHAUST	1	
12	43112-99E00	PIPE, EXHAUST	1	
13	09116-10124	BOLT (10X150)	6	
14	16910-88L00	GAUGE, OIL LEVEL	1	
15	16930-88L00	GUIDE, OIL LEVEL GAUGE	1	
16	09280-09008	O RING (D:2.1,ID:8.8)	1	
17	01550-06127	BOLT	1	

FIG.180E




FIG.180E (1-D-9) OIL PAN (DF60AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11489-88L01	GASKET, OIL PAN	1	
2	11501-88L01-YAY	PAN, OIL (BLACK)	1	
3	09116-08128	BOLT (8X40)	6	
4	09168-12012	GASKET (12.5X20X2.5)	1	
5	09248-12009	PLUG (12X18.65)	1	OIL DRAIN
6	11551-88L00-YAY	COVER, WATER JACKET OIL PAN (BLACK)	1	
7	11552-88L00	GASKET, OIL PAN WTR JKT COV	1	
8	09116-06121	BOLT (6X25)	4	
9	17913-93J00	PLUG, WATER	1	
10	17914-93J00	GASKET, WATER PLUG	1	
11	11543-88L00	SILENCER, EXHAUST	1	
12	43112-99E00	PIPE, EXHAUST	1	
13	09116-10124	BOLT (10X150)	6	
14	16910-88L00	GAUGE, OIL LEVEL	1	
15	16930-88L00	GUIDE, OIL LEVEL GAUGE	1	
16	09280-09008	O RING (D:2.1,ID:8.8)	1	
17	01550-06127	BOLT	1	

DF60A_E03_017_180E
OIL PAN

FIG.204A




FIG.204A (1-D-10) CLUTCH SHAFT (DF40A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21126-88L00	HOLDER, CLUTCH SHAFT	1	
2	21151-88L00	HOLDER, CLUTCH LEVER	1	
3	01550-06167	BOLT	2	
4	01550-06307	BOLT	2	
5	21210-88L00	SHAFT, CLUTCH	1	
6	23111-88L10	ROD, CLUTCH (L)	1	
7	29141-93J00	NUT, CLUTCH ROD	1	
8	23115-88L00	LINK, CLUTCH LEVER	1	
9	23210-88L00	LEVER, CLUTCH CONTROL	1	
10	09160-06055	WASHER (7X12X1)	2	
11	09385-06012	CLIP	2	
12	23213-89J01	SPRING, NOTCH PLATE NO.1	1	
13	23214-89J00	SPRING, NOTCH PLATE NO.2	1	
14	01550-06127	BOLT	1	
15	23311-95J00	TURNBUCKLE, CLUTCH ROD	1	
16	67341-88L01	HOLDER, REMOCON CABLE	1	
17	01550-06167	BOLT	2	
18	67343-88L01	STOPPER, REMOCON CABLE	1	
19	09352-70103-600	HOSE (7X10.2X600)	2	L:600->14
20	01570-06167	BOLT	1	
21	67467-89J01	CONNECTOR, REMOCON CABLE	2	
22	09160-06055	WASHER (7X12X1)	2	
23	09385-06012	CLIP	2	

FIG.204B




FIG.204B (1-D-11) CLUTCH SHAFT (DF50A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21126-88L00	HOLDER, CLUTCH SHAFT	1	
2	21151-88L00	HOLDER, CLUTCH LEVER	1	
3	01550-06167	BOLT	2	
4	01550-06307	BOLT	2	
5	21210-88L00	SHAFT, CLUTCH	1	
6	23111-88L10	ROD, CLUTCH (L)	1	
7	29141-93J00	NUT, CLUTCH ROD	1	
8	23115-88L00	LINK, CLUTCH LEVER	1	
9	23210-88L00	LEVER, CLUTCH CONTROL	1	
10	09160-06055	WASHER (7X12X1)	2	
11	09385-06012	CLIP	2	
12	23213-89J01	SPRING, NOTCH PLATE NO.1	1	
13	23214-89J00	SPRING, NOTCH PLATE NO.2	1	
14	01550-06127	BOLT	1	
15	23311-95J00	TURNBUCKLE, CLUTCH ROD	1	
16	67341-88L01	HOLDER, REMOCON CABLE	1	
17	01550-06167	BOLT	2	
18	67343-88L01	STOPPER, REMOCON CABLE	1	
19	09352-70103-600	HOSE (7X10.2X600)	2	L:600->14
20	01570-06167	BOLT	1	
21	67467-89J01	CONNECTOR, REMOCON CABLE	2	
22	09160-06055	WASHER (7X12X1)	2	
23	09385-06012	CLIP	2	

FIG.204C




FIG.204C (1-D-12) CLUTCH SHAFT (DF60A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21126-88L00	HOLDER, CLUTCH SHAFT	1	
2	21151-88L00	HOLDER, CLUTCH LEVER	1	
3	01550-06167	BOLT	2	
4	01550-06307	BOLT	2	
5	21210-88L00	SHAFT, CLUTCH	1	
6	23111-88L10	ROD, CLUTCH (L)	1	
7	29141-93J00	NUT, CLUTCH ROD	1	
8	23115-88L00	LINK, CLUTCH LEVER	1	
9	23210-88L00	LEVER, CLUTCH CONTROL	1	
10	09160-06055	WASHER (7X12X1)	2	
11	09385-06012	CLIP	2	
12	23213-89J01	SPRING, NOTCH PLATE NO.1	1	
13	23214-89J00	SPRING, NOTCH PLATE NO.2	1	
14	01550-06127	BOLT	1	
15	23311-95J00	TURNBUCKLE, CLUTCH ROD	1	
16	67341-88L01	HOLDER, REMOCON CABLE	1	
17	01550-06167	BOLT	2	
18	67343-88L01	STOPPER, REMOCON CABLE	1	
19	09352-70103-600	HOSE (7X10.2X600)	2	L:600->14
20	01570-06167	BOLT	1	
21	67467-89J01	CONNECTOR, REMOCON CABLE	2	
22	09160-06055	WASHER (7X12X1)	2	
23	09385-06012	CLIP	2	

FIG.204D




FIG.204D (1-D-13) CLUTCH SHAFT (DF50AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21126-88L00	HOLDER, CLUTCH SHAFT	1	
2	21151-88L00	HOLDER, CLUTCH LEVER	1	
3	01550-06167	BOLT	2	
4	01550-06307	BOLT	2	
5	21210-88L00	SHAFT, CLUTCH	1	
6	23111-88L00	ROD, CLUTCH (S)	1	
7	29141-93J00	NUT, CLUTCH ROD	1	
8	23115-88L00	LINK, CLUTCH LEVER	1	
9	23210-88L00	LEVER, CLUTCH CONTROL	1	
10	09160-06055	WASHER (7X12X1)	2	
11	09385-06012	CLIP	2	
12	23213-89J01	SPRING, NOTCH PLATE NO.1	1	
13	23214-89J00	SPRING, NOTCH PLATE NO.2	1	
14	01550-06127	BOLT	1	
15	23311-95J00	TURNBUCKLE, CLUTCH ROD	1	
16	67341-88L01	HOLDER, REMOCON CABLE	1	
17	01550-06167	BOLT	2	
18	67343-88L01	STOPPER, REMOCON CABLE	1	
19	09352-70103-600	HOSE (7X10.2X600)	2	L:600->14
20	01570-06167	BOLT	1	
21	67467-89J01	CONNECTOR, REMOCON CABLE	2	
22	09160-06055	WASHER (7X12X1)	2	
23	09385-06012	CLIP	2	

FIG.204E




FIG.204E (1-D-14) CLUTCH SHAFT (DF60AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21126-88L00	HOLDER, CLUTCH SHAFT	1	
2	21151-88L00	HOLDER, CLUTCH LEVER	1	
3	01550-06167	BOLT	2	
4	01550-06307	BOLT	2	
5	21210-88L00	SHAFT, CLUTCH	1	
6	23111-88L00	ROD, CLUTCH (S)	1	
7	29141-93J00	NUT, CLUTCH ROD	1	
8	23115-88L00	LINK, CLUTCH LEVER	1	
9	23210-88L00	LEVER, CLUTCH CONTROL	1	
10	09160-06055	WASHER (7X12X1)	2	
11	09385-06012	CLIP	2	
12	23213-89J01	SPRING, NOTCH PLATE NO.1	1	
13	23214-89J00	SPRING, NOTCH PLATE NO.2	1	
14	01550-06127	BOLT	1	
15	23311-95J00	TURNBUCKLE, CLUTCH ROD	1	
16	67341-88L01	HOLDER, REMOCON CABLE	1	
17	01550-06167	BOLT	2	
18	67343-88L01	STOPPER, REMOCON CABLE	1	
19	09352-70103-600	HOSE (7X10.2X600)	2	L:600->14
20	01570-06167	BOLT	1	
21	67467-89J01	CONNECTOR, REMOCON CABLE	2	
22	09160-06055	WASHER (7X12X1)	2	
23	09385-06012	CLIP	2	

FIG.206A




FIG.206A (1-D-15) CLUTCH ROD (DF40A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	25111-88L10	ROD, SHIFT (L)	1	
2	25211-87J00	GUIDE, SHIFT ROD	1	
3	09280-08005	O RING (D:1.7,ID:7.7)	1	
4	09280-11001	O RING (D:2.4,ID:10.8)	1	
5	25212-94401	GUIDE, SHIFT ROD LOWER	1	
6	09205-02013	SPRING PIN (2.5X16)	1	
7	09205-03021	SPRING PIN (3.5X12)	1	
8	09205-02004	SPRING PIN (2.5X12)	1	
9	25223-94400	SEAL, SHIFT ROD DUST	1	
10	25232-96302	MAGNET, GEAR CASE	1	
11	25311-88L00	CAM, SHIFT	1	
12	08331-3115A	CIRCLIP	1	
13	21121-93300	PLATE, DETENT SPRING	1	
14	09260-10005	BALL	1	
15	09440-07078	SPRING	1	

FIG.206B




FIG.206B (1-E-2) CLUTCH ROD (DF50A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	25111-88L10	ROD, SHIFT (L)	1	
2	25211-87J00	GUIDE, SHIFT ROD	1	
3	09280-08005	O RING (D:1.7,ID:7.7)	1	
4	09280-11001	O RING (D:2.4,ID:10.8)	1	
5	25212-94401	GUIDE, SHIFT ROD LOWER	1	
6	09205-02013	SPRING PIN (2.5X16)	1	
7	09205-03021	SPRING PIN (3.5X12)	1	
8	09205-02004	SPRING PIN (2.5X12)	1	
9	25223-94400	SEAL, SHIFT ROD DUST	1	
10	25232-96302	MAGNET, GEAR CASE	1	
11	25311-88L00	CAM, SHIFT	1	
12	08331-3115A	CIRCLIP	1	
13	21121-93300	PLATE, DETENT SPRING	1	
14	09260-10005	BALL	1	
15	09440-07078	SPRING	1	

DF60A_E03_017_206B
CLUTCH ROD

FIG.206C




FIG.206C (1-E-3) CLUTCH ROD (DF60A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	25111-88L10	ROD, SHIFT (L)	1	
2	25211-87J00	GUIDE, SHIFT ROD	1	
3	09280-08005	O RING (D:1.7,ID:7.7)	1	
4	09280-11001	O RING (D:2.4,ID:10.8)	1	
5	25212-94401	GUIDE, SHIFT ROD LOWER	1	
6	09205-02013	SPRING PIN (2.5X16)	1	
7	09205-03021	SPRING PIN (3.5X12)	1	
8	09205-02004	SPRING PIN (2.5X12)	1	
9	25223-94400	SEAL, SHIFT ROD DUST	1	
10	25232-96302	MAGNET, GEAR CASE	1	
11	25311-88L00	CAM, SHIFT	1	
12	08331-3115A	CIRCLIP	1	
13	21121-93300	PLATE, DETENT SPRING	1	
14	09260-10005	BALL	1	
15	09440-07078	SPRING	1	

DF60A_E03_017_206C
CLUTCH ROD

FIG.210A




FIG.210A (1-E-4) SHIFT ROD (DF50AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21121-93300	PLATE, CLUTCH NOTCH	1	
2	25111-88L30	ROD, SHIFT (L)	1	
3	25141-99E03	HOUSING, SHIFT ROD GUIDE	1	
4	25205-94501	COLLAR, SHIFT ROD SPRING	1	
5	25211-94501	GUIDE, SHIFT ROD	1	
6	25230-94300	MAGNET SET	1	
7	25311-94510	CAM, CLUTCH	1	
8	09117-06031	BOLT (6X20)	3	
9	09160-09015	WASHER (9X19X1.0)	1	
10	09160-09010	WASHER (9X30X1.6)	1	
11	09160-08122	WASHER (8.5X18X3.20)	1	
12	09205-02006	SPRING PIN (2X12)	2	
13	09205-03021	SPRING PIN (3.5X12)	2	
14	09260-10005	BALL	1	
15	09280-08008	O RING (D:3.5,ID:7.8)	2	
16	09280-15003	O RING (D:2.4,ID:14.8)	1	
17	09280-69001	O RING (D:3.1,ID:68.5)	1	
18	09284-08003	OIL SEAL (8X19X4.5)	1	
19	09440-07033	SPRING	1	
20	08331-41309	CIRCLIP	1	

FIG.210B




FIG.210B (1-E-5) SHIFT ROD (DF60AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21121-93300	PLATE, CLUTCH NOTCH	1	
2	25111-88L30	ROD, SHIFT (L)	1	
3	25141-99E03	HOUSING, SHIFT ROD GUIDE	1	
4	25205-94501	COLLAR, SHIFT ROD SPRING	1	
5	25211-94501	GUIDE, SHIFT ROD	1	
6	25230-94300	MAGNET SET	1	
7	25311-94510	CAM, CLUTCH	1	
8	09117-06031	BOLT (6X20)	3	
9	09160-09015	WASHER (9X19X1.0)	1	
10	09160-09010	WASHER (9X30X1.6)	1	
11	09160-08122	WASHER (8.5X18X3.20)	1	
12	09205-02006	SPRING PIN (2X12)	2	
13	09205-03021	SPRING PIN (3.5X12)	2	
14	09260-10005	BALL	1	
15	09280-08008	O RING (D:3.5,ID:7.8)	2	
16	09280-15003	O RING (D:2.4,ID:14.8)	1	
17	09280-69001	O RING (D:3.1,ID:68.5)	1	
18	09284-08003	OIL SEAL (8X19X4.5)	1	
19	09440-07033	SPRING	1	
20	08331-41309	CIRCLIP	1	

FIG.220A




FIG.220A (1-E-6) TRANSMISSION (DF40A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	57110-88L12	SHAFT ASSY, DRIVE (L)	1	
2	57133-88L01	COLLAR, DRIVE SHAFT	1	
3	57133-94400	HOUSING, DRIVE SHAFT SPRING	1	
4	09205-03019	SPRING PIN (3X10)	1	
5	09265-20015	BEARING (20X42X15)	1	
6	57300-88810	PINION/GEAR SET	1	
7	09140-12034	NUT	1	
8-1	09181-35101	SHIM (T:0.50)	AR	DRIVE SHAFT ADJUST
8-2	09181-33001	SHIM (T:0.55)	AR	
8-3	09181-33002	SHIM (T:0.60)	AR	
8-4	09181-33003	SHIM (T:0.65)	AR	
8-5	09181-33004	SHIM (T:0.70)	AR	
8-6	09181-33005	SHIM (T:0.75)	AR	
8-7	09181-33006	SHIM (T:0.80)	AR	
8-8	09181-33007	SHIM (T:0.85)	AR	
8-9	09181-33008	SHIM (T:0.90)	AR	
8-10	09181-33009	SHIM (T:0.95)	AR	
8-11	09181-35110	SHIM (T:1.00)	AR	
9-1	09181-30186	SHIM (T:0.50)	AR	FORWARD BACKUP
9-2	09181-30187	SHIM (T:0.60)	AR	
9-3	09181-30188	SHIM (T:0.70)	AR	
9-4	09181-30190	SHIM (T:0.80)	AR	
9-5	09181-30192	SHIM (T:0.90)	AR	
10-1	08221-35455	SHIM	AR	REVERSE BACKUP
10-2	09181-35131	SHIM (T:0.60)	AR	
10-3	09181-35132	SHIM (T:0.70)	AR	
10-4	08221-35456	SHIM	AR	
10-5	09181-35136	SHIM (T:0.90)	AR	
10-6	08211-35451	WASHER	AR	

FIG.220A




FIG.220A (1-E-7) TRANSMISSION (DF40A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
11-1	09160-22018	WASHER (22.2X28X1.8)	1	PROP SHAFT THRUST
11-2	09160-22019	WASHER (22.5X28X1.9)	1	
11-3	09160-22020	WASHER (22.5X28X2)	1	
11-4	09160-22021	WASHER (22.5X28X2.1)	1	
11-5	09160-22022	WASHER (22.5X28X2.2)	1	
11-6	09160-22023	WASHER (22.5X28X2.3)	1	
12	08211-20263	WASHER	1	
13	57610-94402	SHAFT, PROPELLER	1	
14	57621-87J03	SHIFTER, CLUTCH DOG	1	
15	09202-05022	PIN (5.5X38.5)	1	
16	57634-88L00	PIN, PUSH	1	
17	09440-08043	SPRING	1	
18	09440-40002	SPRING	1	
19	57631-95303	ROD, PUSH	1	
20-1	56120-94321-YAY	HOUSING, PROP SHAFT BEARING (BLACK)	1	
20-2	56120-94321-Y5S	HOUSING, PROP SHAFT BEARING (WHITE)	1	
21	09263-22020	.BEARING (22.2X28.5X19)	1	
22	09289-22007	.OIL SEAL (22X35X5)	2	
23	09262-35070	.BEARING (35X62X14)	1	
24	09280-75001	O RING (D:3.3,ID:75)	1	
25	09116-08122	BOLT (8X30)	2	
26-1	56130-87J11-YAY	HOUSING, DRIVE SHAFT BEARING (BLACK)	1	
26-2	56130-87J11-Y5S	HOUSING, DRIVE SHAFT BEARING (WHITE)	1	
27	09282-17005	.OIL SEAL (17X32X6)	2	
28	08331-41329	.CIRCLIP	1	
29	55122-88L00	RING, GEAR CASE SEAL	1	
30	09202-06025	PIN (6X17)	1	
31	09202-06027	PIN (6X23)	1	

FIG.220B




FIG.220B (1-E-8) TRANSMISSION (DF50A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	57110-88L12	SHAFT ASSY, DRIVE (L)	1	
2	57133-88L01	COLLAR, DRIVE SHAFT	1	
3	57133-94400	HOUSING, DRIVE SHAFT SPRING	1	
4	09205-03019	SPRING PIN (3X10)	1	
5	09265-20015	BEARING (20X42X15)	1	
6	57300-88810	PINION/GEAR SET	1	
7	09140-12034	NUT	1	
8-1	09181-35101	SHIM (T:0.50)	AR	DRIVE SHAFT ADJUST
8-2	09181-33001	SHIM (T:0.55)	AR	
8-3	09181-33002	SHIM (T:0.60)	AR	
8-4	09181-33003	SHIM (T:0.65)	AR	
8-5	09181-33004	SHIM (T:0.70)	AR	
8-6	09181-33005	SHIM (T:0.75)	AR	
8-7	09181-33006	SHIM (T:0.80)	AR	
8-8	09181-33007	SHIM (T:0.85)	AR	
8-9	09181-33008	SHIM (T:0.90)	AR	
8-10	09181-33009	SHIM (T:0.95)	AR	
8-11	09181-35110	SHIM (T:1.00)	AR	
9-1	09181-30186	SHIM (T:0.50)	AR	FORWARD BACKUP
9-2	09181-30187	SHIM (T:0.60)	AR	
9-3	09181-30188	SHIM (T:0.70)	AR	
9-4	09181-30190	SHIM (T:0.80)	AR	
9-5	09181-30192	SHIM (T:0.90)	AR	
10-1	08221-35455	SHIM	AR	REVERSE BACKUP
10-2	09181-35131	SHIM (T:0.60)	AR	
10-3	09181-35132	SHIM (T:0.70)	AR	
10-4	08221-35456	SHIM	AR	
10-5	09181-35136	SHIM (T:0.90)	AR	
10-6	08211-35451	WASHER	AR	

FIG.220B




FIG.220B (1-E-9) TRANSMISSION (DF50A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
11-1	09160-22018	WASHER (22.2X28X1.8)	1	PROP SHAFT THRUST
11-2	09160-22019	WASHER (22.5X28X1.9)	1	
11-3	09160-22020	WASHER (22.5X28X2)	1	
11-4	09160-22021	WASHER (22.5X28X2.1)	1	
11-5	09160-22022	WASHER (22.5X28X2.2)	1	
11-6	09160-22023	WASHER (22.5X28X2.3)	1	
12	08211-20263	WASHER	1	
13	57610-94402	SHAFT, PROPELLER	1	
14	57621-87J03	SHIFTER, CLUTCH DOG	1	
15	09202-05022	PIN (5.5X38.5)	1	
16	57634-88L00	PIN, PUSH	1	
17	09440-08043	SPRING	1	
18	09440-40002	SPRING	1	
19	57631-95303	ROD, PUSH	1	
20-1	56120-94321-YAY	HOUSING, PROP SHAFT BEARING (BLACK)	1	
20-2	56120-94321-Y5S	HOUSING, PROP SHAFT BEARING (WHITE)	1	
21	09263-22020	.BEARING (22.2X28.5X19)	1	
22	09289-22007	.OIL SEAL (22X35X5)	2	
23	09262-35070	.BEARING (35X62X14)	1	
24	09280-75001	O RING (D:3.3,ID:75)	1	
25	09116-08122	BOLT (8X30)	2	
26-1	56130-87J11-YAY	HOUSING, DRIVE SHAFT BEARING (BLACK)	1	
26-2	56130-87J11-Y5S	HOUSING, DRIVE SHAFT BEARING (WHITE)	1	
27	09282-17005	.OIL SEAL (17X32X6)	2	
28	08331-41329	.CIRCLIP	1	
29	55122-88L00	RING, GEAR CASE SEAL	1	
30	09202-06025	PIN (6X17)	1	
31	09202-06027	PIN (6X23)	1	

FIG.220C




FIG.220C (1-E-10) TRANSMISSION (DF60A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	57110-88L12	SHAFT ASSY, DRIVE (L)	1	
2	57133-88L01	COLLAR, DRIVE SHAFT	1	
3	57133-94400	HOUSING, DRIVE SHAFT SPRING	1	
4	09205-03019	SPRING PIN (3X10)	1	
5	09265-20015	BEARING (20X42X15)	1	
6	57300-88810	PINION/GEAR SET	1	
7	09140-12034	NUT	1	
8-1	09181-35101	SHIM (T:0.50)	AR	DRIVE SHAFT ADJUST
8-2	09181-33001	SHIM (T:0.55)	AR	
8-3	09181-33002	SHIM (T:0.60)	AR	
8-4	09181-33003	SHIM (T:0.65)	AR	
8-5	09181-33004	SHIM (T:0.70)	AR	
8-6	09181-33005	SHIM (T:0.75)	AR	
8-7	09181-33006	SHIM (T:0.80)	AR	
8-8	09181-33007	SHIM (T:0.85)	AR	
8-9	09181-33008	SHIM (T:0.90)	AR	
8-10	09181-33009	SHIM (T:0.95)	AR	
8-11	09181-35110	SHIM (T:1.00)	AR	
9-1	09181-30186	SHIM (T:0.50)	AR	FORWARD BACKUP
9-2	09181-30187	SHIM (T:0.60)	AR	
9-3	09181-30188	SHIM (T:0.70)	AR	
9-4	09181-30190	SHIM (T:0.80)	AR	
9-5	09181-30192	SHIM (T:0.90)	AR	
10-1	08221-35455	SHIM	AR	REVERSE BACKUP
10-2	09181-35131	SHIM (T:0.60)	AR	
10-3	09181-35132	SHIM (T:0.70)	AR	
10-4	08221-35456	SHIM	AR	
10-5	09181-35136	SHIM (T:0.90)	AR	
10-6	08211-35451	WASHER	AR	

FIG.220C




FIG.220C (1-E-11) TRANSMISSION (DF60A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
11-1	09160-22018	WASHER (22.2X28X1.8)	1	PROP SHAFT THRUST
11-2	09160-22019	WASHER (22.5X28X1.9)	1	
11-3	09160-22020	WASHER (22.5X28X2)	1	
11-4	09160-22021	WASHER (22.5X28X2.1)	1	
11-5	09160-22022	WASHER (22.5X28X2.2)	1	
11-6	09160-22023	WASHER (22.5X28X2.3)	1	
12	08211-20263	WASHER	1	
13	57610-94402	SHAFT, PROPELLER	1	
14	57621-87J03	SHIFTER, CLUTCH DOG	1	
15	09202-05022	PIN (5.5X38.5)	1	
16	57634-88L00	PIN, PUSH	1	
17	09440-08043	SPRING	1	
18	09440-40002	SPRING	1	
19	57631-95303	ROD, PUSH	1	
20-1	56120-94321-YAY	HOUSING, PROP SHAFT BEARING (BLACK)	1	
20-2	56120-94321-Y5S	HOUSING, PROP SHAFT BEARING (WHITE)	1	
21	09263-22020	.BEARING (22.2X28.5X19)	1	
22	09289-22007	.OIL SEAL (22X35X5)	2	
23	09262-35070	.BEARING (35X62X14)	1	
24	09280-75001	O RING (D:3.3,ID:75)	1	
25	09116-08122	BOLT (8X30)	2	
26-1	56130-87J11-YAY	HOUSING, DRIVE SHAFT BEARING (BLACK)	1	
26-2	56130-87J11-Y5S	HOUSING, DRIVE SHAFT BEARING (WHITE)	1	
27	09282-17005	.OIL SEAL (17X32X6)	2	
28	08331-41329	.CIRCLIP	1	
29	55122-88L00	RING, GEAR CASE SEAL	1	
30	09202-06025	PIN (6X17)	1	
31	09202-06027	PIN (6X23)	1	

FIG.220D




FIG.220D (1-E-12) TRANSMISSION (DF50AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	57110-88L30	SHAFT ASSY, DRIVE (L)	1	
2	57133-90J02	COLLAR, DRIVE SHAFT	1	
3	09265-25046	BEARING (25X52X19.25)	1	
4	57300-99824	PINION/GEAR SET	1	
5	09140-14024	NUT	1	
6-1	09181-40186	SHIM (T:0.50)	1	
6-2	09181-41002	SHIM (T:0.55)	1	
6-3	09181-41003	SHIM (T:0.60)	1	
6-4	09181-41004	SHIM (T:0.65)	1	
6-5	09181-41005	SHIM (T:0.70)	1	
6-6	09181-41006	SHIM (T:0.75)	1	
6-7	09181-40190	SHIM (T:0.80)	1	
6-8	09181-41008	SHIM (T:0.85)	1	
6-9	09181-41009	SHIM (T:0.90)	1	
6-10	09181-41010	SHIM (T:0.95)	1	
6-11	09181-40195	SHIM (T:1.00)	1	
6-12	09181-41012	SHIM (T:1.05)	1	
6-13	09181-41013	SHIM (T:1.10)	1	
6-14	09181-41014	SHIM (T:1.15)	1	
7	09265-50003	BEARING (50X85X26)	1	PART OF GEAR CASE
8-1	09181-50020	SHIM (T:0.45)	1	FORWARD GEAR
8-2	09181-50021	SHIM (T:0.50)	1	
8-3	09181-50022	SHIM (T:0.55)	1	
8-4	09181-50023	SHIM (T:0.60)	1	
8-5	09181-50024	SHIM (T:0.65)	1	
8-6	09181-50025	SHIM (T:0.70)	1	
8-7	09181-50026	SHIM (T:0.75)	1	
8-8	09181-50027	SHIM (T:0.80)	1	
8-9	09181-50028	SHIM (T:0.85)	1	
8-10	09181-50029	SHIM (T:0.95)	1	
9-1	09181-45003	SHIM (T:1.00)	1	REVERSE GEAR
9-2	09181-45004	SHIM (T:1.10)	1	
9-3	09181-45005	SHIM (T:1.20)	1	

FIG.220D




FIG.220D (1-E-13) TRANSMISSION (DF50AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
9-4	09181-45006	SHIM (T:1.30)	1	
9-5	09181-45007	SHIM (T:1.40)	1	
9-6	09181-45008	SHIM (T:1.50)	1	
9-7	09181-45009	SHIM (T:1.60)	1	
10-1	09181-28015	SHIM (T:0.90)	1	PROP SHAFT REVERSE THRUST
10-2	09181-28016	SHIM (T:1.00)	1	
10-3	09181-28017	SHIM (T:1.20)	1	
10-4	09181-28018	SHIM (T:1.30)	1	
10-5	09181-28019	SHIM (T:1.40)	1	
10-6	09181-28020	SHIM (T:1.60)	1	
11	57610-88L10	SHAFT ASSY, PROPELLER	1	
12	57621-88L00	SHIFTER, CLUTCH DOG	1	
13	09202-07002	PIN (7X48)	1	
14	57631-99E01	ROD, PUSH	1	
15	09440-11020	SPRING	1	
16	09209-12007	PIN	1	
17	09181-25030	SHIM (25X32X3)	1	
18	09440-49004	SPRING	1	
19	56120-90J02-YAY	HOUSING, PROP SFT BRG (BLACK)	1	
20	56123-90J00	.WASHER, OIL SEAL PROTECTOR	1	
21	09263-28047	.BEARING (28X37X30)	1	
22	09280-97001	.O RING (D:3.5,ID:95)	1	
23	09282-28002	.OIL SEAL (28X50X6)	2	
24	08113-62090	.BEARING	1	
25	09387-52001	.RING SET	1	
26	09116-08122	BOLT (8X30)	2	
27	56130-87E00	HOUSING	1	
28	09280-46004	.O RING (D:3.5,ID:45.7)	1	
29	09282-22007	.OIL SEAL (22X36X6)	2	
30	09117-08110	BOLT (8X25)	4	
31	09181-31001	SHIM (31X46X2)	3	
32	09169-31001	WASHER	1	
33	09164-31001	WASHER	1	

FIG.220E




FIG.220E (1-E-14) TRANSMISSION (DF60AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	57110-88L30	SHAFT ASSY, DRIVE (L)	1	
2	57133-90J02	COLLAR, DRIVE SHAFT	1	
3	09265-25046	BEARING (25X52X19.25)	1	
4	57300-99824	PINION/GEAR SET	1	
5	09140-14024	NUT	1	
6-1	09181-40186	SHIM (T:0.50)	1	
6-2	09181-41002	SHIM (T:0.55)	1	
6-3	09181-41003	SHIM (T:0.60)	1	
6-4	09181-41004	SHIM (T:0.65)	1	
6-5	09181-41005	SHIM (T:0.70)	1	
6-6	09181-41006	SHIM (T:0.75)	1	
6-7	09181-40190	SHIM (T:0.80)	1	
6-8	09181-41008	SHIM (T:0.85)	1	
6-9	09181-41009	SHIM (T:0.90)	1	
6-10	09181-41010	SHIM (T:0.95)	1	
6-11	09181-40195	SHIM (T:1.00)	1	
6-12	09181-41012	SHIM (T:1.05)	1	
6-13	09181-41013	SHIM (T:1.10)	1	
6-14	09181-41014	SHIM (T:1.15)	1	
7	09265-50003	BEARING (50X85X26)	1	PART OF GEAR CASE
8-1	09181-50020	SHIM (T:0.45)	1	FORWARD GEAR
8-2	09181-50021	SHIM (T:0.50)	1	
8-3	09181-50022	SHIM (T:0.55)	1	
8-4	09181-50023	SHIM (T:0.60)	1	
8-5	09181-50024	SHIM (T:0.65)	1	
8-6	09181-50025	SHIM (T:0.70)	1	
8-7	09181-50026	SHIM (T:0.75)	1	
8-8	09181-50027	SHIM (T:0.80)	1	
8-9	09181-50028	SHIM (T:0.85)	1	
8-10	09181-50029	SHIM (T:0.95)	1	
9-1	09181-45003	SHIM (T:1.00)	1	REVERSE GEAR
9-2	09181-45004	SHIM (T:1.10)	1	
9-3	09181-45005	SHIM (T:1.20)	1	

FIG.220E




FIG.220E (1-E-15) TRANSMISSION (DF60AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
9-4	09181-45006	SHIM (T:1.30)	1	
9-5	09181-45007	SHIM (T:1.40)	1	
9-6	09181-45008	SHIM (T:1.50)	1	
9-7	09181-45009	SHIM (T:1.60)	1	
10-1	09181-28015	SHIM (T:0.90)	1	PROP SHAFT REVERSE THRUST
10-2	09181-28016	SHIM (T:1.00)	1	
10-3	09181-28017	SHIM (T:1.20)	1	
10-4	09181-28018	SHIM (T:1.30)	1	
10-5	09181-28019	SHIM (T:1.40)	1	
10-6	09181-28020	SHIM (T:1.60)	1	
11	57610-88L10	SHAFT ASSY, PROPELLER	1	
12	57621-88L00	SHIFTER, CLUTCH DOG	1	
13	09202-07002	PIN (7X48)	1	
14	57631-99E01	ROD, PUSH	1	
15	09440-11020	SPRING	1	
16	09209-12007	PIN	1	
17	09181-25030	SHIM (25X32X3)	1	
18	09440-49004	SPRING	1	
19	56120-90J02-YAY	HOUSING, PROP SFT BRG (BLACK)	1	
20	56123-90J00	.WASHER, OIL SEAL PROTECTOR	1	
21	09263-28047	.BEARING (28X37X30)	1	
22	09280-97001	.O RING (D:3.5,ID:95)	1	
23	09282-28002	.OIL SEAL (28X50X6)	2	
24	08113-62090	.BEARING	1	
25	09387-52001	.RING SET	1	
26	09116-08122	BOLT (8X30)	2	
27	56130-87E00	HOUSING	1	
28	09280-46004	.O RING (D:3.5,ID:45.7)	1	
29	09282-22007	.OIL SEAL (22X36X6)	2	
30	09117-08110	BOLT (8X25)	4	
31	09181-31001	SHIM (31X46X2)	3	
32	09169-31001	WASHER	1	
33	09164-31001	WASHER	1	

FIG.301A




FIG.301A (1-F-2) STARTING MOTOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31100-94J22	STARTING MOTOR	1	
2	31131-94J00	.BRUSH SET, PLUS	1	
3	31135-90J00	.SPRING	4	
4	31151-94J01	.CASE, GEAR	1	
5	31152-90J00	.PLATE, CENTER	1	
6	31153-90J00	.BRACKET, PLANET GEAR	1	
7	31171-96J00	.COVER KIT, DUST	1	
8	31173-94J01	.HOLDER ASSY, BRUSH	1	
9	31191-96J00	.LEVER, SHIFT	1	
10	31220-94J00	.SWITCH, MAGNET	1	
11	31310-90J00	.ARMATURE	1	
12	31320-94J00	.PINION	1	
13	31341-94J00	.SHAFT, PINION	1	
14	31343-90J00	.INTERNAL GEAR	1	
15	31344-90J00	.GEAR, PLANETARY	3	
16	31360-93J01	.WASHER SET	1	
17	31170-94J00	.COVER ASSY, STARTER MOTER REAR	1	
18	31912-88L00	BAND, STARTER MOTOR	1	
19	31918-87L00	DAMPER, LOWER	1	
20	01550-06167	BOLT	2	LOWER
21	01550-08307	BOLT	2	UPPER

DF60A_E03_017_301A
STARTING MOTOR

FIG.303A




FIG.303A (1-F-3) MAGNETO

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32102-88L01	FLYWHEEL	1	
2	09103-14024	BOLT (14X50)	1	
3	09160-14065	WASHER (14.5X36X4.5)	1	
4	09420-04008	KEY	1	
5	32120-88L00	COIL, BATTERY CHARGING	1	
6	32160-88L00	COIL, IGNITION TIMING	1	
7	09106-05030	BOLT (5X10)	2	
8	33220-64L10	SENSOR ASSY, CAM POSITION	1	
9	01547-06167	BOLT	1	
10	09403-13408	CLAMP	1	
11	01550-06127	BOLT	1	
12	02112-06307	SCREW	3	

FIG.310A




FIG.310A (1-F-4) RECTIFIER/IGNITION COIL

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-88L00	RECTIFIER/REGULATOR ASSY	1	
2	01550-06257	BOLT	2	
3	32890-88L00	HOLDER, ELECTRIC PARTS	1	
4	09116-06202	BOLT (6X25)	3	
5	09169-06062	WASHER	3	
6	09320-09016	CUSHION	3	
7	33410-87L00	COIL ASSY, IGNITION	3	
8	01547-06207	BOLT	3	

FIG.315A




FIG.315A (1-F-5) SENSOR (DF40A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34830-87J20	SENSOR ASSY, CYLINDER TEMP	1	
2	34840-98J03	SENSOR ASSY, TRIM	1	
3	09125-05048	SCREW (5X16)	1	
4	09160-05029	WASHER (5.5X12X0.8)	1	
5	09103-06093	BOLT (6X20)	2	
6	37820-99E01	SWITCH, OIL PRESSURE	1	
7	09403-07340	CLAMP	1	
8	36656-88L00	GROMMET, PTT CABLE	1	
9	09407-14407	CLAMP (L:145)	3	
10	34841-88L00	LEVER, TRIM SENSOR	1	
11	34845-88L01	BRACKET, TRIM SENSOR	1	
12	29404-93J10	CLAMP, PTT CABLE	1	

FIG.315B




FIG.315B (1-F-6) SENSOR (DF50A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34830-87J20	SENSOR ASSY, CYLINDER TEMP	1	
2	34840-98J03	SENSOR ASSY, TRIM	1	
3	09125-05048	SCREW (5X16)	1	
4	09160-05029	WASHER (5.5X12X0.8)	1	
5	09103-06093	BOLT (6X20)	2	
6	37820-99E01	SWITCH, OIL PRESSURE	1	
7	09403-07340	CLAMP	1	
8	36656-88L00	GROMMET, PTT CABLE	1	
9	09407-14407	CLAMP (L:145)	3	
10	34841-88L00	LEVER, TRIM SENSOR	1	
11	34845-88L01	BRACKET, TRIM SENSOR	1	
12	29404-93J10	CLAMP, PTT CABLE	1	

FIG.315C




FIG.315C (1-F-7) SENSOR (DF60A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34830-87J20	SENSOR ASSY, CYLINDER TEMP	1	
2	34840-98J11	SENSOR ASSY, TRIM	1	
3	09125-05046	SCREW (5X12)	1	
4	34846-87L00	WASHER, TRIM SENSOR	1	
5	34841-87L10	LEVER, TRIM SENSOR	1	
6	34842-88L10	CAM, TRIM SENSOR UPPER	1	
7	34843-87L00	CAM, TRIM SENSOR LOWER	1	
8	34845-88L10	BRACKET, TRIM SENSOR	1	
9	09103-06093	BOLT (6X20)	1	
10	37820-99E01	SWITCH, OIL PRESSURE	1	
11	36617-88L00	BRACKET, PTT CABLE CLAMP	1	
12	29103-93J00	BOLT, PTT CABLE CLAMP BRACKET	1	
13	09403-07340	CLAMP	1	
14	09403-11321	CLAMP	1	
15	36656-88L00	GROMMET, PTT CABLE	1	
16	09407-14407	CLAMP (L:145)	2	

FIG.315D




FIG.315D (1-F-8) SENSOR (DF50AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34830-87J20	SENSOR ASSY, CYLINDER TEMP	1	
2	34840-98J11	SENSOR ASSY, TRIM	1	
3	09125-05046	SCREW (5X12)	1	
4	34846-87L00	WASHER, TRIM SENSOR	1	
5	34841-87L10	LEVER, TRIM SENSOR	1	
6	34842-88L10	CAM, TRIM SENSOR UPPER	1	
7	34843-87L00	CAM, TRIM SENSOR LOWER	1	
8	34845-88L10	BRACKET, TRIM SENSOR	1	
9	09103-06093	BOLT (6X20)	1	
10	37820-99E01	SWITCH, OIL PRESSURE	1	
11	36617-88L00	BRACKET, PTT CABLE CLAMP	1	
12	29103-93J00	BOLT, PTT CABLE CLAMP BRACKET	1	
13	09403-07340	CLAMP	1	
14	09403-11321	CLAMP	1	
15	36656-88L00	GROMMET, PTT CABLE	1	
16	09407-14407	CLAMP (L:145)	2	

FIG.315E




FIG.315E (1-F-9) SENSOR (DF60AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34830-87J20	SENSOR ASSY, CYLINDER TEMP	1	
2	34840-98J11	SENSOR ASSY, TRIM	1	
3	09125-05046	SCREW (5X12)	1	
4	34846-87L00	WASHER, TRIM SENSOR	1	
5	34841-87L10	LEVER, TRIM SENSOR	1	
6	34842-88L10	CAM, TRIM SENSOR UPPER	1	
7	34843-87L00	CAM, TRIM SENSOR LOWER	1	
8	34845-88L10	BRACKET, TRIM SENSOR	1	
9	09103-06093	BOLT (6X20)	1	
10	37820-99E01	SWITCH, OIL PRESSURE	1	
11	36617-88L00	BRACKET, PTT CABLE CLAMP	1	
12	29103-93J00	BOLT, PTT CABLE CLAMP BRACKET	1	
13	09403-07340	CLAMP	1	
14	09403-11321	CLAMP	1	
15	36656-88L00	GROMMET, PTT CABLE	1	
16	09407-14407	CLAMP (L:145)	2	

FIG.322A




FIG.322A (1-F-10) HARNESS (DF40A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-88L10	CABLE ASSY, STARTER MOTOR	1	
2	08316-10087	NUT	1	
3	36610-88LD1	HARNESS ASSY, WIRING	1	
4	33634-96J00	.CAP, SERVICE CONNECTOR	1	
5	36668-87L00	.HOLDER, CONDENSER	1	
6	09320-08021	.CUSHION	2	
7	36737-96J00	.PULLER, FUSE	1	
8	36721-96J00	.O RING, UPPER COVER	1	
9	36738-88L00	.COVER, FUSE CASE UPPER	1	
10	38860-76F01	.RELAY, ENG CONTROL UNIT	1	
11	38860-76F01	.RELAY ASSY, STARTER MOTOR	1	
12	09481-15501	.FUSE (15A)	3	
13	09481-30501	.FUSE (30A)	3	
14	09481-30401	.FUSE (30A)	2	
15	36612-96J00	.CAP, TERMINAL	1	
16	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
17	08310-00067	NUT	1	
18	08321-01067	WASHER	1	
19	09407-14403	CLAMP (L:125)	1	
20	09407-14407	CLAMP (L:145)	1	
21	36617-88L00	BRACKET, HARNESS	2	
22	36617-88L10	BRACKET, HARNESS	1	
23	36617-93J10	BRACKET, HARNESS	2	
24	01550-06127	BOLT	5	
25	09407-18402	CLAMP (L:165)	1	

DF60A_E03_017_322A
HARNESS

FIG.322B




FIG.322B (1-F-11) HARNESS (DF50A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-88L10	CABLE ASSY, STARTER MOTOR	1	
2	08316-10087	NUT	1	
3	36610-88LD1	HARNESS ASSY, WIRING	1	
4	33634-96J00	.CAP, SERVICE CONNECTOR	1	
5	36668-87L00	.HOLDER, CONDENSER	1	
6	09320-08021	.CUSHION	2	
7	36737-96J00	.PULLER, FUSE	1	
8	36721-96J00	.O RING, UPPER COVER	1	
9	36738-88L00	.COVER, FUSE CASE UPPER	1	
10	38860-76F01	.RELAY, ENG CONTROL UNIT	1	
11	38860-76F01	.RELAY ASSY, STARTER MOTOR	1	
12	09481-15501	.FUSE (15A)	3	
13	09481-30501	.FUSE (30A)	3	
14	09481-30401	.FUSE (30A)	2	
15	36612-96J00	.CAP, TERMINAL	1	
16	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
17	08310-00067	NUT	1	
18	08321-01067	WASHER	1	
19	09407-14403	CLAMP (L:125)	1	
20	09407-14407	CLAMP (L:145)	1	
21	36617-88L00	BRACKET, HARNESS	2	
22	36617-88L10	BRACKET, HARNESS	1	
23	36617-93J10	BRACKET, HARNESS	2	
24	01550-06127	BOLT	5	
25	09407-18402	CLAMP (L:165)	1	

FIG.322C




FIG.322C (1-F-12) HARNESS (DF60A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-88L10	CABLE ASSY, STARTER MOTOR	1	
2	08316-10087	NUT	1	
3	36610-88LE2	HARNESS ASSY, WIRING	1	
4	33634-96J00	.CAP, SERVICE CONNECTOR	1	
5	36668-87L00	.HOLDER, CONDENSER	1	
6	09320-08021	.CUSHION	2	
7	36737-96J00	.PULLER, FUSE	1	
8	36721-96J00	.O RING, UPPER COVER	1	
9	36738-88L00	.COVER, FUSE CASE UPPER	1	
10	38860-76F01	.RELAY, ENG CONTROL UNIT	1	
11	38860-76F01	.RELAY ASSY, STARTER MOTOR	1	
12	09481-15501	.FUSE (15A)	3	
13	09481-30501	.FUSE (30A)	3	
14	09481-30401	.FUSE (30A)	2	
15	36612-96J00	.CAP, TERMINAL	1	
16	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
17	36611-88L00	.HARNESS ASSY,WIRING SUB	1	
18	08310-00067	NUT	1	
19	08321-01067	WASHER	1	
20	09407-14403	CLAMP (L:125)	1	
21	09407-14407	CLAMP (L:145)	1	
22	36617-88L00	BRACKET, HARNESS	2	
23	36617-88L10	BRACKET, HARNESS	1	
24	36617-93J10	BRACKET, HARNESS	2	
25	01550-06127	BOLT	5	
26	09407-18402	CLAMP (L:165)	1	

DF60A_E03_017_322C
HARNESS

FIG.322D




FIG.322D (1-F-13) HARNESS (DF50AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-88L10	CABLE ASSY, STARTER MOTOR	1	
2	08316-10087	NUT	1	
3	36610-88LE2	HARNESS ASSY, WIRING	1	
4	33634-96J00	.CAP, SERVICE CONNECTOR	1	
5	36668-87L00	.HOLDER, CONDENSER	1	
6	09320-08021	.CUSHION	2	
7	36737-96J00	.PULLER, FUSE	1	
8	36721-96J00	.O RING, UPPER COVER	1	
9	36738-88L00	.COVER, FUSE CASE UPPER	1	
10	38860-76F01	.RELAY, ENG CONTROL UNIT	1	
11	38860-76F01	.RELAY ASSY, STARTER MOTOR	1	
12	09481-15501	.FUSE (15A)	3	
13	09481-30501	.FUSE (30A)	3	
14	09481-30401	.FUSE (30A)	2	
15	36612-96J00	.CAP, TERMINAL	1	
16	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
17	36611-88L00	.HARNESS ASSY,WIRING SUB	1	
18	08310-00067	NUT	1	
19	08321-01067	WASHER	1	
20	09407-14403	CLAMP (L:125)	1	
21	09407-14407	CLAMP (L:145)	1	
22	36617-88L00	BRACKET, HARNESS	2	
23	36617-88L10	BRACKET, HARNESS	1	
24	36617-93J10	BRACKET, HARNESS	2	
25	01550-06127	BOLT	5	
26	09407-18402	CLAMP (L:165)	1	

FIG.322E




FIG.322E (1-F-14) HARNESS (DF60AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-88L10	CABLE ASSY, STARTER MOTOR	1	
2	08316-10087	NUT	1	
3	36610-88LE2	HARNESS ASSY, WIRING	1	
4	33634-96J00	.CAP, SERVICE CONNECTOR	1	
5	36668-87L00	.HOLDER, CONDENSER	1	
6	09320-08021	.CUSHION	2	
7	36737-96J00	.PULLER, FUSE	1	
8	36721-96J00	.O RING, UPPER COVER	1	
9	36738-88L00	.COVER, FUSE CASE UPPER	1	
10	38860-76F01	.RELAY, ENG CONTROL UNIT	1	
11	38860-76F01	.RELAY ASSY, STARTER MOTOR	1	
12	09481-15501	.FUSE (15A)	3	
13	09481-30501	.FUSE (30A)	3	
14	09481-30401	.FUSE (30A)	2	
15	36612-96J00	.CAP, TERMINAL	1	
16	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
17	36611-88L00	.HARNESS ASSY,WIRING SUB	1	
18	08310-00067	NUT	1	
19	08321-01067	WASHER	1	
20	09407-14403	CLAMP (L:125)	1	
21	09407-14407	CLAMP (L:145)	1	
22	36617-88L00	BRACKET, HARNESS	2	
23	36617-88L10	BRACKET, HARNESS	1	
24	36617-93J10	BRACKET, HARNESS	2	
25	01550-06127	BOLT	5	
26	09407-18402	CLAMP (L:165)	1	

DF60A_E03_017_322E
HARNESS

FIG.326A




FIG.326A (1-F-15) PTT SWITCH/ENGINE CONTROL UNIT (DF40A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37721-93J00	SWITCH ASSY, NEUTRAL	1	
2	09137-04004	SCREW (4X16)	2	
3	37725-88L00	BRACKET, NEUTRAL SWITCH	1	
4	09407-10404	CLAMP (L:100)	1	
5	09408-00184	CLAMP	1	
6	38410-93J12	RELAY ASSY, PTT	1	
7	38415-93J00	HOLDER, PTT RELAY	1	
8	01550-06127	BOLT	1	
9	33940-88L20	UNIT, ENGINE CONTROL	1	
10	33925-88L10	CUSHION, ENGINE CONTROL UNIT	1	
11	37850-92J00	SWITCH ASSY, PTT	1	
12	37856-92J00	.TAPE, PTT SWITCH	1	
13	37857-92J00	BUSH, PTT SWITH	1	

DF60A_E03_017_326A
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326B




FIG.326B (1-G-2) PTT SWITCH/ENGINE CONTROL UNIT (DF50A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37721-93J00	SWITCH ASSY, NEUTRAL	1	
2	09137-04004	SCREW (4X16)	2	
3	37725-88L00	BRACKET, NEUTRAL SWITCH	1	
4	09407-10404	CLAMP (L:100)	1	
5	09408-00184	CLAMP	1	
6	38410-93J12	RELAY ASSY, PTT	1	
7	38415-93J00	HOLDER, PTT RELAY	1	
8	01550-06127	BOLT	1	
9	33940-88L40	UNIT, ENGINE CONTROL	1	
10	33925-88L10	CUSHION, ENGINE CONTROL UNIT	1	
11	37850-92J00	SWITCH ASSY, PTT	1	
12	37856-92J00	.TAPE, PTT SWITCH	1	
13	37857-92J00	BUSH, PTT SWITH	1	

DF60A_E03_017_326B
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326C




FIG.326C (1-G-3) PTT SWITCH/ENGINE CONTROL UNIT (DF60A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37721-93J00	SWITCH ASSY, NEUTRAL	1	
2	09137-04004	SCREW (4X16)	2	
3	37725-88L00	BRACKET, NEUTRAL SWITCH	1	
4	09407-10404	CLAMP (L:100)	1	
5	09408-00184	CLAMP	1	
6	38410-93J12	RELAY ASSY, PTT	1	
7	38415-93J00	HOLDER, PTT RELAY	1	
8	01550-06127	BOLT	1	
9	33940-88L00	UNIT, ENGINE CONTROL	1	
10	33925-88L10	CUSHION, ENGINE CONTROL UNIT	1	
11	37850-92J00	SWITCH ASSY, PTT	1	
12	37856-92J00	.TAPE, PTT SWITCH	1	
13	37857-92J00	BUSH, PTT SWITH	1	

DF60A_E03_017_326C
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326D




FIG.326D (1-G-4) PTT SWITCH/ENGINE CONTROL UNIT (DF50AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37721-93J00	SWITCH ASSY, NEUTRAL	1	
2	09137-04004	SCREW (4X16)	2	
3	37725-88L00	BRACKET, NEUTRAL SWITCH	1	
4	09407-10404	CLAMP (L:100)	1	
5	09408-00184	CLAMP	1	
6	38410-93J12	RELAY ASSY, PTT	1	
7	38415-93J00	HOLDER, PTT RELAY	1	
8	01550-06127	BOLT	1	
9	33940-88L70	UNIT, ENGINE CONTROL	1	
10	33925-88L10	CUSHION, ENGINE CONTROL UNIT	1	
11	37850-92J00	SWITCH ASSY, PTT	1	
12	37856-92J00	.TAPE, PTT SWITCH	1	
13	37857-92J00	BUSH, PTT SWITH	1	

DF60A_E03_017_326D
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326E




FIG.326E (1-G-5) PTT SWITCH/ENGINE CONTROL UNIT (DF60AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37721-93J00	SWITCH ASSY, NEUTRAL	1	
2	09137-04004	SCREW (4X16)	2	
3	37725-88L00	BRACKET, NEUTRAL SWITCH	1	
4	09407-10404	CLAMP (L:100)	1	
5	09408-00184	CLAMP	1	
6	38410-93J12	RELAY ASSY, PTT	1	
7	38415-93J00	HOLDER, PTT RELAY	1	
8	01550-06127	BOLT	1	
9	33940-88L50	UNIT, ENGINE CONTROL	1	
10	33925-88L10	CUSHION, ENGINE CONTROL UNIT	1	
11	37850-92J00	SWITCH ASSY, PTT	1	
12	37856-92J00	.TAPE, PTT SWITCH	1	
13	37857-92J00	BUSH, PTT SWITH	1	

DF60A_E03_017_326E
PTT SWITCH/ENGINE CONTROL UNIT

FIG.335A




FIG.335A (1-G-6) CLAMP BRACKET (DF40A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	41111-88L20-YAY	BRACKET, CLAMP STBD (BLACK)	1	
1-2	41111-88L20-Y5S	BRACKET, CLAMP STBD (WHITE)	1	
2-1	41121-88L10-YAY	BRACKET, CLAMP PORT (BLACK)	1	
2-2	41121-88L10-Y5S	BRACKET, CLAMP PORT (WHITE)	1	
3	41130-87J11	SHAFT, CLAMP BRACKET	1	
4	45421-89J00	PIN, TILT LOCK	2	
5	09160-12066	WASHER (12.5X22X2.5)	2	
6	55321-87J01	ANODE, PROTECTION	2	
7	09103-06281	BOLT (6X14)	2	
8-1	09100-12093	BOLT (12X100)	4	
8-2	09100-12091	BOLT (12X115)	1	OPT
9	09159-12014	NUT	4	
10	09159-22006	NUT	1	
11	09160-12044	WASHER (12.5X35X3.2)	4	
12	09160-12126	WASHER	4	
13	09159-10050	NUT	2	
14	09160-10082	WASHER (10.5X19X2)	2	
15	41135-93J00	WASHER, CLAMP BRACKET SHAFT	1	

FIG.335B




FIG.335B (1-G-7) CLAMP BRACKET (DF50A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	41111-88L20-YAY	BRACKET, CLAMP STBD (BLACK)	1	
1-2	41111-88L20-Y5S	BRACKET, CLAMP STBD (WHITE)	1	
2-1	41121-88L10-YAY	BRACKET, CLAMP PORT (BLACK)	1	
2-2	41121-88L10-Y5S	BRACKET, CLAMP PORT (WHITE)	1	
3	41130-87J11	SHAFT, CLAMP BRACKET	1	
4	45421-89J00	PIN, TILT LOCK	2	
5	09160-12066	WASHER (12.5X22X2.5)	2	
6	55321-87J01	ANODE, PROTECTION	2	
7	09103-06281	BOLT (6X14)	2	
8-1	09100-12093	BOLT (12X100)	4	
8-2	09100-12091	BOLT (12X115)	1	OPT
9	09159-12014	NUT	4	
10	09159-22006	NUT	1	
11	09160-12044	WASHER (12.5X35X3.2)	4	
12	09160-12126	WASHER	4	
13	09159-10050	NUT	2	
14	09160-10082	WASHER (10.5X19X2)	2	
15	41135-93J00	WASHER, CLAMP BRACKET SHAFT	1	

FIG.335C




FIG.335C (1-G-8) CLAMP BRACKET (DF60A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	41111-88L10-YAY	BRACKET, CLAMP STBD (BLACK)	1	
1-2	41111-88L10-Y5S	BRACKET, CLAMP STBD (WHITE)	1	
2-1	41121-88L01-YAY	BRACKET, CLAMP PORT (BLACK)	1	
2-2	41121-88L01-Y5S	BRACKET, CLAMP PORT (WHITE)	1	
3	41130-88L10	SHAFT, CLAMP BRACKET	1	
4	41135-93J00	WASHER, CLAMP BRACKET SHAFT	1	
5	09116-08137	BOLT (8X22)	1	
6	09159-22006	NUT	1	
7-1	09100-12093	BOLT (12X100)	4	
7-2	09100-12091	BOLT (12X115)	1	OPT
8	09159-12014	NUT	4	
9	09160-12126	WASHER	4	
10	09160-12044	WASHER (12.5X35X3.2)	4	
11	55320-94900	ZINC, PROTECTION	1	
12	09116-06121	.BOLT (6X25)	2	
13	09106-10065	BOLT (10X20)	2	
14	09160-10082	WASHER (10.5X19X2)	2	

FIG.335D




FIG.335D (1-G-9) CLAMP BRACKET (DF50AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-88L10-YAY	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-88L01-YAY	BRACKET, CLAMP PORT (BLACK)	1	
3	41130-88L10	SHAFT, CLAMP BRACKET	1	
4	41135-93J00	WASHER, CLAMP BRACKET SHAFT	1	
5	09116-08137	BOLT (8X22)	1	
6	09159-22006	NUT	1	
7-1	09100-12093	BOLT (12X100)	4	
7-2	09100-12091	BOLT (12X115)	1	OPT
8	09159-12014	NUT	4	
9	09160-12126	WASHER	4	
10	09160-12044	WASHER (12.5X35X3.2)	4	
11	55321-87J01	ANODE, PROTECTION	2	
12	09103-06281	BOLT (6X14)	2	
13	09106-10065	BOLT (10X20)	2	
14	09160-10082	WASHER (10.5X19X2)	2	

FIG.335E




FIG.335E (1-G-10) CLAMP BRACKET (DF60AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-88L10-YAY	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-88L01-YAY	BRACKET, CLAMP PORT (BLACK)	1	
3	41130-88L10	SHAFT, CLAMP BRACKET	1	
4	41135-93J00	WASHER, CLAMP BRACKET SHAFT	1	
5	09116-08137	BOLT (8X22)	1	
6	09159-22006	NUT	1	
7-1	09100-12093	BOLT (12X100)	4	
7-2	09100-12091	BOLT (12X115)	1	OPT
8	09159-12014	NUT	4	
9	09160-12126	WASHER	4	
10	09160-12044	WASHER (12.5X35X3.2)	4	
11	55321-87J01	ANODE, PROTECTION	2	
12	09103-06281	BOLT (6X14)	2	
13	09106-10065	BOLT (10X20)	2	
14	09160-10082	WASHER (10.5X19X2)	2	

FIG.336A




FIG.336A (1-G-11) SWIVEL BRACKET (DF40A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	43111-88L21-YAY	BRACKET, SWIVEL (L) (BLACK)	1	
1-2	43111-88L21-Y5S	BRACKET, SWIVEL (L) (WHITE)	1	
2	43211-87J00	BUSH, SWIVEL BRACKET	2	
3	43711-89J10	BUSH, STEERING	2	
4-1	43750-88L22-YAY	BRACKET, STEERING (L) (BLACK)	1	
4-2	43750-88L22-Y5S	BRACKET, STEERING (L) (WHITE)	1	
5	22511-99011	NIPPLE, GREASE	3	
6	36894-95201	LEAD (CLAMP TO SWIVEL)	1	
7	36895-87D01	LEAD (SWIVEL TO MOUNT BRKT)	1	
8	36895-87D01	LEAD (SWIVEL TO HOUSING)	1	
9	09125-06063	SCREW (6X10)	2	
10	09125-05050	SCREW (5X8)	3	
11	43755-88L00	ATTACHMENT, STEERING BRKT	1	
12	09108-10161	STUD BOLT	2	
13	09159-10050	NUT	2	
14	09160-10141	WASHER (10.5X19X2)	2	
15	09160-39003	WASHER (39.5X58X0.3)	2	
16	09282-39001	OIL SEAL (39X51X5)	1	
17	09160-39002	WASHER (39.5X58X1)	2	
18	09380-38003	CIRCLIP	1	
19	41226-97E00	BUSH, TILT LOCK LEVER	2	
20	41270-89J10	LEVER, TILT LOCK STBD	1	
21	41280-89J04	LEVER, TILT LOCK PORT	1	
22	45731-96312	BRACKET, SPRING	1	
23	09116-06236	BOLT (6X16)	1	
24	41230-97E10	SPRING, TILT LOCK	1	
25	09205-03012	SPRING PIN (3X16)	1	

DF60A_E03_017_336A
SWIVEL BRACKET

FIG.336B




FIG.336B (1-G-12) SWIVEL BRACKET (DF50A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	43111-88L21-YAY	BRACKET, SWIVEL (L) (BLACK)	1	
1-2	43111-88L21-Y5S	BRACKET, SWIVEL (L) (WHITE)	1	
2	43211-87J00	BUSH, SWIVEL BRACKET	2	
3	43711-89J10	BUSH, STEERING	2	
4-1	43750-88L22-YAY	BRACKET, STEERING (L) (BLACK)	1	
4-2	43750-88L22-Y5S	BRACKET, STEERING (L) (WHITE)	1	
5	22511-99011	NIPPLE, GREASE	3	
6	36894-95201	LEAD (CLAMP TO SWIVEL)	1	
7	36895-87D01	LEAD (SWIVEL TO MOUNT BRKT)	1	
8	36895-87D01	LEAD (SWIVEL TO HOUSING)	1	
9	09125-06063	SCREW (6X10)	2	
10	09125-05050	SCREW (5X8)	3	
11	43755-88L00	ATTACHMENT, STEERING BRKT	1	
12	09108-10161	STUD BOLT	2	
13	09159-10050	NUT	2	
14	09160-10141	WASHER (10.5X19X2)	2	
15	09160-39003	WASHER (39.5X58X0.3)	2	
16	09282-39001	OIL SEAL (39X51X5)	1	
17	09160-39002	WASHER (39.5X58X1)	2	
18	09380-38003	CIRCLIP	1	
19	41226-97E00	BUSH, TILT LOCK LEVER	2	
20	41270-89J10	LEVER, TILT LOCK STBD	1	
21	41280-89J04	LEVER, TILT LOCK PORT	1	
22	45731-96312	BRACKET, SPRING	1	
23	09116-06236	BOLT (6X16)	1	
24	41230-97E10	SPRING, TILT LOCK	1	
25	09205-03012	SPRING PIN (3X16)	1	

DF60A_E03_017_336B
SWIVEL BRACKET

FIG.336C




FIG.336C (1-G-13) SWIVEL BRACKET (DF60A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	43111-88L40-YAY	BRACKET, SWIVEL (L) (BLACK)	1	
1-2	43111-88L40-Y5S	BRACKET, SWIVEL (L) (WHITE)	1	
2	43211-88L00	BUSH, SWIVEL BRACKET	2	
3	43711-97E01	BUSH, STEERING	2	
4-1	43750-88L22-YAY	BRACKET, STEERING (L) (BLACK)	1	
4-2	43750-88L22-Y5S	BRACKET, STEERING (L) (WHITE)	1	
5	22511-99011	NIPPLE, GREASE	4	
6	36894-87D00	LEAD (CLAMP TO SWIVEL)	1	
7	36895-87D01	LEAD (SWIVEL TO MOUNT BRKT)	1	
8	36895-87D01	LEAD (SWIVEL TO HOUSING)	1	
9	09125-06063	SCREW (6X10)	4	
10	09125-05050	SCREW (5X8)	1	
11	43119-88L00	PLATE, SWIVEL BRKT LOWER STBD	1	
12	43119-88L10	PLATE, SWIVEL BRKT LOWER PORT	1	
13	09125-06067	SCREW (6X16)	2	
14	43114-88L00	WASHER, SWIVEL TO CLAMP BRKT	2	
15	09160-39003	WASHER (39.5X58X0.3)	2	
16	09282-39001	OIL SEAL (39X51X5)	1	
17	09160-39002	WASHER (39.5X58X1)	2	
18	09380-38003	CIRCLIP	1	
19	43755-88L00	ATTACHMENT, STEERING BRKT	1	
20	09108-10161	STUD BOLT	2	
21	09159-10050	NUT	2	
22	09160-10141	WASHER (10.5X19X2)	2	
23	41221-88L00	LEVER, TILT LOCK STBD	1	
24	41280-88L10	LEVER, TILT LOCK PORT	1	
25	41224-88L00	BUSH, TILT LOCK LEVER	2	
26	29141-93J00	NUT, TILT LOCK LEVER STBD	1	
27	41231-88L01	LINK, TILT LOCK LEVER	1	
28	41234-88L00	ARM, TILT LOCK LINK	1	
29	45731-96312	BRACKET, SPRING	1	
30	09125-06063	SCREW (6X10)	1	
31	09443-10043	SPRING	1	

FIG.336D




FIG.336D (1-G-14) SWIVEL BRACKET (DF50AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	43111-88L50-YAY	BRACKET, SWIVEL (S) (BLACK)	1	
2	43211-88L00	BUSH, SWIVEL BRACKET	2	
3	43711-97E01	BUSH, STEERING	2	
4	43750-88L32-YAY	BRACKET, STEERING (S) (BLACK)	1	
5	22511-99011	NIPPLE, GREASE	4	
6	36894-87D00	LEAD (CLAMP TO SWIVEL)	1	
7	36895-87D01	LEAD (SWIVEL TO MOUNT BRKT)	1	
8	36895-87D01	LEAD (SWIVEL TO HOUSING)	1	
9	09125-06063	SCREW (6X10)	4	
10	09125-05050	SCREW (5X8)	1	
11	43119-88L00	PLATE, SWIVEL BRKT LOWER STBD	1	
12	43119-88L10	PLATE, SWIVEL BRKT LOWER PORT	1	
13	09125-06067	SCREW (6X16)	2	
14	43114-88L00	WASHER, SWIVEL TO CLAMP BRKT	2	
15	09160-39003	WASHER (39.5X58X0.3)	2	
16	09282-39001	OIL SEAL (39X51X5)	1	
17	09160-39002	WASHER (39.5X58X1)	2	
18	09380-38003	CIRCLIP	1	
19	43755-88L00	ATTACHMENT, STEERING BRKT	1	
20	09108-10161	STUD BOLT	2	
21	09159-10050	NUT	2	
22	09160-10141	WASHER (10.5X19X2)	2	
23	41221-88L00	LEVER, TILT LOCK STBD	1	
24	41280-88L10	LEVER, TILT LOCK PORT	1	
25	41224-88L00	BUSH, TILT LOCK LEVER	2	
26	29141-93J00	NUT, TILT LOCK LEVER STBD	1	
27	41231-88L01	LINK, TILT LOCK LEVER	1	
28	41234-88L00	ARM, TILT LOCK LINK	1	
29	45731-96312	BRACKET, SPRING	1	
30	09125-06063	SCREW (6X10)	1	
31	09443-10043	SPRING	1	

FIG.336E




FIG.336E (1-G-15) SWIVEL BRACKET (DF60AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	43111-88L50-YAY	BRACKET, SWIVEL (S) (BLACK)	1	
2	43211-88L00	BUSH, SWIVEL BRACKET	2	
3	43711-97E01	BUSH, STEERING	2	
4	43750-88L32-YAY	BRACKET, STEERING (S) (BLACK)	1	
5	22511-99011	NIPPLE, GREASE	4	
6	36894-87D00	LEAD (CLAMP TO SWIVEL)	1	
7	36895-87D01	LEAD (SWIVEL TO MOUNT BRKT)	1	
8	36895-87D01	LEAD (SWIVEL TO HOUSING)	1	
9	09125-06063	SCREW (6X10)	4	
10	09125-05050	SCREW (5X8)	1	
11	43119-88L00	PLATE, SWIVEL BRKT LOWER STBD	1	
12	43119-88L10	PLATE, SWIVEL BRKT LOWER PORT	1	
13	09125-06067	SCREW (6X16)	2	
14	43114-88L00	WASHER, SWIVEL TO CLAMP BRKT	2	
15	09160-39003	WASHER (39.5X58X0.3)	2	
16	09282-39001	OIL SEAL (39X51X5)	1	
17	09160-39002	WASHER (39.5X58X1)	2	
18	09380-38003	CIRCLIP	1	
19	43755-88L00	ATTACHMENT, STEERING BRKT	1	
20	09108-10161	STUD BOLT	2	
21	09159-10050	NUT	2	
22	09160-10141	WASHER (10.5X19X2)	2	
23	41221-88L00	LEVER, TILT LOCK STBD	1	
24	41280-88L10	LEVER, TILT LOCK PORT	1	
25	41224-88L00	BUSH, TILT LOCK LEVER	2	
26	29141-93J00	NUT, TILT LOCK LEVER STBD	1	
27	41231-88L01	LINK, TILT LOCK LEVER	1	
28	41234-88L00	ARM, TILT LOCK LINK	1	
29	45731-96312	BRACKET, SPRING	1	
30	09125-06063	SCREW (6X10)	1	
31	09443-10043	SPRING	1	

FIG.337A




FIG.337A (1-H-2) TRIM CYLINDER (DF40A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-88L15	TRIM ASSY, POWER WITH TILT	1	
2	29404-93J10	.CLAMP	1	
3	38100-88L11	.MOTOR ASSY, PTT	1	
4	48320-87J10	.VALVE, UPPER PRESSURE	1	
5	48330-87J10	.VALVE, DOWN PRESSURE	1	
6	48510-97E00	.PUMP ASSY, GEAR	1	
7	48541-87J10	.BOLT	2	
8	48541-87J20	.BOLT	1	
9	48551-88L00	.VALVE, MANUAL	1	
10	48553-88L00	.SEAL WASHER	1	
11	48557-87J10	.O RING SET	1	
12	48571-88L00	.TANK, RESERVOIR	1	
13	48572-87L00	.PLUG	1	
14	48582-97E01	.FILTER	1	
15	48583-87J10	.JOINT, DRIVE	1	
16	48611-88L00	.JOINT, METAL	1	
17	48681-87J11	.CIRCLIP	1	
18	48862-87J20	.BOLT, TANK	4	
19	47225-87J00	COLLAR, TILT CYLINDER LOWER	1	
20	48121-89J10	SHAFT, TILT CYL LOWER	1	
21	48321-89J11	SHAFT, TILT CYL UPPER	1	
22	48325-89J00	BUSH, TILT CYL UPPER	2	
23	48326-87J00	BUSH, TILT CYL LOWER	1	
24	09380-12002	SNAP RING	2	
25	09116-10179	BOLT	2	
26	55321-87J01	ANODE, PROTECTION	1	
27	09103-06281	BOLT (6X14)	1	
28	09160-10139	WASHER (10.5X35X3)	2	

DF60A_E03_017_337A
TRIM CYLINDER

FIG.337B




FIG.337B (1-H-3) TRIM CYLINDER (DF50A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-88L15	TRIM ASSY, POWER WITH TILT	1	
2	29404-93J10	.CLAMP	1	
3	38100-88L11	.MOTOR ASSY, PTT	1	
4	48320-87J10	.VALVE, UPPER PRESSURE	1	
5	48330-87J10	.VALVE, DOWN PRESSURE	1	
6	48510-97E00	.PUMP ASSY, GEAR	1	
7	48541-87J10	.BOLT	2	
8	48541-87J20	.BOLT	1	
9	48551-88L00	.VALVE, MANUAL	1	
10	48553-88L00	.SEAL WASHER	1	
11	48557-87J10	.O RING SET	1	
12	48571-88L00	.TANK, RESERVOIR	1	
13	48572-87L00	.PLUG	1	
14	48582-97E01	.FILTER	1	
15	48583-87J10	.JOINT, DRIVE	1	
16	48611-88L00	.JOINT, METAL	1	
17	48681-87J11	.CIRCLIP	1	
18	48862-87J20	.BOLT, TANK	4	
19	47225-87J00	COLLAR, TILT CYLINDER LOWER	1	
20	48121-89J10	SHAFT, TILT CYL LOWER	1	
21	48321-89J11	SHAFT, TILT CYL UPPER	1	
22	48325-89J00	BUSH, TILT CYL UPPER	2	
23	48326-87J00	BUSH, TILT CYL LOWER	1	
24	09380-12002	SNAP RING	2	
25	09116-10179	BOLT	2	
26	55321-87J01	ANODE, PROTECTION	1	
27	09103-06281	BOLT (6X14)	1	
28	09160-10139	WASHER (10.5X35X3)	2	

DF60A_E03_017_337B
TRIM CYLINDER

FIG.337C




FIG.337C (1-H-4) TRIM CYLINDER (DF60A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-88L15	TRIM ASSY, POWER WITH TILT	1	
2	29404-93J10	.CLAMP	1	
3	38100-88L11	.MOTOR ASSY, PTT	1	
4	48320-87J10	.VALVE, UPPER PRESSURE	1	
5	48330-87J10	.VALVE, DOWN PRESSURE	1	
6	48510-97E00	.PUMP ASSY, GEAR	1	
7	48541-87J10	.BOLT	2	
8	48541-87J20	.BOLT	1	
9	48551-88L00	.VALVE, MANUAL	1	
10	48553-88L00	.SEAL WASHER	1	
11	48557-87J10	.O RING SET	1	
12	48571-88L00	.TANK, RESERVOIR	1	
13	48572-87L00	.PLUG	1	
14	48582-97E01	.FILTER	1	
15	48583-87J10	.JOINT, DRIVE	1	
16	48611-88L00	.JOINT, METAL	1	
17	48681-87J11	.CIRCLIP	1	
18	48862-87J20	.BOLT, TANK	4	
19	47225-88L00	COLLAR, TILT CYLINDER LOWER	1	
20	48121-88L00	SHAFT, TILT CYL LOWER	1	
21	48321-89J11	SHAFT, TILT CYL UPPER	1	
22	48325-89J00	BUSH, TILT CYL UPPER	2	
23	48326-87J00	BUSH, TILT CYL LOWER	1	
24	09380-12002	SNAP RING	2	
25	09116-10179	BOLT	2	
26	55321-87J01	ANODE, PROTECTION	1	
27	09103-06281	BOLT (6X14)	1	

DF60A_E03_017_337C
TRIM CYLINDER

FIG.337D




FIG.337D (1-H-5) TRIM CYLINDER (DF50AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-88L20	TRIM ASSY, POWER WITH TILT	1	
2	29404-93J10	.CLAMP	1	
3	38100-88L11	.MOTOR ASSY, PTT	1	
4	48320-87J10	.VALVE, UPPER PRESSURE	1	
5	48330-87J20	.VALVE, DOWN PRESSURE	1	
6	48510-97E10	.PUMP ASSY, GEAR	1	
7	48541-87J20	.BOLT	3	
8	48551-88L10	.VALVE, MANUAL	1	
9	48553-88L00	.SEAL WASHER	1	
10	48557-87J10	.O RING SET	1	
11	48571-88L00	.TANK, RESERVOIR	1	
12	48572-87L00	.PLUG	1	
13	48583-87J10	.JOINT, DRIVE	1	
14	48611-88L00	.JOINT, METAL	1	
15	48681-87J11	.CIRCLIP	1	
16	48862-87J20	.BOLT, TANK	4	
17	47225-88L00	COLLAR, TILT CYLINDER LOWER	1	
18	48121-88L10	SHAFT, TILT CYL LOWER	1	
19	48321-89J20	SHAFT, TILT CYL UPPER	1	
20	48325-89J10	BUSH, TILT CYL UPPER	2	
21	48326-87J00	BUSH, TILT CYL LOWER	1	
22	09380-12002	SNAP RING	2	
23	09116-10179	BOLT	2	
24	55321-87J01	ANODE, PROTECTION	1	
25	09103-06281	BOLT (6X14)	1	

FIG.337E




FIG.337E (1-H-6) TRIM CYLINDER (DF60AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-88L20	TRIM ASSY, POWER WITH TILT	1	
2	29404-93J10	.CLAMP	1	
3	38100-88L11	.MOTOR ASSY, PTT	1	
4	48320-87J10	.VALVE, UPPER PRESSURE	1	
5	48330-87J20	.VALVE, DOWN PRESSURE	1	
6	48510-97E10	.PUMP ASSY, GEAR	1	
7	48541-87J20	.BOLT	3	
8	48551-88L10	.VALVE, MANUAL	1	
9	48553-88L00	.SEAL WASHER	1	
10	48557-87J10	.O RING SET	1	
11	48571-88L00	.TANK, RESERVOIR	1	
12	48572-87L00	.PLUG	1	
13	48583-87J10	.JOINT, DRIVE	1	
14	48611-88L00	.JOINT, METAL	1	
15	48681-87J11	.CIRCLIP	1	
16	48862-87J20	.BOLT, TANK	4	
17	47225-88L00	COLLAR, TILT CYLINDER LOWER	1	
18	48121-88L10	SHAFT, TILT CYL LOWER	1	
19	48321-89J20	SHAFT, TILT CYL UPPER	1	
20	48325-89J10	BUSH, TILT CYL UPPER	2	
21	48326-87J00	BUSH, TILT CYL LOWER	1	
22	09380-12002	SNAP RING	2	
23	09116-10179	BOLT	2	
24	55321-87J01	ANODE, PROTECTION	1	
25	09103-06281	BOLT (6X14)	1	

DF60A_E03_017_337E
TRIM CYLINDER

FIG.340A




FIG.340A (1-H-7) PTT MOTOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-88L11	MOTOR ASSY, PTT	1	
2	31311-87J10	.ARMATURE	1	
3	31173-88L11	.HOLDER ASSY, BRUSH	1	
4	31123-97E10	..O RING	1	
5	31133-94900	..BRUSH	1	
6	31135-94900	..SPRING	2	
7	31136-87J10	..BREAKER ASSY	1	
8	33799-97E00	..SEAL, OIL	1	
9	31111-87J10	.SCREW	3	

DF60A_E03_017_340A
PTT MOTOR

FIG.401A




FIG.401A (1-H-8) ENGINE HOLDER (DF40A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	51110-88L10-YAY	HOLDER, ENGINE (BLACK)	1	
1-2	51110-88L10-Y5S	HOLDER, ENGINE (WHITE)	1	
2	51211-88L00	GASKET, ENGINE HOLDER	1	
3	09116-08159	BOLT (8X55)	8	
4	01550-0845A	BOLT	1	
5	01550-0885A	BOLT	1	
6	09202-08006	PIN (8X12)	2	
7	09202-08006	PIN (8X12)	2	
8	51122-88L00	COVER, MOUNT CASE	1	
9	51123-88L00	GASKET, MOUNT CASE COVER	1	
10	01550-0825A	BOLT	6	
11	09202-08006	PIN (8X12)	2	
12	54137-88L00	COVER, UPPER MOUNT	1	
13	09116-10176	BOLT (10X44)	3	
14	51170-88L00	BRACKET, WATER INDICATOR	1	
15	29116-93J00	BOLT, WATER INDICATOR UNION	1	
16	09282-17011	OIL SEAL (16.5X28X6)	2	
17	54124-88L20	BRACKET, UPPER THRUST	1	
18	54130-88L00	MOUNT, UPPER	2	
19	54166-95J02	BOLT, UPPER MOUNT	2	
20	54114-90J01	WASHER, UPPER MOUNT BOLT (12.5X22X3)	2	
21	09159-12014	NUT	2	
22	54114-90J01	WASHER, UPPER THRUST MOUNT NUT (12.5X22X3)	2	
23	54121-88L00	MOUNT, UPPER THRUST FR	2	
24	54123-88L00	MOUNT, UPPER THRUST RR	1	

FIG.401B




FIG.401B (1-H-9) ENGINE HOLDER (DF50A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	51110-88L10-YAY	HOLDER, ENGINE (BLACK)	1	
1-2	51110-88L10-Y5S	HOLDER, ENGINE (WHITE)	1	
2	51211-88L00	GASKET, ENGINE HOLDER	1	
3	09116-08159	BOLT (8X55)	8	
4	01550-0845A	BOLT	1	
5	01550-0885A	BOLT	1	
6	09202-08006	PIN (8X12)	2	
7	09202-08006	PIN (8X12)	2	
8	51122-88L00	COVER, MOUNT CASE	1	
9	51123-88L00	GASKET, MOUNT CASE COVER	1	
10	01550-0825A	BOLT	6	
11	09202-08006	PIN (8X12)	2	
12	54137-88L00	COVER, UPPER MOUNT	1	
13	09116-10176	BOLT (10X44)	3	
14	51170-88L00	BRACKET, WATER INDICATOR	1	
15	29116-93J00	BOLT, WATER INDICATOR UNION	1	
16	09282-17011	OIL SEAL (16.5X28X6)	2	
17	54124-88L20	BRACKET, UPPER THRUST	1	
18	54130-88L00	MOUNT, UPPER	2	
19	54166-95J02	BOLT, UPPER MOUNT	2	
20	54114-90J01	WASHER, UPPER MOUNT BOLT (12.5X22X3)	2	
21	09159-12014	NUT	2	
22	54114-90J01	WASHER, UPPER THRUST MOUNT NUT (12.5X22X3)	2	
23	54121-88L00	MOUNT, UPPER THRUST FR	2	
24	54123-88L00	MOUNT, UPPER THRUST RR	1	

FIG.401C




FIG.401C (1-H-10) ENGINE HOLDER (DF60A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	51110-88L10-YAY	HOLDER, ENGINE (BLACK)	1	
1-2	51110-88L10-Y5S	HOLDER, ENGINE (WHITE)	1	
2	51211-88L00	GASKET, ENGINE HOLDER	1	
3	09116-08159	BOLT (8X55)	8	
4	01550-0845A	BOLT	1	
5	01550-0885A	BOLT	1	
6	09202-08006	PIN (8X12)	2	
7	09202-08006	PIN (8X12)	2	
8	51122-88L00	COVER, MOUNT CASE	1	
9	51123-88L00	GASKET, MOUNT CASE COVER	1	
10	01550-0825A	BOLT	6	
11	09202-08006	PIN (8X12)	2	
12	54137-88L00	COVER, UPPER MOUNT	1	
13	09116-10176	BOLT (10X44)	3	
14	51170-88L00	BRACKET, WATER INDICATOR	1	
15	29116-93J00	BOLT, WATER INDICATOR UNION	1	
16	09282-17011	OIL SEAL (16.5X28X6)	2	
17	54124-88L20	BRACKET, UPPER THRUST	1	
18	54130-88L00	MOUNT, UPPER	2	
19	54166-95J02	BOLT, UPPER MOUNT	2	
20	54114-90J01	WASHER, UPPER MOUNT BOLT (12.5X22X3)	2	
21	09159-12014	NUT	2	
22	54114-90J01	WASHER, UPPER THRUST MOUNT NUT (12.5X22X3)	2	
23	54121-88L00	MOUNT, UPPER THRUST FR	2	
24	54123-88L00	MOUNT, UPPER THRUST RR	1	

FIG.401D




FIG.401D (1-H-11) ENGINE HOLDER (DF50AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	51110-88L10-YAY	HOLDER, ENGINE (BLACK)	1	
2	51211-88L00	GASKET, ENGINE HOLDER	1	
3	09116-08159	BOLT (8X55)	8	
4	01550-0845A	BOLT	1	
5	01550-0885A	BOLT	1	
6	09202-08006	PIN (8X12)	2	
7	09202-08006	PIN (8X12)	2	
8	51122-88L00	COVER, MOUNT CASE	1	
9	51123-88L00	GASKET, MOUNT CASE COVER	1	
10	01550-0825A	BOLT	6	
11	09202-08006	PIN (8X12)	2	
12	54137-88L00	COVER, UPPER MOUNT	1	
13	09116-10176	BOLT (10X44)	3	
14	51170-88L00	BRACKET, WATER INDICATOR	1	
15	29116-93J00	BOLT, WATER INDICATOR UNION	1	
16	09282-17011	OIL SEAL (16.5X28X6)	2	
17	54120-88L00	MOUNT, UPPER THRUST F	1	
18	54130-88L00	MOUNT, UPPER	2	
19	54166-95J02	BOLT, UPPER MOUNT	2	
20	54114-90J01	WASHER, UPPER MOUNT BOLT (12.5X22X3)	2	
21	09159-12014	NUT	2	
22	54114-90J01	WASHER, UPPER THRUST MOUNT NUT (12.5X22X3)	2	

FIG.401E




FIG.401E (1-H-12) ENGINE HOLDER (DF60AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	51110-88L10-YAY	HOLDER, ENGINE (BLACK)	1	
2	51211-88L00	GASKET, ENGINE HOLDER	1	
3	09116-08159	BOLT (8X55)	8	
4	01550-0845A	BOLT	1	
5	01550-0885A	BOLT	1	
6	09202-08006	PIN (8X12)	2	
7	09202-08006	PIN (8X12)	2	
8	51122-88L00	COVER, MOUNT CASE	1	
9	51123-88L00	GASKET, MOUNT CASE COVER	1	
10	01550-0825A	BOLT	6	
11	09202-08006	PIN (8X12)	2	
12	54137-88L00	COVER, UPPER MOUNT	1	
13	09116-10176	BOLT (10X44)	3	
14	51170-88L00	BRACKET, WATER INDICATOR	1	
15	29116-93J00	BOLT, WATER INDICATOR UNION	1	
16	09282-17011	OIL SEAL (16.5X28X6)	2	
17	54120-88L00	MOUNT, UPPER THRUST F	1	
18	54130-88L00	MOUNT, UPPER	2	
19	54166-95J02	BOLT, UPPER MOUNT	2	
20	54114-90J01	WASHER, UPPER MOUNT BOLT (12.5X22X3)	2	
21	09159-12014	NUT	2	
22	54114-90J01	WASHER, UPPER THRUST MOUNT NUT (12.5X22X3)	2	

FIG.405A




FIG.405A (1-H-13) DRIVE SHAFT HOUSING (DF40A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	52111-88L10-YAY	HOUSING, DRIVE SHAFT (L) (BLACK)	1	
1-2	52111-88L10-Y5S	HOUSING, DRIVE SHAFT (L) (WHITE)	1	
2	09116-10176	BOLT (10X44)	8	
3	09202-08006	PIN (8X12)	2	
4-1	54221-88L20-YAY	COVER, LOWER MOUNT STBD (BLACK)	1	
4-2	54221-88L20-Y5S	COVER, LOWER MOUNT STBD (WHITE)	1	
5-1	54231-88L10-YAY	COVER, LOWER MOUNT PORT (BLACK)	1	
5-2	54231-88L10-Y5S	COVER, LOWER MOUNT PORT (WHITE)	1	
6	09116-10176	BOLT (10X44)	4	
7-1	54211-87J30-YAY	BRACKET, LOWER MOUNT (BLACK)	1	
7-2	54211-87J30-Y5S	BRACKET, LOWER MOUNT (WHITE)	1	
8	54151-88L00	MOUNT, LOWER THRUST	1	
9	54160-88L10	MOUNT, LOWER	2	
10	54167-87L01	MOUNT, LOWER SIDE	2	
11	54180-88L00	DAMPER, FWD STOPPER	2	
12	54166-95J02	BOLT, LOWER MOUNT	2	
13	09159-12014	NUT	2	
14	54114-90J01	WASHER, LOWER MOUNT NUT (12.5X22X3)	2	

FIG.405B




FIG.405B (1-H-14) DRIVE SHAFT HOUSING (DF50A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	52111-88L10-YAY	HOUSING, DRIVE SHAFT (L) (BLACK)	1	
1-2	52111-88L10-Y5S	HOUSING, DRIVE SHAFT (L) (WHITE)	1	
2	09116-10176	BOLT (10X44)	8	
3	09202-08006	PIN (8X12)	2	
4-1	54221-88L20-YAY	COVER, LOWER MOUNT STBD (BLACK)	1	
4-2	54221-88L20-Y5S	COVER, LOWER MOUNT STBD (WHITE)	1	
5-1	54231-88L10-YAY	COVER, LOWER MOUNT PORT (BLACK)	1	
5-2	54231-88L10-Y5S	COVER, LOWER MOUNT PORT (WHITE)	1	
6	09116-10176	BOLT (10X44)	4	
7-1	54211-87J30-YAY	BRACKET, LOWER MOUNT (BLACK)	1	
7-2	54211-87J30-Y5S	BRACKET, LOWER MOUNT (WHITE)	1	
8	54151-88L00	MOUNT, LOWER THRUST	1	
9	54160-88L10	MOUNT, LOWER	2	
10	54167-87L01	MOUNT, LOWER SIDE	2	
11	54180-88L00	DAMPER, FWD STOPPER	2	
12	54166-95J02	BOLT, LOWER MOUNT	2	
13	09159-12014	NUT	2	
14	54114-90J01	WASHER, LOWER MOUNT NUT (12.5X22X3)	2	

FIG.405C




FIG.405C (1-H-15) DRIVE SHAFT HOUSING (DF60A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	52111-88L10-YAY	HOUSING, DRIVE SHAFT (L) (BLACK)	1	
1-2	52111-88L10-Y5S	HOUSING, DRIVE SHAFT (L) (WHITE)	1	
2	09116-10176	BOLT (10X44)	8	
3	09202-08006	PIN (8X12)	2	
4-1	54221-88L20-YAY	COVER, LOWER MOUNT STBD (BLACK)	1	
4-2	54221-88L20-Y5S	COVER, LOWER MOUNT STBD (WHITE)	1	
5-1	54231-88L10-YAY	COVER, LOWER MOUNT PORT (BLACK)	1	
5-2	54231-88L10-Y5S	COVER, LOWER MOUNT PORT (WHITE)	1	
6	09116-10176	BOLT (10X44)	4	
7-1	54211-87J30-YAY	BRACKET, LOWER MOUNT (BLACK)	1	
7-2	54211-87J30-Y5S	BRACKET, LOWER MOUNT (WHITE)	1	
8	54151-88L00	MOUNT, LOWER THRUST	1	
9	54160-88L10	MOUNT, LOWER	2	
10	54167-87L01	MOUNT, LOWER SIDE	2	
11	54180-88L00	DAMPER, FWD STOPPER	2	
12	54166-95J02	BOLT, LOWER MOUNT	2	
13	09159-12014	NUT	2	
14	54114-90J01	WASHER, LOWER MOUNT NUT (12.5X22X3)	2	

FIG.405D




FIG.405D (1-I-2) DRIVE SHAFT HOUSING (DF50AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	52111-88L20-YAY	HOUSING, DRIVE SHAFT (S) (BLACK)	1	
2	09116-10176	BOLT (10X44)	8	
3	09202-08006	PIN (8X12)	2	
4	54221-88L20-YAY	COVER, LOWER MOUNT STBD (BLACK)	1	
5	54231-88L10-YAY	COVER, LOWER MOUNT PORT (BLACK)	1	
6	09116-10176	BOLT (10X44)	4	
7	52131-88L11-YAY	CASE, EXTENSION (BLACK)	1	
8	09116-08131	BOLT (8X45)	4	
9	09116-10150	BOLT (10X55)	2	
10	09202-06031	PIN (6X12)	2	
11	55321-87J01	ANODE, PROTECTION	1	
12	09103-06281	BOLT (6X14)	1	
13	54211-87J30-YAY	BRACKET, LOWER MOUNT (BLACK)	1	
14	54151-88L00	MOUNT, LOWER THRUST	1	
15	54160-88L10	MOUNT, LOWER	2	
16	54167-87L01	MOUNT, LOWER SIDE	2	
17	54180-88L00	DAMPER, FWD STOPPER	2	
18	54166-95J02	BOLT, LOWER MOUNT	2	
19	09159-12014	NUT	2	
20	54114-90J01	WASHER, LOWER MOUNT NUT (12.5X22X3)	2	

FIG.405E




FIG.405E (1-I-3) DRIVE SHAFT HOUSING (DF60AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	52111-88L20-YAY	HOUSING, DRIVE SHAFT (S) (BLACK)	1	
2	09116-10176	BOLT (10X44)	8	
3	09202-08006	PIN (8X12)	2	
4	54221-88L20-YAY	COVER, LOWER MOUNT STBD (BLACK)	1	
5	54231-88L10-YAY	COVER, LOWER MOUNT PORT (BLACK)	1	
6	09116-10176	BOLT (10X44)	4	
7	52131-88L11-YAY	CASE, EXTENSION (BLACK)	1	
8	09116-08131	BOLT (8X45)	4	
9	09116-10150	BOLT (10X55)	2	
10	09202-06031	PIN (6X12)	2	
11	55321-87J01	ANODE, PROTECTION	1	
12	09103-06281	BOLT (6X14)	1	
13	54211-87J30-YAY	BRACKET, LOWER MOUNT (BLACK)	1	
14	54151-88L00	MOUNT, LOWER THRUST	1	
15	54160-88L10	MOUNT, LOWER	2	
16	54167-87L01	MOUNT, LOWER SIDE	2	
17	54180-88L00	DAMPER, FWD STOPPER	2	
18	54166-95J02	BOLT, LOWER MOUNT	2	
19	09159-12014	NUT	2	
20	54114-90J01	WASHER, LOWER MOUNT NUT (12.5X22X3)	2	

FIG.407A




FIG.407A (1-I-4) GEAR CASE (DF40A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55100-87J50-YAY	CASE ASSY, GEAR (BLACK)	1	
1-2	55100-87J50-Y5S	CASE ASSY, GEAR (WHITE)	1	
2	09263-22039	.BEARING (22X30X30)	1	
3	09265-30004	.BEARING (30X62X17.25)	1	
4	55125-94400	TAB, TRIM	1	
5	09117-08109	BOLT (8X16)	1	
6	09248-10008	PLUG (10X7.5)	3	
7	09168-10022	GASKET (10X17X1.5)	3	
8	09116-08131	BOLT (8X45)	6	
9-1	58100-88L03-019	PROPELLER (3X11-1/2X9) (BLACK)	1	
9-2	58100-88L13-019	PROPELLER (3X11-1/2X10) (BLACK)	1	
9-3	58100-88L23-019	PROPELLER (3X11-1/2X11) (BLACK)	1	
9-4	58100-88LA0-019	PROPELLER (3X11-5/8X12) (BLACK)	1	
9-5	58100-88LB0-019	PROPELLER (3X11-1/2X13) (BLACK)	1	
9-6	58100-88L52-019	PROPELLER (3X11-3/8X14) (BLACK)	1	
9-7	58100-88L62-019	PROPELLER (3X11-1/4X15) (BLACK)	1	
9-8	58100-88L72-019	PROPELLER (3X11-1/8X16) (BLACK)	1	
9-9	58100-88L83-019	PROPELLER (3X11X17) (BLACK)	1	
9-10	58200-88L30	PROPELLER (3X11-1/2X16)	1	OPT
10	58120-88L01	.BUSH, PROPELLER	1	
11	57632-95320	STOPPER, PROPELLER BUSH	1	
12	57633-94300	SPACER, PROPELLER NUT	1	
13	09141-18005	NUT	1	
14	09204-03003	COTTER PIN (D:3.6,L:25)	1	
15	09160-18028	WASHER (18.5X31X1)	1	

FIG.407A




FIG.407A (1-I-5) GEAR CASE (DF40A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
16	57630-94300	KIT, PROPELLER NUT	1	OPT
17	55181-95200	ATTACHMENT, FLUSH HOSE	1	OPT
18	55300-95500	ZINK ASSY, PROTECTION	1	OPT
19	55321-87J11	ANODE (MAGNESIUM)	1	OPT
20	25700-88L00	SEALING KIT, GEAR CASE	1	OPT
				NOT ILLUSTRATED

FIG.407B




FIG.407B (1-I-6) GEAR CASE (DF50A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55100-87J50-YAY	CASE ASSY, GEAR (BLACK)	1	
1-2	55100-87J50-Y5S	CASE ASSY, GEAR (WHITE)	1	
2	09263-22039	.BEARING (22X30X30)	1	
3	09265-30004	.BEARING (30X62X17.25)	1	
4	55125-94400	TAB, TRIM	1	
5	09117-08109	BOLT (8X16)	1	
6	09248-10008	PLUG (10X7.5)	3	
7	09168-10022	GASKET (10X17X1.5)	3	
8	09116-08131	BOLT (8X45)	6	
9-1	58100-88L03-019	PROPELLER (3X11-1/2X9) (BLACK)	1	
9-2	58100-88L13-019	PROPELLER (3X11-1/2X10) (BLACK)	1	
9-3	58100-88L23-019	PROPELLER (3X11-1/2X11) (BLACK)	1	
9-4	58100-88LA0-019	PROPELLER (3X11-5/8X12) (BLACK)	1	
9-5	58100-88LB0-019	PROPELLER (3X11-1/2X13) (BLACK)	1	
9-6	58100-88L52-019	PROPELLER (3X11-3/8X14) (BLACK)	1	
9-7	58100-88L62-019	PROPELLER (3X11-1/4X15) (BLACK)	1	
9-8	58100-88L72-019	PROPELLER (3X11-1/8X16) (BLACK)	1	
9-9	58100-88L83-019	PROPELLER (3X11X17) (BLACK)	1	
9-10	58200-88L30	PROPELLER (3X11-1/2X16)	1	OPT
10	58120-88L01	.BUSH, PROPELLER	1	
11	57632-95320	STOPPER, PROPELLER BUSH	1	
12	57633-94300	SPACER, PROPELLER NUT	1	
13	09141-18005	NUT	1	
14	09204-03003	COTTER PIN (D:3.6,L:25)	1	
15	09160-18028	WASHER (18.5X31X1)	1	

FIG.407B




FIG.407B (1-I-7) GEAR CASE (DF50A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
16	57630-94300	KIT, PROPELLER NUT	1	OPT
17	55181-95200	ATTACHMENT, FLUSH HOSE	1	OPT
18	55300-95500	ZINK ASSY, PROTECTION	1	OPT
19	55321-87J11	ANODE (MAGNESIUM)	1	OPT
20	25700-88L00	SEALING KIT, GEAR CASE	1	OPT
				NOT ILLUSTRATED

FIG.407C




FIG.407C (1-I-8) GEAR CASE (DF60A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55100-87J50-YAY	CASE ASSY, GEAR (BLACK)	1	
1-2	55100-87J50-Y5S	CASE ASSY, GEAR (WHITE)	1	
2	09263-22039	.BEARING (22X30X30)	1	
3	09265-30004	.BEARING (30X62X17.25)	1	
4	55125-94400	TAB, TRIM	1	
5	09117-08109	BOLT (8X16)	1	
6	09248-10008	PLUG (10X7.5)	3	
7	09168-10022	GASKET (10X17X1.5)	3	
8	09116-08131	BOLT (8X45)	6	
9-1	58100-88L03-019	PROPELLER (3X11-1/2X9) (BLACK)	1	
9-2	58100-88L13-019	PROPELLER (3X11-1/2X10) (BLACK)	1	
9-3	58100-88L23-019	PROPELLER (3X11-1/2X11) (BLACK)	1	
9-4	58100-88LA0-019	PROPELLER (3X11-5/8X12) (BLACK)	1	
9-5	58100-88LB0-019	PROPELLER (3X11-1/2X13) (BLACK)	1	
9-6	58100-88L52-019	PROPELLER (3X11-3/8X14) (BLACK)	1	
9-7	58100-88L62-019	PROPELLER (3X11-1/4X15) (BLACK)	1	
9-8	58100-88L72-019	PROPELLER (3X11-1/8X16) (BLACK)	1	
9-9	58100-88L83-019	PROPELLER (3X11X17) (BLACK)	1	
9-10	58200-88L30	PROPELLER (3X11-1/2X16)	1	OPT
10	58120-88L01	.BUSH, PROPELLER	1	
11	57632-95320	STOPPER, PROPELLER BUSH	1	
12	57633-94300	SPACER, PROPELLER NUT	1	
13	09141-18005	NUT	1	
14	09204-03003	COTTER PIN (D:3.6,L:25)	1	
15	09160-18028	WASHER (18.5X31X1)	1	

FIG.407C




FIG.407C (1-I-9) GEAR CASE (DF60A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
16	57630-94300	KIT, PROPELLER NUT	1	OPT
17	55181-95200	ATTACHMENT, FLUSH HOSE	1	OPT
18	55300-95500	ZINK ASSY, PROTECTION	1	OPT
19	55321-87J11	ANODE (MAGNESIUM)	1	OPT
20	25700-88L00	SEALING KIT, GEAR CASE	1	OPT
				NOT ILLUSTRATED

FIG.407D




FIG.407D (1-I-10) GEAR CASE (DF50AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	55110-90J15-YAY	CASE, GEAR (BLACK)	1	
2	09263-28016	.BEARING (28.6X38X31.8)	1	
3	55125-90J01	TAB, TRIM	1	
4	55127-87D00	UNION, SPEEDOMETER HOSE	1	
5	55321-90J01	ANODE, GEAR CASE	1	
6	55332-87D11	RUBBER, EXHAUST SEAL	1	
7	55333-87D10	PLATE, EXHAUST SEAL	1	
8	09100-06131	BOLT (6X12)	1	
9	09116-08137	BOLT (8X22)	1	
10	09116-10150	BOLT (10X55)	6	
11	09117-10039	BOLT (10X80)	1	
12	09160-06085	WASHER (6.5X15X1)	1	
13	09168-10022	GASKET (10X17X1.5)	2	
14	09202-08006	PIN (8X12)	2	
15	09248-10008	PLUG (10X7.5)	2	
16	09355-40805-600	HOSE (4X8X600)	1	L:600->70
17	09362-09008	UNION	1	
18	09407-10404	CLAMP (L:100)	2	
19-1	58100-87LA0-019	PROPELLER (3X14X13) (BLACK)	1	
19-2	58100-87LB0-019	PROPELLER (3X13.875X15) (BLACK)	1	
19-3	58100-87LC0-019	PROPELLER (3X13.75X17) (BLACK)	1	
19-4	58100-87LJ0-019	PROPELLER (3X13.75X12) (BLACK)	1	
19-5	58100-87LH0-019	PROPELLER (3X14X11) (BALCK)	1	
19-6	58100-87LG1-019	PROPELLER (3X14X9) (BALCK)	1	
20	58105-90J00	.BUSH	1	
21	57633-90J02	SPACER, PROPELLER NUT	1	
22	57635-90J01	STOPPER, PROPELLER BUSH	1	
23	09141-18005	NUT	1	
24	09160-18028	WASHER (18.5X31X1)	1	
25	09204-03003	COTTER PIN (D:3.6,L:25)	1	
26	57630-90J00	KIT, PROPELLER NUT	1	OPT
27	55300-95500	ZINK ASSY, PROTECTION	1	OPT
28	55181-95200	ATTACHMENT, FLUSH HOSE	1	OPT

DF60A_E03_017_407D
GEAR CASE

FIG.407D




FIG.407D (1-I-11) GEAR CASE (DF50AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	56145-99E01	HOUSING, SHIFT CAM	1	
30	09206-09012	PIN (7.4X9X10)	2	
31	01550-06307	BOLT	3	
32	25700-99E00	SEALING KIT, GEAR CASE	1	OPT
				NOT ILLUSTRATED

DF60A_E03_017_407D
GEAR CASE

FIG.407E




FIG.407E (1-I-12) GEAR CASE (DF60AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	55110-90J15-YAY	CASE, GEAR (BLACK)	1	
2	09263-28016	.BEARING (28.6X38X31.8)	1	
3	55125-90J01	TAB, TRIM	1	
4	55127-87D00	UNION, SPEEDOMETER HOSE	1	
5	55321-90J01	ANODE, GEAR CASE	1	
6	55332-87D11	RUBBER, EXHAUST SEAL	1	
7	55333-87D10	PLATE, EXHAUST SEAL	1	
8	09100-06131	BOLT (6X12)	1	
9	09116-08137	BOLT (8X22)	1	
10	09116-10150	BOLT (10X55)	6	
11	09117-10039	BOLT (10X80)	1	
12	09160-06085	WASHER (6.5X15X1)	1	
13	09168-10022	GASKET (10X17X1.5)	2	
14	09202-08006	PIN (8X12)	2	
15	09248-10008	PLUG (10X7.5)	2	
16	09355-40805-600	HOSE (4X8X600)	1	L:600->70
17	09362-09008	UNION	1	
18	09407-10404	CLAMP (L:100)	2	
19-1	58100-87LA0-019	PROPELLER (3X14X13) (BLACK)	1	
19-2	58100-87LB0-019	PROPELLER (3X13.875X15) (BLACK)	1	
19-3	58100-87LC0-019	PROPELLER (3X13.75X17) (BLACK)	1	
19-4	58100-87LJ0-019	PROPELLER (3X13.75X12) (BLACK)	1	
19-5	58100-87LH0-019	PROPELLER (3X14X11) (BALCK)	1	
19-6	58100-87LG1-019	PROPELLER (3X14X9) (BALCK)	1	
20	58105-90J00	.BUSH	1	
21	57633-90J02	SPACER, PROPELLER NUT	1	
22	57635-90J01	STOPPER, PROPELLER BUSH	1	
23	09141-18005	NUT	1	
24	09160-18028	WASHER (18.5X31X1)	1	
25	09204-03003	COTTER PIN (D:3.6,L:25)	1	
26	57630-90J00	KIT, PROPELLER NUT	1	OPT
27	55300-95500	ZINK ASSY, PROTECTION	1	OPT
28	55181-95200	ATTACHMENT, FLUSH HOSE	1	OPT

DF60A_E03_017_407E
GEAR CASE

FIG.407E




FIG.407E (1-I-13) GEAR CASE (DF60AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	56145-99E01	HOUSING, SHIFT CAM	1	
30	09206-09012	PIN (7.4X9X10)	2	
31	01550-06307	BOLT	3	
32	25700-99E00	SEALING KIT, GEAR CASE	1	OPT
				NOT ILLUSTRATED

DF60A_E03_017_407E
GEAR CASE

FIG.410A




FIG.410A (1-I-14) SIDE COVER (DF40A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61112-88L10	RUBBER, SIDE COVER	1	
2	61134-88L10	SEAL, SIDE COVER	1	
3-1	61811-88L20-YAY	COVER, SIDE STBD (BLACK)	1	
3-2	61811-88L20-Y5S	COVER, SIDE STBD (WHITE)	1	
4-1	61821-88L20-YAY	COVER, SIDE PORT (BLACK)	1	
4-2	61821-88L20-Y5S	COVER, SIDE PORT (WHITE)	1	
5	09136-06148	SCREW (6X35)	10	
6	61151-88L00	CUSHION, SIDE COVER	1	
7-1	61831-88L10-YAY	PANEL, FRONT (BLACK)	1	
7-2	61831-88L10-Y5S	PANEL, FRONT (WHITE)	1	
8	09116-08163	BOLT (8X38)	2	
9	09169-08039	WASHER	2	
10	09320-11013	CUSHION	2	
11	61412-88L00	HOOK, FRONT PANEL	1	
12	03542-05169	SCREW	2	
13	61632-93J00	SHAFT, ENGINE COVER HOOK	1	
14	61641-88L00	HOOK, ENGINE COVER	1	
15	09116-06127	BOLT (6X12)	1	
16	61633-88L00	LEVER, HOOK REAR	1	
17	09160-13014	WASHER (13.2X25X1)	1	
18	09164-14008	WASHER	1	
19	09202-04022	PIN	1	
20	09306-13007	BUSH	1	
21	09352-50901-600	HOSE (5X9X600)	1	L:600->20
22	61673-93J11	LATCH, HOOK LEVER	1	
23	09116-05010	BOLT (5X12)	2	
24	61124-88L10	GROMMET, REMOCON CABLE	1	
25	09407-25402	CLAMP (L:250)	1	

FIG.410B




FIG.410B (1-I-15) SIDE COVER (DF50A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61112-88L10	RUBBER, SIDE COVER	1	
2	61134-88L10	SEAL, SIDE COVER	1	
3-1	61811-88L20-YAY	COVER, SIDE STBD (BLACK)	1	
3-2	61811-88L20-Y5S	COVER, SIDE STBD (WHITE)	1	
4-1	61821-88L20-YAY	COVER, SIDE PORT (BLACK)	1	
4-2	61821-88L20-Y5S	COVER, SIDE PORT (WHITE)	1	
5	09136-06148	SCREW (6X35)	10	
6	61151-88L00	CUSHION, SIDE COVER	1	
7-1	61831-88L10-YAY	PANEL, FRONT (BLACK)	1	
7-2	61831-88L10-Y5S	PANEL, FRONT (WHITE)	1	
8	09116-08163	BOLT (8X38)	2	
9	09169-08039	WASHER	2	
10	09320-11013	CUSHION	2	
11	61412-88L00	HOOK, FRONT PANEL	1	
12	03542-05169	SCREW	2	
13	61632-93J00	SHAFT, ENGINE COVER HOOK	1	
14	61641-88L00	HOOK, ENGINE COVER	1	
15	09116-06127	BOLT (6X12)	1	
16	61633-88L00	LEVER, HOOK REAR	1	
17	09160-13014	WASHER (13.2X25X1)	1	
18	09164-14008	WASHER	1	
19	09202-04022	PIN	1	
20	09306-13007	BUSH	1	
21	09352-50901-600	HOSE (5X9X600)	1	L:600->20
22	61673-93J11	LATCH, HOOK LEVER	1	
23	09116-05010	BOLT (5X12)	2	
24	61124-88L10	GROMMET, REMOCON CABLE	1	
25	09407-25402	CLAMP (L:250)	1	

FIG.410C




FIG.410C (1-J-2) SIDE COVER (DF60A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61112-88L10	RUBBER, SIDE COVER	1	
2	61134-88L10	SEAL, SIDE COVER	1	
3-1	61811-88L20-YAY	COVER, SIDE STBD (BLACK)	1	
3-2	61811-88L20-Y5S	COVER, SIDE STBD (WHITE)	1	
4-1	61821-88L20-YAY	COVER, SIDE PORT (BLACK)	1	
4-2	61821-88L20-Y5S	COVER, SIDE PORT (WHITE)	1	
5	09136-06148	SCREW (6X35)	10	
6	61151-88L00	CUSHION, SIDE COVER	1	
7-1	61831-88L10-YAY	PANEL, FRONT (BLACK)	1	
7-2	61831-88L10-Y5S	PANEL, FRONT (WHITE)	1	
8	09116-08163	BOLT (8X38)	2	
9	09169-08039	WASHER	2	
10	09320-11013	CUSHION	2	
11	61412-88L00	HOOK, FRONT PANEL	1	
12	03542-05169	SCREW	2	
13	61632-93J00	SHAFT, ENGINE COVER HOOK	1	
14	61641-88L00	HOOK, ENGINE COVER	1	
15	09116-06127	BOLT (6X12)	1	
16	61633-88L00	LEVER, HOOK REAR	1	
17	09160-13014	WASHER (13.2X25X1)	1	
18	09164-14008	WASHER	1	
19	09202-04022	PIN	1	
20	09306-13007	BUSH	1	
21	09352-50901-600	HOSE (5X9X600)	1	L:600->20
22	61673-93J11	LATCH, HOOK LEVER	1	
23	09116-05010	BOLT (5X12)	2	
24	61124-88L10	GROMMET, REMOCON CABLE	1	
25	09407-25402	CLAMP (L:250)	1	

FIG.410D




FIG.410D (1-J-3) SIDE COVER (DF50AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61112-88L10	RUBBER, SIDE COVER	1	
2	61134-88L10	SEAL, SIDE COVER	1	
3	61811-88L30-YAY	COVER, SIDE STBD (S) (BLACK)	1	
4	61821-88L30-YAY	COVER, SIDE PORT (S) (BLACK)	1	
5	09136-06148	SCREW (6X35)	9	
6	61151-88L00	CUSHION, SIDE COVER	1	
7	61831-88L10-YAY	PANEL, FRONT (BLACK)	1	
8	09116-08163	BOLT (8X38)	2	
9	09169-08039	WASHER	2	
10	09320-11013	CUSHION	2	
11	61412-88L00	HOOK, FRONT PANEL	1	
12	03542-05169	SCREW	2	
13	61632-93J00	SHAFT, ENGINE COVER HOOK	1	
14	61641-88L00	HOOK, ENGINE COVER	1	
15	09116-06127	BOLT (6X12)	1	
16	61633-88L00	LEVER, HOOK REAR	1	
17	09160-13014	WASHER (13.2X25X1)	1	
18	09164-14008	WASHER	1	
19	09202-04022	PIN	1	
20	09306-13007	BUSH	1	
21	09352-50901-600	HOSE (5X9X600)	1	L:600->20
22	61673-93J11	LATCH, HOOK LEVER	1	
23	09116-05010	BOLT (5X12)	2	
24	61124-88L10	GROMMET, REMOCON CABLE	1	
25	09407-25402	CLAMP (L:250)	1	

FIG.410E




FIG.410E (1-J-4) SIDE COVER (DF60AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61112-88L10	RUBBER, SIDE COVER	1	
2	61134-88L10	SEAL, SIDE COVER	1	
3	61811-88L30-YAY	COVER, SIDE STBD (S) (BLACK)	1	
4	61821-88L30-YAY	COVER, SIDE PORT (S) (BLACK)	1	
5	09136-06148	SCREW (6X35)	9	
6	61151-88L00	CUSHION, SIDE COVER	1	
7	61831-88L10-YAY	PANEL, FRONT (BLACK)	1	
8	09116-08163	BOLT (8X38)	2	
9	09169-08039	WASHER	2	
10	09320-11013	CUSHION	2	
11	61412-88L00	HOOK, FRONT PANEL	1	
12	03542-05169	SCREW	2	
13	61632-93J00	SHAFT, ENGINE COVER HOOK	1	
14	61641-88L00	HOOK, ENGINE COVER	1	
15	09116-06127	BOLT (6X12)	1	
16	61633-88L00	LEVER, HOOK REAR	1	
17	09160-13014	WASHER (13.2X25X1)	1	
18	09164-14008	WASHER	1	
19	09202-04022	PIN	1	
20	09306-13007	BUSH	1	
21	09352-50901-600	HOSE (5X9X600)	1	L:600->20
22	61673-93J11	LATCH, HOOK LEVER	1	
23	09116-05010	BOLT (5X12)	2	
24	61124-88L10	GROMMET, REMOCON CABLE	1	
25	09407-25402	CLAMP (L:250)	1	

FIG.420A




FIG.420A (1-J-5) ENGINE COVER (DF40A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-88820-YAY	COVER SET, ENGINE (BLACK)	1	
1-2	61400-88830-Y5S	COVER SET, ENGINE (WHITE)	1	
2-1	61431-88L10-YAY	.HANDLE, TILT UP (BLACK)	1	
2-2	61431-88L10-Y5S	.HANDLE, TILT UP (WHITE)	1	
3	61438-88L00	.SEAL, TILT UP HANDLE NO.1	1	
4	61439-88L00	.SEAL, TILT UP HANDLE NO.2	1	
5	03542-06169	.SCREW	5	
6	61476-88L00	.SEAL, AIR VENT	1	
7	61610-95J00	.FASTENER	1	
8	09159-06084	.NUT	1	
9-1	61443-88L20	.STRIPE, ENGINE COVER STBD	1	FOR YAY
9-2	61443-88L30	.STRIPE, ENGINE COVER STBD	1	FOR Y5S
10-1	61453-88L20	.STRIPE, ENGINE COVER PORT	1	FOR YAY
10-2	61453-88L30	.STRIPE, ENGINE COVER PORT	1	FOR Y5S
11	68111-18G20	.EMBLEM (S)	1	
12-1	61422-88L30	MARK, EMBLEM FRONT (40)	1	FOR YAY
12-2	61422-88L60	MARK, EMBLEM FRONT (40)	1	FOR Y5S
13-1	61435-88L60	MARK, EMBLEM REAR (40)	1	FOR YAY
13-2	61435-88L90	MARK, EMBLEM REAR (40)	1	FOR Y5S
14	61458-90J00	LABEL, ENGINE COVER	1	
15	09800-81812	TOOL ASSY	1	
16	18210-88L00	KNOB ASSY, STARTER	1	
17	68110-88L00	COVER, WEATHER	1	OPT
18-1	99011-88L60-054	MANUAL, OWNER'S	1	
18-2	99011-88L60-03B	MANUAL, OWNER'S	1	
19	17917-87L00	CONNECTOR, FLUSH WATER	1	

FIG.420B




FIG.420B (1-J-6) ENGINE COVER (DF50A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-88820-YAY	COVER SET, ENGINE (BLACK)	1	
1-2	61400-88830-Y5S	COVER SET, ENGINE (WHITE)	1	
2-1	61431-88L10-YAY	.HANDLE, TILT UP (BLACK)	1	
2-2	61431-88L10-Y5S	.HANDLE, TILT UP (WHITE)	1	
3	61438-88L00	.SEAL, TILT UP HANDLE NO.1	1	
4	61439-88L00	.SEAL, TILT UP HANDLE NO.2	1	
5	03542-06169	.SCREW	5	
6	61476-88L00	.SEAL, AIR VENT	1	
7	61610-95J00	.FASTENER	1	
8	09159-06084	.NUT	1	
9-1	61443-88L20	.STRIPE, ENGINE COVER STBD	1	FOR YAY
9-2	61443-88L30	.STRIPE, ENGINE COVER STBD	1	FOR Y5S
10-1	61453-88L20	.STRIPE, ENGINE COVER PORT	1	FOR YAY
10-2	61453-88L30	.STRIPE, ENGINE COVER PORT	1	FOR Y5S
11	68111-18G20	.EMBLEM (S)	1	
12-1	61422-88L40	MARK, EMBLEM FRONT (50)	1	FOR YAY
12-2	61422-88L70	MARK, EMBLEM FRONT (50)	1	FOR Y5S
13-1	61435-88L70	MARK, EMBLEM REAR (50)	1	FOR YAY
13-2	61435-88LA0	MARK, EMBLEM REAR (50)	1	FOR Y5S
14	61458-90J00	LABEL, ENGINE COVER	1	
15	09800-81812	TOOL ASSY	1	
16	18210-88L00	KNOB ASSY, STARTER	1	
17	68110-88L00	COVER, WEATHER	1	OPT
18-1	99011-88L60-054	MANUAL, OWNER'S	1	
18-2	99011-88L60-03B	MANUAL, OWNER'S	1	
19	17917-87L00	CONNECTOR, FLUSH WATER	1	

FIG.420C




FIG.420C (1-J-7) ENGINE COVER (DF60A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-88820-YAY	COVER SET, ENGINE (BLACK)	1	
1-2	61400-88830-Y5S	COVER SET, ENGINE (WHITE)	1	
2-1	61431-88L10-YAY	.HANDLE, TILT UP (BLACK)	1	
2-2	61431-88L10-Y5S	.HANDLE, TILT UP (WHITE)	1	
3	61438-88L00	.SEAL, TILT UP HANDLE NO.1	1	
4	61439-88L00	.SEAL, TILT UP HANDLE NO.2	1	
5	03542-06169	.SCREW	5	
6	61476-88L00	.SEAL, AIR VENT	1	
7	61610-95J00	.FASTENER	1	
8	09159-06084	.NUT	1	
9-1	61443-88L20	.STRIPE, ENGINE COVER STBD	1	FOR YAY
9-2	61443-88L30	.STRIPE, ENGINE COVER STBD	1	FOR Y5S
10-1	61453-88L20	.STRIPE, ENGINE COVER PORT	1	FOR YAY
10-2	61453-88L30	.STRIPE, ENGINE COVER PORT	1	FOR Y5S
11	68111-18G20	.EMBLEM (S)	1	
12-1	61422-88L50	MARK, EMBLEM FRONT (60)	1	FOR YAY
12-2	61422-88L80	MARK, EMBLEM FRONT (60)	1	FOR Y5S
13-1	61435-88L80	MARK, EMBLEM REAR (60)	1	FOR YAY
13-2	61435-88LB0	MARK, EMBLEM REAR (60)	1	FOR Y5S
14	61458-90J00	LABEL, ENGINE COVER	1	
15	09800-81812	TOOL ASSY	1	
16	18210-88L00	KNOB ASSY, STARTER	1	
17	68110-88L00	COVER, WEATHER	1	OPT
18-1	99011-88L60-054	MANUAL, OWNER'S	1	
18-2	99011-88L60-03B	MANUAL, OWNER'S	1	
19	17917-87L00	CONNECTOR, FLUSH WATER	1	

FIG.420D




FIG.420D (1-J-8) ENGINE COVER (DF50AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-88820-YAY	COVER SET, ENGINE (BLACK)	1	
2	61431-88L10-YAY	.HANDLE, TILT UP (BLACK)	1	
3	61438-88L00	.SEAL, TILT UP HANDLE NO.1	1	
4	61439-88L00	.SEAL, TILT UP HANDLE NO.2	1	
5	03542-06169	.SCREW	5	
6	61476-88L00	.SEAL, AIR VENT	1	
7	61610-95J00	.FASTENER	1	
8	09159-06084	.NUT	1	
9	61443-88L20	.STRIPE, ENGINE COVER STBD	1	
10	61453-88L20	.STRIPE, ENGINE COVER PORT	1	
11	68111-18G20	.EMBLEM (S)	1	
12	61422-88L40	MARK, EMBLEM FRONT (50)	1	
13	61435-88L70	MARK, EMBLEM REAR (50)	1	
14	61458-90J00	LABEL, ENGINE COVER	1	
15	09800-81812	TOOL ASSY	1	
16	18210-88L00	KNOB ASSY, STARTER	1	
17	68110-88L00	COVER, WEATHER	1	OPT
18-1	99011-88L60-054	MANUAL, OWNER'S	1	
18-2	99011-88L60-03B	MANUAL, OWNER'S	1	
19	17917-87L00	CONNECTOR, FLUSH WATER	1	

FIG.420E




FIG.420E (1-J-9) ENGINE COVER (DF60AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-88820-YAY	COVER SET, ENGINE (BLACK)	1	
2	61431-88L10-YAY	.HANDLE, TILT UP (BLACK)	1	
3	61438-88L00	.SEAL, TILT UP HANDLE NO.1	1	
4	61439-88L00	.SEAL, TILT UP HANDLE NO.2	1	
5	03542-06169	.SCREW	5	
6	61476-88L00	.SEAL, AIR VENT	1	
7	61610-95J00	.FASTENER	1	
8	09159-06084	.NUT	1	
9	61443-88L20	.STRIPE, ENGINE COVER STBD	1	
10	61453-88L20	.STRIPE, ENGINE COVER PORT	1	
11	68111-18G20	.EMBLEM (S)	1	
12	61422-88L50	MARK, EMBLEM FRONT (60)	1	
13	61435-88L80	MARK, EMBLEM REAR (60)	1	
14	61458-90J00	LABEL, ENGINE COVER	1	
15	09800-81812	TOOL ASSY	1	
16	18210-88L00	KNOB ASSY, STARTER	1	
17	68110-88L00	COVER, WEATHER	1	OPT
18-1	99011-88L60-054	MANUAL, OWNER'S	1	
18-2	99011-88L60-03B	MANUAL, OWNER'S	1	
19	17917-87L00	CONNECTOR, FLUSH WATER	1	

FIG.430A




FIG.430A (1-J-10) FUEL HOSE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	65700-88L03	HOSE, FUEL	1	
2	65750-95500	.SOCKET	1	
3	65770-90J02	.PUMP, SQUEEZE	1	
4	61188-88L00	GROMMET, FUEL HOSE	1	
5	09251-07003	CAP (OD:11.5)	1	
6	09367-08001	JOINT	1	
7	09401-11423	CLIP	1	
8	09409-05312-6GS	CLIP (GRAY)	1	
9	65770-90J02	PUMP, SQUEEZE	1	N/HOSE, FUEL

FIG.442A




FIG.442A (1-J-11) DRAG LINK

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-87J11	LINK, DRAG	1	
3	67721-87J00	.SPACER	1	
4	67725-99E00	.BOLT, DRAG LINK	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.501A




FIG.501A (1-J-12) OPT:METER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	34800-93J00	METER ASSY, TRIM	1	BLACK
1-2	34800-93J11	METER ASSY, TRIM	1	WHITE
2	09471-12108	.BULB (12V,1.7W)	1	
3-1	34100-93J00	SPEEDOMETER ASSY	1	MAX 130KM/H BLACK
3-2	34100-93J11	SPEEDOMETER ASSY	1	MAX 130KM/H WHITE
3-3	34100-93J20	SPEEDOMETER ASSY	1	MAX 80KM/H BLACK
3-4	34100-93J31	SPEEDOMETER ASSY	1	MAX 80KM/H WHITE
3-5	34100-93J40	SPEEDOMETER ASSY	1	MAX 45KNOTS BLACK
3-6	34100-93J51	SPEEDOMETER ASSY	1	MAX 45KNOTS WHITE
3-7	34100-93J60	SPEEDOMETER ASSY	1	MAX 65KNOTS WHITE
4	09471-12028	.BULB (12V,3.4W)	1	
5	34191-92E00	.TUBE	1	
6	09407-14407	.CLAMP (L:145)	2	
7	36615-96300	.TERMINAL, RESIN	2	
8-1	34600-93J00	METER ASSY, VOLTAGE	1	BLACK
8-2	34600-93J11	METER ASSY, VOLTAGE	1	WHITE
9	09471-12103	.BULB (12V,3W,T6.5)	1	
10-1	34300-93J00	GAUGE ASSY, FUEL	1	BLACK
10-2	34300-93J11	GAUGE ASSY, FUEL	1	WHITE
11	34310-92E00	.LEAD, FUEL GAUGE	1	
12	34360-92E00	.ADAPTER, FUEL GAUGE	1	
13	09471-12103	.BULB (12V,3W,T6.5)	1	
14-1	34500-93J00	METER ASSY, HOUR	1	BLACK
14-2	34500-93J11	METER ASSY, HOUR	1	WHITE
15	09471-12103	.BULB (12V,3W,T6.5)	1	
16-1	34650-93J20	GAUGE ASSY, WATER PRESSURE	1	15PSI BLACK
16-2	34650-93J31	GAUGE ASSY, WATER PRESSURE	1	15PSI WHITE
17	34191-92E00	.TUBE	1	
18	09407-14407	.CLAMP (L:145)	2	
19	09471-12103	.BULB (12V,3W,T6.5)	1	
20-1	34200-93J00	TACHOMETER ASSY, WITH MONITOR	1	BLACK
20-2	34200-93J12	TACHOMETER ASSY, WITH MONITOR	1	WHITE
21	09471-12077	.BULB (12V,1.7W)	1	

FIG.501A




FIG.501A (1-J-13) OPT:METER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
22-1	34200-93J40	TACHOMETER ASSY, WITH MONITOR	1	BLACK
22-2	34200-93J51	TACHOMETER ASSY, WITH MONITOR	1	WHITE
23	09471-12077	.BULB (12V,1.7W)	1	
24	34190-95500	SENDER ASSY, SPEEDOMETER	1	
25	03112-0630B	.SCREW	2	
26	34190-87D00	SENDER, SPEEDOMETER	1	

FIG.507A




FIG.507A (1-J-14) OPT:WATER PRESSURE GAUGE SUB KIT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34660-90J02	WATER PRESSURE GAUGE SUB KIT	1	
2	09352-50903-600	.HOSE (5X9X600)	1	L:600->160
3	09352-50903-600	.HOSE (5X9X600)	1	L:600->210
4	09367-06006	.3 WAY	1	
5	09401-08413	.CLIP	4	
6	18498-99EA0	.PROTECTOR (L:80)	1	
7	09407-25402	.CLAMP (L:250)	1	

FIG.515A




FIG.515A (1-J-15) OPT:REMOCON CABLE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	2	
1-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	2	
1-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	2	
1-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	2	
1-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	2	
1-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	2	
1-7	67320-93J60	CABLE, REMOCON 20F (6.0M)	2	
1-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	2	
1-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	2	

FIG.521A




FIG.521A (1-K-2) OPT:HARNESS

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	36620-93J10	WIRE ASSY, REMOCON EXTENSION	1	L:2000
1-2	36620-93J40	WIRE ASSY, REMOCON EXTENSION	1	L:3000
2	36620-93J30	WIRE ASSY, REMOCON ADAPTER	1	L:2000
3	38500-93J00	BUZZER ASSY, WARNING	1	
4-1	36620-93J02	WIRE ASSY, REMOTE CONTROL	1	L:5000
4-2	36620-93J52	WIRE ASSY, REMOTE CONTROL	1	L:3500
4-3	36620-93J62	WIRE ASSY, REMOTE CONTROL	1	L:6500
5	09481-10501	.FUSE (10A)	1	
6	36990-87D00	TERMINAL & SLEEVE SET	1	
7	36682-92E00	WIRE, MONITOR GAUGE EXTENSION	1	
8	36667-96L20	WIRE, GAUGE EXT	1	

FIG.530A




FIG.530A (1-K-3) OPT:SWITCH

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-96J00	PANEL ASSY, IGNITION SW	1	
2	37110-93J01	.SWITCH ASSY, IGNITION	1	
3-1	37141-99E00	..KEY (931)	2	
3-2	37141-99E10	..KEY (932)	2	
3-3	37141-99E20	..KEY (933)	2	
3-4	37141-99E30	..KEY (934)	2	
3-5	37141-99E40	..KEY (935)	2	
3-6	37141-99E50	..KEY (936)	2	
3-7	37141-99E60	..KEY (937)	2	
3-8	37141-99E70	..KEY (938)	2	
3-9	37141-99E80	..KEY (939)	2	
3-10	37141-99E90	..KEY (940)	2	
3-11	37141-99EA0	..KEY (941)	2	
3-12	37141-99EB0	..KEY (942)	2	
4	37143-99E00	..CAP, KEY	1	
5	37149-93J00	..CAP, CYLINDER BODY	1	
6	37139-99E00	.PANEL, IGNITION SW	1	
7	38500-93J90	.BUZZER ASSY, WARNING	1	
8	09407-08401	.CLAMP (L:80)	1	
9	37803-93J04	PANEL ASSY, EMERGENCY SW	1	
10	37820-93J04	.SWITCH ASSY, EMERGENCY	1	
11	37823-92E01	..PLATE, LOCK	1	
12	37826-92J00	..NUT	1	
13	37825-99E00	.PANEL, EMERGENCY SW	1	
14	03122-05165	.SCREW	4	
15	37805-93J00	PANEL ASSY, PTT SW	1	
16	37855-99E00	.PANEL, PTT SW	1	
17	37210-93J00	PANEL ASSY, LIGHTING SW	1	
18	37212-93J00	.PANEL, LIGHTING SW	1	
19	37100-96J24	PANEL ASSY, ENGINE SW	1	
20	37110-93J01	.SWITCH ASSY, IGNITION	1	
21-1	37141-99E00	..KEY (931)	2	
21-2	37141-99E10	..KEY (932)	2	
21-3	37141-99E20	..KEY (933)	2	
21-4	37141-99E30	..KEY (934)	2	
21-5	37141-99E40	..KEY (935)	2	

DF60A_E03_017_530A
OPT:SWITCH

FIG.530A




FIG.530A (1-K-4) OPT:SWITCH

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
21-6	37141-99E50	..KEY (936)	2	
21-7	37141-99E60	..KEY (937)	2	
21-8	37141-99E70	..KEY (938)	2	
21-9	37141-99E80	..KEY (939)	2	
21-10	37141-99E90	..KEY (940)	2	
21-11	37141-99EA0	..KEY (941)	2	
21-12	37141-99EB0	..KEY (942)	2	
22	37143-99E00	..CAP, KEY	1	
23	37149-93J00	..CAP, CYLINDER BODY	1	
24	37139-99E20	.PANEL, IGNITION SWITCH	1	
25	37820-93J04	.SWITCH ASSY, EMERGENCY	1	
26	37823-92E01	..PLATE ASSY, EMERGENCY	1	
27	37826-92J00	..NUT	1	
28	03121-0516A	.SCREW	4	
29	38500-93J90	.BUZZER ASSY, WARNING	1	
30	09407-08401	.CLAMP (L:80)	1	
31	37860-87L00	PANEL ASSY, TROLLING CONTROL	1	
32	37862-87L00	.PANEL	1	
33	09131-05004	.SCREW (5X16)	4	

DF60A_E03_017_530A
OPT:SWITCH

FIG.544A




FIG.544A (1-K-5) OPT:REMOTE CONTROL ASSY SINGLE (1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.545A




FIG.545A (1-K-6) OPT:REMOTE CONTROL ASSY SINGLE (2)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, NEUTRAL	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545A




FIG.545A (1-K-7) OPT:REMOTE CONTROL ASSY SINGLE (2)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

DF60A_E03_017_545A
OPT:REMOTE CONTROL ASSY SINGLE (2)

FIG.570A




FIG.570A (1-K-8) OPT:TILLER HANDLE (DF40A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63002-88L22-YAY	KIT TILLER HANDLE (BLACK)	1	
2	21110-88L00	.LEVER, SHIFT	1	
3	23230-88L00	.CABLE, SHIFT	1	
4	36620-88L10	.WIRE ASSY, HANDLE	1	
5	37110-87L01	.SWITCH ASSY, IGNITION	1	
6-1	37141-99E00	..KEY (931)	1	
6-2	37141-99E10	..KEY (932)	1	
6-3	37141-99E20	..KEY (933)	1	
6-4	37141-99E30	..KEY (934)	1	
6-5	37141-99E40	..KEY (935)	1	
6-6	37141-99E50	..KEY (936)	1	
6-7	37141-99E60	..KEY (937)	1	
6-8	37141-99E70	..KEY (938)	1	
6-9	37141-99E80	..KEY (939)	1	
6-10	37141-99E90	..KEY (940)	1	
6-11	37141-99EA0	..KEY (941)	1	
6-12	37141-99EB0	..KEY (942)	1	
7	37143-99E00	..CAP, KEY	1	
8	37149-93J00	..CAP, CYLINDER BODY	1	
9	37820-87L01	.SWITCH ASSY, EMERGENCY	1	
10	37823-92E01	..PLATE, LOCK	1	
11	37826-92J00	..NUT	1	
12	38500-93J90	.BUZZER	1	
13	37850-87L01	.SWITCH ASSY, PTT	1	
14	37852-87J00	.PLATE, TRIM SWITCH	1	
15	63121-88L00	.COVER, UNDER	1	
16	63210-88L00	.GRIP, HANDLE	1	
17	63221-88L00	.SHAFT, THROTTLE	1	
18	63223-92D00	.STOPPER, HANDLE ROD	1	
19	63225-88L00	.BUSH, HANDLE ROD	1	
20	63227-93200	.PIN, HANDLE ROD	1	
21	63235-88L00	.PLATE, THROTTLE SHAFT	1	
22	63246-88L00	.STOPPER THROTTLE ADJ	1	
23	63250-88L00	.ARM ASSY, THROTTLE	1	

FIG.570A




FIG.570A (1-K-9) OPT:TILLER HANDLE (DF40A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
24	63251-87J00	.BOLT, SHIFT GEAR ASSY	4	
25	63260-88L00	.GEAR ASSY, SHIFT	1	
26	63272-87J00	..PLATE, BALL GUIDE	1	
27	63273-87J00	..BALL	1	
28	63262-87J00	.BUSH, SHIFT LEVER	1	
29	63271-87J00	.PLATE, LOCK	1	
30	63248-99J00	.PLATE, THROTTLE ADJ NOTCH	1	
31	63261-87J00	.BUSH, SHIFT GEAR	1	
32	63274-87J00	.E RING	1	
33	63610-88L00	.CABLE, THROTTLE	1	
34	37853-88L90	.GROMMET, PTT SWITCH LEAD	1	
35	63626-88L00	.GROMMET, WIRE HARNESS	1	
36	67292-87J00	.E RING	2	
37	09126-06015	.SCREW (6X23)	1	
38	09163-06001	.LOCK WASHER	1	
39	09440-12027	.SPRING	1	
40	21112-88L00	.BOLT SHIFT LEVER	1	
41	09125-05047	.SCREW (5X14)	6	
42	63611-88L00	.BOLT CLAMP BRACKET	3	
43	63612-87J00	.BRACKET, CLAMP	1	
44	34200-87L00	.TACHOMETER ASSY, WITH MONITOR	1	
45	36617-88L90	.CLAMP PLATE, MAIN HARNESS	1	
46	37112-88L91	.LABEL, IGNITION SWITCH	1	
47	37835-95D00	.LABEL, STOP	1	
48	37851-88L90	.BASE, PTT SWITCH	1	
49	37852-88L90	.HARNESS, GUIDE	1	
50	37861-87L11	.SWITCH, TROLLING CONTROL	1	
51	37864-88L91	.LABEL, TROLL MODE	1	
52	63244-99J00	.KNOB, THROTTLE ADJ	1	
53	63245-99J00	.BUSH, THROTTLE ADJ	1	
54	63612-88L10	.BRACKET, CLAMP SHIFT	1	
55	09260-10006	.BALL	1	
56	19120-88L11	.LEVER, THROTTLE	1	
57	21131-88L01	.MARK, CLUTCH SHIFT	1	

FIG.570A




FIG.570A (1-K-10) OPT:TILLER HANDLE (DF40A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
58	43761-88L01-YAY	.BRACKET, TILLER HANDLE (BLACK)	1	
59	43762-88L00	.BOLT TILLER HANDLE PIVOT	1	
60	43768-88L00	.SPACER, TILLER HANDLE	1	
61	09116-08137	.BOLT (8X22)	1	
62	09159-12014	.NUT	1	
63	09160-12066	.WASHER (12.5X22X2.5)	2	
64	09160-12124	.WASHER (12.5X32X1.5)	1	
65	63115-88L00	.BUSH, TILLER HANDLE	2	
66	09164-13010	.WASHER	1	
67	63215-93110	.MARK, HANDLE GRIP	1	
68	09116-10150	.BOLT (10X55)	2	
69	63132-88L00	.STOPPER, TILLER HANDLE	1	
70	63251-88L90	.BOLT	2	
71	37855-88L90	.SCREW, THROTTLE GRIP	1	
72	37854-88L90	.WASHER,THROTTLE GRIP	1	
73	63258-88L00	.WASHER	1	
74	09440-06037	.SPRING	1	
75	03522-05169	.SCREW	3	
76	63247-99J00	.PLATE, THROTTLE ADJ KNOB	1	
77	63111-88L00-YAY	.HOUSING, TILLER HANDLE (BLACK)	1	
78	33834-88L00	.TUBE, CABLE PROTECTOR	1	
79	65793-88L00	.HOLDER, FUEL HOSE	1	
80	09116-06237	.BOLT (6X15)	2	
81	22511-99011	.NIPPLE, GREASE	1	
82	43411-88L00	.ADJUSTER, STEERING	1	
83	43415-88L00	.PLATE, STEERING ADJUSTER	1	
84	43512-88L00	.SHAFT, STEERING ADJ THREAD	1	
85	43513-88L00	.BOLT, STEERING ADJUSTER	1	
86	43514-88L00	.PLATE, STEERING ADJ FRICTION	2	
87	43515-88L00	.WASHER, STRG ADJ FRICTION PLATE	2	
88	43516-88L00	.WASHER, STRG ADJ FRICTION	1	
89	43517-88L00	.SPACER, STEERING ADJUSTER	1	

DF60A_E03_017_570A
OPT:TILLER HANDLE

FIG.570A




FIG.570A (1-K-11) OPT:TILLER HANDLE (DF40A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
90	09159-08059	.NUT	1	
91	09161-08011	.WASHER (8.2X18X1.2)	2	

FIG.570B




FIG.570B (1-K-12) OPT:TILLER HANDLE (DF50A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63002-88L22-YAY	KIT TILLER HANDLE (BLACK)	1	
2	21110-88L00	.LEVER, SHIFT	1	
3	23230-88L00	.CABLE, SHIFT	1	
4	36620-88L10	.WIRE ASSY, HANDLE	1	
5	37110-87L01	.SWITCH ASSY, IGNITION	1	
6-1	37141-99E00	..KEY (931)	1	
6-2	37141-99E10	..KEY (932)	1	
6-3	37141-99E20	..KEY (933)	1	
6-4	37141-99E30	..KEY (934)	1	
6-5	37141-99E40	..KEY (935)	1	
6-6	37141-99E50	..KEY (936)	1	
6-7	37141-99E60	..KEY (937)	1	
6-8	37141-99E70	..KEY (938)	1	
6-9	37141-99E80	..KEY (939)	1	
6-10	37141-99E90	..KEY (940)	1	
6-11	37141-99EA0	..KEY (941)	1	
6-12	37141-99EB0	..KEY (942)	1	
7	37143-99E00	..CAP, KEY	1	
8	37149-93J00	..CAP, CYLINDER BODY	1	
9	37820-87L01	.SWITCH ASSY, EMERGENCY	1	
10	37823-92E01	..PLATE, LOCK	1	
11	37826-92J00	..NUT	1	
12	38500-93J90	.BUZZER	1	
13	37850-87L01	.SWITCH ASSY, PTT	1	
14	37852-87J00	.PLATE, TRIM SWITCH	1	
15	63121-88L00	.COVER, UNDER	1	
16	63210-88L00	.GRIP, HANDLE	1	
17	63221-88L00	.SHAFT, THROTTLE	1	
18	63223-92D00	.STOPPER, HANDLE ROD	1	
19	63225-88L00	.BUSH, HANDLE ROD	1	
20	63227-93200	.PIN, HANDLE ROD	1	
21	63235-88L00	.PLATE, THROTTLE SHAFT	1	
22	63246-88L00	.STOPPER THROTTLE ADJ	1	
23	63250-88L00	.ARM ASSY, THROTTLE	1	

FIG.570B




FIG.570B (1-K-13) OPT:TILLER HANDLE (DF50A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
24	63251-87J00	.BOLT, SHIFT GEAR ASSY	4	
25	63260-88L00	.GEAR ASSY, SHIFT	1	
26	63272-87J00	..PLATE, BALL GUIDE	1	
27	63273-87J00	..BALL	1	
28	63262-87J00	.BUSH, SHIFT LEVER	1	
29	63271-87J00	.PLATE, LOCK	1	
30	63248-99J00	.PLATE, THROTTLE ADJ NOTCH	1	
31	63261-87J00	.BUSH, SHIFT GEAR	1	
32	63274-87J00	.E RING	1	
33	63610-88L00	.CABLE, THROTTLE	1	
34	37853-88L90	.GROMMET, PTT SWITCH LEAD	1	
35	63626-88L00	.GROMMET, WIRE HARNESS	1	
36	67292-87J00	.E RING	2	
37	09126-06015	.SCREW (6X23)	1	
38	09163-06001	.LOCK WASHER	1	
39	09440-12027	.SPRING	1	
40	21112-88L00	.BOLT SHIFT LEVER	1	
41	09125-05047	.SCREW (5X14)	6	
42	63611-88L00	.BOLT CLAMP BRACKET	3	
43	63612-87J00	.BRACKET, CLAMP	1	
44	34200-87L00	.TACHOMETER ASSY, WITH MONITOR	1	
45	36617-88L90	.CLAMP PLATE, MAIN HARNESS	1	
46	37112-88L91	.LABEL, IGNITION SWITCH	1	
47	37835-95D00	.LABEL, STOP	1	
48	37851-88L90	.BASE, PTT SWITCH	1	
49	37852-88L90	.HARNESS, GUIDE	1	
50	37861-87L11	.SWITCH, TROLLING CONTROL	1	
51	37864-88L91	.LABEL, TROLL MODE	1	
52	63244-99J00	.KNOB, THROTTLE ADJ	1	
53	63245-99J00	.BUSH, THROTTLE ADJ	1	
54	63612-88L10	.BRACKET, CLAMP SHIFT	1	
55	09260-10006	.BALL	1	
56	19120-88L11	.LEVER, THROTTLE	1	
57	21131-88L01	.MARK, CLUTCH SHIFT	1	

DF60A_E03_017_570B
OPT:TILLER HANDLE

FIG.570B




FIG.570B (1-K-14) OPT:TILLER HANDLE (DF50A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
58	43761-88L01-YAY	.BRACKET, TILLER HANDLE (BLACK)	1	
59	43762-88L00	.BOLT TILLER HANDLE PIVOT	1	
60	43768-88L00	.SPACER, TILLER HANDLE	1	
61	09116-08137	.BOLT (8X22)	1	
62	09159-12014	.NUT	1	
63	09160-12066	.WASHER (12.5X22X2.5)	2	
64	09160-12124	.WASHER (12.5X32X1.5)	1	
65	63115-88L00	.BUSH, TILLER HANDLE	2	
66	09164-13010	.WASHER	1	
67	63215-93110	.MARK, HANDLE GRIP	1	
68	09116-10150	.BOLT (10X55)	2	
69	63132-88L00	.STOPPER, TILLER HANDLE	1	
70	63251-88L90	.BOLT	2	
71	37855-88L90	.SCREW, THROTTLE GRIP	1	
72	37854-88L90	.WASHER,THROTTLE GRIP	1	
73	63258-88L00	.WASHER	1	
74	09440-06037	.SPRING	1	
75	03522-05169	.SCREW	3	
76	63247-99J00	.PLATE, THROTTLE ADJ KNOB	1	
77	63111-88L00-YAY	.HOUSING, TILLER HANDLE (BLACK)	1	
78	33834-88L00	.TUBE, CABLE PROTECTOR	1	
79	65793-88L00	.HOLDER, FUEL HOSE	1	
80	09116-06237	.BOLT (6X15)	2	
81	22511-99011	.NIPPLE, GREASE	1	
82	43411-88L00	.ADJUSTER, STEERING	1	
83	43415-88L00	.PLATE, STEERING ADJUSTER	1	
84	43512-88L00	.SHAFT, STEERING ADJ THREAD	1	
85	43513-88L00	.BOLT, STEERING ADJUSTER	1	
86	43514-88L00	.PLATE, STEERING ADJ FRICTION	2	
87	43515-88L00	.WASHER, STRG ADJ FRICTION PLATE	2	
88	43516-88L00	.WASHER, STRG ADJ FRICTION	1	
89	43517-88L00	.SPACER, STEERING ADJUSTER	1	

FIG.570B




FIG.570B (1-K-15) OPT:TILLER HANDLE (DF50A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
90	09159-08059	.NUT	1	
91	09161-08011	.WASHER (8.2X18X1.2)	2	

FIG.570C




FIG.570C (1-L-2) OPT:TILLER HANDLE (DF60A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63002-88L12-YAY	KIT TILLER HANDLE (BLACK)	1	
2	21110-88L00	.LEVER, SHIFT	1	
3	23230-88L00	.CABLE, SHIFT	1	
4	36620-88L10	.WIRE ASSY, HANDLE	1	
5	37110-87L01	.SWITCH ASSY, IGNITION	1	
6-1	37141-99E00	..KEY (931)	1	
6-2	37141-99E10	..KEY (932)	1	
6-3	37141-99E20	..KEY (933)	1	
6-4	37141-99E30	..KEY (934)	1	
6-5	37141-99E40	..KEY (935)	1	
6-6	37141-99E50	..KEY (936)	1	
6-7	37141-99E60	..KEY (937)	1	
6-8	37141-99E70	..KEY (938)	1	
6-9	37141-99E80	..KEY (939)	1	
6-10	37141-99E90	..KEY (940)	1	
6-11	37141-99EA0	..KEY (941)	1	
6-12	37141-99EB0	..KEY (942)	1	
7	37143-99E00	..CAP, KEY	1	
8	37149-93J00	..CAP, CYLINDER BODY	1	
9	37820-87L01	.SWITCH ASSY, EMERGENCY	1	
10	37823-92E01	..PLATE, LOCK	1	
11	37826-92J00	..NUT	1	
12	38500-93J90	.BUZZER	1	
13	37850-87L01	.SWITCH ASSY, PTT	1	
14	37852-87J00	.PLATE, TRIM SWITCH	1	
15	63121-88L00	.COVER, UNDER	1	
16	63210-88L00	.GRIP, HANDLE	1	
17	63221-88L00	.SHAFT, THROTTLE	1	
18	63223-92D00	.STOPPER, HANDLE ROD	1	
19	63225-88L00	.BUSH, HANDLE ROD	1	
20	63227-93200	.PIN, HANDLE ROD	1	
21	63235-88L00	.PLATE, THROTTLE SHAFT	1	
22	63246-88L00	.STOPPER THROTTLE ADJ	1	
23	63250-88L00	.ARM ASSY, THROTTLE	1	

FIG.570C




FIG.570C (1-L-3) OPT:TILLER HANDLE (DF60A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
24	63251-87J00	.BOLT, SHIFT GEAR ASSY	4	
25	63260-88L00	.GEAR ASSY, SHIFT	1	
26	63272-87J00	..PLATE, BALL GUIDE	1	
27	63273-87J00	..BALL	1	
28	63262-87J00	.BUSH, SHIFT LEVER	1	
29	63271-87J00	.PLATE, LOCK	1	
30	63248-99J00	.PLATE, THROTTLE ADJ NOTCH	1	
31	63261-87J00	.BUSH, SHIFT GEAR	1	
32	63274-87J00	.E RING	1	
33	63610-88L00	.CABLE, THROTTLE	1	
34	37853-88L90	.GROMMET, PTT SWITCH LEAD	1	
35	63626-88L00	.GROMMET, WIRE HARNESS	1	
36	67292-87J00	.E RING	2	
37	09126-06015	.SCREW (6X23)	1	
38	09163-06001	.LOCK WASHER	1	
39	09440-12027	.SPRING	1	
40	21112-88L00	.BOLT SHIFT LEVER	1	
41	09125-05047	.SCREW (5X14)	6	
42	63611-88L00	.BOLT CLAMP BRACKET	3	
43	63612-87J00	.BRACKET, CLAMP	1	
44	34200-87L00	.TACHOMETER ASSY, WITH MONITOR	1	
45	36617-88L90	.CLAMP PLATE, MAIN HARNESS	1	
46	37112-88L91	.LABEL, IGNITION SWITCH	1	
47	37835-95D00	.LABEL, STOP	1	
48	37851-88L90	.BASE, PTT SWITCH	1	
49	37852-88L90	.HARNESS, GUIDE	1	
50	37861-87L11	.SWITCH, TROLLING CONTROL	1	
51	37864-88L91	.LABEL, TROLL MODE	1	
52	63244-99J00	.KNOB, THROTTLE ADJ	1	
53	63245-99J00	.BUSH, THROTTLE ADJ	1	
54	63612-88L10	.BRACKET, CLAMP SHIFT	1	
55	09260-10006	.BALL	1	
56	19120-88L11	.LEVER, THROTTLE	1	
57	21131-88L01	.MARK, CLUTCH SHIFT	1	

FIG.570C




FIG.570C (1-L-4) OPT:TILLER HANDLE (DF60A E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
58	43761-88L01-YAY	.BRACKET, TILLER HANDLE (BLACK)	1	
59	43762-88L00	.BOLT TILLER HANDLE PIVOT	1	
60	43768-88L00	.SPACER, TILLER HANDLE	1	
61	09116-08137	.BOLT (8X22)	1	
62	09159-12014	.NUT	1	
63	09160-12066	.WASHER (12.5X22X2.5)	2	
64	09160-12124	.WASHER (12.5X32X1.5)	1	
65	63115-88L00	.BUSH, TILLER HANDLE	2	
66	09164-13010	.WASHER	1	
67	63215-93110	.MARK, HANDLE GRIP	1	
68	09116-10150	.BOLT (10X55)	2	
69	43770-99E03	.ADJUSTER ASSY, STEERING	1	
70	63132-88L00	.STOPPER, TILLER HANDLE	1	
71	63251-88L90	.BOLT	2	
72	37855-88L90	.SCREW, THROTTLE GRIP	1	
73	37854-88L90	.WASHER,THROTTLE GRIP	1	
74	63258-88L00	.WASHER	1	
75	09440-06037	.SPRING	1	
76	03522-05169	.SCREW	3	
77	63247-99J00	.PLATE, THROTTLE ADJ KNOB	1	
78	63111-88L00-YAY	.HOUSING, TILLER HANDLE (BLACK)	1	
79	33834-88L00	.TUBE, CABLE PROTECTOR	1	
80	65793-88L00	.HOLDER, FUEL HOSE	1	
81	09116-06237	.BOLT (6X15)	2	

FIG.570D




FIG.570D (1-L-5) OPT:TILLER HANDLE (DF50AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63002-88L12-YAY	KIT TILLER HANDLE (BLACK)	1	
2	21110-88L00	.LEVER, SHIFT	1	
3	23230-88L00	.CABLE, SHIFT	1	
4	36620-88L10	.WIRE ASSY, HANDLE	1	
5	37110-87L01	.SWITCH ASSY, IGNITION	1	
6-1	37141-99E00	..KEY (931)	1	
6-2	37141-99E10	..KEY (932)	1	
6-3	37141-99E20	..KEY (933)	1	
6-4	37141-99E30	..KEY (934)	1	
6-5	37141-99E40	..KEY (935)	1	
6-6	37141-99E50	..KEY (936)	1	
6-7	37141-99E60	..KEY (937)	1	
6-8	37141-99E70	..KEY (938)	1	
6-9	37141-99E80	..KEY (939)	1	
6-10	37141-99E90	..KEY (940)	1	
6-11	37141-99EA0	..KEY (941)	1	
6-12	37141-99EB0	..KEY (942)	1	
7	37143-99E00	..CAP, KEY	1	
8	37149-93J00	..CAP, CYLINDER BODY	1	
9	37820-87L01	.SWITCH ASSY, EMERGENCY	1	
10	37823-92E01	..PLATE, LOCK	1	
11	37826-92J00	..NUT	1	
12	38500-93J90	.BUZZER	1	
13	37850-87L01	.SWITCH ASSY, PTT	1	
14	37852-87J00	.PLATE, TRIM SWITCH	1	
15	63121-88L00	.COVER, UNDER	1	
16	63210-88L00	.GRIP, HANDLE	1	
17	63221-88L00	.SHAFT, THROTTLE	1	
18	63223-92D00	.STOPPER, HANDLE ROD	1	
19	63225-88L00	.BUSH, HANDLE ROD	1	
20	63227-93200	.PIN, HANDLE ROD	1	
21	63235-88L00	.PLATE, THROTTLE SHAFT	1	
22	63246-88L00	.STOPPER THROTTLE ADJ	1	
23	63250-88L00	.ARM ASSY, THROTTLE	1	

FIG.570D




FIG.570D (1-L-6) OPT:TILLER HANDLE (DF50AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
24	63251-87J00	.BOLT, SHIFT GEAR ASSY	4	
25	63260-88L00	.GEAR ASSY, SHIFT	1	
26	63272-87J00	..PLATE, BALL GUIDE	1	
27	63273-87J00	..BALL	1	
28	63262-87J00	.BUSH, SHIFT LEVER	1	
29	63271-87J00	.PLATE, LOCK	1	
30	63248-99J00	.PLATE, THROTTLE ADJ NOTCH	1	
31	63261-87J00	.BUSH, SHIFT GEAR	1	
32	63274-87J00	.E RING	1	
33	63610-88L00	.CABLE, THROTTLE	1	
34	37853-88L90	.GROMMET, PTT SWITCH LEAD	1	
35	63626-88L00	.GROMMET, WIRE HARNESS	1	
36	67292-87J00	.E RING	2	
37	09126-06015	.SCREW (6X23)	1	
38	09163-06001	.LOCK WASHER	1	
39	09440-12027	.SPRING	1	
40	21112-88L00	.BOLT SHIFT LEVER	1	
41	09125-05047	.SCREW (5X14)	6	
42	63611-88L00	.BOLT CLAMP BRACKET	3	
43	63612-87J00	.BRACKET, CLAMP	1	
44	34200-87L00	.TACHOMETER ASSY, WITH MONITOR	1	
45	36617-88L90	.CLAMP PLATE, MAIN HARNESS	1	
46	37112-88L91	.LABEL, IGNITION SWITCH	1	
47	37835-95D00	.LABEL, STOP	1	
48	37851-88L90	.BASE, PTT SWITCH	1	
49	37852-88L90	.HARNESS, GUIDE	1	
50	37861-87L11	.SWITCH, TROLLING CONTROL	1	
51	37864-88L91	.LABEL, TROLL MODE	1	
52	63244-99J00	.KNOB, THROTTLE ADJ	1	
53	63245-99J00	.BUSH, THROTTLE ADJ	1	
54	63612-88L10	.BRACKET, CLAMP SHIFT	1	
55	09260-10006	.BALL	1	
56	19120-88L11	.LEVER, THROTTLE	1	
57	21131-88L01	.MARK, CLUTCH SHIFT	1	

FIG.570D




FIG.570D (1-L-7) OPT:TILLER HANDLE (DF50AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
58	43761-88L01-YAY	.BRACKET, TILLER HANDLE (BLACK)	1	
59	43762-88L00	.BOLT TILLER HANDLE PIVOT	1	
60	43768-88L00	.SPACER, TILLER HANDLE	1	
61	09116-08137	.BOLT (8X22)	1	
62	09159-12014	.NUT	1	
63	09160-12066	.WASHER (12.5X22X2.5)	2	
64	09160-12124	.WASHER (12.5X32X1.5)	1	
65	63115-88L00	.BUSH, TILLER HANDLE	2	
66	09164-13010	.WASHER	1	
67	63215-93110	.MARK, HANDLE GRIP	1	
68	09116-10150	.BOLT (10X55)	2	
69	43770-99E03	.ADJUSTER ASSY, STEERING	1	
70	63132-88L00	.STOPPER, TILLER HANDLE	1	
71	63251-88L90	.BOLT	2	
72	37855-88L90	.SCREW, THROTTLE GRIP	1	
73	37854-88L90	.WASHER,THROTTLE GRIP	1	
74	63258-88L00	.WASHER	1	
75	09440-06037	.SPRING	1	
76	03522-05169	.SCREW	3	
77	63247-99J00	.PLATE, THROTTLE ADJ KNOB	1	
78	63111-88L00-YAY	.HOUSING, TILLER HANDLE (BLACK)	1	
79	33834-88L00	.TUBE, CABLE PROTECTOR	1	
80	65793-88L00	.HOLDER, FUEL HOSE	1	
81	09116-06237	.BOLT (6X15)	2	

FIG.570E




FIG.570E (1-L-8) OPT:TILLER HANDLE (DF60AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63002-88L12-YAY	KIT TILLER HANDLE (BLACK)	1	
2	21110-88L00	.LEVER, SHIFT	1	
3	23230-88L00	.CABLE, SHIFT	1	
4	36620-88L10	.WIRE ASSY, HANDLE	1	
5	37110-87L01	.SWITCH ASSY, IGNITION	1	
6-1	37141-99E00	..KEY (931)	1	
6-2	37141-99E10	..KEY (932)	1	
6-3	37141-99E20	..KEY (933)	1	
6-4	37141-99E30	..KEY (934)	1	
6-5	37141-99E40	..KEY (935)	1	
6-6	37141-99E50	..KEY (936)	1	
6-7	37141-99E60	..KEY (937)	1	
6-8	37141-99E70	..KEY (938)	1	
6-9	37141-99E80	..KEY (939)	1	
6-10	37141-99E90	..KEY (940)	1	
6-11	37141-99EA0	..KEY (941)	1	
6-12	37141-99EB0	..KEY (942)	1	
7	37143-99E00	..CAP, KEY	1	
8	37149-93J00	..CAP, CYLINDER BODY	1	
9	37820-87L01	.SWITCH ASSY, EMERGENCY	1	
10	37823-92E01	..PLATE, LOCK	1	
11	37826-92J00	..NUT	1	
12	38500-93J90	.BUZZER	1	
13	37850-87L01	.SWITCH ASSY, PTT	1	
14	37852-87J00	.PLATE, TRIM SWITCH	1	
15	63121-88L00	.COVER, UNDER	1	
16	63210-88L00	.GRIP, HANDLE	1	
17	63221-88L00	.SHAFT, THROTTLE	1	
18	63223-92D00	.STOPPER, HANDLE ROD	1	
19	63225-88L00	.BUSH, HANDLE ROD	1	
20	63227-93200	.PIN, HANDLE ROD	1	
21	63235-88L00	.PLATE, THROTTLE SHAFT	1	
22	63246-88L00	.STOPPER THROTTLE ADJ	1	
23	63250-88L00	.ARM ASSY, THROTTLE	1	

FIG.570E




FIG.570E (1-L-9) OPT:TILLER HANDLE (DF60AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
24	63251-87J00	.BOLT, SHIFT GEAR ASSY	4	
25	63260-88L00	.GEAR ASSY, SHIFT	1	
26	63272-87J00	..PLATE, BALL GUIDE	1	
27	63273-87J00	..BALL	1	
28	63262-87J00	.BUSH, SHIFT LEVER	1	
29	63271-87J00	.PLATE, LOCK	1	
30	63248-99J00	.PLATE, THROTTLE ADJ NOTCH	1	
31	63261-87J00	.BUSH, SHIFT GEAR	1	
32	63274-87J00	.E RING	1	
33	63610-88L00	.CABLE, THROTTLE	1	
34	37853-88L90	.GROMMET, PTT SWITCH LEAD	1	
35	63626-88L00	.GROMMET, WIRE HARNESS	1	
36	67292-87J00	.E RING	2	
37	09126-06015	.SCREW (6X23)	1	
38	09163-06001	.LOCK WASHER	1	
39	09440-12027	.SPRING	1	
40	21112-88L00	.BOLT SHIFT LEVER	1	
41	09125-05047	.SCREW (5X14)	6	
42	63611-88L00	.BOLT CLAMP BRACKET	3	
43	63612-87J00	.BRACKET, CLAMP	1	
44	34200-87L00	.TACHOMETER ASSY, WITH MONITOR	1	
45	36617-88L90	.CLAMP PLATE, MAIN HARNESS	1	
46	37112-88L91	.LABEL, IGNITION SWITCH	1	
47	37835-95D00	.LABEL, STOP	1	
48	37851-88L90	.BASE, PTT SWITCH	1	
49	37852-88L90	.HARNESS, GUIDE	1	
50	37861-87L11	.SWITCH, TROLLING CONTROL	1	
51	37864-88L91	.LABEL, TROLL MODE	1	
52	63244-99J00	.KNOB, THROTTLE ADJ	1	
53	63245-99J00	.BUSH, THROTTLE ADJ	1	
54	63612-88L10	.BRACKET, CLAMP SHIFT	1	
55	09260-10006	.BALL	1	
56	19120-88L11	.LEVER, THROTTLE	1	
57	21131-88L01	.MARK, CLUTCH SHIFT	1	

FIG.570E




FIG.570E (1-L-10) OPT:TILLER HANDLE (DF60AVT E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
58	43761-88L01-YAY	.BRACKET, TILLER HANDLE (BLACK)	1	
59	43762-88L00	.BOLT TILLER HANDLE PIVOT	1	
60	43768-88L00	.SPACER, TILLER HANDLE	1	
61	09116-08137	.BOLT (8X22)	1	
62	09159-12014	.NUT	1	
63	09160-12066	.WASHER (12.5X22X2.5)	2	
64	09160-12124	.WASHER (12.5X32X1.5)	1	
65	63115-88L00	.BUSH, TILLER HANDLE	2	
66	09164-13010	.WASHER	1	
67	63215-93110	.MARK, HANDLE GRIP	1	
68	09116-10150	.BOLT (10X55)	2	
69	43770-99E03	.ADJUSTER ASSY, STEERING	1	
70	63132-88L00	.STOPPER, TILLER HANDLE	1	
71	63251-88L90	.BOLT	2	
72	37855-88L90	.SCREW, THROTTLE GRIP	1	
73	37854-88L90	.WASHER,THROTTLE GRIP	1	
74	63258-88L00	.WASHER	1	
75	09440-06037	.SPRING	1	
76	03522-05169	.SCREW	3	
77	63247-99J00	.PLATE, THROTTLE ADJ KNOB	1	
78	63111-88L00-YAY	.HOUSING, TILLER HANDLE (BLACK)	1	
79	33834-88L00	.TUBE, CABLE PROTECTOR	1	
80	65793-88L00	.HOLDER, FUEL HOSE	1	
81	09116-06237	.BOLT (6X15)	2	

FIG.585A




FIG.585A (1-L-11) OPT:GASKET SET

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11400-88871	GASKET SET	1	
2	11141-88L00	.GASKET, CYLINDER HEAD	1	
3	11189-88L00	.GASKET, CYLINDER HEAD COVER	1	
4	11413-88L00	.GASKET, UPPER OIL SEAL	1	
5	14151-88L00	.GASKET, EXHAUST COVER	1	
6	17472-96303	.GASKET, PUMP CASE UNDER	1	NOT AVAILABLE FOR AV ORDER 17472-87E10 FOR AV
7	11433-88L00	.GASKET, UNDER OIL SEAL	1	
8	11489-88L01	.GASKET, OIL PAN	1	
9	51211-88L00	.GASKET, ENGINE HOLDER	1	
10	51123-88L00	.GASKET, MOUNT CASE COVER	1	
11	11552-88L00	.GASKET, OIL PAN WTR JKT COV	1	

DF60A_E03_017_585A
OPT:GASKET SET

FIG.600A




FIG.600A (1-L-12) OPT:MULTI FUNCTION GAUGE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34000-96L41	KIT, SINGLE GAUGE MECH	1	
2	34011-96L11	.SET, MULTI GAUGE	1	
3	34112-96L00	..NUT, GAUGE	1	
4	34193-96L00	..BEZEL, GAUGE	1	
5	34211-96L00	..COVER, GAUGE	1	
6	34825-96L00	..PACKING, GAUGE	1	
7	36661-96L10	.ADAPTER, GAUGE	1	
8	36615-96300	..TERMINAL	5	
9	36663-98J10	.WIRE, GAUGE POWER (6M)	1	
10	09481-05501	..FUSE (5A)	1	
11	36001-88L00	SET, WIRE	1	
12	36662-88L10	.WIRE, 2 EXTENSION	1	
13	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
14	36664-88L00	.CONNECTOR, BRANCH	1	
15	36665-88L00	.UNIT, RESISTOR FEMALE	1	
16	36665-88L10	.UNIT, RESISTOR MALE	1	
17	34190-88L00	SENSOR ASSY, PAD WHEEL	1	
18	36662-88L10	WIRE, 2 EXTENSION	1	
19	36662-88L20	WIRE, 6 EXTENSION	1	
20	36662-88L30	WIRE, 15 EXTENSION	1	
21	36662-88L00	WIRE, 25 EXTENSION	1	
22	39950-88L02	MODULE ASSY, GPS RECEIVER	1	
23	36663-88L00	HARNESS ASSY, NETWORK POWER	1	
24	36665-88L00	UNIT, RESISTOR FEMALE	1	
25	36665-88L10	UNIT, RESISTOR MALE	1	
26	36663-98J00	WIRE, GAUGE POWER (2.5M)	1	
27	09481-05501	.FUSE (5A)	1	
28	36663-98J10	WIRE, GAUGE POWER (6M)	1	
29	09481-05501	.FUSE (5A)	1	
30	36664-88L00	CONNECTOR, BRANCH	1	

DF60A_E03_017_600A
OPT:MULTI FUNCTION GAUGE

10000

PART NO.	FIG.NO.-REF.NO.
11100-88L10	111A-1
	111B-1
	111C-1
	111D-1
	111E-1
11112-88L00	113A-7
11115-73G01-001	111A-2
	111A-29
	111B-2
	111B-29
	111C-2
	111C-29
	111D-2
	111D-29
	111E-2
	111E-29
11117-89J20	113A-4
11119-87J00	111A-10
	111B-10
	111C-10
	111D-10
	111E-10
11141-88L00	111A-11
	111B-11
	111C-11
	111D-11
	111E-11
	585A-2
11170-88L10	111A-16
	111B-16
	111C-16
	111D-16
	111E-16
11173-88L00	111A-20
	111B-20
	111C-20
	111D-20
	111E-20
11174-88L00	111A-22
	111B-22
	111C-22
	111D-22
	111E-22
11189-88L00	111A-17
	111B-17
	111C-17
	111D-17
	111E-17
	585A-3
11194-88L10	111A-26
	111B-26
	111C-26
	111D-26
	111E-26
11196-88L00	162A-8
	162B-8
	162C-8
	162D-8
	162E-8
11261-93J00	111A-5
	111B-5
	111C-5
	111D-5
	111E-5
11291-88L00	113A-1
11301-88L10	113A-3
11382-93J00	111A-14
	111B-14
	111C-14
	111D-14
	111E-14
11400-88871	585A-1
11411-88L00	136A-6
11413-88L00	136A-7
	585A-4
11433-88L00	175A-1
	585A-7
11489-88L01	180A-1
	180B-1
	180C-1
	180D-1
	180E-1
	585A-8
11501-88L01-Y5S	180A-2-2
	180B-2-2
	180C-2-2
11501-88L01-YAY	180A-2-1
	180B-2-1
	180C-2-1
	180D-2
	180E-2
11510-88L00	136A-1
11514-88L00	136A-5
11543-88L00	180A-11
	180B-11
	180C-11
	180D-11
	180E-11
11551-88L00-Y5S	180A-6-2
	180B-6-2
	180C-6-2
11551-88L00-YAY	180A-6-1
	180B-6-1
	180C-6-1
	180D-6
	180E-6
11552-88L00	180A-7
	180B-7
	180C-7
	180D-7
	180E-7
	585A-11
12100-51810-0A0	116A-8-1
12100-51810-0B0	116A-8-2
12100-51810-0C0	116A-8-3
12100-51810-0D0	116A-8-4
12100-51810-0E0	116A-8-5
12100-88L00-050	116A-13
12111-88L00	116A-1
12140-88L00	116A-2
12140-88L00-050	116A-14
12151-54A50	116A-3
12160-88L01	116A-5
12163-69J00	116A-6
12220-88L00	116A-9
12281-87J00	116A-12
12340-75F00-0C0	116A-10-3
12340-75F00-0D0	116A-10-4
12340-75F00-0E0	116A-10-5
12340-75FA0-0A0	116A-10-1
12340-75FA0-0B0	116A-10-2
12710-88L00	121A-1
12720-88L00	121A-2
12741-88L00	121A-3
12761-88L00	119A-1
12771-87J00	119A-2
12776-85FA0	119A-3
12811-88L00	119A-4
12812-73G10	119A-7
12813-73G00	119A-8
12821-88L00	119A-11
12831-90J02	119A-9
12891-73G01	121A-7
12892-73G01-218	121A-8-1
12892-73G01-220	121A-8-2

PART NO.	FIG.NO.-REF.NO.
12892-73G01-222	121A-8-3
12892-73G01-224	121A-8-4
12892-73G01-226	121A-8-5
12892-73G01-228	121A-8-6
12892-73G01-230	121A-8-7
12892-73G01-232	121A-8-8
12892-73G01-234	121A-8-9
12892-73G01-236	121A-8-10
12892-73G01-238	121A-8-11
12892-73G01-240	121A-8-12
12892-73G01-242	121A-8-13
12892-73G01-244	121A-8-14
12892-73G01-246	121A-8-15
12892-73G01-248	121A-8-16
12892-73G01-250	121A-8-17
12892-73G01-252	121A-8-18
12892-73G01-254	121A-8-19
12892-73G01-256	121A-8-20
12892-73G01-258	121A-8-21
12892-73G01-260	121A-8-22
12892-73G01-262	121A-8-23
12892-73G01-264	121A-8-24
12892-73G01-266	121A-8-25
12892-73G01-268	121A-8-26
12892-73G01-270	121A-8-27
12892-73G01-272	121A-8-28
12892-73G01-274	121A-8-29
12892-73G01-276	121A-8-30
12892-73G01-278	121A-8-31
12892-73G01-280	121A-8-32
12892-73G01-282	121A-8-33
12892-73G01-284	121A-8-34
12892-73G01-286	121A-8-35
12892-73G01-288	121A-8-36
12892-73G01-290	121A-8-37
12892-73G01-292	121A-8-38
12892-73G01-294	121A-8-39
12892-73G01-296	121A-8-40
12892-73G01-298	121A-8-41
12892-73G01-300	121A-8-42
12911-88L00	121A-9
12915-73G20	121A-10
12921-87J10	121A-11
12931-78G00	121A-12
12932-24400	121A-13
12933-51E00	121A-14
13110-88L00	124A-1
	124B-1
	124C-1
	124D-1
	124E-1
13119-88L00	124A-2
	124B-2
	124C-2
	124D-2
	124E-2
13125-88L00	124A-3
	124B-3
	124C-3
	124D-3
	124E-3
13300-88L01	163A-1
13315-88L00	163A-2
13370-88L00	143A-2
13510-88L00	163A-6
13810-88L00	124A-10
	124B-10
	124C-10
	124D-10
	124E-10
13813-88L00	124C-11
	124E-11
13820-88L00	124A-11
13820-88L10	124B-11
	124D-11
14141-88L00	124A-13
	124B-13
	124C-13
	124D-13
	124E-13
14151-88L00	124A-14
	124B-14
	124C-14
	124D-14
	124E-14
	585A-5
15100-90J11	146A-1
15191-88L20	146A-10
15192-88L20	146A-11
15197-88L00	146A-15
15200-88L00	143A-3
15410-88L00	146A-4
15419-87J00	146A-5
15421-88L00	146A-8
15422-96J00	146A-7
15600-88L03	143A-1
15612-88L00	143A-21
15613-88L00	143A-22
15613-92J00	143A-23
15614-88L00	143A-24
15626-88L00	143A-4
15628-99E00	143A-5
15629-99E10	143A-6
15641-88L00	143A-7
15641-88L31	143A-18
15641-88L51	143A-19
15642-88L00	143A-8
15642-88L10	143A-20
15643-88L00	143A-17
15644-88L00	143A-13
15645-88L00	143A-14
15650-99E00	143A-9
15654-88L00	143A-10
15681-88L10	144A-7
15683-87J00	143A-11
15710-85K00	144A-1
15716-65DT0	144A-2
15750-88L10	144A-4
15760-88L00	143A-12
16400-88L00	175A-2
16510-87J00	175A-9
16519-87L00	175A-8
16520-88L00	175A-5
16910-88L00	180A-14
	180B-14
	180C-14
	180D-14
	180E-14
16930-88L00	180A-15
	180B-15
	180C-15
	180D-15
	180E-15
17400-88L00	160A-21
	160B-21
	160C-21
17400-99E10	160D-20
	160E-20
17410-88L00	160A-1
	160B-1
	160C-1
17410-99E10	160D-1
	160E-1
17413-95J00	160A-2
	160B-2
	160C-2
17413-99E11	160D-18
	160E-18
17416-95J00	160A-3
	160B-3

PART NO.	FIG.NO.-REF.NO.
	160C-3
17416-99E10	160D-19
	160E-19
17461-87E12	160D-2
	160E-2
17461-96312	160A-9
	160B-9
	160C-9
17471-95J01	160A-10
	160B-10
	160C-10
17471-99E00	160D-3
	160E-3
17472-87E10	160D-4
	160E-4
17472-96303	160A-11
	160B-11
	160C-11
	585A-6
17560-88L10	160A-12
	160B-12
	160C-12
17560-88L30	160D-5
	160E-5
17562-87L00	160A-13
	160A-14
	160B-13
	160B-14
	160C-13
	160C-14
	160D-6
	160D-7
	160E-6
	160E-7
17564-87D00	160D-8
	160E-8
17564-88L00	160A-4
	160B-4
	160C-4
17611-90J00-Y5S	162A-1-2
	162B-1-2
	162C-1-2
17611-90J00-YAY	162A-1-1
	162B-1-1
	162C-1-1
	162D-1
	162E-1
17631-90J00	160D-9
	160E-9
17631-96320	160A-16
	160B-16
	160C-16
17632-90J00	160D-10
	160E-10
17635-87E00	160A-18-1
	160B-18-1
	160C-18-1
17635-87E10	160A-18-2
	160B-18-2
	160C-18-2
	160D-21
	160E-21
17635-90J00	160D-11
	160E-11
17660-99E01	162A-2
	162B-2
	162C-2
	162D-2
	162E-2
17670-93953	162A-5
	162B-5
	162C-5
	162D-5
	162E-5
17681-88L00	162A-6
	162B-6
	162C-6
	162D-6
	162E-6
17712-88L00	162A-11
	162B-11
	162C-11
	162D-11
	162E-11
17913-93J00	180A-9
	180B-9
	180C-9
	180D-9
	180E-9
17914-93J00	180A-10
	180B-10
	180C-10
	180D-10
	180E-10
17917-87L00	420A-19
	420B-19
	420C-19
	420D-19
	420E-19
18137-88L01	124A-8
	124B-8
	124C-8
	124D-8
	124E-8
18210-88L00	420A-16
	420B-16
	420C-16
	420D-16
	420E-16
18498-88L10	143A-31
18498-94J20	162A-10
	162B-10
	162C-10
	162D-10
	162E-10
18498-96J20	146A-14
18498-99E10	146A-13
18498-99EA0	507A-6
19120-88L01	163A-7
19120-88L11	570A-56
	570B-56
	570C-56
	570D-56
	570E-56
19131-95502	163A-8
20000	
21110-88L00	570A-2
	570B-2
	570C-2
	570D-2
	570E-2
21112-88L00	570A-40
	570B-40
	570C-40
	570D-40
	570E-40
21121-93300	206A-13
	206B-13
	206C-13
	210A-1
	210B-1
21126-88L00	204A-1
	204B-1
	204C-1
	204D-1
	204E-1

PART NO.	FIG.NO.-REF.NO.
21131-88L01	570A-57
	570B-57
	570C-57
	570D-57
	570E-57
21151-88L00	204A-2
	204B-2
	204C-2
	204D-2
	204E-2
21210-88L00	204A-5
	204B-5
	204C-5
	204D-5
	204E-5
22511-99011	336A-5
	336B-5
	336C-5
	336D-5
	336E-5
	570A-81
	570B-81
23111-88L00	204D-6
	204E-6
23111-88L10	204A-6
	204B-6
	204C-6
23115-88L00	204A-8
	204B-8
	204C-8
	204D-8
	204E-8
23210-88L00	204A-9
	204B-9
	204C-9
	204D-9
	204E-9
23213-89J01	204A-12
	204B-12
	204C-12
	204D-12
	204E-12
23214-89J00	204A-13
	204B-13
	204C-13
	204D-13
	204E-13
23230-88L00	570A-3
	570B-3
	570C-3
	570D-3
	570E-3
23311-95J00	204A-15
	204B-15
	204C-15
	204D-15
	204E-15
25111-88L10	206A-1
	206B-1
	206C-1
25111-88L30	210A-2
	210B-2
25141-99E03	210A-3
	210B-3
25205-94501	210A-4
	210B-4
25211-87J00	206A-2
	206B-2
	206C-2
25211-94501	210A-5
	210B-5
25212-94401	206A-5
	206B-5
	206C-5
25223-94400	206A-9
	206B-9
	206C-9
25230-94300	210A-6
	210B-6
25232-96302	206A-10
	206B-10
	206C-10
25311-88L00	206A-11
	206B-11
	206C-11
25311-94510	210A-7
	210B-7
25700-88L00	407A-20
	407B-20
	407C-20
25700-99E00	407D-32
	407E-32
29103-93J00	315C-12
	315D-12
	315E-12
29116-93J00	401A-15
	401B-15
	401C-15
	401D-15
	401E-15
29116-93J10	160D-12
	160E-12
29141-93J00	160A-5
	160B-5
	160C-5
	204A-7
	204B-7
	204C-7
	204D-7
	204E-7
	336C-26
	336D-26
	336E-26
29162-93J00	160A-6
	160B-6
	160C-6
29404-93J10	315A-12
	315B-12
	337A-2
	337B-2
	337C-2
	337D-2
	337E-2
30000	
31100-94J22	301A-1
31111-87J10	340A-9
31123-97E10	340A-4
31131-94J00	301A-2
31133-94900	340A-5
31135-90J00	301A-3
31135-94900	340A-6
31136-87J10	340A-7
31151-94J01	301A-4
31152-90J00	301A-5
31153-90J00	301A-6
31170-94J00	301A-17
31171-96J00	301A-7
31173-88L11	340A-3
31173-94J01	301A-8
31191-96J00	301A-9
31220-94J00	301A-10
31310-90J00	301A-11
31311-87J10	340A-2
31320-94J00	301A-12

PART NO.	FIG.NO.-REF.NO.
31341-94J00	301A-13
31343-90J00	301A-14
31344-90J00	301A-15
31360-93J01	301A-16
31912-88L00	301A-18
31918-87L00	301A-19
32102-88L01	303A-1
32120-88L00	303A-5
32160-88L00	303A-6
32800-88L00	310A-1
32890-88L00	310A-3
33220-64L10	303A-8
33410-87L00	310A-7
33634-96J00	322A-4
	322B-4
	322C-4
	322D-4
	322E-4
33799-97E00	340A-8
33810-88L10	322A-1
	322B-1
	322C-1
	322D-1
	322E-1
33834-88L00	570A-78
	570B-78
	570C-79
	570D-79
	570E-79
33925-88L10	326A-10
	326B-10
	326C-10
	326D-10
	326E-10
33940-88L00	326C-9
33940-88L20	326A-9
33940-88L40	326B-9
33940-88L50	326E-9
33940-88L70	326D-9
34000-96L41	600A-1
34011-96L11	600A-2
34100-93J00	501A-3-1
34100-93J11	501A-3-2
34100-93J20	501A-3-3
34100-93J31	501A-3-4
34100-93J40	501A-3-5
34100-93J51	501A-3-6
34100-93J60	501A-3-7
34112-96L00	600A-3
34190-87D00	501A-26
34190-88L00	600A-17
34190-95500	501A-24
34191-92E00	501A-5
	501A-17
34193-96L00	600A-4
34200-87L00	570A-44
	570B-44
	570C-44
	570D-44
	570E-44
34200-93J00	501A-20-1
34200-93J12	501A-20-2
34200-93J40	501A-22-1
34200-93J51	501A-22-2
34211-96L00	600A-5
34300-93J00	501A-10-1
34300-93J11	501A-10-2
34310-92E00	501A-11
34360-92E00	501A-12
34500-93J00	501A-14-1
34500-93J11	501A-14-2
34600-93J00	501A-8-1
34600-93J11	501A-8-2
34650-93J20	501A-16-1
34650-93J31	501A-16-2
34660-90J02	507A-1
34800-93J00	501A-1-1
34800-93J11	501A-1-2
34825-96L00	600A-6
34830-87J20	315A-1
	315B-1
	315C-1
	315D-1
	315E-1
34840-98J03	315A-2
	315B-2
34840-98J11	315C-2
	315D-2
	315E-2
34841-87L10	315C-5
	315D-5
	315E-5
34841-88L00	315A-10
	315B-10
34842-88L10	315C-6
	315D-6
	315E-6
34843-87L00	315C-7
	315D-7
	315E-7
34845-88L01	315A-11
	315B-11
34845-88L10	315C-8
	315D-8
	315E-8
34846-87L00	315C-4
	315D-4
	315E-4
36001-88L00	600A-11
36610-88LD1	322A-3
	322B-3
36610-88LE2	322C-3
	322D-3
	322E-3
36611-88L00	322C-17
	322D-17
	322E-17
36612-96J00	322A-15
	322B-15
	322C-15
	322D-15
	322E-15
36615-96300	501A-7
	600A-8
36617-88L00	315C-11
	315D-11
	315E-11
	322A-21
	322B-21
	322C-22
	322D-22
	322E-22
36617-88L10	322A-22
	322B-22
	322C-23
	322D-23
	322E-23
36617-88L90	570A-45
	570B-45
	570C-45
	570D-45
	570E-45
36617-93J10	322A-23
	322B-23
	322C-24
	322D-24
	322E-24
36618-43410	322A-16
	322B-16
	322C-16

PART NO.	FIG.NO.-REF.NO.
	322D-16
	322E-16
36620-88L10	570A-4
	570B-4
	570C-4
	570D-4
	570E-4
36620-93J02	521A-4-1
36620-93J10	521A-1-1
36620-93J30	521A-2
36620-93J40	521A-1-2
36620-93J52	521A-4-2
36620-93J62	521A-4-3
36656-88L00	315A-8
	315B-8
	315C-15
	315D-15
	315E-15
36661-96L10	600A-7
36662-88L00	600A-21
36662-88L10	600A-12
	600A-18
36662-88L20	600A-19
36662-88L30	600A-20
36663-88L00	600A-13
	600A-23
36663-98J00	600A-26
36663-98J10	600A-9
	600A-28
36664-88L00	600A-14
	600A-30
36665-88L00	600A-15
	600A-24
36665-88L10	600A-16
	600A-25
36667-96L20	521A-8
36668-87L00	322A-5
	322B-5
	322C-5
	322D-5
	322E-5
36682-92E00	521A-7
36721-96J00	322A-8
	322B-8
	322C-8
	322D-8
	322E-8
36737-96J00	322A-7
	322B-7
	322C-7
36738-88L00	322A-9
	322B-9
	322C-9
	322D-9
	322E-9
36890-93J00	544A-16
36894-87D00	336C-6
	336D-6
	336E-6
36894-95201	336A-6
	336B-6
36895-87D01	336A-7
	336A-8
	336B-7
	336B-8
	336C-7
	336C-8
	336D-7
	336D-8
	336E-7
	336E-8
36990-87D00	521A-6
37100-96J00	530A-1
37100-96J24	530A-19
37110-87L01	570A-5
	570B-5
	570C-5
	570D-5
	570E-5
37110-93J01	530A-2
	530A-20
37112-88L91	570A-46
	570B-46
	570C-46
	570D-46
	570E-46
37139-99E00	530A-6
37139-99E20	530A-24
37141-99E00	530A-3-1
	530A-21-1
	570A-6-1
	570B-6-1
	570C-6-1
	570D-6-1
	570E-6-1
37141-99E10	530A-3-2
	530A-21-2
	570A-6-2
37141-99E20	530A-3-3
	530A-21-3
	570A-6-3
	570B-6-3
	570C-6-3
	570D-6-3
	570E-6-3
37141-99E30	530A-3-4
	530A-21-4
	570A-6-4
	570B-6-4
	570C-6-4
	570D-6-4
	570E-6-4
37141-99E40	530A-3-5
	530A-21-5
	570A-6-5
	570B-6-5
	570C-6-5
	570D-6-5
	570E-6-5
37141-99E50	530A-3-6
	530A-21-6
	570A-6-6
	570B-6-6
	570C-6-6
	570D-6-6
	570E-6-6
37141-99E60	530A-3-7
	530A-21-7
	570A-6-7
	570B-6-7
	570C-6-7
	570D-6-7
	570E-6-7
37141-99E70	530A-3-8
	530A-21-8
	570A-6-8
	570B-6-8
	570C-6-8
	570D-6-8
	570E-6-8
37141-99E80	530A-3-9
	530A-21-9
	570A-6-9
	570B-6-9

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	570C-6-9		326E-3		570E-48
	570D-6-9	37803-93J04	530A-9	37852-87J00	570A-14
	570E-6-9	37805-93J00	530A-15		570B-14
37141-99E90	530A-3-10	37820-87L01	570A-9		570C-14
	530A-21-10		570B-9		570D-14
	570A-6-10		570C-9		570E-14
	570B-6-10		570D-9	37852-88L90	570A-49
	570C-6-10		570E-9		570B-49
	570D-6-10	37820-93J04	530A-10		570C-49
	570E-6-10		530A-25		570D-49
37141-99EA0	530A-3-11	37820-99E01	315A-6		570E-49
	530A-21-11		315B-6	37853-88L90	570A-34
	570A-6-11		315C-10		570B-34
	570B-6-11		315D-10		570C-34
	570C-6-11		315E-10		570D-34
	570D-6-11	37823-92E01	530A-11		570E-34
	570E-6-11		530A-26	37854-88L90	570A-72
37141-99EB0	530A-3-12		570A-10		570B-72
	530A-21-12		570B-10		570C-73
	570A-6-12		570C-10		570D-73
	570B-6-12		570D-10		570E-73
	570C-6-12		570E-10	37855-88L90	570A-71
	570D-6-12	37825-99E00	530A-13		570B-71
	570E-6-12	37826-92J00	530A-12		570C-72
37143-99E00	530A-4		530A-27		570D-72
	530A-22		570A-11		570E-72
	570A-7		570B-11	37855-99E00	530A-16
	570B-7		570C-11	37856-92J00	326A-12
	570C-7		570D-11		326B-12
	570D-7		570E-11		326C-12
	570E-7	37835-95D00	570A-47		326D-12
37149-93J00	530A-5		570B-47		326E-12
	530A-23		570C-47	37857-92J00	326A-13
	570A-8		570D-47		326B-13
	570B-8		570E-47		326C-13
	570C-8	37850-87L01	570A-13		326D-13
	570D-8		570B-13		326E-13
	570E-8		570C-13	37860-87L00	530A-31
37210-93J00	530A-17		570D-13	37861-87L11	570A-50
37212-93J00	530A-18		570E-13		570B-50
37721-93J00	326A-1	37850-92J00	326A-11		570C-50
	326B-1		326B-11		570D-50
	326C-1		326C-11		570E-50
	326D-1		326D-11	37862-87L00	530A-32
	326E-1		326E-11	37864-88L91	570A-51
37721-95500	545A-11	37850-93J10	544A-4		570B-51
37725-88L00	326A-3	37851-88L90	570A-48		570C-51
	326B-3		570B-48		570D-51
	326C-3		570C-48		570E-51
	326D-3		570D-48	38100-88L11	337A-3

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	337B-3		335D-2		180C-12
	337C-3		335E-2		180D-12
	337D-3	41121-88L10-Y5S	335A-2-2		180E-12
	337E-3		335B-2-2	43114-88L00	336C-14
	340A-1	41121-88L10-YAY	335A-2-1		336D-14
38410-93J12	326A-6		335B-2-1		336E-14
	326B-6	41130-87J11	335A-3	43119-88L00	336C-11
	326C-6		335B-3		336D-11
	326D-6	41130-88L10	335C-3		336E-11
	326E-6		335D-3	43119-88L10	336C-12
38415-93J00	326A-7		335E-3		336D-12
	326B-7	41135-93J00	335A-15		336E-12
	326C-7		335B-15	43211-87J00	336A-2
	326D-7		335C-4		336B-2
	326E-7		335D-4	43211-88L00	336C-2
38500-93J00	521A-3		335E-4		336D-2
38500-93J90	530A-7	41161-94400	442A-1		336E-2
	530A-29	41221-88L00	336C-23	43411-88L00	570A-82
	570A-12		336D-23		570B-82
	570B-12		336E-23	43415-88L00	570A-83
	570C-12	41224-88L00	336C-25		570B-83
	570D-12		336D-25	43512-88L00	570A-84
	570E-12		336E-25		570B-84
38860-76F01	322A-10	41226-97E00	336A-19	43513-88L00	570A-85
	322A-11		336B-19		570B-85
	322B-10	41230-97E10	336A-24	43514-88L00	570A-86
	322B-11		336B-24		570B-86
	322C-10	41231-88L01	336C-27	43515-88L00	570A-87
	322C-11		336D-27		570B-87
	322D-10		336E-27	43516-88L00	570A-88
	322D-11	41234-88L00	336C-28		570B-88
	322E-10		336D-28	43517-88L00	570A-89
	322E-11		336E-28		570B-89
39950-88L02	600A-22	41270-89J10	336A-20	43711-89J10	336A-3
			336B-20		336B-3
		41280-88L10	336C-24	43711-97E01	336C-3
			336D-24		336D-3
40000			336E-24		336E-3
		41280-89J04	336A-21	43750-88L22-Y5S	336A-4-2
			336B-21		336B-4-2
41111-88L10-Y5S	335C-1-2	43111-88L21-Y5S	336A-1-2		336C-4-2
41111-88L10-YAY	335C-1-1		336B-1-2	43750-88L22-YAY	336A-4-1
	335D-1	43111-88L21-YAY	336A-1-1		336B-4-1
	335E-1		336B-1-1		336C-4-1
41111-88L20-Y5S	335A-1-2	43111-88L40-Y5S	336C-1-2	43750-88L32-YAY	336D-4
	335B-1-2	43111-88L40-YAY	336C-1-1		336E-4
41111-88L20-YAY	335A-1-1	43111-88L50-YAY	336D-1	43755-88L00	336A-11
	335B-1-1		336E-1		336B-11
41121-88L01-Y5S	335C-2-2	43112-99E00	180A-12		336C-19
41121-88L01-YAY	335C-2-1		180B-12		336D-19

PART NO.	FIG.NO.-REF.NO.
	336E-19
43761-88L01-YAY	570A-58
	570B-58
	570C-58
	570D-58
	570E-58
43762-88L00	570A-59
	570B-59
	570C-59
	570D-59
	570E-59
43768-88L00	570A-60
	570B-60
	570C-60
	570D-60
	570E-60
43770-99E03	570C-69
	570D-69
	570E-69
45421-89J00	335A-4
	335B-4
45731-96312	336A-22
	336B-22
	336C-29
	336D-29
	336E-29
47225-87J00	337A-19
	337B-19
47225-88L00	337C-19
	337D-17
	337E-17
48000-88L15	337A-1
	337B-1
	337C-1
48000-88L20	337D-1
	337E-1
48121-88L00	337C-20
48121-88L10	337D-18
	337E-18
48121-89J10	337A-20
	337B-20
48320-87J10	337A-4
	337B-4
	337C-4
	337D-4
	337E-4
48321-89J11	337A-21
	337B-21
	337C-21
48321-89J20	337D-19

PART NO.	FIG.NO.-REF.NO.
	337E-19
48325-89J00	337A-22
	337B-22
	337C-22
48325-89J10	337D-20
	337E-20
48326-87J00	337A-23
	337B-23
	337C-23
	337D-21
	337E-21
48330-87J10	337A-5
	337B-5
	337C-5
48330-87J20	337D-5
	337E-5
48510-97E00	337A-6
	337B-6
	337C-6
48510-97E10	337D-6
	337E-6
48541-87J10	337A-7
	337B-7
	337C-7
48541-87J20	337A-8
	337B-8
	337C-8
	337D-7
	337E-7
48551-88L00	337A-9
	337B-9
	337C-9
48551-88L10	337D-8
	337E-8
48553-88L00	337A-10
	337B-10
	337C-10
	337D-9
	337E-9
48557-87J10	337A-11
	337B-11
	337C-11
	337D-10
	337E-10
48571-88L00	337A-12
	337B-12
	337C-12
	337D-11
	337E-11
48572-87L00	337A-13

PART NO.	FIG.NO.-REF.NO.
	337B-13
	337C-13
	337D-12
	337E-12
48582-97E01	337A-14
	337B-14
	337C-14
48583-87J10	337A-15
	337B-15
	337C-15
	337D-13
	337E-13
48611-88L00	337A-16
	337B-16
	337C-16
	337D-14
	337E-14
48681-87J11	337A-17
	337B-17
	337C-17
	337D-15
	337E-15
48862-87J20	337A-18
	337B-18
	337C-18
	337D-16
	337E-16

50000

PART NO.	FIG.NO.-REF.NO.
51110-88L10-Y5S	401A-1-2
	401B-1-2
	401C-1-2
51110-88L10-YAY	401A-1-1
	401B-1-1
	401C-1-1
	401D-1
	401E-1
51122-88L00	401A-8
	401B-8
	401C-8
	401D-8
	401E-8
51123-88L00	401A-9
	401B-9

PART NO.	FIG.NO.-REF.NO.
	401C-9
	401D-9
	401E-9
	585A-10
51170-88L00	401A-14
	401B-14
	401C-14
	401D-14
	401E-14
51211-88L00	401A-2
	401B-2
	401C-2
	401D-2
	401E-2
	585A-9
52111-88L10-Y5S	405A-1-2
	405B-1-2
	405C-1-2
52111-88L10-YAY	405A-1-1
	405B-1-1
	405C-1-1
52111-88L20-YAY	405D-1
	405E-1
52131-88L11-YAY	405D-7
	405E-7
54114-90J01	401A-20
	401A-22
	401B-20
	401B-22
	401C-20
	401C-22
	401D-20
	401D-22
	401E-20
	401E-22
	405A-14
	405B-14
	405C-14
	405D-20
	405E-20
54120-88L00	401D-17
	401E-17
54121-88L00	401A-23
	401B-23
	401C-23
54123-88L00	401A-24
	401B-24
	401C-24
54124-88L20	401A-17
	401B-17

PART NO.	FIG.NO.-REF.NO.
	401C-17
54130-88L00	401A-18
	401B-18
	401C-18
	401D-18
	401E-18
54137-88L00	401A-12
	401B-12
	401C-12
	401D-12
	401E-12
54151-88L00	405A-8
	405B-8
	405C-8
	405D-14
	405E-14
54160-88L10	405A-9
	405B-9
	405C-9
	405D-15
	405E-15
54166-95J02	401A-19
	401B-19
	401C-19
	401D-19
	401E-19
	405A-12
	405B-12
	405C-12
	405D-18
	405E-18
54167-87L01	405A-10
	405B-10
	405C-10
	405D-16
	405E-16
54180-88L00	405A-11
	405B-11
	405C-11
	405D-17
	405E-17
54211-87J30-Y5S	405A-7-2
	405B-7-2
	405C-7-2
54211-87J30-YAY	405A-7-1
	405B-7-1
	405C-7-1
	405D-13
	405E-13
54221-88L20-Y5S	405A-4-2

PART NO.	FIG.NO.-REF.NO.
	405B-4-2
	405C-4-2
54221-88L20-YAY	405A-4-1
	405B-4-1
	405C-4-1
	405D-4
	405E-4
54231-88L10-Y5S	405A-5-2
	405B-5-2
	405C-5-2
54231-88L10-YAY	405A-5-1
	405B-5-1
	405C-5-1
	405D-5
	405E-5
55100-87J50-Y5S	407A-1-2
	407B-1-2
	407C-1-2
55100-87J50-YAY	407A-1-1
	407B-1-1
	407C-1-1
55110-90J15-YAY	407D-1
	407E-1
55122-88L00	220A-29
	220B-29
	220C-29
55125-90J01	407D-3
	407E-3
55125-94400	407A-4
	407B-4
	407C-4
55127-87D00	143A-36
	407D-4
	407E-4
55181-95200	407A-17
	407B-17
	407C-17
	407D-28
	407E-28
55300-95500	407A-18
	407B-18
	407C-18
	407D-27
	407E-27
55320-94900	335C-11
55321-87J01	111A-7-1
	111B-7-1
	111C-7-1
	111D-7-1
	111E-7-1

PART NO.	FIG.NO.-REF.NO.
	113A-8
	335A-6
	335B-6
	335D-11
	335E-11
	337A-26
	337B-26
	337C-26
	337D-24
	337E-24
	405D-11
	405E-11
55321-87J11	111A-7-2
	111B-7-2
	111C-7-2
	111D-7-2
	111E-7-2
	160D-22
	160E-22
	407A-19
	407B-19
	407C-19
55321-90J01	407D-5
	407E-5
55332-87D11	407D-6
	407E-6
55333-87D10	407D-7
	407E-7
56120-90J02-YAY	220D-19
	220E-19
56120-94321-Y5S	220A-20-2
	220B-20-2
	220C-20-2
56120-94321-YAY	220A-20-1
	220B-20-1
	220C-20-1
56123-90J00	220D-20
	220E-20
56130-87E00	220D-27
	220E-27
56130-87J11-Y5S	220A-26-2
	220B-26-2
	220C-26-2
56130-87J11-YAY	220A-26-1
	220B-26-1
	220C-26-1
56145-99E01	407D-29
	407E-29
57110-88L12	220A-1
	220B-1
57110-88L30	220D-1
	220E-1
57133-88L01	220A-2
	220B-2
57133-90J02	220D-2
	220E-2
57133-94400	220A-3
	220B-3
57300-88810	220A-6
	220B-6
	220C-6
57300-99824	220D-4
	220E-4
57610-88L10	220D-11
	220E-11
57610-94402	220A-13
	220B-13
57621-87J03	220A-14
	220B-14
	220C-14
57621-88L00	220D-12
	220E-12
57630-90J00	407D-26
	407E-26
57630-94300	407A-16
	407B-16
57631-95303	407C-16
	220A-19
	220B-19
57631-99E01	220C-19
	220D-14
57632-95320	220E-14
	407A-11
	407B-11
	407C-11
57633-90J02	407D-21
	407E-21
57633-94300	407A-12
	407B-12
	407C-12
57634-88L00	220A-16
	220B-16
	220C-16
57635-90J01	407D-22
	407E-22
58100-87LA0-019	407D-19-1
	407E-19-1
58100-87LB0-019	407D-19-2
	407E-19-2
58100-87LC0-019	407D-19-3
	407E-19-3
58100-87LG1-019	407D-19-6
	407E-19-6
58100-87LH0-019	407D-19-5
	407E-19-5
58100-87LJ0-019	407D-19-4
	407E-19-4
58100-88L03-019	407A-9-1
	407B-9-1
	407C-9-1
58100-88L13-019	407A-9-2
	407B-9-2
	407C-9-2
58100-88L23-019	407A-9-3
	407B-9-3
	407C-9-3
58100-88L52-019	407A-9-6
	407B-9-6
	407C-9-6
58100-88L62-019	407A-9-7
	407B-9-7
	407C-9-7
58100-88L72-019	407A-9-8
	407B-9-8
	407C-9-8
58100-88L83-019	407A-9-9
	407B-9-9
	407C-9-9
58100-88LA0-019	407A-9-4
	407B-9-4
	407C-9-4
58100-88LB0-019	407A-9-5
	407B-9-5
	407C-9-5
58105-90J00	407D-20
	407E-20
58120-88L01	407A-10
	407B-10
	407C-10
58200-88L30	407A-9-10
	407B-9-10
	407C-9-10

60000

PART NO.	FIG.NO.-REF.NO.
61112-88L10	410A-1
	410B-1
	410C-1
	410D-1
	410E-1
61124-88L10	410A-24
	410B-24
	410C-24
	410D-24
	410E-24
61134-88L10	410A-2
	410B-2
	410C-2
	410D-2
	410E-2
61151-88L00	410A-6
	410B-6
	410C-6
	410D-6
	410E-6
61188-88L00	430A-4
61400-88820-YAY	420A-1-1
	420B-1-1
	420C-1-1
	420D-1
	420E-1
61400-88830-Y5S	420A-1-2
	420B-1-2
	420C-1-2
61412-88L00	410A-11
	410B-11
	410C-11
	410D-11
	410E-11
61422-88L30	420A-12-1
61422-88L40	420B-12-1
	420D-12
61422-88L50	420C-12-1
	420E-12
61422-88L60	420A-12-2
61422-88L70	420B-12-2
61422-88L80	420C-12-2
61431-88L10-Y5S	420A-2-2
	420B-2-2
	420C-2-2
61431-88L10-YAY	420A-2-1
	420B-2-1
	420C-2-1
	420D-2
	420E-2
61435-88L60	420A-13-1
61435-88L70	420B-13-1
	420D-13
61435-88L80	420C-13-1
	420E-13
61435-88L90	420A-13-2
61435-88LA0	420B-13-2
61435-88LB0	420C-13-2
61438-88L00	420A-3
	420B-3
	420C-3
	420D-3
	420E-3
61439-88L00	420A-4
	420B-4
	420C-4
	420D-4
	420E-4
61443-88L20	420A-9-1
	420B-9-1
	420C-9-1
	420D-9
	420E-9
61443-88L30	420A-9-2
	420B-9-2
	420C-9-2
61453-88L20	420A-10-1
	420B-10-1
	420C-10-1
	420D-10
	420E-10
61453-88L30	420A-10-2
	420B-10-2
	420C-10-2
61458-90J00	420A-14
	420B-14
	420C-14
	420D-14
	420E-14
61472-88L00	136A-10
61476-88L00	420A-6
	420B-6
	420C-6
	420D-6
	420E-6
61494-88L01	136A-12
61610-95J00	420A-7
	420B-7
	420C-7
	420D-7
	420E-7
61632-93J00	410A-13
	410B-13
	410C-13
	410D-13
	410E-13
61633-88L00	410A-16
	410B-16
	410C-16
	410D-16
	410E-16
61641-88L00	410A-14
	410B-14
	410C-14
	410D-14
	410E-14
61673-93J11	410A-22
	410B-22
	410C-22
	410D-22
	410E-22
61811-88L20-Y5S	410A-3-2
	410B-3-2
	410C-3-2
61811-88L20-YAY	410A-3-1
	410B-3-1
	410C-3-1
61811-88L30-YAY	410D-3
	410E-3
61821-88L20-Y5S	410A-4-2
	410B-4-2
	410C-4-2
61821-88L20-YAY	410A-4-1
	410B-4-1
	410C-4-1
61821-88L30-YAY	410D-4
	410E-4
61831-88L10-Y5S	410A-7-2
	410B-7-2
	410C-7-2
61831-88L10-YAY	410A-7-1
	410B-7-1
	410C-7-1
	410D-7
	410E-7

PART NO.	FIG.NO.-REF.NO.
63002-88L12-YAY	570C-1
	570D-1
	570E-1
63002-88L22-YAY	570A-1
	570B-1
63111-88L00-YAY	570A-77
	570B-77
	570C-78
	570D-78
	570E-78
63115-88L00	570A-65
	570B-65
	570C-65
	570D-65
	570E-65
63121-88L00	570A-15
	570B-15
	570C-15
	570D-15
	570E-15
63132-88L00	570A-69
	570B-69
	570C-70
	570D-70
	570E-70
63210-88L00	570A-16
	570B-16
	570C-16
	570D-16
	570E-16
63215-93110	570A-67
	570B-67
	570C-67
	570D-67
	570E-67
63221-88L00	570A-17
	570B-17
	570C-17
	570D-17
	570E-17
63223-92D00	570A-18
	570B-18
	570C-18
	570D-18
	570E-18
63225-88L00	570A-19
	570B-19
	570C-19
	570D-19
	570E-19
63227-93200	570A-20
	570B-20
	570C-20
	570D-20
	570E-20
63235-88L00	570A-21
	570B-21
	570C-21
	570D-21
	570E-21
63244-99J00	570A-52
	570B-52
	570C-52
	570D-52
	570E-52
63245-99J00	570A-53
	570B-53
	570C-53
	570D-53
	570E-53
63246-88L00	570A-22
	570B-22
	570C-22
	570D-22
	570E-22
63247-99J00	570A-76
	570B-76
	570C-77
	570D-77
	570E-77
63248-99J00	570A-30
	570B-30
	570C-30
	570D-30
	570E-30
63250-88L00	570A-23
	570B-23
	570C-23
	570D-23
	570E-23
63251-87J00	570A-24
	570B-24
	570C-24
	570D-24
	570E-24
63251-88L90	570A-70
	570B-70
	570C-71
	570D-71
	570E-71
63258-88L00	570A-73
	570B-73
	570C-74
	570D-74
	570E-74
63260-88L00	570A-25
	570B-25
	570C-25
	570D-25
	570E-25
63261-87J00	570A-31
	570B-31
	570C-31
	570D-31
	570E-31
63262-87J00	570A-28
	570B-28
	570C-28
	570D-28
	570E-28
63271-87J00	570A-29
	570B-29
	570C-29
	570D-29
	570E-29
63272-87J00	570A-26
	570B-26
	570C-26
	570D-26
	570E-26
63273-87J00	570A-27
	570B-27
	570C-27
	570D-27
	570E-27
63274-87J00	570A-32
	570B-32
	570C-32
	570D-32
	570E-32
63610-88L00	570A-33
	570B-33
	570C-33
	570D-33
	570E-33
63611-88L00	570A-42
	570B-42
	570C-42
	570D-42
	570E-42

PART NO.	FIG.NO.-REF.NO.
63612-87J00	570A-43
	570B-43
	570C-43
	570D-43
	570E-43
63612-88L10	570A-54
	570B-54
	570C-54
	570D-54
	570E-54
63626-88L00	570A-35
	570B-35
	570C-35
	570D-35
	570E-35
65700-88L03	430A-1
65750-95500	430A-2
65770-90J02	430A-3
	430A-9
65793-88L00	570A-79
	570B-79
	570C-80
	570D-80
	570E-80
67200-93J13	544A-1
	545A-1
67211-93J00	544A-27
67221-92E00	545A-8
67222-92E00	545A-2
67223-92E00	545A-3
67224-92E00	545A-9
67226-92E00	545A-15
67226-92E10	545A-16
67227-92E00	545A-24
67228-92E00	545A-18
67230-92E00	545A-20
67231-92E00	545A-41
67232-95600	545A-42
67232-95620	545A-28
67233-92E00	545A-26
67234-92E00	545A-22
67235-92E00	545A-27
67236-92E00	545A-32
67237-92E01	545A-33
67238-92E00	545A-34
67239-92E00	545A-35
67239-92E10	545A-45
67240-92E00	545A-17
67241-92E10	545A-43
67243-92E00	545A-44
67245-92E00	545A-23
67246-92E00	545A-36
67251-93J00	544A-12
67252-92E10	545A-39
67253-92E00	544A-15
67253-92E10	545A-38
67253-95600	545A-40
67257-92E00	544A-11
67261-93J00	544A-2
67263-93J00	544A-3
67269-92E00	545A-29
67271-92E00	544A-26
67273-92E00	544A-23
67273-95600	544A-22
67274-92E00	544A-24
67275-95600	544A-21
67281-93J00	544A-17
67286-92E00	545A-19
67287-92E00	544A-20
67288-92E00	545A-4
67288-92E10	545A-6
67288-92E20	544A-7
67288-92E30	544A-14
67288-92E40	544A-10
67291-92E00	545A-7
67291-92E10	545A-37
67292-87J00	570A-36
	570B-36
	570C-36
	570D-36
	570E-36
67292-94300	545A-5
67294-92E00	545A-10
67295-92E00	544A-8
67295-92E10	544A-5
67296-88D10	544A-6
	545A-13
	545A-30
67296-92E11	545A-12
67296-92E20	545A-14
67296-92E30	544A-18
67296-92E60	544A-13
67296-92E70	544A-9
	544A-28
67296-95610	544A-25
67320-93J00	515A-1-1
67320-93J10	515A-1-2
67320-93J20	515A-1-3
67320-93J30	515A-1-4
67320-93J40	515A-1-5
67320-93J50	515A-1-6
67320-93J60	515A-1-7
67320-93J70	515A-1-8
67320-93J80	515A-1-9
67341-88L01	204A-16
	204B-16
	204C-16
	204D-16
	204E-16
67343-88L01	204A-18
	204B-18
	204C-18
	204D-18
	204E-18
67467-89J01	204A-21
	204B-21
	204C-21
	204D-21
	204E-21
67500-93J00	544A-29
67701-87J11	442A-2
67721-87J00	442A-3
67725-99E00	442A-4
67726-99E00	442A-5
67728-99E00	442A-6
68110-88L00	420A-17
	420B-17
	420C-17
	420D-17
	420E-17
68111-18G20	420A-11
	420B-11
	420C-11
	420D-11
	420E-11
69711-93E10	136A-11
99011-88L60-03B	420A-18-2
	420B-18-2
	420C-18-2
	420D-18-2
	420E-18-2

90000

PART NO.	FIG.NO.-REF.NO.
99011-88L60-054	420A-18-1
	420B-18-1
	420C-18-1
	420D-18-1
	420E-18-1
00000	
01421-08607	124A-4
	124B-4
	124C-4
	124D-4
	124E-4
01547-06167	124A-12
	124B-12
	124C-12
	124D-12
	124E-12
	303A-9
01547-06207	310A-8
01547-06257	111A-18
	111B-18
	111C-18
	111D-18
	111E-18
01547-0640A	175A-3
01547-06457	111A-19
	111B-19
	111C-19
	111D-19
	111E-19
01550-06127	111A-25
	111B-25
	111C-25
	111D-25
	111E-25
	146A-16
	180A-17
	180B-17
	180C-17
	180D-17
	180E-17
	204A-14
	204B-14
	204C-14
	204D-14
	204E-14
	303A-11
	322A-24
	322B-24
	322C-25
	322D-25
	322E-25
	326A-8
	326B-8
	326C-8
	326D-8
	326E-8
01550-0612A	119A-12
01550-06167	111A-27
	111B-27
	111C-27
	111D-27
	111E-27
	146A-9
	163A-4
	204A-3
	204A-17
	204B-3
	204B-17
	204C-3
	204C-17
	204D-3
	204D-17
	204E-3
	204E-17
01550-06207	124A-15
	124B-15
	124C-15
	124D-15
	124E-15
	162A-7
	162B-7
	162C-7
	162D-7
	162E-7
01550-0620A	119A-10
01550-06257	136A-8
	146A-2
	310A-2
01550-06307	136A-2
	143A-25
	204A-4
	204B-4
	204C-4
	204D-4
	204E-4
	407D-31
	407E-31
01550-06407	163A-11
01550-06457	163A-3
01550-08207	111A-9
	111B-9
	111C-9
	111D-9
	111E-9
	113A-2
	163A-5
01550-0825A	401A-10
	401B-10
	401C-10
	401D-10
	401E-10
01550-08307	124A-5
	124B-5
	124C-5
	124D-5
	124E-5
	301A-21
01550-08407	113A-6
	124A-6
	124B-6
	124C-6
	124D-6
	124E-6
01550-08457	111A-12
	111B-12
	111C-12
	111D-12
	111E-12
01550-0845A	401A-4
	401B-4
	401C-4
	401D-4
	401E-4
01550-0885A	401A-5
	401B-5
	401C-5
	401D-5
	401E-5
01570-06167	204A-20
	204B-20
	204C-20
	204D-20
	204E-20
01570-0616A	175A-7
02112-0408A	143A-15

PART NO.	FIG.NO.-REF.NO.
02112-06307	303A-12
02112-34167	124A-9
	124B-9
	124C-9
	124D-9
	124E-9
02142-0408B	143A-16
02142-0612A	111A-21
	111B-21
	111C-21
	111D-21
	111E-21
03112-0630B	501A-25
03121-0516A	530A-28
03122-05165	530A-14
03142-04309	160A-17
	160B-17
	160C-17
03522-05169	570A-75
	570B-75
	570C-76
	570D-76
	570E-76
03542-05169	410A-12
	410B-12
	410C-12
	410D-12
	410E-12
03542-06169	420A-5
	420B-5
	420C-5
	420D-5
	420E-5
03542-06209	136A-4
04211-09109	175A-4
04211-13189	111A-13
	111B-13
	111C-13
	111D-13
	111E-13
04221-04089	116A-7
	136A-9
04221-05109	121A-6
07120-06357	144A-5
08113-62090	220D-24
	220E-24
08211-20263	220A-12
	220B-12
	220C-12
08211-35451	220A-10-6
08221-35455	220A-10-1
	220B-10-1
	220C-10-1
08221-35456	220A-10-4
	220B-10-4
	220C-10-4
08310-00067	322A-17
	322B-17
	322C-18
	322D-18
	322E-18
08316-10087	124A-7
	124B-7
	124C-7
	124D-7
	124E-7
	322A-2
	322B-2
	322C-2
	322D-2
	322E-2
08321-01067	322A-18
	322B-18
	322C-19
	322D-19
	322E-19
08331-3115A	206A-12
	206B-12
	206C-12
08331-41309	210A-20
	210B-20
08331-41329	220A-28
	220B-28
	220C-28
09100-06131	407D-8
	407E-8
09100-08260	119A-5
09100-12091	335A-8-2
	335B-8-2
	335C-7-2
	335D-7-2
	335E-7-2
09100-12093	335A-8-1
	335B-8-1
	335C-7-1
	335D-7-1
	335E-7-1
09103-06093	315A-5
	315B-5
	315C-9
	315D-9
	315E-9
09103-06266	111A-3
	111B-3
	111C-3
	111D-3
	111E-3
09103-06281	111A-8
	111B-8
	111C-8
	111D-8
	111E-8
	113A-9
	335A-7
	335B-7
	335D-12
	335E-12
	337A-27
	337B-27
	337C-27
	337D-25
	337E-25
	405D-12
	405E-12
09103-10189	121A-4
09103-14024	303A-2
09106-05030	303A-7
09106-10065	335C-13
	335D-13
	335E-13
09108-06143	160A-7
	160B-7
	160C-7
09108-06144	160A-8
	160B-8
	160C-8
09108-10161	336A-12
	336B-12
	336C-20
	336D-20
	336E-20
09116-05010	410A-23
	410B-23
	410C-23
	410D-23
	410E-23
09116-06121	162A-3
	162B-3

PART NO.	FIG.NO.-REF.NO.
	162C-3
	162D-3
	162E-3
	180A-8
	180B-8
	180C-8
	180D-8
	180E-8
	335C-12
09116-06127	410A-15
	410B-15
	410C-15
	410D-15
	410E-15
09116-06202	310A-4
09116-06236	160A-15
	160B-15
	160C-15
	160D-14
	160E-14
	336A-23
	336B-23
09116-06237	570A-80
	570B-80
	570C-81
	570D-81
	570E-81
09116-08122	220A-25
	220B-25
	220C-25
	220D-26
	220E-26
09116-08128	180A-3
	180B-3
	180C-3
	180D-3
	180E-3
09116-08131	405D-8
	405E-8
	407A-8
	407B-8
	407C-8
09116-08137	335C-5
	335D-5
	335E-5
	407D-9
	407E-9
	570A-61
	570B-61
	570C-61
	570D-61
	570E-61
09116-08159	401A-3
	401B-3
	401C-3
	401D-3
	401E-3
09116-08163	410A-8
	410B-8
	410C-8
	410D-8
	410E-8
09116-10124	180A-13
	180B-13
	180C-13
	180D-13
	180E-13
09116-10150	405D-9
	405E-9
	407D-10
	407E-10
	570A-68
	570B-68
	570C-68
	570D-68
	570E-68
09116-10176	401A-13
	401B-13
	401C-13
	401D-13
	401E-13
	405A-2
	405A-6
	405B-2
	405B-6
	405C-2
	405C-6
	405D-2
	405D-6
	405E-2
	405E-6
09116-10179	337A-25
	337B-25
	337C-25
	337D-23
	337E-23
09117-06031	210A-8
	210B-8
09117-08109	407A-5
	407B-5
	407C-5
09117-08110	220D-30
	220E-30
09117-10039	407D-11
	407E-11
09125-05042	545A-21
09125-05046	160A-19
	160B-19
	160C-19
	160D-13
	160E-13
	315C-3
	315D-3
	315E-3
09125-05047	570A-41
	570B-41
	570C-41
	570D-41
	570E-41
09125-05048	315A-3
	315B-3
09125-05050	336A-10
	336B-10
	336C-10
	336D-10
	336E-10
09125-05135	544A-30
09125-06063	336A-9
	336B-9
	336C-9
	336C-30
	336D-9
	336D-30
	336E-9
	336E-30
09125-06067	336C-13
	336D-13
	336E-13
09126-06006	545A-25
09126-06015	570A-37
	570B-37
	570C-37
	570D-37
	570E-37
09131-05004	530A-33
09132-04034	160D-17
	160E-17
09136-06148	410A-5
	410B-5
	410C-5
	410D-5
	410E-5
09137-04004	326A-2
	326B-2
	326C-2
	326D-2
	326E-2
09140-05005	163A-9
	544A-32
09140-06020	545A-31
09140-12034	220A-7
	220B-7
	220C-7
09140-14024	220D-5
	220E-5
09141-18005	407A-13
	407B-13
	407C-13
	407D-23
	407E-23
09159-06084	420A-8
	420B-8
	420C-8
	420D-8
	420E-8
09159-08059	570A-90
	570B-90
09159-10050	335A-13
	335B-13
	336A-13
	336B-13
	336C-21
	336D-21
	336E-21
09159-12014	335A-9
	335B-9
	335C-8
	335D-8
	335E-8
	401A-21
	401B-21
	401C-21
	401D-21
	401E-21
	405A-13
	405B-13
	405C-13
	405D-19
	405E-19
	570A-62
	570B-62
	570C-62
	570D-62
	570E-62
09159-22006	335A-10
	335B-10
	335C-6
	335D-6
	335E-6
09160-05024	544A-19
09160-05029	315A-4
	315B-4
	544A-31
09160-06047	163A-10
09160-06055	204A-10
	204A-22
	204B-10
	204B-22
	204C-10
	204C-22
	204D-10
	204D-22
	204E-10
	204E-22
09160-06084	143A-27
09160-06085	407D-12
	407E-12
09160-06094	124A-16
	124B-16
	124C-16
	124D-16
	124E-16
09160-08122	210A-11
	210B-11
09160-08123	119A-6
09160-09010	210A-10
	210B-10
09160-09015	210A-9
	210B-9
09160-10082	335A-14
	335B-14
	335C-14
	335D-14
	335E-14
09160-10093	121A-5
09160-10139	337A-28
	337B-28
09160-10141	336A-14
	336B-14
	336C-22
	336D-22
	336E-22
09160-12044	335A-11
	335B-11
	335C-10
	335D-10
	335E-10
09160-12066	335A-5
	335B-5
	570A-63
	570B-63
	570C-63
	570D-63
	570E-63
09160-12124	570A-64
	570B-64
	570C-64
	570D-64
	570E-64
09160-12126	335A-12
	335B-12
	335C-9
	335D-9
	335E-9
09160-13014	410A-17
	410B-17
	410C-17
	410D-17
	410E-17
09160-14065	303A-3
09160-18028	407A-15
	407B-15
	407C-15
	407D-24
	407E-24
09160-22018	220A-11-1
	220B-11-1
	220C-11-1
09160-22019	220A-11-2
	220B-11-2
	220C-11-2
09160-22020	220A-11-3
	220B-11-3
	220C-11-3
09160-22021	220A-11-4
	220B-11-4
	220C-11-4
09160-22022	220A-11-5
	220B-11-5
	220C-11-5

PART NO.	FIG.NO.-REF.NO.
09160-22023	220A-11-6
	220B-11-6
	220C-11-6
09160-39002	336A-17
	336B-17
	336C-17
	336D-17
	336E-17
09160-39003	336A-15
	336B-15
	336C-15
	336D-15
	336E-15
09161-08011	570A-91
	570B-91
09163-06001	570A-38
	570B-38
	570C-38
	570D-38
	570E-38
09164-13010	570A-66
	570B-66
	570C-66
	570D-66
	570E-66
09164-14008	410A-18
	410B-18
	410C-18
	410D-18
	410E-18
09164-31001	220D-33
	220E-33
09168-10022	407A-7
	407B-7
	407C-7
	407D-13
	407E-13
09168-12012	180A-4
	180B-4
	180C-4
	180D-4
	180E-4
09169-06062	310A-5
09169-06075	143A-26
09169-08039	410A-9
	410B-9
	410C-9
	410D-9
	410E-9
09169-31001	220D-32
	220E-32
09180-06198	144A-6
09181-25030	220D-17
	220E-17
09181-28015	220D-10-1
	220E-10-1
09181-28016	220D-10-2
	220E-10-2
09181-28017	220D-10-3
	220E-10-3
09181-28018	220D-10-4
	220E-10-4
09181-28019	220D-10-5
	220E-10-5
09181-28020	220D-10-6
	220E-10-6
09181-30186	220A-9-1
	220B-9-1
	220C-9-1
09181-30187	220A-9-2
	220B-9-2
	220C-9-2
09181-30188	220A-9-3
	220B-9-3
	220C-9-3
09181-30190	220A-9-4
	220B-9-4
	220C-9-4
09181-30192	220A-9-5
	220B-9-5
	220C-9-5
09181-31001	220D-31
	220E-31
09181-33001	220A-8-2
	220B-8-2
	220C-8-2
09181-33002	220A-8-3
	220B-8-3
	220C-8-3
09181-33003	220A-8-4
	220B-8-4
	220C-8-4
09181-33004	220A-8-5
	220B-8-5
	220C-8-5
09181-33005	220A-8-6
	220B-8-6
	220C-8-6
09181-33006	220A-8-7
	220B-8-7
	220C-8-7
09181-33007	220A-8-8
	220B-8-8
	220C-8-8
09181-33008	220A-8-9
	220B-8-9
	220C-8-9
09181-33009	220A-8-10
	220B-8-10
	220C-8-10
09181-35101	220A-8-1
	220B-8-1
	220C-8-1
09181-35110	220A-8-11
	220B-8-11
	220C-8-11
09181-35131	220A-10-2
	220B-10-2
	220C-10-2
09181-35132	220A-10-3
	220B-10-3
	220C-10-3
09181-35136	220A-10-5
	220B-10-5
	220C-10-5
09181-40186	220D-6-1
	220E-6-1
09181-40190	220D-6-7
	220E-6-7
09181-40195	220D-6-11
	220E-6-11
09181-41002	220D-6-2
	220E-6-2
09181-41003	220D-6-3
	220E-6-3
09181-41004	220D-6-4
	220E-6-4
09181-41005	220D-6-5
	220E-6-5
09181-41006	220D-6-6
	220E-6-6
09181-41008	220D-6-8
	220E-6-8
09181-41009	220D-6-9
	220E-6-9
09181-41010	220D-6-10
	220E-6-10
09181-41012	220D-6-12
	220E-6-12
09181-41013	220D-6-13
	220E-6-13
09181-41014	220D-6-14
	220E-6-14
09181-45003	220D-9-1
	220E-9-1
09181-45004	220D-9-2
	220E-9-2
09181-45005	220D-9-3
	220E-9-3
09181-45006	220D-9-4
	220E-9-4
09181-45007	220D-9-5
	220E-9-5
09181-45008	220D-9-6
	220E-9-6
09181-45009	220D-9-7
	220E-9-7
09181-50020	220D-8-1
	220E-8-1
09181-50021	220D-8-2
	220E-8-2
09181-50022	220D-8-3
	220E-8-3
09181-50023	220D-8-4
	220E-8-4
09181-50024	220D-8-5
	220E-8-5
09181-50025	220D-8-6
	220E-8-6
09181-50026	220D-8-7
	220E-8-7
09181-50027	220D-8-8
	220E-8-8
09181-50028	220D-8-9
	220E-8-9
09181-50029	220D-8-10
	220E-8-10
09202-04022	410A-19
	410B-19
	410C-19
	410D-19
	410E-19
09202-05022	220A-15
	220B-15
	220C-15
09202-06025	220A-30
	220B-30
	220C-30
09202-06027	220A-31
	220B-31
	220C-31
09202-06031	160D-15
	160E-15
09202-07002	220D-13
	220E-13
09202-08006	401A-6
	401A-7
	401A-11
	401B-6
	401B-7
	401B-11
	401C-6
	401C-7
	401C-11
	401D-6
	401D-7
	401D-11
	401E-6
	401E-7
	401E-11
	405A-3
	405B-3
	405C-3
	405D-3
	405E-3
	407D-14
	407E-14
09204-03003	407A-14
	407B-14
	407C-14
	407D-25
	407E-25
09205-02004	206A-8
	206B-8
	206C-8
09205-02006	210A-12
	210B-12
09205-02013	206A-6
	206B-6
	206C-6
09205-03012	336A-25
	336B-25
09205-03019	220A-4
	220B-4
	220C-4
09205-03021	206A-7
	206B-7
	206C-7
	210A-13
	210B-13
09206-08001	111A-4
	111B-4
	111C-4
	111D-4
	111E-4
09206-09012	407D-30
	407E-30
09206-13019	113A-5
09209-12007	220D-16
	220E-16
09248-10008	407A-6
	407B-6
	407C-6
	407D-15
	407E-15
09248-12009	180A-5
	180B-5
	180C-5
	180D-5
	180E-5
09251-07003	430A-5
09260-10005	206A-14
	206B-14
	206C-14
	210A-14
	210B-14
09260-10006	570A-55
	570B-55
	570C-55
	570D-55
	570E-55
09262-35070	220A-23
	220B-23
	220C-23
09263-22020	220A-21
	220B-21
	220C-21
09263-22039	407A-2
	407B-2
	407C-2
09263-28016	407D-2
	407E-2
09263-28047	220D-21
	220E-21
09265-20015	220A-5
	220B-5
	220C-5
09265-25046	220D-3

PART NO.	FIG.NO.-REF.NO.
	220E-3
09265-30004	407A-3
	407B-3
	407C-3
09265-50003	220D-7
	220E-7
09280-08005	206A-3
	206B-3
	206C-3
09280-08008	210A-15
	210B-15
09280-09008	180A-16
	180B-16
	180C-16
	180D-16
	180E-16
09280-11001	206A-4
	206B-4
	206C-4
09280-12008	175A-6
09280-15003	210A-16
	210B-16
09280-22019	111A-6
	111B-6
	111C-6
	111D-6
	111E-6
09280-26005	146A-3
09280-26006	111A-15
	111B-15
	111C-15
	111D-15
	111E-15
	162A-4
	162B-4
	162C-4
	162D-4
	162E-4
09280-46004	220D-28
	220E-28
09280-69001	210A-17
	210B-17
09280-75001	220A-24
	220B-24
	220C-24
09280-97001	220D-22
	220E-22
09282-17005	220A-27
	220B-27
	220C-27
09282-17011	401A-16
	401B-16
	401C-16
	401D-16
	401E-16
09282-22007	220D-29
	220E-29
09282-28002	220D-23
	220E-23
09282-39001	336A-16
	336B-16
	336C-16
	336D-16
	336E-16
09283-37005	116A-11
09284-08003	210A-18
	210B-18
09289-05012	121A-15
09289-22007	220A-22
	220B-22
	220C-22
09306-13007	410A-20
	410B-20
	410C-20
	410D-20
	410E-20
09320-08021	322A-6
	322B-6
	322C-6
	322D-6
	322E-6
09320-08062	144A-3
09320-08076	143A-32
09320-09016	310A-6
09320-09039	143A-28
09320-09501	136A-3
09320-11013	410A-10
	410B-10
	410C-10
	410D-10
	410E-10
09343-70503-080	146A-12
09352-50003-770	143A-29
09352-50901-600	410A-21
	410B-21
	410C-21
	410D-21
	410E-21
09352-50903-600	162A-12
	162B-12
09352-70103-600	204A-19
	204B-19
	204C-19
	204D-19
	204E-19
09355-40805-600	407D-16
	407E-16
09359-50901-980	162A-13
	162B-13
	162C-13
	162D-13
	162E-13
09362-09008	407D-17
	407E-17
09367-06006	507A-4
09367-08001	430A-6
09380-12002	337A-24
	337B-24
	337C-24
	337D-22
	337E-22
09380-38003	336A-18
	336B-18
	336C-18
	336D-18
	336E-18
09381-18002	116A-4
09385-06012	204A-11
	204A-23
	204B-11
	204B-23
	204C-11
	204C-23
	204D-11
	204D-23
	204E-11
	204E-23
09387-52001	220D-25
	220E-25
09401-08412	143A-30
09401-08413	162A-14
	162B-14
	162C-14
	162D-14
	162E-14

PART NO.	FIG.NO.-REF.NO.
	507A-5
09401-10415	162A-15
	162B-15
	162C-15
	162D-15
	162E-15
09401-11423	146A-6
	146A-18
	430A-7
09401-11425	144A-8
09401-15414	111A-23
	111B-23
	111C-23
	111D-23
	111E-23
09401-25406	162A-9
	162B-9
	162C-9
	162D-9
	162E-9
09403-07340	315A-7
	315B-7
	315C-13
	315D-13
	315E-13
09403-11320	146A-17
09403-11321	315C-14
	315D-14
	315E-14
09403-13408	303A-10
09403-17303	111A-24
	111B-24
	111C-24
	111D-24
	111E-24
09407-08401	530A-8
	530A-30
09407-10404	326A-4
	326B-4
	326C-4
	326D-4
	326E-4
	407D-18
	407E-18
09407-14403	322A-19
	322B-19
	322C-20
	322D-20
	322E-20
09407-14407	315A-9
	315B-9
	315C-16
	315D-16
	315E-16
	322A-20
	322B-20
	322C-21
	322D-21
	322E-21
	501A-6
	501A-18
09407-18402	322A-25
	322B-25
	322C-26
	322D-26
	322E-26
09407-25402	410A-25
	410B-25
	410C-25
	410D-25
	410E-25
	507A-7
09408-00043	143A-33
09408-00121	143A-34
09408-00145	143A-35
	146A-19
09408-00174	144A-9
09408-00175	162A-16
	162B-16
	162C-16
	162D-16
	162E-16
09408-00184	326A-5
	326B-5
	326C-5
	326D-5
	326E-5
09409-05312-6GS	430A-8
09420-04006	160A-20
	160B-20
	160C-20
09420-04008	303A-4
09420-04009	160D-16
	160E-16
09440-06037	570A-74
	570B-74
	570C-75
	570D-75
	570E-75
09440-07033	210A-19
09440-07078	206A-15
	206B-15
	206C-15
09440-08043	220A-17
	220B-17
	220C-17
09440-11020	220D-15
	220E-15
09440-12027	570A-39
	570B-39
	570C-39
	570D-39
	570E-39
09440-40002	220A-18
	220B-18
	220C-18
09440-49004	220D-18
	220E-18
09443-10043	336C-31
	336D-31
	336E-31
09471-12028	501A-4
09471-12077	501A-21
	501A-23
09471-12103	501A-9
	501A-13
	501A-15
	501A-19
09471-12108	501A-2
09481-05501	600A-10
	600A-27
	600A-29
09481-10501	521A-5
09481-15501	322A-12
	322B-12
	322C-12
	322D-12
	322E-12
09481-30401	322A-14
	322B-14
	322C-14
	322D-14
	322E-14
09481-30501	322A-13
	322B-13
	322C-13
	322D-13
	322E-13
09482-00446	111A-28

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	111B-28				
	111C-28				
	111D-28				
	111E-28				
09800-81812	420A-15				
	420B-15				
	420C-15				
	420D-15				
	420E-15				

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.

SUZUKI **DF40A/50A/60A** PARTS CATALOGUE

SUZUKI MOTOR CORPORATION All rights reserved
No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Suzuki Motor Corporation.

SUZUKI MOTOR CORPORATION
Technical Readiness Group, Quality Administration Department
300 Takatsuka, Minami, Hamamatsu, Japan

Reprint Prohibited

SUZUKI MOTOR CORPORATION

PRINTED IN JAPAN

9900B-45356